



Info Printouts & Parameters

- General Information 5
 - Important setting instructions 5
 - Area of application 5
- Operating the parameter menu 7
 - Example 7
 - Parameter Menu 8
- Overview Parameter Menus 9
 - Understanding the Parameter Overviews . 9
 - AP 5.4 Parameter 10
- Alphabetical Parameter List 13

PRINT INFO

- Printer status 16
- Memory status 18
- Font status 19
- Flashdata status 22
- Service Status 23
- Dottest endless 24
- Dottest punched 24
- Reference label 25
- RFID Status 26

PRINT PARAMETERS

- Print speed 27
- Feed speed 27
- Material type 28
- Material length 28
- Material width 28
- Print direction 29
- Punch offset 30
- Bar code multip. 30
- Tradit. Imaging 31
- UPC plain-copy 31
- EAN Readline 31
- EAN sep. lines 32
- Rotated Barcodes 32
- Dispenseposition 32
- Cut mode 33
- Cut speed 35
- Cut position 35
- Double cut 35
- Rewind direction 36

- X - Printadjust 36
- Y – Printadjust 36
- Punch mode 37
- Punch level 37

INTERFACE PARA

- > EASYPLUGINTERPR
 - Interface 38
 - Spooler mode 38
 - Printer ID No. 39
 - Spooler size 39
 - Offline mode 39
 - Interface delay 39
- > COM1 PORT
 - Baud rate 40
 - No. of data bits 40
 - Parity 40
 - Stop bits 40
 - Data synch 41
 - Frame error 41
- > COM3 PORT
 - Baud rate 41
 - No. of data bits 41
 - Parity 41
 - Stop bits 42
 - Data synch 42
 - Frame error 42
 - Serial Port Mode 42
- > COM4 PORT
 - Baud rate 43
 - No. of data bits 43
 - Parity 43
 - Stop bits 43
 - Data synch 43
 - Frame error 43
- > USB
 - USB select 44
- > NETWORK PARAM.
 - IP addressassign 44
 - IP address 44

Net mask	44	Gap detect mode	58
Gateway address	45	Periph. device	59
Port address	45	Singlestartquant.....	59
Ethernet speed	45	External signal	59
MAC address	45	Start print mode	60
SNMP agent.....	45	Print contrast.....	60
SNMP password	45	Ram disk size	60
FTP server	46	Font downl. area.....	61
FTP password	46	Free store size	62
WEB server	47	Print info mode.....	62
WEB display refr	48	Reprint function.....	62
WEB admin passw.	48	Language.....	63
WEB supervisor p.	48	Keyboard	63
Time client.....	49	Access authoriz.	63
Time server IP	49	Realtime clock	65
Sync. Interval	49		
DHCP host name	50		
> OPTIONS			
RFID Option	50		
StandAlone Input.....	50		
> DRIVEASSIGNMENT			
Drive C	51		
Drive D	51		
SYSTEM PARAMETERS			
Foil end warning.....	52		
Foil warn stop.....	52		
Print Interpret.	52		
Character sets.....	53		
Character filter.....	54		
Light sens. type	54		
Head-sensor dist.	54		
Sens. punch-LS.....	55		
Foil mode	55		
Turn-on mode.....	55		
Error reprint	55		
EasyPlug error	56		
Single job mode	56		
Head resistance	56		
Temp. reduction	57		
Thin line emphas.....	57		
Voltage offset	58		
Miss. label tol.	58		
		I/O BOARD	
		Start print mode	66
		Reprint Signal	66
		Feed input.....	67
		Pause input.....	67
		Error output.....	67
		Error Polarity.....	68
		Status output	68
		Status polarity.....	68
		End print mode	69
		DISPENSER PARA	
		Dispense Mode.....	70
		Dispenseposition	71
		Display mode	72
		Dispense counter.....	72
		Application mode	72
		Start source	73
		Calibration mode.....	73
		Start offset	73
		Start error stop.....	74
		Product length.....	74
		Current mode.....	74
		Min. rew. current.....	75
		Max. rew. current.....	75
		Start rew. current	76
		Start cur. len.	76

Pullback current	76	Store Diagnosis	86
Back diameter	77	Data blocks del.	86
Brake current.....	77	EasyPl. file log	87
Brake diameter	77	Log files delete.....	87
		RFID stat. del.....	87
REWINDER PARA		SERVICE FUNCTION	
Rewind direction.....	78	Service.....	88
Current mode	78	Head exchange.....	88
Min. rew. current	78	Roller exchange.....	88
Max rew. current	78	Cutter exchange	89
Start rew. curr.....	78	Serv. data reset	89
Start cur. len.....	79	EasyPlug monitor.....	89
Pullback current	79	EP Monitor Mode	90
Back diameter	79	Sensor adjust.....	90
Brake current.....	79	Sensor test	90
Break diameter	79	Cutter test	90
		Matend tolerance	91
MLI PARAMETERS		Feedadjust label	91
Darkness	80	Feed adjust.....	91
Control Prefix	80	Punch y calibr.	91
Format Prefix.....	80	Memory card test.....	92
Delimiter Char	81	Send test	93
Label Top	81	Receive test.....	94
Left Position	81	Rewinder adjust.....	95
Manual Calibrate	81	Printtest.....	95
Resolution	81		
Error Indication.....	82	SERVICE DATA	
Error Checking	82	> MODULE FW VERS.	
Image Save Path.....	82	System version	96
Command ^PR.....	82	System revision	96
Command ^MT.....	82	System date.....	96
Label Invert	83	Bootloader	96
Command ^JM	83	uMon.....	96
Command ^MD/~SD	83	Peripheraldriver	96
		Intern. rewinder.....	97
SPECIAL FUNCTION		> OPERATION DATA	
Printer type.....	84	Serv. operations.....	97
Default Values.....	84	Headnumber	97
Command sequence	84	Roll number	97
Delete job	84	Cutter number.....	97
Delete spooler	85	Head run length	98
Factory settings.....	85	Roll run length.....	98
Store Parameters	85		

Cuts on knife	98	Serial number	100
Tot. mat. length	98	Production date.....	101
Tot. foil length.....	98	PCB part number.....	101
Total cuts.....	98	Board part numb.....	101
Head strobes.....	99	Manufacturer.....	101
Head temperature	99	Work place.....	101
Foil diameter	99	Company name	101
Dispensing cycl.	99	> DISPLAY DATA	
Operation time.....	99	Display version	102
> POWERSUPPLYDATA		Display SerialNr.....	102
Type	100	> MEMORY DATA	
PS temperature	100	Ram memory size.....	102
> CPU BOARD DATA		Flash mem size.....	102
CPU identifier	100	SD card.....	103
PCB revision	100	Space for Jobs.....	103
FPGA version.....	100	Max. Labellength	103
MAC address	100	Default values.....	103

General Information

Important setting instructions

Starting in offline mode, you get to the parameter menu by pressing the prog button. There you can set/alter the different parameters of the printer and activate/deactivate options.

Many Parameters provide a range within the setting can be changed with a standard step width. By this step width, the setting is changed, if the Cut-(Apply-) or Feed button is pressed once.

▣▣▣▣➔ The step width can be increased ten times, if the Online button is pressed simultaneously (Cut+Online or Feed+Online).

▣▣▣▣➔ Wait at least 10 seconds between switching the device off and on again, otherwise any modified parameter settings are not saved.

▣▣▣▣➔ With some parameters, false settings can result in the device being damaged (e. g. if the print head temperature is too high). Data and/or print orders are also deleted during formatting and with other settings.

▣▣▣▣➔ Pay attention to the corresponding notes in the following description to ensure that no damage occurs!



Area of application

The description counts for all devices listed in the headline of this document. All status printouts and parameters are described in the same order as they *may appear* in the parameter menu of the respective printer.

▣▣▣▣➔ Not all of the parameters appear in each of the listed printers!

At the beginning of each parameter description can be found information about the availability of the parameter:

AP 5.4	AP 5.6
▣▣▣▣➔ Only with installed I/O board.	

Fig. 1: At the beginning of each parameter description, the availability of the parameter is specified: Between the two lines is a list of the concerned printer types; the remark below (arrow) quotes further conditions.

If a parameter appears in the menu of a certain printer type or not, depends on the following, which can be read from this bar:

- The *printer type*:
Printers, which have the parameter available in the parameter menu, are listed between the lines. Example (see fig. 1): AP 5.4, AP 5.6.
- The configuration with *options* and/or certain *parameter settings*:
Example (see fig. 1): The parameter only appears in the menu of an AP 5.4/5.6, if the device is equipped with an I/O board. If the remark is not assigned to a special printer type, it is valid for all listed printers.

Firmware

This description applies to all printers which are equipped with a firmware version 7.34 Pre 4081 for AP 5.4/AP 5.6.

- The paragraph „Overview Parameter Menues“ in this topic section contains an overview of all available parameters of the respective printer.

Operating the parameter menu

The illustrations on the following pages clarify the operating principle of the parameter menu. The return path shown on the left of the screen, called up using the Prog. button, also applies for parameters in the middle of the screen.

Setting values

The setting of a parameter always follows this scheme:

1. Select the parameter.
2. Press the Online button.
3. Set the parameter to the intended value by pressing the Cut or Feed button.
4. Confirm by pressing the Online button.

Example

Setting the parameter `PRINT PARAMETERS > Material type` to punched material.

1. Press prog button.

OFFLINE 0 JOBS Initial state: off-line mode

2. Press prog button.

PRINT INFO

3. Press cut button.

PRINT PARAMETERS

4. Press online button.

PRINT PARAMETERS First parameter in the `PRINT PARAMETERS` menu.
Print speed

5. Press cut button repeatedly, until the following is displayed:

Material type
Endless

6. Press feed button.

Material type Setting the parameter to the intended value by
Punched pressing the Cut or Feed button.

7. Press online button.

PRINT PARAMETERS Confirm with Online button.
Material type

8. Press prog button 2x.

OFFLINE 0 JOBS "Way back" by pressing the Prog button.

Parameter Menu




Fig. 1: Guideline through the parameter menu. Start into it by pressing the Prog button in off-line mode.

Overview Parameter Menus

Understanding the Parameter Overviews

The charts in the following show all of the parameters implemented in the printer firmware. Some parameters are only visible in the parameter menu under specific preconditions. These parameters are provided with a gray background and a digit at the right column edge. The digit refers to a footnote describing the precondition under which the parameter is visible.

PRINT INFO	PRINT PARAMETERS	INTERFACE PARA	(INTERFACE PARA cont.)	(INTERFACE PARA cont.)	SYSTEM PARAMETER
Printer status	Print speed	> EASYPLUGINTERPR	Parity	> OPTIONS	Foil end warning
Memory status	Feed speed	Interface	Stop bits	RFID Option	Foil warn stop
Font status	Material type	Spooler mode	Data synch.	StandAlone Input	Print Interpret.
Flashdata status 4	Material length	Printer ID No.	Frame error		Character sets
Service status	Material width	Spooler size		> DRIVEASSIGNMENT	Character filter
Dottest endless	Print direction	Offline mode	> USB	Drive C	Light sens. type
Dottest punched	Punch offset	Interface delay	USB select	Drive D	Head-sensor dist 13/14
Reference label	Bar code Multi.				Sens. punch-LS
RFID status 22	Tradit. Imaging 13	> COM1 PORT	> NETWORK PARAM.		Foil mode
	UPC plain-copy	Baud rate	IP Addressassign		Turn-on mode
	EAN Readline	No. of data bits	IP Address		Error reprint
	EAN sep. lines	Parity	Net mask		EasyPlug errors
	Cut mode 6	Stop bits	Gateway address		Single job mode
	Cut position 6	Data synch.	Port address		Head resistance
	Double cut 6	Frame error	Ethernet speed		Temp. reduction
	Rewind direction 5		MAC address		Thin line emphas 13
	Rotated barcodes	> COM3 PORT 23	SNMP agent		Voltage offset
	Dispenseposition 8	Baud rate 23	SNMP password 13		Miss. label tol.
	X – Printadjust	No. of data bits 23	FTP server		Gap detect mode
	Y – Printadjust	Parity 23	FTP password 13		Periph. device
	Punch mode	Stop bits 23	WEB server		Singlestartquant
	Punch level 12	Data synch. 23	WEB display refr 1		External signal
		Serial Port Mode 23	WEB admin passw. 13		Start print mode 24
		Frame error 23	WEB supervisor p. 13		Print contrast
			Time client		Ram disk size
		> COM4 PORT	Time server IP 3		Font downl. area
		Baud rate	Sync. intervall 3		Free store size
		No. of data bits	DHCP host name		Print info mode

1. Only with INTERF.PARAM. > NETWORK PARAM. > WEB Server = „enabled“ 2. Only with BLDC firmware version V4-T36 or higher 3. Only with INTERF.PARAM. > NETWORK PARAM. > Time client = „Enabled“
 4. Only with at least one data block stored in the flash memory 5. Only with rewinder 6. Only with cutter 7. Only with „AP 5.4 peripheral“ 8. Only if SYSTEM PARAMETERS > Periph. device = „Tear-off edge“ or „Tear off + sensor“ 10. Only with activated MONARCH LANGUAGE INTERPRETER™ 12. Only if PRINT PARAMETERS > Punch mode = „Manual“ 13. Only in production mode 14. As in 13. or with a setting value > 0 18. Only with installed RFID option 20. Only if SYSTEM PARAMETERS > Periph. device = „Dispenser“ 21. Only if SYSTEM PARAMETERS > Periph. device = „Int Rewinder“ 22. Only with an activated RFID option 23. Only with I/O board 24. Not with I/O board 29. Availability depends on device configuration 30. Only with a memory card inserted

(SYSTEM PARAM. cont.)

		I/O BOARD PARA 23	MLI PARAMETERS 10	DISPENSER PARA 20	REWINDER PARA 21	SPECIAL FUNCTION				
Reprint function	Start delay	23	Version	10	Dispense Mode	20	Rewind direction	21	Printer type	13
Language	Start print mode	23	Darkness	10	Dispenseposition	20	Current mode	13+21	Default values	13
Keyboard	Reprint Signal	23	Control Prefix	10	Display mode	20	Min rew. current	13+21	Command sequence	13
Access authoriz.	Feed input	23	Format Prefix	10	Dispense counter	20	Max rew. current	13+21	Delete job	
Realtime Clock	Pause input	23	Delimiter Char	10	Application mode	20	Start rew. curr.	13+21	Delete spooler	
	Error output	23	Label Top	10	Start source	20	Start cur. len.	13+21	Factory settings	
	Error polarity	23	Left Position	10	Calibration mode	20	Pullback current	13+21	Store parameters	
	Status output	23	Manual Calibrate	10	Start offset	20	Back diameter	13+21	Store diagnosis	
	Status polarity	23	Resolution	10	Start error stop	20	Break current	13+21	EasyPI. file log	30
	End print mode	23	Error Indication	10	Product length	20	Break diameter	13+21	Log files delete	30
			Error Checking	10	Speed Adaption	20			Data blocks del.	4
			305 DPI Scaling	10	Current mode	13+20			RFID stat. del.	22
			Image Save Path	10	Min rew. current	13+20				
			Command ^PR	10	Max rew. current	13+20				
			Command ^MT	10	Start rew. curr.	13+20				
			Label Invert	10	Start cur. len.	13+20				
			Command ^JM	10	Pullback current	13+20				
					Back diameter	13+20				
					Break current	13+20				
					Break diameter	13+20				

1. Only with INTERF.PARAM. > NETWORK PARAM. > WEB Server = „enabled“ 2. Only with BLDC firmware version V4-T36 or higher 3. Only with INTERF.PARAM. > NETWORK PARAM. > Time client = „Enabled“ 4. Only with at least one data block stored in the flash memory 5. Only with rewinder 6. Only with cutter 7. Only with „AP 5.4 peripheral“ 8. Only if SYSTEM PARAMETERS > Periph. device = „Tear-off edge“ or „Tear off + sensor“ 10. Only with activated MONARCH LANGUAGE INTERPRETER™ 12. Only if PRINT PARAMETERS > Punch mode = „Manual“ 13. Only in production mode 14. As in 13. or with a setting value > 0 18. Only with installed RFID option 20. Only if SYSTEM PARAMETERS > Periph. device = „Dispenser“ 21. Only if SYSTEM PARAMETERS > Periph. device = „Int Rewinder“ 22. Only with an activated RFID option 23. Only with I/O board 24. Not with I/O board 29. Availability depends on device configuration 30. Only with a memory card inserted

SERVICE FUNCTION	SERVICE DATA	(Service Data cont.)
Service 13	> MODULE FW VERS.	> CPU BOARD DATA
Head exchange 13	System version	CPU identifier
Roller exchange 13	System revision	PCB revision
Cutter exchange 13+6	System date	FPGA version
Serv. data reset 13	Bootloader	MAC address
EasyPlug monitor 23	uMon	Serial number
EP Monitor Mode 13	Peripheraldriver 7	Production date
Sensor adjust 13	Intern. rewinder 21	PCB part number
Sensor test		Board part numb.
Cutter test	> OPERATION DATA	Manufacturer 13
Matend adjust	Serv. operations	Work place 13
Matend tolerance	Headnumber	Company name 13
Feedadjust label	Roll number	
Feed adjust	Cutter number 6	> DISPLAY DATA
Punch y calibr. 13	Head run length	Display version
Memory card test	Roll run length	Display SerialNr
Send test	Cuts on knife 6	
Receive test	Tot. mat. length	> MEMORY DATA
Rewinder adjust 5	Tot. foil length	Ram memory size
Print test	Total cuts 6	Flash mem size
	Head strobes	SD card 30
	Head temperature	Space for Jobs
	Foil diameter	Max. Labellength
	Operation time	Default values
	> POWERSUPPLYDATA	
	Type	
	PS temperature	

1. Only with INTERF.PARAM. > NETWORK PARAM. > WEB Server = „enabled“ 2. Only with BLDC firmware version V4-T36 or higher 3. Only with INTERF.PARAM. > NETWORK PARAM. > Time client = „Enabled“ 4. Only with at least one data block stored in the flash memory 5. Only with rewinder 6. Only with cutter 7. Only with „AP 5.4 peripheral“ 8. Only if SYSTEM PARAMETERS > Periph. device = „Tear-off edge“ or „Tear off + sensor“ 10. Only with activated MONARCH LANGUAGE INTERPRETER™ 12. Only if PRINT PARAMETERS > Punch mode = „Manual“ 13. Only in production mode 14. As in 13. or with a setting value > 0 18. Only with installed RFID option 20. Only if SYSTEM PARAMETERS > Periph. device = „Dispenser“ 21. Only if SYSTEM PARAMETERS > Periph. device = „Int Rewinder“ 22. Only with an activated RFID option 23. Only with I/O board 24. Not with I/O board 29. Availability depends on device configuration 30. Only with a memory card inserted

Alphabetical Parameter List

Access authoriz.	63	Default values.	103	Flashdata status	22
Application mode	72	Default Values	84	Foil diameter	99
Back diameter.	77	Delete job.	84	Foil end warning	52
Back diameter.	79	Delete spooler	85	Foil mode.	55
Bar code multip.	30	Delimiter Char	81	Foil warn stop	52
Baud rate	40	DHCP host name	50	Font downl. area	61
Baud rate	41	Dispense counter	72	Font status	19
Baud rate	43	Dispense Mode	70	Format Prefix	80
Board part numb.	101	Dispenseposition	32	FPGA version	100
Bootloader	96	Dispenseposition	71	Frame error	41
Brake current	77	Dispensing cycl.	99	Frame error	42
Brake current	79	Display mode	72	Frame error	43
Brake diameter	77	Display SerialNr	102	Free store size.	62
Break diameter	79	Display version.	102	FTP password	46
Calibration mode.	73	Dottest endless.	24	FTP server	46
Character filter	54	Dottest punched	24	Gap detect mode.	58
Character sets	53	Double cut	35	Gateway address.	45
Command ^JM.	83	Drive C	51	Head exchange	88
Command ^MT	82	Drive D	51	Head resistance.	56
Command ^PR	82	EAN Readline.	31	Head run length.	98
Command ^MD/~SD.	83	EAN sep. lines	32	Head strobes	99
Command sequence.	84	EasyPI. file log	87	Head temperature	99
Company name	101	EasyPlug error	56	Headnumber	97
Control Prefix	80	EasyPlug monitor.	89	Head-sensor dist.	54
CPU identifier	100	End print mode.	69	Image Save Path.	82
Current mode	74	EP Monitor Mode	90	Interface delay	39
Current mode	78	Error Checking	82	Interface.	38
Cut mode	33	Error Indication.	82	Intern. rewinder	97
Cut position.	35	Error output	67	IP address	44
Cut speed	35	Error Polarity	68	IP addressassign.	44
Cuts on knife.	98	Error reprint	55	Keyboard	63
Cutter exchange	89	Ethernet speed.	45	Label Invert	83
Cutter number.	97	External signal	59	Label Top.	81
Cutter test	90	Factory settings	85	Language.	63
Darkness.	80	Feed adjust.	91	Left Position.	81
Data blocks del.	86	Feed input	67	Light sens. type	54
Data synch.	41	Feed speed	27	Log files delete.	87
Data synch.	42	Feedadjust label.	91	MAC address.	100
Data synch.	43	Flash mem size	102	MAC address.	45

AP 5.4 Gen II – AP 5.6

Manual Calibrate.	81	PS temperature	100	Space for Jobs.	103
Manufacturer.	101	Pullback current	76	Spooler mode	38
Matend tolerance	91	Pullback current	79	Spooler size	39
Material length	28	Punch level.	37	StandAlone Input.	50
Material type	28	Punch mode	37	Start cur. len.	76
Material width	28	Punch offset	30	Start cur. len.	79
Max rew. current.	78	Punch y calibr.	91	Start error stop.	74
Max. Labellength	103	Ram disk size	60	Start offset	73
Max. rew. current	75	Ram memory size	102	Start print mode	60
Memory card test	92	Realtime clock	65	Start print mode	66
Memory status	18	Receive test	94	Start rew. curr.	78
Min. rew. current.	75	Reference label	25	Start rew. current.	76
Min. rew. current.	78	Reprint function	62	Start source	73
Miss. label tol.	58	Reprint Signal.	66	Status output	68
Net mask.	44	Resolution	81	Status polarity	68
No. of data bits	40	Rewind direction.	36	Stop bits.	40
No. of data bits	41	Rewind direction.	78	Stop bits.	42
No. of data bits	43	Rewinder adjust	95	Stop bits.	43
Offline mode	39	RFID Option	50	Store Diagnosis	86
Operation time	99	RFID stat. del.	87	Store Parameters.	85
Parity.	40	RFID Status	26	Sync. Interval.	49
Parity.	41	Roll number	97	System date.	96
Parity.	43	Roll run length	98	System revision	96
Pause input.	67	Roller exchange	88	System version	96
PCB part number	101	Rotated Barcodes.	32	Temp. reduction.	57
PCB revision.	100	SD card	103	Thin line emphas	57
Periph. device.	59	Send test	93	Time client	49
Peripheraldriver	96	Sens. punch-LS	55	Time server IP	49
Port address	45	Sensor adjust	90	Tot. foil length	98
Print contrast.	60	Sensor test	90	Tot. mat. length	98
Print direction	29	Serial number	100	Total cuts.	98
Print info mode	62	Serial Port Mode.	42	Tradit. Imaging	31
Print Interpret.	52	Serv. data reset	89	Turn-on mode	55
Print speed	27	Serv. operations	97	Type.	100
Printer ID No.	39	Service Status	23	uMon	96
Printer status.	16	Service	88	UPC plain-copy	31
Printer type	84	Single job mode	56	USB select.	44
Printtest.	95	Singlestartquant	59	Voltage offset.	58
Product length.	74	SNMP agent.	45	WEB admin passw.	48
Production date.	101	SNMP password.	45	WEB display refr	48

WEB server	47
WEB supervisor p.	48
Work place	101
X - Printadjust	36
Y – Printadjust	36

PRINT INFO

▣▣▣▣ Printing of individual reports can be deactivated for certain options (e. g. for the infeed option).

A material width of 100 mm is necessary to print the reports. The status print-out is approx. 200 mm long.

Printer status

AP 5.4 AP 5.6

A protocol can be printed to get an overview of customer-specific parameter settings (three pages, see [1]).

▣▣▣▣ Which parameters are listed, depends on the printer type.

Systemversion	: V2.46 Jan 18 2002 [R2.46 H2.46]	COM2 Port Parameter		Dispenser Interface	
Printer type	: Avery 64-05	Function Option	: None	Interface type	: USI Interface
Printer Parameter Menu		Baud rate	: 9600 Baud	Start delay	: 0.0 mm
Print speed	: 8 Inch/s	No. of data bits	: 8	Start print mode	: Pulse falling
Feed speed	: 6 Inch/s	Parity	: None	End print mode	: Mode 0
Materialtype	: Punched	Stop bits	: 1 Bit	Reprint signal	: Disabled
Materiallength	: 206.0 mm	Data synch.	: RTS/CTS	Ribbon signal	: Enabled
Materialwidth	: 65.0 mm	Printer system menu		Material signal	: Disabled
Punch offset	: 0 mm	Foil end warning	: 25.4 mm	Feed input	: Standard
Bar code multip.	: * 1	Autom. dot check	: Off	Pause Input	: Standard
UPC plain-copy	: In line	Print emulation	: Easyplug	Start error stop	: Off
EAN Readline	: Standard	Character sets	: IBM	Internal inputs	: Enabled
Cut mode	: Real 1:1 mode	Character filter	: Chars >= 20Hex	Internal Options	
Cut speed	: 3 Inch/s	Light sens. type	: Punched	Default values	Standard
Cut position	: 0.0 mm	Sens. punch-LS	: 50 %	Realtime Clock	14.02.2001 16:02
Double cut	: 0.0 mm	Ribbon autoecon.	: Disabled	Com2 Option	Installed
X - Printadjust	: 0.0 mm	Ribb. eco. limit	: 10.0 mm		
Y - Printadjust	: 0.0 mm	Turn-on mode	: Online		
Punchmode	: Automatic	Error reprint	: Enabled		
Printer Interface Menu		Single-job mode	: Disabled		
Easyplug Interpreter		Head resistance	: 1277 Ohm		
Interface	: Centronics	Temp. reduction	: 20 %		
Spooler mode	: Mult. print jobs	Voltage offset	: 0 %		
Printer ID no.	: 1	Punch search qt.	: 2		
Spooler size	: 64 KBytes	Mat. end detect.	: Transparent		
COM1 Port Parameter		Periph. device	: Cutter		
Baud rate	: 9600 Baud	Singlestartquant	: 1		
No. of data bits	: 8	Start mode	: Edge		
Parity	: None	Start source	: Foot switch		
Stop bits	: 1 Bit	External signal	: Disabled		
Data synch.	: RTS/CTS	Signal edge	: Falling edge		
		Print contrast	: 30 %		
		Ram disk size	: 512 KBytes		
		Font downl. area	: 256 KBytes		
		Free store size	: 512 KBytes		
		Language	: English		
		Signal / buzzer	: On		
		Access authoriz.	: Deactivated		

[1] Example printout „printer status“ (64-05 with firmware version 2.46).

Listed items:

- Systemversion:
 - Shows the installed firmware version as well as the release date of this version.
 - Firmware version: R = firmware RISC processor, H = firmware H8 processor.

- Printer type:
 - Shows the printer type, which has been set using parameter `SERVICE FUNCTIONS > printer type` (e.g. Avery 64-04)
 - "USA" displayed after the printer type indicates that the USA font is loaded.
 - "8DOT" displayed after the printer type indicates that the 8-Dot emulation is loaded.
- Printer Parameter Menu
Shows the setting of the parameters in the `PRINT PARAMETERS` menu.
- Printer Interface Menu
Shows the setting of the parameters in the `INTERFACE PARA` menu.
- Printer system menu
Shows the setting of the parameters in the `SYSTEM PARAMETERS` menu.
- Dispenser Interface
Shows the setting of the parameters in the `DP INTERFACE` menu.
- Internal Options
 - Default values: Shows the values which are used in case of a factory reset (Standard or Default). See parameter `SPECIAL FUNCTION > Default Values`.
 - Realtime Clock: Shows the set time and date, if a realtime clock is installed. In case of a too low battery, the line "Battery empty" is added.
 - 2. com port: Shows if an additional serial Interface is installed (not supported).

Memory status

AP 5.4 AP 5.6

A memory protocol can be printed to provide an overview of the distribution of the available memory capacity (one page).

Internal Memory Configuration	
Total memory size	: 8 MB
Flash memory size	: 2 MB AMD
Space for spooler	: 64 KB
Space for Ramdisc	: 512 KB
Font downl. area	: 256 KB
Free store size	: 512 KB
Space for Jobs	: 4.3 MB
Max. Labellength	: 1786 mm
Default values	: Standard
Logos on Ramdisc	
Graphics on ram disc	
Fonts on Ramdisc	

[2] Example of a memory Status printout.

Listed items:

- Internal Memory Configuration
- See paragraph > [MEMORY DATA](#) on page 168.
- Logos on RAM disc
- Graphics on RAM disc
- Fonts on RAM disc
- See [Plug-in card manual](#), topic section „Application“, chapter „Compact-Flash card“.

Font status

AP 5.4 AP 5.6

Print samples of all installed characters, bar codes and line samples (several pages).

Page „Font Library“ shows a list of the internal fonts and line styles.

Internal Fonts

- ➔ Use the Easy-Plug commands listed in the first column of the report (e.g. #YT100), to print using the appropriate font.
- Easy Plug commands: Refer to the Easy Plug Manual, topic section [Description of Commands](#) □.
- For a list of all characters contained in the internal fonts, refer to the User Manual, topic section [Internal Fonts](#) □.

FONT LIBRARY		
Number of Fonts : 20 (internal)		
Ep. Cmd	Hgh.	Font Sample
Y100	0,83	0123456789ABCDEF0123456789ABCDEF
Y101	1,33	0123456789ABCDEF0123456789ABCDEF
Y102	1,50	0123456789ABCDEF0123456789ABCDEF
Y103	2,00	0123456789ABCDEF0123456789ABCDEF
Y104	2,92	0123456789ABCDEF
Y105	1,50	0123456789ABCDEF0123456789ABCDEF
Y106	2,00	0123456789ABCDEF0123456789ABCDEF
Y107	2,92	0123456789ABCDE
Y108	3,25	0123456789ABCDEF
Y109	5,16	0123456789
Y110	2,75	0123456789ABCDEF
Y111	1,41	0123456789ABCDEF0123456789ABCDEF
Y112	1,92	0123456789ABCDEF0123456789ABCDEF
Y113	1,92	0123456789ABCDEF0123456789ABCDEF
Y114	2,33	0123456789ABCDEF0123456789ABCDEF
Y115	2,33	0123456789ABCDEF0123456789ABCDEF
Y116	2,38	0123456789ABCDEF0123456789ABCDEF
Y100	40 P	0123456789ABCDEF
Y101	40 P	0123456789ABCDEF
Y102	40 P	0123456789ABCDEF
Line Style	Line Sample	
Typ 0	—————	
Typ 1	- - - - -	
Typ 2	
Typ 3	: : : : :	
Typ 4	: : : : :	
Typ 5	: : : : :	
Typ 6	: : : : :	
Typ 7	: : : : :	
Typ 8	: : : : :	
Typ 9	: : : : :	
Typ 10	: : : : :	
Typ 11	: : : : :	
Typ 12	: : : : :	

[3] Print sample „Font Status“ / „Font Library“.

Internal Line Styles

- ➔ Use the line style number (first column) with one of the Easy Plug commands #YL or #YR to print lines in the matching style.
- Easy Plug commands: Refer to the Easy Plug Manual, topic section [Description of Commands](#) □.
- ➔ Additionally, the following line styles are available:
 - 13: Checked pattern with 3 dot edge length
 - 14: Checked pattern with 1 mm edge length
 - 15: Checked pattern with 5 mm edge length

▣ The line width has to be defined as a multiple of the edge length of the checked pattern!

Internal bar codes

The pages titled „Barcode Library“ show print samples of the internal bar codes (see [4], [8]).

BARCODE LIBRARY			BARCODE LIBRARY			BARCODE LIBRARY		
Number of Barcodes : 31 (internal)								
EasyPlug Nr.	Barcode Sample		EasyPlug Nr.	Barcode Sample		EasyPlug Nr.	Barcode Sample	
0		EAN 8	14		MSI	27		CODE 128 Pharmacy
1		EAN 13	15		EAN 128			
2		UPCA	16		CODE 39 12:11			
3		CODE 93	17		POSTCODE Intelligent Mailcode			
4		CODE 2/5 Interleaved	18		POSTCODE Intelligent Mailcode			
5		CODE 2/5 Matrix	19		CODE 128 (UPSI)			
6		CODE 2/5 5 Schritte	20		CODE 128 (UPSI)			
7		CODE 39	21		CODE 39 12:5:11			
8		CODABAR	22		CODE 2/5 Matrix Ratio 11:2:3			
9		UPCE	23		CODE 2/5 Matrix Ratio 11:2:3			
10		HELD ON 2	24		CODE 39 Extended			
11		HELD ON 5	25		CODE 128 A			
12		ITF	26		CODE 128 B			
13		CODE 128			CODE 128 C			

[4] Print sample „Font Status“ / „Font Library“: Bar code listing.

- *One-dimensional bar codes* are printed with the Easy-Plug command #YB, see manual Easy-Plug, topic section [Description of Commands](#) □.
- *Two-dimensional bar codes* are printed by means of special Easy-Plug commands:


Easy-Plug command	Bar code
#IDM	Data Matrix Code
#MXC	Maxi Code
#PDF	PDF 417
#CBF	Codabar F
#CFN	Code 49
#SQR	QR Matrix Code

[1] Internal, two-dimensional bar codes.

- *GS1 DataBar* (formerly RSS) and *Composite Component* (CC) bar codes are printed by means of the Easy-Plug command #RSS. The bar code is

determined by the number in the first column of the subsequent table. This number is added to the command as a parameter.

BARCODE LIBRARY		
EasyFlag Nr.	Barcode Sample	
#RSS1		DS1 Databar Genadr.
#RSS2		DS1 Databar Truncated
#RSS3		DS1 Databar Stacked
#RSS4		DS1 Databar Stacked Omnidirectional
#RSS5		DS1 Databar Limited
#RSS6		DS1 Databar Expanded
#RSS7		UPC-B + CC-A/CC-B
#RSS8		UPC-E + CC-A/CC-B
#RSS9		EAN-13 + CC-A/CC-B
#RSS10		EAN-8 + CC-A/CC-B
#RSS11		UCC/EAN-128 + CC-A/CC-B
#RSS12		UCC/EAN-128 + CC-C

BARCODE LIBRARY		
EasyFlag Nr.	Barcode Sample	
		Data Matrix Code
		Maxi Code
		PDF 417
		Creditback F
		Data 49
		QR Code

[5] Print sample „Font Status“ / „Font Library“: Listing of RSS-Codes and 2-dim. bar codes.

Flashdata status

AP 5.4 AP 5.6

Prints a list of all fonts stored in the flash memory. This can be e. g. customized fonts or diagnose data.

- For details see topic section [Internal Fonts](#) , paragraph „Customized fonts“.
- For detailed information about diagnosis data refer to the service manual, topic section „Fault location“, „Reading out diagnosis data“.

FLASH DATA BLOCKS	
Total flash for data blocks	: 1872 KByte
Flash data block partition size	: 16 KByte
Number of flash data blocks	: 2
Remaining flash for data blocks	: 1104 KByte
<hr/>	
Block 0	Diagnostics information 128 KByte
<hr/>	
Block 1	MPCL Block 128 KByte
<hr/>	

[6] Example printout „Flashdata status“.

Service Status

AP 5.4 AP 5.6

Print the Service status report to read about operation time, no. of services, no. of exchanged parts and other matters of service interest (one page).

Use the parameter `SERVICE FUNCTION > Serv. data reset`, to set all the counters to zero, which are listed on the printout.

Service Status	
Operational Data	
Service operations	: 4294967295
Head number	: 0
Roll number	: 0
Knife number	: 0
Head run length	: 0 m
Roll run length	: 0 m
Cuts on knife	: 9
Total material length	: 358429 m
Total foil length	: 358150 m
Total cuts	: 2187
Total head moves	: 2414
Head strobes	: 1922179
Foil diameter	: 44.5 mm
Operation time	: 20 hours 16 min
Power supply data	
Type:	: CME PSupply
CPU board data	
CPU identifier	: 34-16
System controller	: GT-64111
Board Revision	: REV04
Peripheraldriver	
Feed driver	: V 3 - T 3
Foil driver	: V 3 - T 3
Head driver	: V 3 - T 3
Peripheraldriver	: V 3 - T 3
USI interface	: V 2 - T 1

[7] Example of a „Service Status“ printout.

- For information on the operational data on the service status printout refer to paragraph > [OPERATION DATA](#)  on page 159.
- For information on the power supply data on the service status printout refer to paragraph > [POWERSUPPLYDATA](#)  on page 164.
- For information on the CPU board data on the service status printout refer to paragraph > [CPU BOARD DATA](#)  on page 165.
- For information on the peripheral driver data on the service status printout refer to paragraph > [MODULE FW VERS.](#)  on page 157.

Dottest endless

AP 5.4 AP 5.6

Dottest for application with endless label stock.

This function prints a pattern which enables trained personnel to check the adjustment as well as the function of the printhead.

Test pattern

The „Dottest endless“ or „Dottest punched“ prints a pattern consisting of 33 rows filled with vertical lines on the upper label area. All lines have a constant distance of 4 dot. With every new row, the line pattern is shifted one dot. The resulting line-pattern repeats every four rows.

The test pattern shows missing dots clearly as white vertical lines running through the pattern.

The lower label area is filled with testpatterns, which are kept close to those used by Kyocera. The patterns are useful for printout comparison.

The bars underneath the test pattern allow the adjustment of the different zero lines.

Dottest punched

AP 5.4 AP 5.6


Dottest for application with punched material.

- See parameter [Dottest endless](#) on page 25.

Reference label

AP5.4 AP5.6

Prints a label with some examples of barcodes, fonts, logos... just try out!



[8] Example of a Reference label printout INFO AUSDRUCKEN > Reference label.

RFID Status

☛ Only with activated RFID option.

 AP 5.4

 AP 5.6

Prints a status printout with RFID specific data:

RFID Status	
System version	: V4.00 Jun 23 2005 [R4.00 PE2.50 H4.00Q]
Printer type	: Avery 64-05
Nr CMD retries	: 3
Nr invalid tags	: 3
<hr/>	
Statistics	
<hr/>	
Nr of Tags	: 7043
Nr. invalid tags	: 2788
Total Nr. SELECT	: 7803
Invalid SELECT	: 16%
Total Nr. READ	: 1189
Invalid READ	: 29%
Total Nr. WRITES	: 5483
Invalid WRITE	: 37%
Rate READ	: 45
Rate WRITE	: 46

[2] *Beispiel eines Ausdrucks* INFO AUSTRUCKEN > RFID Status.

PRINT PARAMETERS

Print speed

AP 5.4 AP 5.6

The print speed (material feed) can be adjusted according to the ribbon and material combination being used in order to optimise the contrast depth and the density of the print image.

x Inch/s

Setting range: see table; Unit interval: 0,2 inch/s;
Default setting: 8 Inch/s

Feed speed

AP 5.4 AP 5.6

The feed speed can be increased between print periods hereby reducing the total print time, particularly with long labels with a minimum printed surface.

Setting:

The value for the feed speed should not be set too high for print applications with long calculating units (e. g. consecutive numbering). This can help to avoid alternating between abrupt braking to 0 (zero) and acceleration to print speed.

▣▶ When altering the print speed, the feed speed is equal to the print speed. If a different feed speed is required, this must be set again.

x inch/s

Setting range: 2 to 12 inch/s; Unit interval: 1 inch/s
Default setting: 8 inch/s

Material type

AP 5.4 AP 5.6

Definition of the materials used. A distinction is made between reel material and gapped material (hole gaps, self-adhesive material with register gaps). The detected gap position corresponds to the start of the label.

▣▶ The value is overwritten by the appropriate Easy Plug command when sending label formats.

Endless

If material is to be used without gaps.

Punched

If material is to be used with gaps (default setting).

Material length

AP 5.4 AP 5.6

The material length (label length) is the distance between the gaps, measured from the front edge (beginning) of a label to the front edge of the next label.

▣▶ The value is overwritten by the appropriate Easy Plug command when sending label formats.

xxx mm

Setting range: 5 mm to "max. length entry"; Unit interval: 0.1 mm
Default setting: 100 mm

Maximum length entry: dependent on the print head width and memory configuration.

Material width

AP 5.4 AP 5.6

Zero position of the left border. If the printer is working in line-printer mode, alterations can be made in millimetre units.

xxx mm


Setting range: "min. width" to "max. width"; Unit interval: 0.1 mm
Default setting: 100 mm

- Min. width: dependent on the printer type
- Max. width: dependent on print head width and memory configuration.

○ For detailed material width information, refer to topic section „Specifications“.

Print direction

AP 5.4 AP 5.6



[9] Orientation of the printout „Foot first“ (A) or „Head first“ (B).

Foot first

(Default) Orientation of the printout according to [10A].

Head first

Orientation of the printout according to [10B]. Mind the following:

▣ Define the „true“ label length (without gap length) in parameter PRINT PARAMETERS > Material length. If the label gap is wider than 5 mm, the parameter SYSTEM PARAMETERS > Miss. label tol. must be set to a value more than zero.

▣ The distance between material base line and the first printable dot is 1 mm. To keep this distance while printing „head first“, the material width must be calculated as follows::

$$b_{Mat} = b_{Bp} - 2mm , \text{ with}$$

b_{Mat} : Material width

b_{Bp} : Backing paper width

Punch offset

AP 5.4 AP 5.6

The zero position can be determined offset in millimetre units from the detected gap position.


▣▶ The value is overwritten by the appropriate Easy Plug command when sending label formats.

xxx mm

Setting range: -8 to +max. label length; Unit interval: 0,1 mm
Default setting: 0 mm

Maximum offset in feed direction: -8 mm

Minimum offset against feed direction: +max. label length



[10] Positive and negative offset in relation to the feed direction (arrow).

Bar code multip.

AP 5.4 AP 5.6

Bar code height scaling factor

Increases the bar code height defined in the label layout (Easy-Plug) by multiplication by a factor of 1 to 10.

x

Setting range: 1 to 10; Unit interval: 1; Default setting: 1

The printed bar code height calculates starting with the value defined in the label layout multiplied by the scaling factor x.

Tradit. Imaging

AP 5.4 AP 5.6

■ In production mode only.

Up to firmware version x.31, the barcode height was calculated with the formula:

$$\text{Barcodeheight}_{Print} = (\text{Barcodeheight}_{Layout} + 1) \cdot x$$

with $x = \text{PRINT PARAMETERS} > \text{Barcode Multi.}$

By doing so, the printed barcode height in millimeters was by 1 higher than the value defined in the layout (1 --> 2 mm, 2 --> 3 mm, etc.)¹⁾.

From firmware version x.31 on, the printed barcode is exactly as high in millimeters, as the value in the layout is (1 --> 1 mm, 2 --> 2 mm, etc.)¹⁾.

No	New height calculation (1 --> 1 mm, 2 --> 2 mm, etc.) is applied (default setting). The plain copy line is printed with OCR-B font.
Yes	Setting for customers with print layouts based on the <i>old</i> height calculation scheme. The plain copy line of the barcodes EAN8, EAN13, UPC-A and UPC-E is printed with the same fonts, which older printer types like TTK or TTX x50 have used.

UPC plain-copy

AP 5.4 AP 5.6

The position of the first and last digit in the plain-copy line - underneath the bar code - can be adjusted as required.

Raised	First and last digit of the UPCA or first digit with the UPCE are raised (default setting).
In line	All digits in the decoded line are in line under the code.

EAN Readline

AP 5.4 AP 5.6

<> Signs	Readline enclosed in "<>" signs or terminated by a ">"-Sign (EAN 13).
Standard	Readline without "<>" or ">" signs (default).

1) Assumed that $\text{PRINT PARAMETERS} > \text{Barcode Multi.} = „1“$.

EAN sep. lines

AP 5.4 AP 5.6

EAN separation lines. Parameter for controlling of EAN or UPC barcodes if they are printed without readline.

With readl. only

(Default) The separation bars at the beginning, end and in the middle of the barcode are only long, if the barcode is printed with a readline.

Always long

The separation bars at the beginning, end and in the middle of the barcode are always long, regardless if the barcode is printed with or without readline. The position of the barcode is the same as with the readline option switched on.

Rotated Barcodes

AP 5.4 AP 5.6

Improves the readability of rotated (90° and 270°) bar codes.

Normal

„Normal“ printing without a special processing of rotated bar codes.

Optimized


(Default setting) The line and gap widths of rotated bar codes are modified in order to improve their readability.

Dispenseposition

AP 5.4 AP 5.6

Dispense position

Adjusts the dispense position in or against the feed direction. Depending on the set dispense position, the dispensed label sticks to the backing paper with a more or less wide strip [13]. The required width of this strip depends on the further processing.



[11] Dispense position (= stopp position) of the dispensed label.

x.x mm

Setting range: -30.0 to +20.0 mm; Unit interval: 0,1 mm; Default setting: 0 mm

Cut mode


AP5.4 AP5.6

☛ Only with mounted and activated cutter (SYSTEM PARAMETERS > Periph. device = „Cutter“).

This is where the procedure for the label output and cut is defined.

Real 1:1 mode

The whole surface of the label is printable. The label is pushed forward to the cutter for cutting. After the cut, the beginning of the next label is drawn back under the print head. This reduces the output volume (in relation to a certain time).




[12] Printing process (schematic) in „Real 1:1 Mode“.

Batch mode

The whole surface of the label is printable. Cutting takes place during printing. This can result in brief interruptions within the print zone of the following label. The output volume is at its maximum level.

Requirements for the batch mode are:

- Ribbon economy is not active (parameter SYSTEM PARAMETERS > Ribbon autoecon. = "Deactivated")
- Material length >18 mm (>14 mm on the TTX 350)
- Number of cuts for a print job - at least 2 or more




[13] Printing process in Batch mode (schematic).

Normal 1:1 mode

In N1:1 mode, cutting takes place during printing. The zero-line of the printing is shifted 18 mm in y-direction. This offset equals the distance cutter-printhead. Caused by this shifting, the first 18 mm of the label are not printable. These measurement corresponds to the distance between print head and cutter. The output volume is at its maximum level.

(The offset of the zero-line is caused historically and serves the compatibility of older printer models).



[14] Printing process in Normal 1:1 mode (schematic).

Cut speed

AP 5.4 AP 5.6

▣▣▣▣ Only with mounted and activated cutter (SYSTEM PARAMETERS > Periph. device = „Cutter“).

The cut speed is to be adjusted to the material thickness and strength.

x inch/s

Setting range: 2 to 5 inch/s; Unit interval: 1 inch/s

- 2 inch/s: extremely slow; for thick and strong material
- 5 inch/s: extremely fast; for thin material

Cut position

AP 5.4 AP 5.6

▣▣▣▣ Only with mounted and activated cutter (SYSTEM PARAMETERS > Periph. device = „Cutter“).

The cut position is identical to the detected gap position, i. e. with the start of the label. Fine settings to meet specific customer requirements can be programmed using the parameter PRINT PARAMETER > Cut position.

x inch/s

Setting range: -2.0 to +2.0 mm; Unit interval: 0.1mm

- Maximum offset in feed direction: -2.0 mm
- No offset: 0 mm
- Minimum offset against feed direction: -2.0 mm

Double cut

AP 5.4 AP 5.6

▣▣▣▣ Only with mounted and activated cutter (SYSTEM PARAMETERS > Periph. device = „Cutter“).

Joining grids or the gap area between the labels can be removed using a double cut, thereby improving the outline.

The first cut is offset by the distance set from the recognized gap position away in the feed direction, the second cut is made at the gap position.

A possible correction of the cut position ("Cut position" function) is calculated for both cuts and must be taken into consideration.

x inch/s

Setting range: 0.0 to 5.0 mm; Unit interval: 0.1mm

Normal simple cut: 0.0 mm

▣▣▣▣ The smallest possible double cut distance of 1.0 mm must be adhered to!

Rewind direction

AP 5.4 AP 5.6

▣▣▣▣ Only with mounted and activated rewinder (SYSTEM PARAMETERS > Periph. device = „Rewinder“).

Determines the sense of rotation of the optional Rewinder.

Printing outside

Rewind direction: The printed label is facing outside.

Printing inside

Rewind direction: The printed label is facing inside.

X - Printadjust

AP 5.4 AP 5.6

The zero point of the mask is moved in relation to the edge of the label on the X- axis, i. e. lengthways to the material.

▣▣▣▣ If the setting is changed, while the print job is stopped, the printer recalculates the format using the changed values.

▣▣▣▣ Caution with graphics, which are generated via one of the Easy Plug commands #YI, #YIR or #YIB! If the graphics is shifted beyond the label border as a consequence of changing the parameter "X-Printadjust", the part of the graphics which "juts out" will get lost.

x.x mm

Setting range: -5.0 to +5.0 mm; Unit interval: 0.1mm
Default setting: 0.0 mm

- Maximum offset away from the edge of the label: +5.0 mm
- No offset: 0.0mm
- Maximum offset towards the edge of the label: -5.0 mm

Y – Printadjust

AP 5.4 AP 5.6

The zero point of the mask is moved in relation to the gap position on the Y-axis, i. e. in the feed direction.

▣▣▣▣ If the setting is changed, while the print job is stopped, the printer recalculates the format using the changed values.

▣▣▣▣ Caution with graphics, which are generated via one of the Easy Plug commands #YI, #YIR or #YIB! If the graphics is shifted beyond the label border as a consequence of changing the parameter "Y-Printadjust", the part of the graphics which "juts out" will get lost.

x.x mm

Setting range: -5.0 to +5.0 mm; Unit interval: 0.1mm
Default setting: 0.0 mm

- Maximum offset in feed direction: +5.0 mm
- No offset: 0.0mm
- Minimum offset against feed direction: -5.0 mm

Punch mode

AP 5.4 AP 5.6

Automatic

Automatic mode, for material with a contrast zone = gap in the label.

"Automatic" is the default setting, suitable for all materials with which there is a difference in the transparency between the label and gap of more than 2 values (see Description, sensor check).

Manual

Manual setting, for material with several varying contrast zones. Settings are made using the parameter `PRINT PARAMETER > Punch level`.

The range of the value automatically measured by the gap detection can be defined specifically for the label material. This allows materials with high-contrast proof points within the label to be processed, which would otherwise be measured as 'false' gaps by the system. The corresponding setting value is then equal to, or smaller than, the value measured at the actual gap.

Punch level

AP 5.4 AP 5.6

☛ Only if `PRINT PARAMETERS > Punch mode = „Manual“`.

xxx

Setting range: 0 to 255; Unit interval: 1

The value xxx stands for the current contrast within the photoelectric switch of the material which has just been inserted. This serves to determine a threshold value for the inserted material.

```
Punchlevel
Punch xxx Val yyy
```

xxx = current measurement at the punch sensor
yyy = set threshold value

Example

Self-adhesive material with black bars lengthways across the label

- Reading:
 - Masking paper: 30
 - Masking paper + label: 60
 - Masking paper + label + black bars: 190
- Setting value: 60

A setting value of 60 means that all readings over 60 are ignored, therefore also the reading 190 at the black bar.

INTERFACE PARA

Interface parameter

> EASYPLUGINTERPR

Interface

AP 5.4 AP 5.6

Interface type

This parameter sets the interface, by which the printer will receive data.

Serial Com1

Serial interface Com1.

- Selection of the type of serial interface is done with parameter `INTERF. PARAM > EASYPLUGINTERPR > Serial Port Mode`.

Only for Ethernet interface (10/100 Base T):

TCP/IP Socket

Print data can be sent to the printer via a TCP/IP socket

LPD Server

Print data can be sent to the printer via the LPR/LPD-protocol

USB

USB 1.1 interface

Serial Com3

Serial interface Com3.

☛ Only with optional I/O board mounted.

Automatic

All interfaces are enabled to receive data, but *not simultaneously*.

☛ Don't send data to more than one interface at a time.

☛ Except are interfaces, which are being used by an option (e.g. OLV).

Spooler mode

AP 5.4 AP 5.6

The operating mode of the spooler determines whether print series are processed individually, or whether the spooler can receive print data when printing several series.

Single print job

Single print series mode (the interface can only receive data after printing the required number of labels of a single series)

Mult. print jobs

Multiple print series mode (the interface can receive data while the series is being printed)

Printer ID No.

 AP 5.4 AP 5.6

Printer identification number

Determines the identification number of the printer. In such a way, the printer can be addressed by the Easy Plug command #!An (n=printer ID).

The use of ID numbers is in particular reasonable for data transfer by RS422/485 interface, if several printers are connected by one data line. Each of the connected printers then only incorporates the data mapped to him by #!An command.

xx Setting range: 0 to 31; Unit interval: 1

Spooler size

 AP 5.4 AP 5.6

The memory capacity of the printer buffer can be set according to the requirements of each customer.

xxx Kbyte Unit interval: 16-2048 kBytes; step width: 16 kBytes; default setting: 64 kBytes

Offline mode

 AP 5.4 AP 5.6

Interf. disabled Easy-Plug commands are *not* accepted, while the machine is in offline mode (default setting).

Interf. enabled Easy-Plug commands *are* accepted in offline mode.

Interface delay

 AP 5.4 AP 5.6

After switching from online to offline mode, the printer interface is deactivated. This parameter offers a settable delay time before deactivating the interface.

xxxx ms Setting range: 0-1000; Unit interval: 100; Default setting: 0

> COM1 PORT

Baud rate	
AP 5.4	AP 5.6
Data transfer speed	
Speed of data transfer using the serial interface.	
xxxxxx Baud	Setting range: 300 to 115200 Baud; Unit interval: 300/600/1200/2400/4800/9600/19200/38400/115200 (default)
No. of data bits	
AP 5.4	AP 5.6
This parameter can be defined in connection with both the serial and the parallel interface.	
7	7 Data bits
8	8 Data bits
Parity	
AP 5.4	AP 5.6
Defines the parity check of serial transmitted data.	
The parity bit is for checking data transmission. If the check shows an error, a corresponding message is displayed. The setting must be identical at the sender and the receiver. Normally transmission is set without a parity bit.	
Odd	Odd parity. A parity bit is added so that there is an odd number of 1 Bits.
Even	Even parity. A parity bit is added so that there is an even number of 1 Bits.
None	No check bit. Sending and receiving without check bit.
Always zero	Check bit is always 0 (zero). Sending and receiving without parity check.
Stop bits	
AP 5.4	AP 5.6
Number of stop bits	
Number of stop bits at the serial interface.	
1 Bit	1 stop bit
2 Bit	2 stop bits

Data synch.	
AP 5.4	AP 5.6
	Data synchronisation at the serial interface.
RTS/CTS	Data synchronisation through hardware
XON/XOFF	Data synchronisation through software
None	Handshake signals are ignored
Frame error	
AP 5.4	AP 5.6
Display	(Default) An error message is displayed, if a framing error is detected while the printer is receiving serial data.
Ignore	Framing errors will be ignored, no error messages are displayed.

> COM3 PORT

☛ This menu only appears, if the optional I/O board is installed.

Baud rate

AP 5.4	AP 5.6
--------	--------

☛ With mounted and connected I/O board only.

- See parameter [Baud rate](#) on page 45.

No. of data bits

AP 5.4	AP 5.6
--------	--------

☛ With mounted and connected I/O board only.

- See parameter [No. of data bits](#) on page 45.

Parity

AP 5.4	AP 5.6
--------	--------

☛ With mounted and connected I/O board only.

- See parameter [Parity](#) on page 45.

Stop bits

AP 5.4 AP 5.6

▣▣▣▣ With mounted and connected I/O board only.

- See parameter [Stop bits](#) on page 45.

Data synch.

AP 5.4 AP 5.6

▣▣▣▣ With mounted and connected I/O board only.

- See parameter [Data synch.](#) on page 46.

Frame error

AP 5.4 AP 5.6

▣▣▣▣ With mounted and connected I/O board only.

- See parameter [Frame error](#) on page 46.

Serial Port Mode

AP 5.4 AP 5.6

▣▣▣▣ With mounted and connected I/O board only.

Setting of the serial interface type.

RS232

Sets Com2 to RS 232.

Data synchronisation may be done by hardware (RTS/CTS) or by software (XON/XOFF). Maximum cable length is 15 m.

RS422

Sets Com2 to RS 422.

RS 422 is a 4 wire point to point connection, suitable for only one device. Receiver and driver of the printer are always enabled. Data synchronization is only possible by software (XON/XOFF). Maximum cable length is 1 km with twisted telecommunication cable.

RS485

Sets Com2 to RS 485.

RS 485 is a 2 or 4 wire bus system for up to 30 devices. The printer's receiver is always enabled, the printer's driver is only enabled, if the printer sends data to the host. Data synchronization is only possible by software (XON/XOFF). Maximum cable length is 1 km with twisted telecommunication cable.

> COM4 PORT

Internal interface, to which the optional RFID read/write unit can be connected.

Baud rate

AP 5.4 AP 5.6

▣▣▣▣ With mounted and connected I/O board only.

- See parameter [Baud rate](#)  on page 45.

No. of data bits

AP 5.4 AP 5.6

▣▣▣▣ With mounted and connected I/O board only.

Fixed setting of 8 Bits.

Parity

AP 5.4 AP 5.6

▣▣▣▣ With mounted and connected I/O board only.

- See parameter [Parity](#)  on page 45.

Stop bits

AP 5.4 AP 5.6

▣▣▣▣ With mounted and connected I/O board only.

Fixed setting of 2 Bits.

Data synch.

AP 5.4 AP 5.6

▣▣▣▣ With mounted and connected I/O board only.

- See parameter [Data synch.](#)  on page 46.

Frame error

AP 5.4 AP 5.6

▣▣▣▣ With mounted and connected I/O board only.

- See parameter [Frame error](#)  on page 46.

> USB

USB select

 AP 5.4 AP 5.6

External Device	(Default setting) Setting for the connection of an USB device (e. g. USB-Stick).
Internal Device	Setting for the use of the USB port for internal communication (as device).
Internal Host	Setting for the use of the USB port for internal communication (as host).

> NETWORK PARAM.

IP address assign

 AP 5.4 AP 5.6

▣▣▣▣ A change of this parameter setting forces a printer restart.

Fixed IP address	This setting activates the parameters "Net mask" and "Gateway address" (see below).
DHCP	IP address is assigned automatically. The assigned IP address is displayed for a moment on the printer display, while the printer is starting.

IP address

 AP 5.4 AP 5.6

xxx.xxx.xxx.xxx	Setting range per xxx value: 0 to 255 Change between the digits by pressing the Cut or Feed button; Acknowledge the setting by pressing the Online button. After a change of the IP address, the printer will reset automatically.
-----------------	---

Net mask

 AP 5.4 AP 5.6

xxx.xxx.xxx.xxx	Setting range per xxx value: 0 to 255 Depending on the set IP address appears a default value. ▣▣▣▣ We recommend to use the default value!
-----------------	--

Gateway address

 AP 5.4 AP 5.6

xxx.xxx.xxx.xxx

Setting range per xxx value: 0 to 255
 000.000.000.000 = no gateway is used

Port address

 AP 5.4 AP 5.6

Setting range: 1024 to 65535. Default: 9100.

Ethernet speed

 AP 5.4 AP 5.6

Auto negotiation

The communication speed is selected automatically.

10M half duplex

The communication speed is set to 10 MBit/s *half duplex*.

10M full duplex

The communication speed is set to 10 MBit/s *full duplex*.

100M half duplex

The communication speed is set to 100 MBit/s *half duplex*.

100M full duplex

The communication speed is set to 100 MBit/s *full duplex*.

MAC address

 AP 5.4 AP 5.6

Displays the MAC address of the CPU board. This address can not be changed in the parameter menu.

SNMP agent

 AP 5.4 AP 5.6

☛ Function is not released yet.

SNMP password

 AP 5.4 AP 5.6

☛ Only in production mode.

☛ Function is not released yet.

FTP server

AP 5.4 AP 5.6

The File Transfer Protocol (FTP) server (RFC959) allows access to the internal RAM disk of the printer and, if available, to the memory card. The FTP server is capable of multisection mode, without evaluating the user name when logging in. The password must match the set password (see below).

- For further information read the user manual, topic section „Advanced Applications“, chapter „Data transmission with FTP“.

Enabled Switches the FTP server *on*.

Disabled Switches the FTP server *off*.

FTP password

AP 5.4 AP 5.6

■▶ Parameter only appears in production mode.

Input of the FTP server password by means of a connected keyboard or the printers operation panel. Default setting: „avery“.

Changing the password:

1. Press the Esc button. The cursor jumps to the first character.
2. Press the Cut- or Feed button until the wanted character appears. Acknowledge by pressing the Online button.
3. Put in the next character.
4. Acknowledge the new password by pressing the Online button.

■▶ If a keyboard is connected, this can be used for typing in the password.

WEB server

AP 5.4 AP 5.6

The web server may be used to

- read out or change parameter settings of the printer into a web browser
- Operate the printer via a web browser.

Requirements for use of the web server function:

- Printer is connected to network
- A valid IP address is assigned to the printer (by the network administrator or by a DHCP server)
- INTERFACE PARA > NETWORK PARAM. > WEB server must be set to „Enabled“.

Starting the web server:

1. Write down the printers IP address (INTERFACE PARA > NETWORK PARAM. > IP address).

2. Start the web browser.

Insert into the address field:

http://[IP address without leading zeros]

Example: IP address = 144.093.029.031

Input: http://144.93.29.31

3. Click „Login“.
4. Type in user name (admin) and password (admin).

If the login was successful, you will find the following menu items at the left window margin:

Menu item	Function
Home	Jump to the home page
Logout	Interrupt the connection to the printer
Parameter	Opens the parameter menu. By clicking on submenus and parameters, those can be opened and the parameter settings be changed. ■■■► Some parameters force the printer to reset, if their setting is modified by means of the operation panel. If the parameters are changed via the web server, this doesn't happen automatically. Therefore, the modifications only become effective after the next printer restart. A restart can be triggered remote in the „Display view“.
Display view	Opens the display operation panel. Enables remote operation of the printer.
Download	Opens another browser window with the URL of the FTP server. For more information read the description of INTERFACE PARA > NETWORK PARAM. > FTP server.
Help	Help texts

[3] Functions of the web server.

Enabled	Switches the web server <i>on</i> .
Disabled	Switches the web server <i>off</i> .

WEB display refr

WEB display refresh

 AP 5.4 AP 5.6

☛ Only appears, if INTERF.PARAM > NETWORK PARAM. > Time client = „Enabled“.

Automatic updating of the web browser display. The setting determines the time in seconds between two updates.

☛ Setting 0 = „no automatic updating“.

Setting range: 0 to 20; Default setting: 5

xx s

WEB admin passw.

WEB administrator password

 AP 5.4 AP 5.6

☛ Only in production mode.

Modifying the password for web server access as admin.

Default setting: „admin“

☛ The user name is also „admin“.

☛ If the user logs in as admin to the web server, he/she has access to all parameters, which are *not* marked with the footmark „only in production mode“.

Changing the password at the operating panel:

1. Press the Esc button. The cursor jumps to the first character.
2. Press the Cut- or Feed button until the wanted character appears. Acknowledge by pressing the Online button.
3. Type in the next character.
4. Acknowledge the new password by pressing the Online button.

☛ Alternatively, the password can be typed in using a keyboard, or via the web server.

WEB supervisor p.

WEB supervisor password

 AP 5.4 AP 5.6

☛ Only in production mode.

Modifying the password for web server access as supervisor.

Default setting: „supervisor“

☛ The user name is also „supervisor“.

☛ If the user logs in as supervisor to the web server, he/she has access to *all* parameters.

Changing the password at the operating panel:

1. Press the Esc button. The cursor jumps to the first character.
 2. Press the Cut- or Feed button until the wanted character appears. Acknowledge by pressing the Online button.
 3. Type in the next character.
 4. Acknowledge the new password by pressing the Online button.
- ▣▣▣▣ Alternatively, the password can be typed in using a keyboard, or via the web server.

Time client

AP 5.4 AP 5.6

Loads the current time from a time server.

Disabled

The time client is switched off.

Enabled

The time client is switched on. The time is loaded with the frequency set under *Sync. interval* from a time server with the IP address *Time server IP*.



With the time client service, the current date and time can be obtained from a time server using RFC868 time protocol on UDP port 37. For this purpose, a time server IP address needs to be given. Date and time are initially requested at start up an optional in a setable update interval during operation time. It is also stored in the internal real time clock. There is no time offset or daylight saving hour, so the server time must exactly match the local time of the printer.

Time server IP

AP 5.4 AP 5.6

IP address of the time server.

▣▣▣▣ Only appears if *INTERFACE PARA > NETWORK PARAM. > Time client = „Enabled“*.

xxx.xxx.xxx.xxx

Enter the IP address following the xxx.xxx.xxx.xxx schema. Setting range for each xxx value: [0...255].

Sync. Interval

AP 5.4 AP 5.6

Determines the frequency for time requests.

▣▣▣▣ Only appears if *INTERFACE PARA > NETWORK PARAM. > Time client = „Enabled“*.

xxxx

Setting range: [0...9999] s; Default setting: 3600 s.

DHCP host name

AP 5.4 AP 5.6

Host name of the printer. Default setting: „Device name“ + the last 3 figures of the MAC address.

Typing in the host name at the operating panel:

1. Press the Esc button. The cursor jumps to the first character.
2. Press the Cut- or Feed button until the wanted character appears. Acknowledge by pressing the Online button.
 - ▣▣▣▣ Valid characters: A-Z, a-z, 0-9, -
3. Type in the next character.
4. Acknowledge the new password by pressing the Online button.
 - ▣▣▣▣ Alternatively, the password can be typed in using a keyboard, or via the web server.

> OPTIONS

RFID Option

AP 5.4 AP 5.6

Disabled	RFID-Option is <i>not</i> activated (RFID = Radio Frequency Identification). ▣▣▣▣ The RFID reader is connected to Com1 or Com2 <i>internally</i> , what means, that it does not have to be plugged into the external serial interface connector.
Serial Com1	The RFID reader is connected to Com1. ▣▣▣▣ This setting option is only visible, if no other option is activated at Com1.
Serial Com4	The RFID reader is connected to Com4. ▣▣▣▣ This setting option is only visible, if no other option is activated at Com4.

StandAlone Input

AP 5.4 AP 5.6

Defines an interface for data input in standalone mode.

▣▣▣▣ Interfaces are only selectable, if installed and not used by another function (e. g. as data interface). If `INTERFACE PARA > EASYPLUGINTERPR > Interface = „Automatic“`, all interfaces besides Com3 are blanked out.

None	No data input via interface.
Serial Com1	Com1 is applied for data input in standalone mode.
Serial Com3	Com3 is applied for data input in standalone mode.
TCP/IP socket	TCP/IP socket is applied for data input in standalone mode.

> DRIVEASSIGNMENT

- For detailed information read the Easy-Plug manual, topic section [General Notes, Definitions and Command Overview](#) , chapter „Drive names“.

Drive C

AP 5.4	AP 5.6
--------	--------

Assigns drive letter C: to the card slot or to the USB port.

None

C: is not assigned

(Default setting) C: is assigned to the SD card slot.

USB-stick

C: is assigned to the USB host port.

Drive D

AP 5.4	AP 5.6
--------	--------

Assigns drive letter C: to the card slot or to the USB port.

None

D: is not assigned

SD card

D: is assigned to the USB host connector

SYSTEM PARAMETERS

Foil end warning

 AP 5.4 AP 5.6

Setting of a limit diameter for the ribbon roll. If the ribbon roll diameter falls below the set value, the displayed message changes from...

ONLINE X JOBS ...to...

FOLIE X JOBS ...while the display is blinking.

- For details refer to the parameters [DP INTERFACE > Ribbon signal](#) and [SERVICE DATA > OPERATION DATA > Foil diameter](#)

x.xx mm

Setting range: 25.4 to 50.0 mm; Unit interval: 0.1 mm;
Default setting: 25.4 mm

Foil warn stop

 AP 5.4 AP 5.6

Disabled

(Default setting) Printer does *not* stop in case of a „Foil end warning“.

Enabled

If a „Foil end warning“ occurs, the printer stops after the current label and shows the status message:

```
PrintStatus:    5110
Foil low
```

- ➔ Press the online button to acknowledge the message, then the feed button to continue printing.

Print Interpret.

 AP 5.4 AP 5.6

The printer uses the MONARCH LANGUAGE INTERPRETER™ to interpret and process data.

Easyplug

Printjobs written in the Easy-Plug command language can be interpreted.

Lineprinter

Lineprinter (or similar to Lineprinter), print-out of the print command.

Hex Dump

Print-out in hexadecimal format.

In Lineprinter and Hex Dump, commands are printed out in the form of a list with the character set 12.

- ▣➔ When setting Lineprinter or Hex Dump, Easy Plug commands which have not yet been processed are deleted!

MLI

Printjobs written in the ZPL II®¹⁾ command language can be interpreted.

- ▣➔ Firmware loading requires changing into EasyPlug first.

Character sets

AP 5.4 AP 5.6

Setting the character set:

- **8bit:** Choose between IBM and ANSI character set.
- **7Bit:** Additionally to the IBM and ANSI character sets, some country specific character sets are provided, which have some characters allocated differently (see table below)

▣► The country specific character sets are only suitable for older 7bit applications!

Decimal	35	36	64	91	92	93	94	96	123	124	125	126	>127
ASCII	#	\$	@	[\]	^	`	{		}	~	
ISO 8859-2 ^{a)}	#	\$	@	[\]	^	`	{		}	~	print
ANSI (CP 1250) ^{a)}	#	\$	@	[\]	^	`	{		}	~	print
ANSI (CP 1252)	#	\$	@	[\]	^	`	{		}	~	print
IBM	#	\$	@	[\]	^	`	{		}	~	print
Special	f	¢	blank	blank	¼	½	blank	blank	«	•	»	±	blank
Norway	#	\$	@	Æ	¥	Å	^	`	æ	¢	å	~	blank
Spain	#	\$	@	i	Ñ	Ç	^	`	¿	ñ	ç	~	blank
Sweden	#	•	É	Ä	Ö	Å	Ü	é	ä	ö	å	ü	blank
Italy	Š	\$	§	°	ç	é	^	ù	à	ò	è	`	blank
Germany	#	\$	§	Ä	Ö	Ü	^	`	ä	ö	ü	ß	blank
France	£	\$	à	°	ç	§	^	`	é	ù	è	~	blank
United Kingdom	£	\$	@	[\]	^	`	{		}	½	blank
USA	#	\$	@	[\]	^	`	{		}	~	blank
blank = space, print = printable													

[4] Country settings for applications, which base on 7bit ASCII code.

a) Not available with AP 4.4

- For complete tables of all fixfonts characters available with setting "IBM" refer to the User Manual, topic section "Internal Fonts". You also find there a comparison of the IBM and ANSI character sets.

- 1) ZPL II is a registered trademark of ZIH Corp. ZIH Corp. and Avery Dennison (including Paxar Corporation and its subsidiaries) are not related in any way, and ZIH Corp. has not licensed or otherwise sponsored MONARCH® printers or Avery Dennison's MONARCH LANGUAGE INTERPRETER™. MONARCH®, MONARCH LANGUAGE INTERPRETER, MLI are trademarks of Paxar Americas, Inc. Avery Dennison is a registered trademark of Avery Dennison Corporation.

 Character filter

 AP 5.4 AP 5.6

Character >= 20Hex	Filter function is activated. Characters smaller than 20H are filtered out of the data flow.
All character	Filter function is deactivated. Characters smaller than 20H are treated as normal characters.

 Light sens. type

 AP 5.4 AP 5.6

Light sensor type

The optional reflex photoelectric switch for labels with reflecting length markings, or the normal factory-fitted photoelectric switch for labels with transparent or register gaps (self-adhesive labels), must be defined according to the application.

Short label opt.	Activates the optional short label sensor. ■■■▶ Appears only in AP 5.4 printers which are equipped with the short label sensor.
Reflex	Reflex photoelectric switch (for reflecting markings)
Punched	Transparent photoelectric switch (for gaps)

 Head-sensor dist.

 AP 5.4 AP 5.6

■■■▶ Parameter appears only in production mode or if a value > 0 is set.

Printhead-sensor distance

Special function for setting non-standard punch sensors. Such sensors can be applied in special application devices ("Nistan"). The value x is the distance between thermal edge and punch sensor in millimeters.

x mm	Setting range: 0 to 400 mm ■■■▶ A „non standard sensor“ must be installed and connected instead of the regular punch sensor. ■■■▶ 0 = disabled (the regular punch sensor is used).
------	--

Sens. punch-LS

AP 5.4 AP 5.6

Sensitivity punch light sensor

Sets the sensitivity of the material photoelectric switch.

xxx%

Setting range: 10 to 100%; Unit interval: 10%

Default setting: 50%

Maximum sensitivity: 100%. for narrow gaps (perforations).

Minimum sensitivity: 1%. for clearly detectable gaps.

☛ Too high a level of sensitivity can lead to gaps being detected which do not even exist (on proofs, material thickness fluctuations, perforations etc.).

Foil mode

AP 5.4 AP 5.6

Thermo transfer

Thermo transfer printing (Ribbon sensor activated)

Thermal printing

Thermo direct printing (Ribbon sensor deactivated)

Turn-on mode

AP 5.4 AP 5.6

Operating mode of the printer after it has been switched on.

Online

Printer starts in on-line mode.

Offline

Printer starts in off-line mode.

Standalone

Printer starts in standalone mode.

Error reprint

AP 5.4 AP 5.6

If an error occurs while a label is printed, the last printed label will normally be reprinted. In case of label layouts containing variable data like e.g. count fields, switching off the reprint function possibly makes sense.

Enabled

Reprint in error cases (default setting)

Disabled

No reprint in error cases.

EasyPlug error

AP 5.4 AP 5.6

Handling of errors caused by faulty Easy-Plug commands.

- Tolerant handl.** The label is printed, after the Easy-Plug/Bitimage error was acknowledged (default setting).
- Strict handling** The Easy-Plug command, which caused the error, is displayed after approx. 2 seconds in the lower display line. The displayed text is up to 30 characters long and is scrolled automatically.
- If a single character caused the error, this character is marked with „>> <<„ in the display text, to facilitate the detection.
- By pressing the cut button, the display can be toggled between error message and Easy-Plug command text.
- After acknowledging the first occurred Easy-Plug error, the printjob and the spooler are deleted (as by #!CA). This prevents the printing of labels with format errors.

Single job mode

AP 5.4 AP 5.6

In single job mode (also stop mode) the printer stops after every job and waits until the operator restarts the print process.

- Deactivated** Single job mode is switched off (default setting).
- Activated** Single job mode is switched on. The printer always displays "Start next job", before starting a new print job. This requests the user to acknowledge by pressing the Online button.

Head resistance

AP 5.4 AP 5.6

For optimum print quality, the individual print head resistance of the thermo head employed in the device must be set once with this parameter.

When replacing the print head, the resistance value of the print head (to be read off from the print head) must be entered again.



⚠ CAUTION! - Entering a false value can damage the print head!

- Read off the correct value from the print head and set it accordingly.
 ⚡ The value set here remains when the factory settings are carried out.

xxxx Ohm

Setting range: 1000 to 1500 Ohm; Unit interval: 1 Ohm

Setting the print head resistance:

Setting:

1. From the print head, read off the resistance value to be set and make a note of it (1000 to 1500).
2. In off-line mode press the Prog. button, display: *PRINT INFO*.
3. Press the Cut button until *SYSTEM PARAMETER* is displayed.
4. Press the Online button, display:

SYSTEM PARAMETER
Foil end warning

5. Press the Cut button until the following is displayed:

SYSTEM PARAMETER
Head resistance

6. Press the Online button, set value is displayed.
7. Set the previously noted resistance value of the print head using the Feed and Cut buttons.
8. Press the Online button to confirm the set value.
9. Press the Prog. button to return to the display *OFFLINE 0 JOBS*.

Temp. reduction

AP 5.4 AP 5.6

Reduction in the print head temperature

The parameter *SYSTEM PARAMETER > Temperature reduct.* allows the power supply to be reduced in the event of an increase in the print head temperature, thereby ensuring an evenly good print image.

xxx%

Setting range: 0 to 100%; Unit interval: 5%

The following setting alternatives are available:

- 0%: No temperature reduction.
 - xx%: Up to xx% temperature reduction with a hot print head.
 - Default setting: 20%.
- For further information refer to the user manual, topic section „Advanced Application“, chapter „Printing with Temperature Compensation“

Thin line emphasis

AP 5.4 AP 5.6

☛ Only in production mode

Thin line emphasis. Print emphasis for thin lines in order to get a better print result.

On

(Default) Print emphasis for thin lines is switched on.

	Thin lines in the printout, which run crossways to the printing direction, are printed approx. 1.5 times wider. This may have the effect, that small white patches are closed with color (e.g. in the „e“ with very small fonts).
Off	Print emphasis for thin lines is switched off.
Voltage offset	
	AP 5.4 AP 5.6
xx%	The voltage offset increases the head voltage and therefore the head temperature which e.g. was set by Easy Plug command (HV). Setting range: 0 to 20%; Unit interval: 1% Default setting: 0%
Miss. label tol.	
	AP 5.4 AP 5.6
xx	Missing label tolerance The maximum search path for gaps which cannot be found can be varied. In cases of difficult gap detection (i. e. minimum variation in the light transparency, gap to label), shortening the search path is to be recommended. Label loss resulting from gaps not being detected can be reduced in this way. Printing does not take place during the search process. Setting range: 0 to 50; Unit interval: 1 <ul style="list-style-type: none"> • Example 0 (Zero label length): A gap must be found after a printed label otherwise an error message is given. This setting is for detecting every missing label. • Example 5 (Five label lengths): A gap must be found after a maximum of 5 label lengths otherwise an error message is given.
Gap detect mode	
	AP 5.4 AP 5.6
Manual	After one of the following events, the printer must always search for the punch, that is initialize the label material: <ul style="list-style-type: none"> • After switching the printer on • After changing the label material The operator has to initialize the material always manually by pressing the feed key several times.
Autom. Forward	(Default for printers) The material initialization is always done automatically, if necessary. There is no backward movement of the material during the initialization.

Periph. device

AP 5.4 AP 5.6

After installation, options must be selected under "Peripheral device" in order to be assured of the corresponding sensor queries and printer reactions.



⚠ CAUTION! - Selecting an incorrect option can lead to malfunctions or damage!

None	No peripheral device is installed.
Cutter	Sets the printer firmware to the cutter option. Selection permits access to the cut parameters.
Rewinder	Sets the printer firmware to the rewinder option. Selection permits access to the rewinder setting parameters.
Tear-off edge	Sets the printer firmware to the tear-off edge option. The punch is fed forward to the tear-off edge.
Dispenser	Setting for AP 5.4/5.6 dispenser version.
Intern Rewinder	AP 5.4/5.6 dispenser only: Setting for printer operation in „internal rewinder“ mode, that is operation with a deflector and without dispensing edge.
Tear-off + sensor	AP 5.4 only: Setting for using the dispensing edge as tear-off edge. The punch is fed forward to the dispensing edge.
Disp. with LTSI	Setting for operation of a LTSI applicator, see Technical Manual LTSI

Singlestartquant

AP 5.4 AP 5.6

Single start quantity

xx Setting range: 1 to 10; Unit interval: 1

External signal

AP 5.4 AP 5.6

The parameter determines, if and how an incoming signal at the - optional - single start connector will be interpreted.

Disabled	Signal interpretation disabled.
Singlestart	The signal triggers the printing of a single label. This setting may be used e.g. for printing single labels by means of a foot switch.
Stacker full	The signal triggers the display of a status report and stops the printer. This setting may be used when using a stacker (= stacker full signal).

- Detailed information about using start signals can be found in the user manual, topic section „Advanced Applications“, chapter „Printing with start signal“, [Settings in the parameter menu](#)

Start print mode

AP 5.4 AP 5.6

▣▣▣▣ Only appears, if no I/O board is installed. Otherwise, the parameter appears in the I/O BOARD menu.

See parameter [Start print mode](#)  on page 102.

Print contrast

AP 5.4 AP 5.6

xxx%

Setting range: 1 to 120%; Unit interval: 1; Default setting: 60



CAUTION!

The parameter [Print contrast](#) affects directly the life durance of the printhead. It counts: „The higher the setting of [Print contrast](#) is, the lower is the life durance of the printhead“. This counts even more for settings above 100%. Therefore mind:

- ➔ Always choose the lowest possible setting necessary to produce an acceptable print result.

Ram disk size

AP 5.4 AP 5.6

A part of the printer memory can be identified as a RAM disk. The RAM disk can be used in the same way as the Compact Flash Card, e.g. for storage of logos or fonts.

With the parameter [Ram disk size](#), the customer can set the size of the RAM disk to his needs. Be aware, that RAM disk memory is not available for print picture buildup. Use of much RAM disk memory reduces the picture buildup rate of the printer.

▣▣▣▣ Switching the printer off extinguishes the memory content! Fonts, logos etc., which were loaded on the RAM disk, must be loaded again after switching the printer off.

xxxx KBytes

Setting range: 2048 KBytes to the maximum size, which depends on the memory configuration and allocation of the printer; Unit interval: 128 KBytes; Default setting: 512 KBytes

Font downl. area

AP 5.4 AP 5.6

If speedo-fonts are supposed to be used, they have first to be copied to a reserved RAM disk area. Use parameter „Font downl. area“ to reserve the RAM disk area in the required size.

The size of the required RAM disk area depends on the size of the font files to be loaded.

☛ Mind to reserve a big enough RAM disk area!

There are two ways to copy the font files to the RAM disk:

- Copy from SD-card:
The font files must be placed in a folder named \fonts on the SD-card during system startup. The files must be named fontxxx.spd (xxx = No. from 200 up to 999).
- For details refer to the „Plugin-card manual“, topic section „Application“, paragraph [CF/SD-cards](#).
- Copy via Easy Plug command #DF (download file).
- More information: manual „Easy Plug“, subject section [Description of Commands](#).

xxx KBytes

Setting range: 128 KBytes to the maximum size, which depends on the memory configuration and allocation of the printer; Unit interval: 128 KBytes; Default setting: 256 KBytes

☛ Switching the printer off extinguishes the memory content! Fonts, logos etc., which were loaded on the RAM disk, must be loaded again after switching the printer off.

Free store size

AP 5.4 AP 5.6

By setting this parameter, a part of the memory is reserved, which the printer firmware can use if necessary (dynamic memory allocation). If this memory area is dimensioned too small, the printer firmware can not work and the error message „8856 Free store size“ shows up.

▣➔ The more memory is allocated using this parameter, the less memory is available for print jobs.

xxx KBytes

Setting range: 2048 KBytes to the maximum size, which depends on the memory configuration and allocation of the printer; Unit interval: 128 KBytes; Default setting: 2048 KBytes.

➔ A good advice is to increase the set value step by step, starting with the minimum of 2048 KBytes, until the status message 8856 ("Free store size", what means the memory area is low) does no longer appear during data conversion.

- Use with the Easy Plug command #YG, see manual [Easy Plug](#) □.
- See parameter [Memory status](#) □ on page 18.

Print info mode

AP 5.4 AP 5.6

Structure option for info printouts.

Par. values right

Setting for 100 mm material width. The parameter values are printed on the right side of the parameter names:

Parameter name: Value

Par. values left

Setting for 100 mm material width. The parameter values are printed on the left side of the parameter names:

Value: Parameter name

Compact right

Setting for 50 mm material width. The parameter values are printed on the right side of the parameter names:

Parameter name: Value

Compact left

Setting for 50 mm material width. The parameter values are printed on the left side of the parameter names:

Value: Parameter name

Reprint function

AP 5.4 AP 5.6

Disabled

(Default setting) Reprinting is not possible.

Enabled

The last printed label can be reprinted by pressing the feed button in online mode, if the printer is not printing at that moment.

Language

AP 5.4 AP 5.6

Setting the display language.

Turkish
 Polish
 Italian
 Danish
 Dutch
 Spanish
 French
 English
 German

Keyboard

AP 5.4 AP 5.6

Setting the keyboard layout country version for standalone operation.

Polish
 Swedish
 Finish
 Danish
 Spanish
 French
 English
 German

Access authoriz.

AP 5.4 AP 5.6

Access authorization

Limits the access either to all printer functions (Power-up code) or only to the parameter menu (user or supervisor mode). Changed settings become active after the next switch-on.

Key codes

Regardless when the code is prompted, can three different key codes be typed in tab. 9.

Enter code

Entering a key code: Type the corresponding buttons of the control panel in succession. A valid key code switches the printer into the appropriate mode.

Mode	Key code	Impact
User	2x Cut Feed, Online	Access only to the submenus PRINT INFO and SERVICE DATA
Supervisor	2x Online, Feed, Cut, 2x Online	Access to all parameters except production parameters
Production	Cut, Online, Feed, Cut, 3x Online	Access to all parameters

[5] Permissible key codes.



⚠ CAUTION! - The key code "production" allows the access to parameters, which are used during production to adjust the printer. Input errors to those parameters can make the printer inoperable or can damage it. For this reason, the production code may only be applied by *trained service technicians!*

⚠ Especially service technicians may use the direct access into production mode, even if the parameter *Access authoriz.* is set to *Deactivated*, what means that no password will be queried at all. To do so, proceed as follows:

1. Switch printer off.
2. Switch printer on, simultaneously press the Feed+Prog-key until the printer type is displayed.

After the printer was powered up, the key code will be queried:

3. Enter the production code.

Possible Settings

Deactivated	Password interrogation switched off (default)
Power-up code	Activates the password interrogation directly after switching the printer on. After the input of a valid key code, the printer switches into offline mode. Depending on the entered key code, the printer starts in user, supervisor or production mode.
User	Activates the password interrogation when accessing the parameter menu. <ul style="list-style-type: none"> • The printer is in the offline mode after switch-on • Change to the online mode is possible without restriction • To reach the parameters-menu, enter a valid key code • Valid key codes: all
Supervisor	As setting „User“, with different valid key codes: <ul style="list-style-type: none"> • Valid key codes: Supervisor, Production
User auto start	Printer starts without password interrogation. Only the menus PRINT INFO and SERVICE DATA are accessible.

Realtime clock

AP 5.4 AP 5.6

The realtime clock provides actual date and time. Those data can be processed using the Easy-Plug #YC, #YS or #DM commands.

Realtime Clock	dd=Day, mm=Month, yyyy=Year, hh=Hour,
dd.mm.yyyy hh:mm	mm=Minute (Example: 19.02.2001 14:41)

Setting date / time:

1. Press the CUT button repeatedly, until the digit blinks which you want to alter.
2. Set the intended value to the digit by pressing the FEED button (repeatedly).
3. Repeat steps 1 and 2 until date / time is set correctly.
4. Press the ONLINE button.
 - ▣▶ Press the ESC button to leave the parameter without altering the setting.

I/O BOARD

☛ This menu appears only if the optional I/O Board is mounted.

Start print mode

AP 5.4 AP 5.6

☛ Only with an I/O board mounted.

Selecting a print mode. Depending on the selected mode, the input signal START_PRINT will be interpreted differently by the I/O Board signal interface. The parameter is also used for the device connected to the foot switch jack.

- Make sure to select SYSTEM PARAMETER > External Signal = Single Start.
- See parameter [External signal](#) on page 85.
- Note: The parameter Start Print Mode replaces the parameter Signal Edge in the SYSTEM PARAMETER menu.
- Preconditions: Print job is available (DATA READY), printer is in “Online” mode, no error messages.

Pulse falling	(Default setting) The printing of a label is triggered by a high-to-low change of the signal at the input START PRINT. The printing occurs only after the set delay time.
Pulse rising	The printing of a label is triggered by a low-high change of the signal at the input START PRINT. The printing occurs only after the set delay time.
Pulse fall/ris	The printing of a label is triggered by a low-high-change as well as by a high-low change of the signal at the input START PRINT. The printing occurs only after the set delay time.
Level low active	Labels will be printed as long as the signal at input START PRINT is held low.
Level high active	Labels will be printed as long as the signal at input START PRINT is held high.

Reprint Signal

AP 5.4 AP 5.6

☛ Only with an I/O board mounted.

Disabled	The input signal is disabled
Enabled	The last printed label will be reprinted on the falling edge of the REPRINT signal.

Preconditions:

- The label to be reprinted, should be printed and dispensed.
- Printer is in online mode.

If a REPRINT is triggered while the printer is in “I/O-Board Pause” mode, the reprint will proceed as soon as the printer is switched back in online mode. Precondition: in level mode START PRINT must be inactive.

Feed input

AP 5.4 AP 5.6

☛ Only with an I/O board mounted.

Concerns the input signal FEED at the signal interface.

Enabled

(Default setting) Feeding of one label on the falling signal edge. The display shows „I/O board feed“ during feeding. Requirements are:

- Offline mode, „stopped mode“ or „pause mode“
- Online mode and no print job loaded.

Disabled

Signals at the FEED input are ignored.

Pause input

AP 5.4 AP 5.6

☛ Only with an I/O board mounted.

Concerns the input signal PAUSE at the signal interface.

Disabled

Signals at the PAUSE input are ignored.

Pause

A high-to-low transition switches the printer into the „I/O-Board Pause“ mode. The next high-low-transition switches the printer back into the online mode. If parameter *I/O-Board > Start print mode* is set to „Level high active“ or „Level low active“, any activating of the PAUSE signal stops the printing after the current label.

Features:

- Printer display shows „I/O-Board pause“
- ERROR is active (only if *I/O Board > Error output* is set to „Printer err+Offl“)
- If a print job is available: DATA READY becomes inactive (if *I/O Board > Status output* is set to „Print job ready“)
- START PRINT signals are suppressed
- REPRINT requests are processed after switching into online mode.

A "low" signal for 20 ms switches the printer into the pause mode. The pause mode is the same as the "Online stopped" mode and can be switched to the "Online" mode by pressing the feed button.

Error output

AP 5.4 AP 5.6

☛ Only with an I/O board mounted.

This parameter defines different events, which activate the output signal ERROR.

Printer error

ERROR will be activated in all of the following cases:

- Material end
- Ribbon end (only if *SYSTEM PARAMETER > Foil mode* = „Thermo transfer“)
- No punch recognized (only if *PRINT PARAMETERS > Material type* = „punched“)

- Printhead pressure lever was opened during the printing of a label.
 - Start print error
 - Other errors, which keep the printer from printing
- ▣▣▣▣ During the initialization (powering up) of the printer, the ERROR-signal is instable!

Printererr + Offl

In addition to the above mentioned cases activate the following events the ERROR-signal:

- The printer is in offline mode
- The printhead pressure lever is open
- „I/O board pause“ mode
- Stopped mode (the printing was stopped)

Error Polarity

AP 5.4 AP 5.6

▣▣▣▣ Only with an I/O board mounted.

Switches the polarity of the ERROR signal.

Level high activ

The output is high when it is active, otherwise low.

Level low active

The output is low when it is active, otherwise high. (Default)

Status output

AP 5.4 AP 5.6

▣▣▣▣ Only with an I/O board mounted.

This parameter defines different events, which activate the output signal MACHINE STATUS.

Low ribbon warn

The signal is activated, if the ribbon roll diameter is less than the limit.

Print job ready

○ See parameter [Foil end warning](#) □ on page 68.

The signal is activated, if the printer has finished image processing and is ready to start printing.

The signal is *not activated*, if:

- the print job is done,
- the print job was stopped,
- the printer was switched to offline mode,
- the printer is in pause mode.

Status polarity

AP 5.4 AP 5.6

▣▣▣▣ Only with an I/O board mounted.

Switches the polarity of the MACHINE STATUS signal.

Level high active

The output is high when it is active, otherwise low.

Level low active

The output is low when it is active, otherwise high. (Default)

End print mode

AP 5.4 AP 5.6

▣▣▣▣ Only with an I/O board mounted.

▣▣▣▣ Not available in batch mode.

Concerns the output signal PRINT_END at the I/O board signal interface. Determines the signal response after printing of a label.

Mode0 inactive

No print end signal.

Mode1 high level

Low, if the print module is just printing a label, otherwise high. The output is also deactivated (= low) as long as labels are fed with "Feed Button" or "Feed Signal".

Mode2 low level

High, if the print module is just printing a label, otherwise low. The output is also deactivated (= high) as long as labels are fed with "Feed Button" or "Feed Signal".

Mode3 low pulse

(Default setting) Low for 20 ms after printing and dispensing a label. The output is also activated (= low) after a label is fed with "Feed Button" or "Feed Signal".

Mode4 high pulse

High for 20 ms after printing and dispensing a label. The output is also activated (= high) after a label is fed with "Feed Button" or "Feed Signal".

DISPENSER PARA

☛ This menu appears only in AP 5.4/5.6, and only, if **SYSTEM PARAMETER > Periph. device** is set to „Dispenser“.

Dispense Mode

AP 5.4 AP 5.6

☛ Only if **SYSTEM PARAMETER > Periph. device** = „Dispenser“.

Governs the run of the print-dispense procedure.

☛ The ribbon autoeconomy function can only be used in "Real 1:1 Mode"!

Normal 1:1 Mode


- The printer cannot print on the whole label surface. A stripe at the label beginning stays unprinted.
- The label is being dispensed while printing.
- The output volume is at its maximum level.

☛ The width of the unprintable stripe is calculated as follows:

Distance print line to dispensing edge (25 mm) + Dispense position

○ Also refer to parameter **PRINT PARAMETERS > Dispense position**.

○ A graphic can be found under **PRINT PARAMETERS > Cut mode > Normal 1:1 mode**.



[15] The size of the not imprintable area in Normal 1:1 depends of the setting of parameter "SYSTEM PARAMETERS > Dispense Position".

Batch Mode

- The printer can print the whole label surface.
- Dispensing of the label takes place during printing. Printing of the next label is interrupted until the label is completely dispensed.
- The output volume is at its maximum level.

▣▣▣ The *Batch mode* is optimised for printing and dispensing at high speeds. Due to this, it is not possible to use all features available in modes *Normal 1:1* or *Real 1:1*. Also consider, that printing data must be available on time and in sufficient quantity.

▣▣▣ The following Job/Parameter-combinations must not be used:

- Jobs with counter fields
- Jobs with variable fields
- SYSTEM PARAMETER > Dispensing mode must be set to "fast".
- The USI reprint function is not supported. DP INTERFACE > Reprint signal must be set to "deactivated".
- Foil save

○ A graphic can be found under PRINT PARAMETERS > Cut mode > Batch mode.

Real 1:1 Mode

(Default setting)

- The printer can print the whole label surface.
- After dispensing a label, the beginning of the next label is drawn back under the print head.
- The output volume is lower than in *Batch Mode* or *Normal 1:1 Mode*.

○ A graphic can be found under PRINT PARAMETERS > Cut mode > Real 1:1 mode.


Dispenseposition

AP 5.4 AP 5.6

▣▣▣ Only if SYSTEM PARAMETER > Periph. device = „Dispenser“.

Dispense position

Adjusts the dispense position in or against the feed direction. Depending on the set dispense position, the dispensed label sticks to the backing paper with a more or less wide strip (Fig. 11). The required width of this strip depends on the further processing.



[16] Dispense position (= stop position) of the dispensed label.

x.x mm

Setting range: -30.0 to +20.0 mm; Unit interval: 0.1 mm; Default setting: -6.0 mm

Display mode

 AP 5.4 AP 5.6

☛ Only if SYSTEM PARAMETER > Periph. device = „Dispenser“.

Makes the *already* printed labels appear in the display instead of the *not yet* printed ones.

Job rest quant.

Display of the *not yet* printed labels of a print job.

☛ The counter keeps it's value even after switching the printer off.

Dispense counter

Counting of start pulses. Activate the counter by selecting "Dispense counter". The counted number appears on the display after the parameter *Dispense counter* (see below) has been selected.

Dispense counter

 AP 5.4 AP 5.6

☛ Only if SYSTEM PARAMETER > Periph. device = „Dispenser“.

Dispense counter xxxxxx = Number of dispensed labels.
 xxxxxx

☛ The displayed value can be varied by pressing the Cut or Feed button.

There are two ways of setting back the counter:

- Set the parameter *Display mode* (see above) to "Job rest quant." , then back to "Dispense counter" and confirm by pressing the Online button.
- Reduce the displayed number by pressing the Cut button.

Application mode

 AP 5.4 AP 5.6

☛ Only if SYSTEM PARAMETER > Periph. device = „Dispenser“.

Save Mode

A start signal is required to draw the next label back under the print head. This setting bears advantages for label material with a strong adhesive, which would not stay attached to the applicator when the backing paper is fed backwards.

Immediate Mode

After the just printed label has reached the dispense position, the following label is drawn back under the print head. The dispensed label stays attached to the applicator (default setting).

Synchronous mode

Not yet implemented (Fw. 3.33).

Start source

 AP 5.4 AP 5.6

☛ Only if SYSTEM PARAMETER > Periph. device = „Dispenser“.

Choose a signal source for the start signal:

Foot switch

Optional foot switch is used to generate the start signal.

Light barrier

(Default setting) Photoelectric switch at the dispensing edge which detects the taking off of the dispensed label.

☛ The setting "Light barrier" is unsuitable for product sensors! Product sensors must be connected to the I/O board!

Calibration mode

 AP 5.4 AP 5.6

☛ Only if SYSTEM PARAMETER > Periph. device = „Dispenser“.

☛ Is only effective with label material shorter than 40 mm!



If label material shorter than 40 mm is used, the printer automatically initializes before printing. This measuring of the label material improves the impression accuracy. The initialization occurs in the following cases:

- After switching the printer on
- After opening and closing the printhead pressure lever.

☛ *Advice:* Start the material initialization manually before printing. This is done by pressing the feed button in offline mode.

Selecting a material initialization procedure:

Automatic

(Default) Material initialization is done automatically. Therefore, the label material is fed forwards and backwards several times.

☛ There is a risk of the dispensing edge roller getting jammed by labels sticking to it, which were dispensed by the forward/backward movement. If this happens, use the setting „Manual“ instead.

Manual

The label material is fed two or three label lengths forwards. If this is done, dispense two labels by pressing the feed button - only afterwards, the initialization is complete.

Start offset

 AP 5.4 AP 5.6

Function for operation with product sensor.

Use this parameter to set the distance between product sensor (light barrier) and dispensing edge. The recommended delay time is calculated of the "Start delay" distance and the conveyor speed (= print speed in cases of direct application).

xxx.x mm

Setting range: 0.0 bis 999.9 mm; Unit interval: 0.1 mm;
Default setting: 0 mm

Start error stop

 AP 5.4 AP 5.6

Function for operation with product sensor.

Determines the reaction of the machine on a product start error. A product start error occurs in the following cases:

- If a further start signal arrives, before the current label is completely printed.
- *With mounted I/O board only:* If a reprint is requested, before the first label after powering on is printed.
- If a start signal arrives and no printjob is loaded.

If a product start error occurs, the machine stops and displays the appropriate status message. If an I/O board is installed, the following output signals are activated (set low):

- ERROR\
- MACHINE STATUS\

On Start errors are worked up (the machine stops!) (default setting)

Off Start errors are being ignored.

Product length

 AP 5.4 AP 5.6

Function for operation with product sensor.

If this function is activated, the printer ignores all start signals until the product has passed the dispensing edge.

0.0 mm Setting range: [0.0...1999.9] mm; Default setting.: 0,0

Current mode

 AP 5.4 AP 5.6

☛ Only in production mode.

☛ Only if SYSTEM PARAMETER > Periph. device = „Dispenser“.

The setting of this parameter influences the impact of the parameters *Min rew. current* and *Max rew. current*.

Table values Display of the automatically calculated motor current chart PWM values (in %). On the base of this setting, the printer calculates the motor current values for *Min rew. current* and *Max rew. current* out of print speed and material width. The calculated values appear as default 100%.

Absolute values With this setting, the printer doesn't calculate and doesn't adapt to material width and print speed. The set values for *Min rew. current* and *Max rew. current* are given to the output stage without a modification. The values appear as absolute values.

☛ The setting "Absolute values" should only be applied by qualified personell!

Min. rew. current

 AP 5.4 AP 5.6

☛ Only in production mode.

☛ Only if SYSTEM PARAMETER > Periph. device = „Dispenser“.

Minimal rewinder current

This parameter influences the rewinder current with 25 mm rewinder diameter (min. rewinder diameter).

Problem	Solution
The label web runs too loose around the dispensing edge during printer operation. The label roll is wound up too loose.	Increase the setting
The label web runs too tight around the dispensing edge during printer operation. The label roll is wound up too tight.	Decrease the setting

[6] Cases, in which the setting of the minimal rewinder current has to be corrected.

XXX%

Setting range: 50-200%; Default setting: 100%

Precondition for the setting in percent:

Parameter DISPENSER PARA > Current mode = Table values (see above).

XXX

Setting range: 0-750; Default setting: 100;

Precondition for the setting in absolute values:

Parameter DISPENSER PARA > Current mode = Absolute values (see above).

Max. rew. current

 AP 5.4 AP 5.6

☛ Only in production mode.

☛ Only if SYSTEM PARAMETER > Periph. device = „Dispenser“.

Maximum rewinder current

This parameter influences the rewinder current with 120 mm rewinder diameter (max. rewinder diameter).

XXX%

Setting range: 50-200%; Default setting: 100%

Precondition for the setting in percent:

Parameter DISPENSER PARA > Current mode = Table values (see above).

XXX

Setting range: 0-750; Default setting: 250;

Precondition for the setting in absolute values:

Parameter DISPENSER PARA > Current mode = Absolute values (see above).



The two parameter values *Min. rew. current* and *Max. rew. current* are used by the motor output stage to calculate all other current values for diameters lying in between.

Problem	Solution
The label web runs too loose around the dispensing edge during printer operation. The label roll is wound up too loose.	Increase the setting
The label web runs too tight around the dispensing edge during printer operation. The label roll is wound up too tight.	Decrease the setting

[7] Cases, in which the setting of the minimal rewinder current has to be corrected.

Start rew. current

AP 5.4 AP 5.6

☛ Only in production mode.

☛ Only if SYSTEM PARAMETER > Periph. device = „Dispenser“.

Start rewinder current

Setting of the start-up current superelevation in % or the normal motor current.

XXX%

Setting range: 0-100%; Default setting: 0%

Start cur. len.

AP 5.4 AP 5.6

☛ Only in production mode.

☛ Only if SYSTEM PARAMETER > Periph. device = „Dispenser“.

Start current length

Duration of the start-up current superelevation. To be set is the feed length, during which the increased current is supposed to flow.

XX mm

Setting range: 10-40 mm; Default setting: 30 mm

Pullback current

AP 5.4 AP 5.6

☛ Only in production mode.

☛ Only if SYSTEM PARAMETER > Periph. device = „Dispenser“.



After a label was dispensed, the label web has to be pulled back under the printhead. To reach this, the rewinder is rotated slightly in the opposite direction. The braking torque of the rewinder against this rotation may not be too strong, otherwise this could decrease the impression accuracy. Because of the brake torque depending on the diameter of the wound up label web, it has to be corrected at the beginning (min. diameter) and at the end (max. diameter) of the winding-up process. This is done by the *Pullback current* (supports the backwards rotation in case of low diameter) and the *Brake current* (amplifies the brake torque in case of high diameter). Additionally can be set:

The diameter up to which the Pullback current is throttled down to zero (parameter *Back diameter*), and the diameter, from which on the brake current starts (parameter *Brake diameter*).

The parameter *Pullback current* sets the support current for the rewinder at the minimum diameter of 25 mm. When the diameter of the rewound label web reaches the set value (*Back diameter*), the support current will be throttled down to a minimum.

Back diameter

AP 5.4 AP 5.6

Pullback current diameter

- See parameter [Pullback current](#) on page 118.
 - ▣ If the label web is *loose*, while it is fed back under the printhead, *decrease* this value in small steps. If the material is *tightened* too much, *increase* the value in small steps.

XX mm

Setting range: 0-120 mm; Default setting: 50 mm

Brake current

AP 5.4 AP 5.6

- ▣ Only in production mode.
- ▣ Only if SYSTEM PARAMETER > Periph. device = „Dispenser“.

Sets the brake current

XXX

- See parameter [Pullback current](#) on page 118.
 - Setting range: 0-100; Default setting: 0

Brake diameter

AP 5.4 AP 5.6

- ▣ Only in production mode.
- ▣ Only if SYSTEM PARAMETER > Periph. device = „Dispenser“.

Sets the break diameter.

XXX

- See parameter [Pullback current](#) on page 118.
 - Setting range: 0-120; Default setting: 120

REWINDER PARA

☛ This menu appears only in AP 5.4/5.6, and only, if **SYSTEM PARAMETER > Periph. device** is set to „Intern Rewinder“.

Rewind direction

AP 5.4 AP 5.6

☛ Only if **SYSTEM PARAMETER > Periph. device** = „Intern Rewinder“.

(Internal) Rewinder rotation direction

Printing inside

The label face shows *inwards*, when the label stock is wound up.

Printing outside

The label face shows *outwards*, when the label stock is wound up.

Current mode

AP 5.4 AP 5.6

☛ Only in production mode.

☛ Only if **SYSTEM PARAMETER > Periph. device** = „Intern Rewinder“.

○ See parameter [Current mode](#)  on page 116.

Min. rew. current

AP 5.4 AP 5.6

☛ Only in production mode.

☛ Only if **SYSTEM PARAMETER > Periph. device** = „Intern Rewinder“.

○ See parameter [Min. rew. current](#)  on page 117.

Max rew. current

AP 5.4 AP 5.6

☛ Only in production mode.

☛ Only if **SYSTEM PARAMETER > Periph. device** = „Intern Rewinder“.

○ See parameter [Max. rew. current](#)  on page 117.

Start rew. curr.

AP 5.4 AP 5.6

☛ Only in production mode.

☛ Only if **SYSTEM PARAMETER > Periph. device** = „Intern Rewinder“.

○ See parameter [Start rew. current](#)  on page 118.

Start cur. len.

 AP 5.4 AP 5.6

- ▣ Only in production mode.
- ▣ Only if SYSTEM PARAMETER > Periph. device = „Intern Rewinder“.
- See parameter [Start cur. len.](#)  on page 118.

Pullback current

 AP 5.4 AP 5.6

- ▣ Only in production mode.
- ▣ Only if SYSTEM PARAMETER > Periph. device = „Intern Rewinder“.
- See parameter [Pullback current](#)  on page 118.

Back diameter

 AP 5.4 AP 5.6

- ▣ Only in production mode.
- ▣ Only if SYSTEM PARAMETER > Periph. device = „Intern Rewinder“.
- See parameter [Back diameter](#)  on page 119.

Brake current

 AP 5.4 AP 5.6

- ▣ Only in production mode.
- ▣ Only if SYSTEM PARAMETER > Periph. device = „Intern Rewinder“.
- See parameter [Brake current](#)  on page 119.

Break diameter

 AP 5.4 AP 5.6

- ▣ Only in production mode.
- ▣ Only if SYSTEM PARAMETER > Periph. device = „Intern Rewinder“.
- See parameter [Brake diameter](#)  on page 119.

MLI PARAMETERS

Avery Dennison's MONARCH LANGUAGE INTERPRETER™ (MLI™) helps you use an Avery Dennison 4.4, 5.4, 64xx, ALX92X, DPM/PEM, or AP7.t printer which was set up for use with ZIH Corp.'s ZPL II®¹⁾. If you have any questions about using an Avery Dennison printer with these data streams, please contact Service.

This section lists the ZPL II® commands that the Avery Dennison printer's MONARCH LANGUAGE INTERPRETER™ can interpret with any special notes, if applicable.

▣▣▣ This menu appears only with `SYSTEM PARAMETERS > Print Interpret` set to „MLI“ or „EasyPlug / MLI“.

▣▣▣ MLI is not supported in Standalone Mode.

▣▣▣ Recommended settings:

`SYSTEM PARAMETER > RAM disk size` at least 2048 Kbytes

`SYSTEM PARAMETER > Free store size` at least 2048 Kbytes

Darkness

AP 5.4 AP 5.6

Print contrast for MLI printjobs. This setting is modified by printjobs which contain print contrast information. The print contrast set by `SYSTEM PARAMETERS > Print contrast` is not influenced by this setting.

xx

Setting range: 0-30; Step width: 1; Default setting: the Easy-Plug setting is overtaken.

Control Prefix

AP 5.4 AP 5.6

Indicates the start of a MLI control instruction.

xxH

Default: xx = 7E (0x7E = „Tilde“)

Format Prefix

AP 5.4 AP 5.6

Indicates the start of a MLI format instruction.

xxH

Default: xx = 5E (0x5E = „Caret“)

-
- 1) ZPL II is a registered trademark of ZIH Corp. ZIH Corp. and Avery Dennison (including Paxar Corporation and its subsidiaries) are not related in any way, and ZIH Corp. has not licensed or otherwise sponsored MONARCH® printers or Avery Dennison's MONARCH LANGUAGE INTERPRETER™. MONARCH®, MONARCH LANGUAGE INTERPRETER, MLI are trademarks of Paxar Americas, Inc. Avery Dennison is a registered trademark of Avery Dennison Corporation.

Delimiter Char

AP 5.4 AP 5.6

xxH Used as a parameter place marker in MLI format instructions.
 Default: xx = 2C (0x2C = „Comma“)

Label Top

AP 5.4 AP 5.6

xxx Dots Label top offset (y-offet) in dots. Equals the parameter [PRINT PARAMETERS > Y-Printadjust](#), which will be ignored, when MLI printjobs are printed.
 Setting range: -240 - +240; Default: 0; Step width: 1

Left Position

AP 5.4 AP 5.6

xxx Dots Left position offset (x-offset) in dots. Equals the parameter [PRINT PARAMETERS > X-Printadjust](#), which will be ignored, when MLI printjobs are printed.
 Setting range: -9999 - +9999; Default: 0; Step width: 1

Manual Calibrate

AP 5.4 AP 5.6

YES For endless material, the label length information is sent in the printjob. For punched material, the label length has to be detected by activating this function.
 Label length calculation for punched material.

- ▣▶ Activate this function, if label material has changed.
- ▣▶ Calibration should be done after changing material, when there are no printjobs loaded in the printer.
- ▣▶ Shortcut (in offline mode): press the feed + prog buttons simultaneously to activate the calibration.

Resolution

AP 5.4 AP 5.6

xxx DPI Print resolution in dpi. A 200 dpi graphic printjob can be printed with a 300 dpi printhead.
 Setting range: 200/300 dpi; Default: 300 dpi;

Error Indication

 AP 5.4 AP 5.6

Selects the way, in which the printer responds in the event of error occurring during printing.

Low
High
Off

Error Level	Setting		
	LOW	HIGH	OFF
0	Ignore	Ignore	Ignore
1	Ignore	Flash on the display	Ignore
2	Prompt user for action	Prompt user for action	Ignore

[8] Error handling settings.

Error Checking

 AP 5.4 AP 5.6

Enables or disables error checking, when the printer is handling print fields.

YES
NO

Error checking is enabled. (Default)

Error checking is disabled.

Image Save Path

 AP 5.4 AP 5.6

Selects the memory to be used by the ^IS and ^IL commands.

☛ Interpreter version: 1.10 or higher.

CF Card
Internal RAM

Optional CompactFlash card

The printer's internal RAM. (Default)

Command ^PR

 AP 5.4 AP 5.6

Disable
Enable

The **p**rint rate sent in the MLI printjob is ignored.

The print rate is not ignored.

Command ^MT

 AP 5.4 AP 5.6

Disable
Enable


The **m**aterial type sent in the MLI printjob is ignored (thermo-transfer or thermo-direct).

The material type is not ignored.

Label Invert

AP 5.4 AP 5.6

Rotates the printout by 180°. Equals the parameter `PRINT PARAMETERS > Print direction`, which will be ignored, when MLI printjobs are printed.



[17] Orientation of the printout: Setting „Disable“ (A) or „Enable“ (B).

Disable

The label is printed with „normal“ orientation [20A].

Enable

The label printout is rotated by 180° [20B].

Command ^JM

AP 5.4 AP 5.6

Interpreter version: 1.32 or higher

The ^JM command changes the printer resolution:

- ^JMA sets the resolution to the default value = printhead resolution.
- ^JMB sets the resolution to 200 dpi, if the actual resolution is 300 dpi. If the actual resolution is 200 dpi, this command is ignored.

Disable

The resolution setting sent in the MLI printjob is ignored.

Enable

The resolution setting is not ignored.

Command ^MD/~SD

AP 5.4 AP 5.6

The MLI commands ^MD and ~SD (set printhead darkness value) are processed optionally.

Enable

^MD- and ~SD are processed.

Disable

^MD- and ~SD are ignored.

SPECIAL FUNCTION

Printer type

AP 5.4 AP 5.6

▣▶ Only in production mode.

Selection of the machine type. Must be set after the CPU board was replaced or after new firmware was loaded.



▣▶ CAUTION! - Selecting an inappropriate machine type can lead to malfunctions or damage!

AP5

AP 5.6

AP7

AP 7.t

Default Values

AP 5.4 AP 5.6

▣▶ Parameter appears only in production mode.

User defined

The presently selected settings of all parameters will be taken as default values. That is you will get those settings back even after a firmware update. All you have to do is to call the parameter "Factory settings".

Standard

Calling the parameter "Factory settings" will set all parameters to the factory preset values.

Command sequence

AP 5.4 AP 5.6

▣▶ Parameter appears only in production mode.

~

„~“ is used as start sign for Easy-Plug command sequences.

#

(Default setting) „#“ is used as start sign for Easy-Plug command sequences.

Delete job

AP 5.4 AP 5.6

Press the Online-key to cancel the active print job.

Delete Job
Clearing . . .

Delete spooler

AP 5.4 AP 5.6

Press the Online-key to delete all print jobs contained in the spooler.

Delete Spooler
Clearing . . .

Factory settings

AP 5.4 AP 5.6

All parameters are preset ex works to values specific to each device type. These factory settings can be restored at any time.

All parameters are then overwritten by the factory settings.

The currently valid settings can be checked using `PRINT INFO > printer status`.



⚠ CAUTION! - All data present in the spooler, including data belonging to an interrupted print job, is deleted!

Store Parameters

AP 5.4 AP 5.6

Parameter settings are saved in a text file on SD-card (directory FORMATS\). Considered are also parameters which belong to options, which are not activated.

Without adj. par

(Default) Parameters, which contain device specific settings, are *not* saved. (Default file name: SETUP.FOR).

Application example: Transfer of printer settings to another printer (device specific settings as printhead resistance or sensor settings should not be overwritten).

With adjust para

Parameters, which contain device specific settings, are *also* saved. The relevant parameter names are marked with a * in the text file.

(Default file name: SETUPALL.FOR).

Application example: Service

- For more information about saving and reading parameter settings read topic section „Advanced Applications“, chapter „Saving and Transferring parameter settings“.

Store Diagnosis

AP 5.4 AP 5.6

Stores the diagnostic data on SD-card. The default file name composes as follows:

„Diagnose AP 5.4 203 Dpi A429403110613.log“

- *AP 5.4 203 Dpi*: printer type and printhead resolution
 - *A429403110613*: serial number of the CPU board; equals the value displayed under `SERVICE DATA > CPU board data > Serial number`
- For details read the service manual, topic section „Fault Location“, chapter „Reading out diagnostic data“.

Data blocks del.

Delete data blocks

AP 5.4 AP 5.6

☛ Only appears, if at least one data block is in the flash memory.

Bxx

(Default setting) After calling the parameter, data block number 01 is displayed:

```
Data blocks del.
B01 diagnose inf
```

„B01“: block number 01

„diagnose inf“: name of the data block, is contained in the data block header.

If the flash memory contains more than one data block:

→ Press the cut button several times, until the wanted data block appears.

Deleting a data block:

→ Press the online button.

```
Data blocks del.
Delete? --> no
```

→ Press the feed button to change to „yes“.

→ Press the online button to delete the block.

All

All data blocks contained in the flash memory are deleted.

EasyPI. file log

Easy-Plug file log

 AP 5.4 AP 5.6

☛ Only visible, if a SD-card is inserted.

☛ Activating this parameter may slow down the label rate. Therefore disable the function after error analysis.

☛ Activating this parameter may cause error messages, which may be difficult to understand. Therefore disable the function after error analysis. If an error occurs, disable the function and restart the printer.

Disabled

The file log function is switched off.

All data

All received data, including immediate commands, are written into the log file.

Interpreter data

All data is written into the log file, which the Easy-Plug interpreter reads out of the reception spooler. Immediate commands are *not* included.

Log files delete

 AP 5.4 AP 5.6

☛ Only visible, if a SD-card is inserted.

No

(Default setting) No function.

Yes

Deletes all log files on the inserted SD-card, which fulfil the following conditions:

- Filename matches the scheme „EPxxxxxx.log“
xxxxx = number from 1 to 999999, preceding digits filled with „0“. Example: „EP000001.log“.
- Location: folder \LOGFILES on SD-card

Those conditions are matched by logfiles, which are automatically generated by SPECIAL FUNCTION > EasyPI. file log.

RFID stat. del.

 AP 5.4 AP 5.6

Sets all RFID counters to zero.

○ See PRINT INFO > RFID status.

SERVICE FUNCTION

Service

AP 5.4 AP 5.6

Parameter only appears in production mode.

Increases the counter level of the "Service" counter on the "Service Status" printout by one.

- See parameter [Service Status](#) on page 24.

yes

Increases the counter "Services" by one

no

Doesn't increase the counter

Head exchange

AP 5.4 AP 5.6

Parameter only appears in production mode.

Increases the counter „Head number“ on the info printout „Service Status“ by one.

- See parameter [Service Status](#) on page 24.

yes

Increases the counter "Head number" by one

no

Doesn't increase the counter

Roller exchange

AP 5.4 AP 5.6

Parameter only appears in production mode.

Increases the counter „Roll number“ on the info printout „Service Status“ by one.

- See parameter [Service Status](#) on page 24.

yes

Increases the counter "Roll number" by one

no

Doesn't increase the counter

Cutter exchange

AP 5.4 AP 5.6

▣▣▣▣▶ Parameter only appears in production mode and only with a cutter mounted and activated.

Increases the counter „Cutter number“ on the info printout „Service Status“ by one.

- See parameter [Service Status](#)  on page 24.

yes

Increases the counter "Cutter number" by one

no

Doesn't increase the counter

Serv. data reset

AP 5.4 AP 5.6

▣▣▣▣▶ Parameter only appears in production mode.

Sets all counters on the info printout „Service Status“ to zero.

- See parameter [Service Status](#)  on page 24.

EasyPlug monitor

AP 5.4 AP 5.6

▣▣▣▣▶ Parameter only appears in production mode.

The parameter activates the logging of received Easy Plug data. Data is transmitted to COM1 or COM2.

▣▣▣▣▶ Activating this parameter may slow down the label rate. Therefore disable the function after error analysis.

▣▣▣▣▶ To keep the influence of the monitoring function on the data rate as low as possible, the baud rate should be set to 115,000!

Disabled

(Default setting) The monitor function is disabled.

Serial Com1

The Easy-Plug monitor data is transmitted to Com1.

Serial Com2

The Easy-Plug monitor data is transmitted to Com2.

EP Monitor Mode

AP 5.4 AP 5.6

▣▶ Parameter only appears in production mode.

▣▶ Activating this parameter may slow down the label rate. Therefore disable the function after error analysis.

Interpreter data

(Default setting) All received Easy-Plug data, apart from immediate commands, are transmitted.

All data

All received Easy-Plug data, including immediate commands, are transmitted.

Sensor adjust

AP 5.4 AP 5.6

▣▶ Parameter only appears in production mode.

- For detailed instructions sensor adjustment, please refer to the service manual, topic section "Service Electronics", paragraph "Settings".

Sensor test

AP 5.4 AP 5.6

- The description of the sensor test can be found in the printer service manual, topic section „Service Electronics“, chapter [Sensor test](#) □.

The values displayed are for checking the sensors (sensor check) and can be adjusted by service personnel.

Cutter test

AP 5.4 AP 5.6

Makes it possible to test the cutter function without having to set the parameter `SYSTEM PARAMETER > Periph. device` to „cutter“.

Press Cut Key

Triggers a cut, if a cutter is installed. Without a cutter nothing will happen.

Matend tolerance

AP 5.4 AP 5.6

Material end tolerance

This is relevant for label stock with very long punches. To avoid those punches being recognized as material end by mistake, can here the distance be set, after which the gap over the light sensor is interpreted as material end.

▮▮▮▮ By choosing a very high material end tolerance, you loose the protection of the print roller against being printed on!

xxx mm

Setting range: 20-300 mm; Default setting: 35 mm

Feedadjust label

AP 5.4 AP 5.6

Prints a scale, which enables to calculate the feed adjust value (see next parameter).

For application instructions, refer to the Service Manual, topic section „Electronics Gen. 3“, chapter [Adjusting the imprint position](#).

Feed adjust

AP 5.4 AP 5.6

Corrects the material feed length. Such a correction can be necessary when printing on very long labels, to compensate slippage-related feeding inaccuracy.

For application instructions, refer to the Service Manual, topic section „Electronics Gen. 3“, chapter [Adjusting the imprint position](#).

x.x %

Setting range: -10,0 to +10,0; Step width: 0,1%; Default setting: 0%

Punch y calibr.

AP 5.4 AP 5.6

▮▮▮▮ Only in production mode

Compensating the variation of distance between punch sensor and thermal bar of the printhead.

x.x mm

Setting range: -3.0 to 3.0; Default setting: 0.0; Unit interval: 0.1

Memory card test

AP 5.4 AP 5.6

Test SD-cards

Pressing the online button starts a test routine for the Compact Flash Card memory. The following display shows up after successful testing:

```
Memory card test  
Card Test O.K.
```

If the SD-card is defective or not available, a corresponding error report shows up.

For test purposes, the printer creates a file named TESTXXXX.TXT in the root directory of the card. An already existing file with this name will be overwritten.

Receive test

AP 5.4 AP 5.6

Serial connection

Assumption is a serial data line between PC and printer; the parameter `INTERF.PARAM. > Interface` must be set on RS232 or RS485.

1. Start the MS-DOS-window (using Windows).
2. Set the interface to the values adjusted at the printer by means of MS-DOS command MODE:

Example of printer settings:

- Baud rate: 19200
- No. of data bits: 8
- Parity: none
- Stop Bits: 1
- Data synch.: RTS/CTS

DOS-Command: `mode com2 19200 8 n 1`
(if com2 is the serial port)

3. Press the Online-key to start Receive test.

```
Receive test
0 Bytes
```

4. Send any file to the printer (Condition: com2 = Printer port; anyfile.txt = any file):

`copy anyfile.txt com2` (add /b for binary files)

The following shows up on the printer display:

```
Receive test
xxxxx Bytes
```

xxxxxx is the size of the sent file in bytes. This value is being counted up during the test. The test is complete if the file size does not vary any more. If the bytes announced at the printer match the size visible in the MS-DOS window, transfer was successful. Otherwise, transmission errors occurred.

Rewinder adjust

AP 5.4 AP 5.6

☛ Only with „Rewinder 2000“ installed.

Setting up the rewinder.

The rewinder setup compensates differences in characteristic or assembly of the light barrier.



☛ CAUTION! - This parameter counts for both, the external *rewinder option* for AP 5.4 and the *backing paper rewinder* of the ALX 92x. But mind that the setting values are different!

- A setting description for the *rewinder option* is given in the „Manual Rewinder 2000“, paragraph [Adjusting the sensor](#).

☐ Resting pos.xxx

Setup of the resting position (xxx = actual sensor value).

End pos. xxx

Setup of the End position (xxx = actual sensor value).

The setting follows in both cases this scheme:

1. Bring the dancer arm to its resting position.
2. Press the cut button
 - ☛ *Not* the Online button (as with TTX x50)!
3. Bring the dancer arm to its end position.
4. Press the Online button.

Printtest

AP 5.4 AP 5.6

General printtest, prints line by line the set printer type and the firmware version. Material settings (Material type, length, width) are considered.

Stop the printtest by pressing the Online button.

SERVICE DATA

> MODULE FW VERS.

System version

AP 5.4 AP 5.6

Shows the firmware version number.

System revision

AP 5.4 AP 5.6

Shows a consecutive revision number.

▣▣▣▣▶ Only for factory-internal use.

System date

AP 5.4 AP 5.6

Shows the date, at which the firmware was generated.

Bootloader

AP 5.4 AP 5.6

Shows the bootloader version number.

uMon

AP 5.4 AP 5.6

Shows the bootloader version number.

Peripheraldriver

AP 5.4 AP 5.6

▣▣▣▣▶ Only with mounted (optional) peripheral output stage board.

Applied PIC version on the output stage board driving the peripheral motor.

Intern. rewinder (Internal rewinder)

AP 5.4 AP 5.6

▮▮▮▮ „AP 5.4/5.6 peripheral with internal rewinder“ only.

Applied PIC version on the internal rewinder motor output stage board.

> OPERATION DATA

Serv. operations

AP 5.4 AP 5.6

Shows the number of service operations. The counter is increased by calling the parameter `SERVICE FUNCTION > Service = yes`. Maximum value: 4 billions.

Headnumber

AP 5.4 AP 5.6

Shows the number of printhead changes. The counter is increased by calling the parameter `SERVICE FUNCTION > Cutter exchange = yes`. Maximum value: 4 billions.

Roll number

AP 5.4 AP 5.6

Shows the number of exchanged print rollers. The counter is increased by calling the parameter `SERVICE FUNCTION > Roller exchange > yes`. Maximum value: 4 billions.

Cutter number

AP 5.4 AP 5.6

▮▮▮▮ Only with mounted and activated cutter.

Shows the number of exchanged cutters. The counter is increased by calling the parameter `SERVICE FUNCTION > Cutter exchange = yes`. Maximum value: 4 billions.

Head run length

AP 5.4 AP 5.6

Shows the total "covered distance" of the printhead. The counter is reset with each calling of the parameter SERVICE FUNCTION > Cutter exchange = yes. Maximum value: 4 billions.

Roll run length

AP 5.4 AP 5.6

Shows the total "covered distance" of the print roller. The counter is reset with each calling of the parameter SERVICE FUNCTION > Roller exchange = yes. Maximum value: 4 billions.

Cuts on knife

AP 5.4 AP 5.6

☛ Only with mounted and activated cutter.

Shows the number of cuts done by one knife. The counter is reset with each calling of the parameter SERVICE FUNCTION > Cutter exchange = yes. Maximum value: 4 billions.

Tot. mat. length

AP 5.4 AP 5.6

Shows the total "covered distance" of the feed roller. In comparison to the counter Roll run length, this counter is not reset after a roller exchange. Maximum value: 4 billions.

Tot. foil length

AP 5.4 AP 5.6

Shows the total "covered distance" of the ribbon roller.

Total cuts

AP 5.4 AP 5.6

☛ Only with mounted and activated cutter.

Shows the number of cuts done by all knives. In comparison to the counter Cuts on knife, this counter is not reset after a knife exchange. Maximum value: 4 billions.

Head strobes

AP 5.4 AP 5.6

Shows the counted head strobes, which are a measure for the service life of the printhead. A strobe is counted for each line in which at least one dot is printed. Maximum value: 4 billions.

Head temperature

AP 5.4 AP 5.6

Shows the current printhead temperature in °C.

Foil diameter

AP 5.4 AP 5.6

Shows the calculated foil diameter: A measurement routine calculates the actual ribbon roll diameter with an exactness of 7.5%.

The parameter `SYSTEM PARAMETER > Foil end warning` can be used to set a critical foil roll diameter. If the foil roll diameter equals this value, a message appears on the printer display.

- See parameter [Foil end warning](#) on page 68.

Dispensing cycl.

(Dispensing cycles)

AP 5.4 AP 5.6

▣▶ AP 5.4/5.6: Dispenser version only.

Shows the number of dispensed labels.

Operation time

AP 5.4 AP 5.6

Shows the elapsed time since the last switch-on of the machine.

> POWERSUPPLYDATA

Type

AP 5.4 AP 5.6

Shows the type of power supply, e.g. „Blue Mountain“.

PS temperature

AP 5.4 AP 5.6

Shows the current power supply temperature in °C. If for any reason the function is not supported, „??? °C“ is displayed.

> CPU BOARD DATA

CPU identifier

AP 5.4 AP 5.6

Shows the designation of the applied processor.

PCB revision

AP 5.4 AP 5.6

Shows the layout revision and part number of the CPU board.

FPGA version

AP 5.4 AP 5.6

Shows the FPGA version.

MAC address

AP 5.4 AP 5.6

Shows the MAC Address, an unchanging board address, which is programmed by the board manufacturer.

Serial number

AP 5.4 AP 5.6

Serial number: Is programmed by the board manufacturer.

Production date

AP 5.4 AP 5.6

Production date: Is programmed by the board manufacturer.

PCB part number

AP 5.4 AP 5.6

Shows the part number of the board without components.

Board part numb.

AP 5.4 AP 5.6

Shows the part number of the board with components.

Manufacturer

AP 5.4 AP 5.6

▣▶ Parameter appears only in production mode.

Shows the board manufacturer.

Work place

AP 5.4 AP 5.6

▣▶ Parameter appears only in production mode.

Shows the printer work place.

Company name

AP 5.4 AP 5.6

▣▶ Parameter appears only in production mode.

Shows the company name.

> DISPLAY DATA

Display version

 AP 5.4 AP 5.6

Shows the *version number* of the operation panel.

Display SerialNr

 AP 5.4 AP 5.6

Shows the *serial number* of the operation panel.

> MEMORY DATA

Ram memory size

 AP 5.4 AP 5.6

Shows the available RAM memory size.

Flash mem size

 AP 5.4 AP 5.6

Shows the available Flash memory size. The abbreviation which is displayed behind the memory size indicates the manufacturer of the applied Flash-RAM:

Abbreviation	Manufacturer
MX	Macronix
AMD	AMD
FUJ	Fuji

[9] The displayed abbreviations indicate the manufacturer of the Flash-RAM.

SD card

AP 5.4 AP 5.6

▣▶ Only with plugged-in SD-card.

Shows the memory size of the SD-card:

SD card 971 MB / 1024 MB

Display example: 971 MB of 1024 MB are free.

▣▶ The card slot must be assigned to a drive letter, otherwise the displayed text may be faulty.

- Assigning a drive letter: see chapter > [DRIVEASSIGNMENT](#)  on page 65.

Space for Jobs

AP 5.4 AP 5.6

Shows the memory size, which is available for print jobs.

Max. Labellength

AP 5.4 AP 5.6

Shows the maximum printable label length, which results from the memory allocation.

Default values

AP 5.4 AP 5.6

Shows the setting of parameter [SPECIAL FUNCTION > Default values](#).