

Figure 1

1. INTRODUCTION

This instruction sheet covers the use of Cable Tie Installation Tool 734587–1, shown in Figure 1. The tool is used to apply the cable ties listed in Figure 2. Read these instructions thoroughly before installing cable ties

NOTE

Unless otherwise specified, all dimensions are in millimeters [with inches in brackets]. Figures are not drawn to scale.

2. DESCRIPTION

This tool features an incremental tension–adjustment dial, a tension–adjustment indicator, and an automatic cut–off blade.

The tension adjustment regulates the amount of tension applied to the cable tie before the tie is cut. The adjustment is made by turning the adjustment dial until the indicator displays the desired setting.



The higher numerical settings on the tool indicate a greater tension placed on the cable tie.

3. APPLICATION PROCEDURE

1. Determine the diameter of the cable bundle and select the proper cable tie from the table in Figure 2.

2. Turn the tension adjustment dial to the desired tension setting.

3. Loop the cable tie around the cable bundle and insert the tapered end of the tie through the back of the tie head. Refer to Figure 1.

4. Pull the cable tie through until snug.

5. Insert the cable tie into the tool's gripper slot and squeeze the handle completely. The tool will tighten the tie and automatically cut the excess once the pre–set tension is reached.

If the tension on the cable tie is not as originally desired, re–adjust the tool as required.

CAUTION

Exercise care when adjusting the tension. Do NOT turn the adjustment past the zero setting, or damage to the tool may result.

©2003 Tyco Electronics Corporation, Harrisburg, PA. All International Rights Reserved. AMP and Tyco are trademarks. *Trademark This controlled document is subject to change. For latest revision call the AMP FAX* number.

Other products, logos, and company names used are the property of their respective owners.



CABLE BUNDLE DIAMETER		CABLE TIE			
MINIMUM (mm [In.])	MAXIMUM (mm [In.])	LENGTH (mm [In.])	PART NUMBER	TENSILE VALUE (lb)	TOOL TENSION SETTING RANGE
1.5 [.06]	19.1 [.75]	108.0 [4.25]	603230	18	0–1
			603231		
		101.6 [4.00]	604771		
			608701		
		203.2 [8.00]	608687		
	31.8 [1.25]	152.4 [6.00]	603227	- 30	1–2
		158.8 [6.25]	608687		
	50.8 [2.00]	215.9 [8.50]	604476	40	
	76.2 [3.00]	292.1 [11.50]	608688		
	19.1 [.75]●	209.6 [8.25]	608698	50	2–3
	35.1 [1.38]	165.1 [6.50]	608692		
	38.1 [1.50]●	304.8 [12.00]	608699		
	44.5 [1.75]	203.2 [8.00]	608702		
			608704		
			608789		
	50.8 [2.00]	393.7 [15.50]	608700		
	76.2 [3.00]	298.5 [11.75]	604751		
	101.6 [4.00]	381.0 [15.00]	608703		
		393.7 [15.50]	604774		
		406.4 [16.00]	608695		
		412.8 [16.25]	608696		

• Using two cable bundles, each of this size.

4. TOOL MAINTENANCE

The tool should be inspected immediately upon arrival in your plant, and at regularly scheduled intervals, to ensure that the tool has not been damaged. Lubricate the tool as directed in Figure 1.

5. TOOL REPLACEMENT AND ORDERING

If the tool should become damaged, it must be replaced. Additional tools can be purchased through your Tyco Electronics Representative, or call

Figure 2

1–800–526–5142, or send a facsimile of your purchase order to 717–986–7605 or write to:

CUSTOMER SERVICE (038–035) TYCO ELECTRONICS CORPORATION PO BOX 3608 HARRISBURG PA 17105–3608

6. REVISION SUMMARY

Per EC 0990-0438-03:

• Initial release of instruction sheet