

Mako 6500

6500-M User Manual

Covers all M-Model Makos



Quick Reference



Internet connection



ር 🗑 🖗

WAN in use (WAN1 = Green, WAN2 = Yellow) CMS Status (Good = Green, Hold = Yellow) Error

- Wireless operational
 - LAN 1-4: Transmitting/Receiving traffic

Setup:

- 1. Place your Mako in a safe, dry, ventilated area, with strong cellular reception and Wireless availability.
- **2.** Ensure your Internet service and/or cellular service is up and operating before connecting the Mako to your Internet connection or inserting SIM cards.
- **3.** Power is the LAST thing to connect. Connect LAN cables, then DSL/Ethernet, then insert the USB Stick.
- 4. Plug in power. The Mako will automatically configure itself. After the lights on the Mako's front stop flashing, unplug power, then the USB Stick. Wait 15 seconds, then re-plug in power.

Login:

- 1. Prior to installing your Mako, you should have access to a stable ISP account and have given the settings to your Managed Network Provider (MSP). They will preconfigure your Mako before you receive it.
- **2.** Your login name, access code and the URL for the Mako CMS have been emailed to you. Your first action will be to set a password for your account.
- **3.** If you have difficulty accessing the Mako CMS, please phone your Managed Service Provider with your Mako ID, login name, and other relevant details.
- There are no user-serviceable parts in this network appliance. Attempting to open the Mako's case voids its warranty.

This Quick Reference is an overview only. Please read this manual in its entirety for complete details on correct setup and installation.

Welcome to the Mako System

Your Mako 6500-M is an integral part of an affordable and easy-to-use cloud-based network management service. The service offers bank-grade security. We call it The Mako System.

Designed for smaller businesses and distributed enterprises, the Mako System offers a secure solution for the entire network with centralized management across multiple sites. The Mako System consists of two parts; the Mako Central Management System (CMS) and a range of network appliances we simply call 'Makos'. All Makos are managed from the CMS to deliver the powerful services of the Mako System. The CMS uses a standard web browser for configuration and reporting, providing enterprise-level control over your Internet connection and giving you freedom to manage and monitor your business network from anywhere.

1.1 Box Contents

- One (1) Mako 6500-M network appliance
- Optional vertical stand with two (2) mounting screws
- Three (3) CAT-5 Ethernet cables
- One (1) USB key

One (1) Region-specific power cord & 12 V DC power adaptor

- Two (2) external cellular network antennas
- One (1) external Wireless antenna
- One (1) region-specific cable for phone lines

1.2 Setup Requirements

All 6500-M models: Either an active and available WAN connection, through an Ethernet/Cable connection, DSL connection, or both.

6500-M Cellular models: an active and available 3G or 4G/LTE-compatible cellular WAN connection, and a SIM card with an active account through an approved service provider. Your Mako username, access code, and Mako CMS web address. If this information hasn't already been emailed to you, contact your MSP for further instructions.

✓ If you want more than one device sharing one LAN, you may need an Ethernet switch or hub. Switches and hubs allow multiple computers to use one LAN. We recommend Ethernet switches over Ethernet hubs as switches have an extra layer of address management, improving performance and security.

1.3 Other Requirements

To operate the cloud-based Mako CMS, you'll need:

A computer with Internet access and a modern web browser. This computer doesn't need to be on your protected network to configure the CMS – you can configure your network from anywhere around the

1.4 Locating your Mako

Choose a location for the Mako in a spot next to your LAN hub or switch and the incoming Internet connection. The location should be off the floor, out of direct sunlight, adequately ventilated and near a power outlet.

Cellular models only

Ideally, place your Mako in line-of-sight to a cellular tower.

Avoid placing your Mako appliance near devices that may cause radio interference with the cellular data signal, such

world – but we advise caution, as remote configuration of your network from **outside** your network may be vulnerable to observation. In much the same way that talking about sensitive business information in a public café may lead to dire consequences.

as microwave ovens, cordless phones, etc. Things that can inhibit reception include washers, dryers, refrigerators, metal cabinets and especially any water-filled items, such as tubs of water, aquariums, water heaters, etc.

We advise operating cellular Makos out of immediate proximity (within 21 cm/8 in) to any person for extensive periods, in accordance with FCC regulations.

Installation

2.1 Connecting to an Ethernet Switch

You must have AT LEAST ONE WAN connection to an Internet service that's up and running. In the diagram, WAN connections are in **Purple**.

6500-M/3G and 6500-M/LTE models: Ideally, your main WAN would either be a DSL or Cable/Ethernet connection, simply because these connections are more reliable and

cheaper. That way you can use your cellular connection in emergencies with Cellular Failover .

You can also run multiple LANs from the Mako into the same switch, but we advise against this unless you have a sound knowledge of gateway networking.



2.2 Simple Connection

In small networks you may wish to place one device per LAN. This is fine, but be aware that each LAN is separate from the others and requires individual configuration or maintenance. Switched networks (above) tend to be easier to manage.



While smaller, this two-LAN network operates on two distinct sets of rules and settings (unless configured to 'bridge' one LAN to the other internally).

Firmware Installation

Normally, your Mako appliance will arrive pre-configured for your location and network setup. However if your Internet details or service provider settings have changed, your Mako may not be able to connect.

3.1 Auto-Configuration Install (Ethernet/Cable)

- 1) Once your Ethernet cables are connected for your network, connect power to your Mako.
- 2) The Mako will configure itself in two stages: verify and Install. See the Troubleshooting section for descriptions of the light sequences. Allow at least 10 minutes for this

On your Mako's side, **your connection to the Internet should be running and capable**. For instance, if sharing a DSL line with a voice line, ensure the voice lines are filtered appropriately.

process to complete. The Mako's status lights will indicate the stage of progress or error notifications.

3) When the 'Install' light sequence finishes, disconnect power from the Mako for 10 seconds, and re-connect power. When the Error light switches off, your network is ready for use.

3.1 DSL Configuration (using USB Key)

DSL accounts may auto-configure in certain countries, provided the ISP has default routing for your Mako to the Mako System. If this is the case, the procedure is the same as in Auto-Connect Install.

For most DSL accounts, firmware for your Mako's initial deployment must use a USB key (one is enclosed with every Mako).

USB Key format: Prior to 2014, only FAT-32 format USB keys were usable for configuration. Now, general media ('off the shelf') format as well as FAT-32 USB keys may be used.

- 1) Your MSP will email a 'configuration.zip' file to an accessible account. This file contains your Mako's settings.
- 2) Load this file onto a USB key.
- **3)** Disconnect power from your Mako, wait 10 seconds, and plug in your USB key.

- 4) Re-connect power to your Mako.
- 5) The Mako will configure itself in two stages: verify and Install. See the Troubleshooting section for descriptions of the light sequences. Allow at least 10 minutes for this process to complete. The Mako's status lights will indicate the stage of progress or error notifications.
- 6) When the Install sequence finishes, disconnect power.
- 7) Wait 10 seconds, then remove the USB key and reconnect power.
- 8) When the Error light on the front of the Mako goes out, your network is ready to use.
- Once your network is configured and connecting to the CMS, further updates will occur automatically.

Cellular Setup

To use a cellular network for Internet connectivity you must have:

 An account with an approved GSM 3G/ 4G LTE cellular service provider (CDMA not supported).

9.1 SIM card insertion

The Mako 6500-M has been intentionally designed to make SIM card removal difficult. This helps prevent it from accidentally popping out, or unauthorized removal.

To insert a SIM card, push the card into the SIM card slot in the orientation shown on the back of the Mako. It should be going in flat, horizontally.

Use a blunt tool to push the SIM card in another 3-4 mm: this could be something like your thumbnail, or pen-tip.

9.2 Configuring your cellular connection

In most cases, your cellular network settings will have been preconfigured by your Mako service provider. But if you've decided to add cellular connectivity after installation, insert your SIM card, login to the CMS, and configure your cellular connection using the details provided by your service provider.

 Once you've selected your Mako to configure, the appropriate settings are found under:

Configure > Internet > Secondary ISP Setup

○ Ethernet ● 3G

- 2) Select the '3G/Cellular' radio button.
- 3) The page will refresh.

Avoid sharp, metallic tools, such as screwdrivers or knives as a slip could damage the SIM card, the Mako's

A SIM card to access the provider's service.

Authorization on the Mako CMS to use it.

electronics, or yourself. The SIM card will compress a spring when inserted and click into place.

- **4)** Select your Internet Service Provider for your cellular connection.
- 5) Once selected, the page will reflect the options that provider offers with that account. Depending on your account, you may or may not need to completely fill in this page if in doubt, check with your Cellular ISP.
- 6) Click Save, or Save and Setup Alerts.
- ✓ In most areas cellular data is more expensive than broadband data. This is why we recommend setting a cellular connection as a secondary connection, ready for Cellular Failover, and why setting up alerts for this service is important.

	Unconfigured	ISP Plan Request		
Plan	Unconfigured			
User Name: 👔		@ xtra.co.nz (Optional)		
Password:	••••	(Optional)		
Confirm Password:	•••••	(Optional)		
Sim card PIN	(Ontional)			
Sim card PIN	(Optional)			
Sim card PIN again	(Optional)			
Access Point Name (APN)		(Optional)		
Configure DNS 🛛 🛛				
	202.27.158.40			
Primary DNS Server				

Troubleshooting

7.1 Firmware Checks

The configuration installation process uses two main light sequences.

- Verify: The three lights on the right will go through a flash sequence: left light on, center light on, right light on, then each light turns off in reverse. It will continue this back-n-forth sequence as the Mako goes through its verification phase.
- Install: The three lights on the right will go through a similar flash sequence, but reversed: Right light on, center light on, left light on, then each light turns off in reverse. It will continue this back-nforth sequence until the file has been installed.
- 7.2 Testing WAN Connections

DSL/Ethernet

Once your network is set, open a web browser on one of your Mako-protected PCs and access one or two websites.

Your network may have been configured to use a Payment Card Industry Data Security Standard (PCI DSS) template. The default action of this template is to allow access only to pre-approved websites. Consult your network service provider if you are unable to access business-critical websites.

Cellular Failover

If your Mako is configured for Cellular Failover, disconnect your Primary WAN cable (DSL or Ethernet). The WAN light

7.3 Makoscope

Makoscope is Mako Networks' diagnostic reporting tool. After configuring your network and opening a web browser you may access Makoscope two ways:

Entering the LAN address of your network into your browser's address field (the default URL for the Mako is "192.168.[subnet number].254", but variations are common).

- 'configuration.zip' installs successfully when the Install light sequence finishes.
- If either the verification or installation was not successful the lights will freeze. If 10 minutes has elapsed, disconnect the Mako's power, remove the USB key and check to see if the file 'configuration.zip' is still on it – part of a successful install is the auto-deletion of this file.
- In the unlikely event that the first try fails, reload 'configuration.zip' onto the USB key and repeat the installation process.
- Always remember to disconnect power from the Mako before inserting or removing the USB key. If you encounter any other difficulties, please contact your MSP.

(\bigotimes) should turn from green to yellow (\bigotimes) over a period of 2-5 minutes, depending on the complexity of your network.

When yellow, try accessing a website or using a web service like email.

Once tested, re-insert your Primary WAN cable. It will take another similar period to re-establish your primary connection. When the WAN light returns to green, failback is complete.

- If re-inserting your DSL or Ethernet WAN cable doesn't revert to your primary connection within 10 minutes, call your MSP.
- Through the CMS. Login and go to:

Reports > Diagnostics > • Makoscope

Of most importance is the colored text, indicating the status of your connection. For more information on Makoscope, see the **Central Management System: Setup & Configuration manual.**

Fallovel Status	INACTIVE
Last Mako Server Contacted	17 April 2013 04:01:25 AM
Last User Change	None
Firewall Status	ACTIVE
Mako Guardian Status	INACTIVE
Temperature	43C
ADSL	Connected. Receive 16617Kbs and send 996Kbs
РРР	User user@internetprovider.com, Address 192.168.99.254/255.255.255.255 PPPoA PVC 0.100
LAN	Wireless - Home (wlan0) Address 10.1.2.254/24 SSID: Exertion wpa2 DHCP Server Active
LAN	LAN 1 (eth0) Address 192.168.46.254 10Mb/s Half Duplex
LAN	LAN 2 (eth1) Address 192.168.57.254/255.255.255.0 DHCP Server Active 100Mb/s Full Duplex

6500-M Status Lights

This chart outlines the light combinations used to indicate the status or progress of the Mako 6500-M at any given stage.

Generally, lights on the left vary only in power-up sequences. But the core of the status messages lies in the three lights on the right. A subtle difference between the 6500-M and other 6500 Series Makos is that the WAN and CMS lights are dual-color LEDs: yellow and green. During boot-up sequences, both the yellow and green LEDs illuminate at the same time, creating a bright 'chartreuse' color.



	С С))	/ 1 S 2 S			
Installing File						The Mako is installing the configuration file.
			\subset		→	These three lights cycle for the installation period. They turn on from right to left, one at a time, a second apart, until all are lit. They turn off in reverse order.
No Configuration			*	*	۲	The Mako is not configured for use.
			•	•	•	All three lights flash simultaneously, Yellow, Yellow, Red.
Missing Boot Image						No configuration file is present on the USB key.
			•	•	•	All three lights flash simultaneously, Green, Green, Red.
PPP Timeout			*			Period to negotiate a PPP connection has lapsed.
			•		•	WAN (Yellow) and ERROR lights flash alternately.
PPP Authentication			*		*	Unable to verify Mako <> ISP credentials.
			•		•	WAN (Yellow) and ERROR lights flash simultaneously.
SIM Not Present					*	The SIM slot is empty or incorrectly inserted.
					•0	ERROR light flashes short, short, long.
					●0 ●-●0	
SIM PIN Error						The SIM card is unconfigured, damaged or unreadable.
					●-●O	ERROR light flashes twice long, one short.
					••••	

Hardware Specification

LAN Interface	4 x Ethernet RJ45 10/100/1000 Mbps ports. Auto crossover.
WAN Interface	1 x Ethernet RJ45 10/100/1000 Mbps port. Auto crossover. 1 x RJ11 ITU G.992 VDSL2 1/2/2+ port
Power Supply	External 100 or 240 V AC Input (50 or 60 Hz). 12 V DC output.
USB Port	For support functions (i.e. manual configuration).
Chassis Dimension	Length: 8.58 inches (218mmn) Width: 8.58 inches (218mm) Height: 1.57 inches (40mm)
Operating Temperature	41° F to 104° F 5° C to 40° C
Humidity	10% to 90% relative, non-condensing
Hardware VPN Encryption	Supported
Power Consumption	10W - Typical

Wireless Specification

Channels	2
Supported Standards	802.11 b/g/n
Bandwidth	Up to 300 Mbps per channel
Security	WPA2 Personal
Frequencies	802.11b/g: 2.412 GHz - 2.472 GHz 802.11n HT20: 2.412 GHz - 2.472 GHz 802.11n HT40: 2.422 GHz - 2.462 GHz
Other	Integrated access point scanning Wireless Multimedia (WMM) QoS
Output Power	< 100 mW (e.i.r.p.)

DSL2 Modem Specification

ADSL2+, VDSL supporting 1Gbit/s transfer speeds

Cellular Specification

DSL

Protocols	3G, 4G LTE
	00, 10 111



Network Protocols	PPP over Ethernet (RFC 2516 PPPoE)
Electromagnetic Compliance	EN55022 - CSPIR 22 Class B (EMC) EN55024 - CSPIR 24 (Immunity) FCC Part 15 Class B
Wireless Compliance	EN 300328
Safety Standards	CB, IEC 60950, EN 60950 & AS/NZS 60950
NZ Telecoms	PTC 257 (3G)
Environmental	Lead-free and RoHS compliant
Firewall	Stateful Packet Inspection





Limited Warranty

- Standard Limited Warranty. If the products purchased hereunder are resold by a distributor or reseller to an end-user (customer) pursuant to the terms hereof in their original, unmodified, unused condition, Purchaser shall pass on to its customers, or keep as applicable for internal use, the MAKO NETWORKS LTD. standard limited warranty for the products, as summarised in documentation supplied with the product and including provisions and limitations set forth below. The Manufacturer warrants the Mako appliance for one (1) year. The Warranty begins on the date of purchase as shown on your providers invoice.
- 2) Express End-user Limited Warranty. Each MAKO NETWORKS LTD. product purchased hereunder is warranted against defect in material and workmanship and will substantially conform to MAKO NETWORKS LTD. product documentation for the period set forth in the documentation supplied with the product following delivery to end-user (the "Warranty Period"). This warranty extends only to end-user and will not extend to, nor may it be assigned to, any subsequent user, Purchaser or user of a MAKO NETWORKS LTD. product, whether such MAKO NETWORKS LTD. product is alone or incorporated into end-user's product.
- 3) Exclusions. The express warranty set forth above is contingent upon the proper use of a MAKO NETWORKS LTD. product in the application for which it was intended and will not apply to any MAKO NETWORKS LTD. product that has been (i) damaged during shipping, (ii) modified or improperly maintained or repaired by a party other than MAKO NETWORKS LTD. or its designees, or (iii) subjected to unusual physical or electrical stress. This includes operation of the product outside the Operating Specifications of the product.
- 4) Limitation of Remedy. In the event a MAKO NETWORKS LTD. product fails to perform as warranted, MAKO NETWORKS LTD. sole and exclusive liability and end-user's only remedies for breach of this warranty shall be, at MAKO NETWORKS LTD.'s option to repair, replace or credit an amount not exceeding the Purchaser's purchase price of each product found to be defective, provided that:
 - 1. End-user complies with the rejection and warranty procedures contained in Section 5 below and returns the MAKO NETWORKS LTD. product that the end-user considers defective for examination and testing.
 - 2. MAKO NETWORKS LTD. shall not be liable under this warranty if testing and examination by MAKO NETWORKS LTD. discloses that the MAKO NETWORKS LTD. product has been modified or altered in any manner after it was shipped by MAKO NETWORKS LTD.
 - 3. MAKO NETWORKS LTD. shall not be liable under this warranty if testing and examination by MAKO NETWORKS LTD. discloses that the alleged defect in the MAKO NETWORKS LTD. product does not exist or was caused by end-user or any third person's misuse, neglect, improper installation or testing, unapproved attempts to repair or any other cause beyond the range of intended user, or by accident, fire or other hazard.
 - 4. MAKO NETWORKS LTD. shall not be liable under any warranty under this Agreement with respect to any MAKO NETWORKS LTD. product that is not returned in its original shipping container or a functionally equivalent container.
 - 5. If MAKO NETWORKS LTD. testing and examination does not disclose a defect warranted under this Agreement: MAKO NETWORKS LTD. shall so advise Purchaser and dispose of such MAKO NETWORKS LTD. product in accordance with Purchaser's instructions on behalf of end-user and at Purchaser's cost.