HP StorageWorks Ultrium full-height SCSI Tape Drives user guide



Legal and notice information

© Copyright Hewlett-Packard Development Company, L.P.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Linear Tape-Open LTO, the LTO Logo, Ultrium and the Ultrium Logo are registered trademarks of HP, IBM and Quantum in the US and other countries.

Microsoft, Windows, Windows XP, and Windows NT are U.S. registered trademarks of Microsoft Corporation.

UNIX is a registered trademark of The Open Group.

Contents

Α	out this guide	9
	Intended audience	
	Related documentation	
	Document conventions and symbols	
	HP technical support	10
	Product warranties	10
		10
	Registering your tape drive	10
	Subscription service	
	HP websites	11
	Documentation feedback	11
1	Sefore you start	13
	Supported models	13
	Which operating systems are supported?	13
	How do I connect the drive to my server?	13
		14
	External drives	14
	Removable drives	14
	Why is the SCSI but type important?	14
	Why is the SCSI bus type important?	15
	Usage models	16
	Other usage models	17
		17
	Using the HP StorageWorks Tape CD-ROM	17
2	Drivers and backup software	19
_	Install drivers	19
	Installing on Windows	19
		19
		19
		19
		20
		20
3	nstalling an internal tape drive	21
	Check the drive's SCSI ID	21
	Prepare mounting bay	22
	Attach mounting hardware	23
	HP ProLiant servers	23
	Mounting rails	24
	Mounting screws	24
	Other servers	25
		25
	Attach nower and SCSI cables	26
	Attach power and SCSI cables	20 27
		27
	Secure the drive	
	Mounting hardware used (HP ProLiant)	28 28
	No mounting hardware used	28
4	nstalling an external Ultrium tape drive	31

	Check the drive's SCSI ID	32 33 33
5	Installing a removable Ultrium tape drive Which rackmount systems can I use? Electrical specification Airflow requirements How do I connect the drive to my server? Install the drive Set the drive's SCSI ID Why does the tape drive need a terminator? Replacing the drive	35 35 36 37 38
6	Verify installation	41
7	Understanding the LEDs	43 43 43
8	Operating your tape drive	4/
9	Use the correct media Cartridges Data cartridges Data cartridges HP Ultrium WORM data cartridges Ultrium 1840 tape drives and encryption When should I use encryption? How do I enable encryption? How do I enable encryption? When will I be asked to enter the key? What happens if I don't remember the key? Does encryption affect tape drive performance? Does the tape drive encrypt media in an earlier Ultrium format? Where can I get more information? Write protecting cartridges Cleaning the tape drive Handling cartridges Operating and storage environment	49 49 50 50 51 51 51 51 51 51 51 52 53
10	O Using HP OBDR Compatibility	55 55 55 56
1	Diagnostic Tools and Performance	<mark>59</mark> 59

HP Library & Tape To Troubleshooting with Performance Assessment T Optimizing performa Can your system deli	Library & Tape Tools Ince	Tools 	· · · · ·	· · · · ·	· · · · ·	· · · · ·	· · · ·	· · · ·	. 59 . 59 . 60
12 Troubleshooting General Procedure Problems with cartridges The cartridge is jamn Emergency reset The drive will not acc		· · · · ·	· · · · ·	· · · · ·	· · · · ·	· · · · ·	· · · · · · · ·	· · · ·	. 63 . 64 . 64 . 64
13 Replacing a tape To disconnect your drive To reconnect your tape dr									. 67
A SCSI configuration SCSI in HP StorageWorks Daisy chaining device SCSI terminology Setting up the SCSI bus . SCSI ID numbers Identifying SCSI IDs Setting the SCSI ID on HP SCSI termination Removable drives Internal drives External drives SCSI cables Cable length Cable quality With internal de With external de With removable Note on SE and LVD	Sultrium devices		Ves			· · · 69 . 69 . 70 . 70 . 70 . 71 . 71 . 71 . 71 . 71 . 71 . 72 . 74 . 74 . 74 . 74 . 74 . 75 . 75

Figures

1	Front view of full-height Ultrium external tape drive	13
2	Usage model	16
3	Checking the SCSI ID	21
4	Removing cover from ProLiant ML370 server	23
5	Attaching mounting rails in a typical HP ProLiant ML570	24
6	Attaching locating screws in a typical HP ProLiant 350 or 370	25
7	Installing tape drive	25
8	Connecting power and SCSI cables	27
9	Securing drive, mounting hardware used	28
10	Securing drive, no mounting hardware used	29
11	Setting the SCSI ID	31
12	Connecting the SCSI cable	33
13	Connecting the power cable	34
14	Extractor lever on tape drive fully open	36
15	Inserting the tape drive	37
16	SCSI address switch on tape array	38
17	Extractor lever in out position	39
18	Removing the tape drive	39
19	Front view of full-height Ultrium external tape drive	43
20	Inserting a cartridge	47
21	Ejecting a cartridge	48
22	Write protecting a cartridge	52
23	Inserting cartridge for OBDR	56
24	Keeping eject button pressed down, power on in OBDR mode	56
25	SCSI termination in internal drives	72
26	SCSI termination on a single Ultrium tape drive	73
27	SCSI termination in daisy-chained external drives	74

Tables

1	Document conventions	9
2	Supported SCSI bus types	15
3	Recommended usage models	17
4	Electrical specifications, internal drives	26
5	Electrical specifications, external drives	34
6	Electrical specifications, removable drives	35
7	LED sequences	43
8	Rear panel LED sequences	46
9	Data cartridge compatibility	49
10	Environmental specifications for Ultrium tape drives	63

About this guide

This guide provides information about:

- Installing the HP StorageWorks Ultrium SCSI tape drive
- Using the HP StorageWorks Ultrium SCSI tape drive
- Troubleshooting the HP StorageWorks Ultrium SCSI tape drive

Intended audience

This guide is intended for users who install, operate and maintain the HP StorageWorks Ultrium tape drive.

Related documentation

In addition to this guide, the following document provides related information:

• 'Start here' poster for an overview of the installation information in this guide (available in English, French, German and Japanese)

You can find these documents from the Manuals page of the HP Business Support Center website:

http://www.hp.com/support/manuals

In the Storage section, click Tape Storage and Media and then select your product.

Document conventions and symbols

Table 1 Document conventions

Convention	Element
Blue text: Table 1 on page 9	Cross-reference links and e-mail addresses
Blue, underlined text: <u>http://www.hp.com</u>	website addresses
Bold text	 Keys that are pressed Text typed into a GUI element, such as a box GUI elements that are clicked or selected, such as menu and list items, buttons, tabs, and check boxes
Italic text	Text emphasis
Monospace text	 File and directory names System output Code Commands, their arguments, and argument values
Monospace, italic text	Code variablesCommand variables
Monospace, bold text	Emphasized monospace text

▲ WARNING!

Indicates that failure to follow directions could result in bodily harm or death.

\triangle CAUTION:

Indicates that failure to follow directions could result in damage to equipment or data.

IMPORTANT:

Provides clarifying information or specific instructions.

NOTE:

Provides additional information.

HP technical support

For worldwide technical support information, see the HP support website:

http://www.hp.com/support

Before contacting HP, collect the following information:

- Product model names and numbers
- Technical support registration number (if applicable)
- Product serial numbers
- Error messages
- Operating system type and revision level
- Detailed questions

Product warranties

For information about HP StorageWorks product warranties, see the warranty information website:

http://www.hp.com/go/storagewarranty

Registering your tape drive

Once you have installed and tested your HP StorageWorks Ultrium tape drive, please take a few minutes to register your product on the following website:

http://www.register.hp.com

To ensure your registration is complete, there are a number of questions on the electronic form that are mandatory. Other questions are optional. However, the more you feel able to complete, the better HP can meet your needs.

Subscription service

HP recommends that you register your product at the Subscriber's Choice for Business website:

http://www.hp.com/go/e-updates

After registering, you will receive e-mail notification of product enhancements, new driver versions, firmware updates, and other product resources.

After signing up, you can quickly locate your products by selecting **Business support** and then **Storage** under Product Category.

HP websites

For additional information, see the following HP websites:

- http://www.hp.com
- http://www.hp.com/go/storage
- <u>http://www.hp.com/service_locator</u>
- <u>http://www.hp.com/support/manuals</u>
- http://www.hp.com/support/downloads

Documentation feedback

HP welcomes your feedback.

To make comments and suggestions about product documentation, please send a message to storagedocs.feedback@hp.com. All submissions become the property of HP.

1 Before you start

Supported models

This guide describes how to install and operate the following HP StorageWorks Ultrium tape drive models:

- HP StorageWorks Ultrium 1840 internal, external and removable tape drives. These are Ultra 320 SCSI devices with a maximum burst transfer speed of 320 MB/second. They can write uncompressed data at up to 120 MB/second (432 GB/hour).
- HP StorageWorks Ultrium 960 internal, external and removable tape drives: These are Ultra 320 SCSI devices with a maximum burst transfer speed of 320 MB/second. They can write uncompressed data at up to 80 MB/second (288 GB/hour).
- HP StorageWorks Ultrium 460 internal, external and removable tape drives: These are Ultra 160 SCSI devices with a maximum burst transfer speed of 160 MB/second. They can write uncompressed data at up to 30 MB/second (108 GB/hour).

For a detailed product specification, please refer to our World Wide Web site (http://www.hp.com).




Figure 1 Front view of full-height Ultrium external tape drive

Which operating systems are supported?

HP StorageWorks Ultrium drives can be connected to servers running under Windows®, Linux and other major operating systems. Refer to the "Software Compatibility" section on our "HP StorageWorks Tape Compatibility" web site (<u>http://www.hp.com/go/connect/</u>) for the most recent information about the operating system versions that are supported.

How do I connect the drive to my server?

The following guidelines apply:

- You will need a properly installed and configured SCSI host bus adapter (HBA) or a built-in SCSI controller on your server and a suitably-rated SCSI cable. See also Why is the SCSI bus type important?.
- For optimum performance the drive should be the only device on the SCSI bus.
- Always terminate the SCSI bus. Ultrium internal and removable tape drives require terminators; external drives are auto terminating, as long as they are on a dedicated SCSI bus or the last device on a chain.
- Do not attach the drive to the same SCSI bus as your disk drive or to a RAID controller (unless you are connecting to a ProLiant server with a Smart Array 6i RAID controller).

PNOTE:

Always refer to <u>http://www.hp.com/go/connect/</u> to ensure that you are connecting to a supported HBA running the recommended firmware version.

Internal drives

The tape drive is installed into a spare, industry-standard, 5¼-inch, full-height drive bay in your server (or into an HP Rack-Mount Option Kit) and is attached to the SCSI bus of the host server. Use an LVDS-compatible ribbon cable to connect the tape drive to a spare 68-pin, high density (HD), wide SCSI connector on the host server. For most servers we recommend that you use the terminated SCSI ribbon cable supplied with the drive.

See also Installing an internal Ultrium tape drive.

External drives

Your tape drive is supplied with a 68-pin, wide, VHD-to-HD SCSI cable to attach to the host server. See also Installing an external Ultrium tape drive.

Check the usage models on Usage models. This shows how the HP StorageWorks Ultrium tape drive can be used in different system architectures.

Removable drives

The individual tape drives are connected to their host server via the high-density LVD/SE SCSI connectors on the back of the tape array. They do not require any SCSI cables to plug into the tape array. However, cabling and terminators are required to connect the tape array with the SCSI host. See also Installing a removable Ultrium tape drive.

Why is the SCSI bus type important?

The SCSI bus type determines the speed at which data can be transferred between devices on the bus and the maximum length of cable that can be used. HP Ultrium 1840 and 960 drives support a burst transfer rate of 320 MB/sec. HP Ultrium 460 drives support a burst transfer rate of 160 MB/sec. To benefit from this level of performance, it is important to ensure that the drives are connected to a SCSI bus of a similar or higher specification. This means that you need:

- An Ultra320 bus for HP Ultrium 1840 and 960 drives. An Ultra160 or Ultra320 SCSI bus for HP ultrium 460 drives. If you attach the drive to a lower specification SCSI bus, it may still work but data will not be transferred as quickly.
- LVD-rated SCSI cabling and terminators. The LVD interface enables the data to be transferred at the drive's maximum rate.

Table 2 Supported SCSI bus types


SCSI Bus Type	Supported
Ultra320 LVD	Yes. This is a recommended configuration for all Ultrium full-height tape drives. Do not daisy chain Ultrium 1840 or Ultrium 960 tape drives because performance will be degraded. Up to two Ultrium 460 tape drives may be daisy-chained.
Ultra 1 60 LVD	Yes. This is a recommended configuration for Ultrium 460 tape drives. It is an acceptable configuration for Ultrium 960 and 1840 tape drives. Up to two Ultrium 460 tape drives may be daisy-chained. Do not daisy-chain Ultrium 1840 and Ultrium 960 tape drives.
Ultra2 LVD	Yes. This is acceptable for one Ultrium 460 drive per bus, but performance may be impaired. Do not use with Ultrium 1840 or 960 tape drives and do not daisy-chain Ultrium 460 tape drives.
Ultra wide LVD and single-ended	These are not recommended configurations as they will restrict performance.
Ultra narrow, single-ended	No. This will severely restrict performance and you will need a suitable cable or adapter.
High Voltage Differential	No. The drive will not work and you may damage the drive or controller

How can I check the SCSI bus type and SCSI ID?

For many operating systems, you can install and run HP Library & Tape Tools from either the HP StorageWorks Tape CD-ROM or http://www.hp.com/support/tapetools to check your server's current SCSI configuration (see also Diagnostic tools). This will provide information about the SCSI bus and the SCSI IDs in use.

Usage models

HP StorageWorks Ultrium tape drives can be used in a standalone or network environment. However, they should always be directly attached to suitably-rated SCSI connector on the storage server.



- A Server
- B Tape drive

Figure 2 Usage model

The following table shows the recommended usage models and Optimizing performance provides further information about factors that can affect performance.

Table 3 Recommended usage models

	Direct Attach, single storage server	Across the Network, single storage server, multiple clients	
	A −SCSI→ B	A -SCSI-B	
Ultrium 1840	Recommended	Not recommended	
Ultrium 960	Recommended	Requires careful design to utilize the drive's performance capabilities, even Gigabit Ethernet will limit performance	
Ultrium 460	Recommended	Recommended, anything less than Gigabit Ethernet may limit performance	

A RAID disk subsystem is recommended for all usage models.

A single spindle disk will not be able to deliver good data throughput for an Ultrium 1840 or Ultrium 960 tape drive at any compression ratio. To maximize the capability of your Ultrium 1840 or 960 tape drive, utilize aggregated disk sources (RAID) with multiple disk spindles.

A single spindle disk, particularly a fast disk such as a 15K RPM drive, will be sufficient for Ultrium 460 tape drives, but be aware of other factors that can affect performance—such as, compressibility of data, disk fragmentation and the number of files. See also Optimizing performance.

You can use our free performance assessment tools, which are available standalone or integrated into HP Library & Tape Tools, to check tape performance and test whether your disk subsystem can supply data at the optimum transfer rate. You can also use these tools to calibrate your restore performance and maximal tape performance with more compressible data.

Other usage models

The tape drive may work with other usage models, such as network attach storage (NAS) and storage area networks (SAN), but HP does not currently provide technical support for installing and using standalone Ultrium tape drives with these architectures. Similarly, connection to fibre channel may be possible, if you purchase and install a fibre channel/SCSI bridge, but it is not currently a supported option. Please check http://www.hp.com/go/connect for the latest supported configurations.

Using the HP StorageWorks Tape CD-ROM

The HP StorageWorks Tape CD-ROM is a central source of information about your tape drive with utilities for getting the best performance from your tape drive.

Use the HP StorageWorks Tape CD-ROM to check installation, as described in this guide, and to verify and troubleshoot performance after installation. It helps you to:

- Install your product, which includes access to drivers, and performance information and tools
- Learn about your product
- Register your product
- Buy media online
- Troubleshoot with HP Library & Tape Tools.

2 Drivers and backup software

Install drivers

PNOTE:

The HP Tape driver is suitable for use in most applications, but refer also to the documentation of your software application to ensure you are using the recommended driver.

Installing on Windows

The driver available from Microsoft update is acceptable, but the HP driver provides better support for all the features of your new tape drive.

The CD-ROM contains a driver install package for the following Microsoft Windows operating systems: Windows Server 2000, Windows Server 2003 and Windows XP. If you prefer to use Windows Device Manager to install the tape drivers manually, you will find them in the **drivers** directory on the CD-ROM.

NOTE:

We recommend that you use the installer package on the HP StorageWorks CD-ROM to install the drivers BEFORE you connect the tape drive.

Updates to the drivers may be provided from time to time on the HP support web site (<u>http://www.hp.com/support</u>). We recommend that these are installed after using the installer on the CD-ROM.

Installing on UNIX

The recommended backup applications use the operating system's standard, built-in device drivers. To upgrade drivers we recommend that you patch to the latest version of the operating system or configure device files, as described in the UNIX Configuration Guide on the CD-ROM.

Installing on IA64

If you are installing on an IA64 system, such as an HP Integrity server, check <u>http://www.hp.com/go/</u> <u>connect</u> for the latest information on the availability of backup application upgrades and drivers.

Upgrade backup software

It is important to check <u>http://www.hp.com/go/connect</u> for software compatibility and install any recommended upgrades.

For optimum performance it is important to use a backup application that is appropriate for your system's configuration. In a direct attach configuration, where the tape drive is attached to a standalone server, you can use backup software that is designed for a single server environment. In network configurations you will need backup software that supports enterprise environments. HP, Symantec, Legato, Yosemite and Computer Associates all provide suitable products. Further details about these and other products that may be appropriate can be found on our connectivity web site.

- 1. Go to our connectivity web site: http://www.hp.com/go/connect and select tape backup.
- 2. Select software compatibility.

- 3. Select your combination of operating system and tape drive model in the table. A list of supported backup applications is displayed. This will also tell you whether your configuration is compatible with HP One-Button Disaster Recovery, HP OBDR. (All HP StorageWorks Ultrium tape drives support HP OBDR. However, you can only use this feature if your system configuration and backup application also support it. See "Compatibility" on page 55.)
- 4. Make sure you have a backup application that supports HP StorageWorks Ultrium tape drives and download any upgrades or patches, if required.

Enabling encryption

Your HP Ultrium 1840 tape drive includes hardware capable of performing data encryption while writing and data decryption while reading, both at full speed. This is only possible with Ultrium 1.6 TB media. See also "Encryption" on page.

If you wish to make use of the encryption capability, you must enable this feature via the backup software application. Refer to http://www.hp.com/go/connect to find out which applications support this advanced data protection capability.

3 Installing an internal tape drive

If you are installing an external Ultrium tape drive, please refer to Installing an external Ultrium tape drive.


If you are installing a removable Ultrium tape drive, please refer to Installing a removable Ultrium tape drive.

Check the drive's SCSI ID

Your HP StorageWorks Ultrium drive is shipped with a default SCSI ID of 3. Each device on the SCSI bus must have an unique SCSI ID number. The drive can be assigned any *unused* ID between 0 and 15. Do not use SCSI ID 7, which is reserved for the SCSI controller. SCSI ID 0 is typically assigned to the boot disk and should also not be used unless the tape drive is on a dedicated SCSI bus.

\triangle CAUTION:

Static electricity can damage electronic components. Always wear an antistatic wriststrap if possible. If not, to equalize the electromagnetic charges, touch a bare metal part of the server (such as the back plate) before you remove the tape drive from its bag.



1. Determine whether you need to change the SCSI ID from the default of 3.

For most operating systems you can run HP Library & Tape Tools from the HP StorageWorks Tape CD-ROM to check your server's current SCSI configuration (see <u>Diagnostic tools</u>). This will provide information about the SCSI bus and the SCSI IDs in use. To do this, select the 'troubleshoot with L&TT' option from the CD-ROM menu.

The UNIX Configuration Guide on the HP StorageWorks Tape CD-ROM also contains instructions on how to determine the SCSI IDs of existing devices on UNIX servers.

2. Change the tape drive's SCSI ID, if necessary.

The SCSI ID is set using jumpers on a set of pins at the rear of the drive, as shown in Figure 3. Use tweezers or small pliers to move the jumpers to the pattern corresponding to the ID you want. Spare jumpers are provided with the drive.

Prepare mounting bay

For many servers, no mounting tray or rails are required. Devices simply slide into the server's chassis and are fixed with screws. Other servers have built-in trays or rails.

Rail kits for a number of industry-standard servers may be available. For more details refer to: http://www.hp.com/go/connect.

Some servers use non-standard mounting rails and do not include spares. If this is the case with your system, you will have to order these accessories from the server manufacturer before you can install the tape drive.

▲ WARNING!

To avoid personal injury or damage to the server or tape drive, ensure that the server is disconnected from the mains power supply while you install the drive.

\triangle CAUTION:

Static electricity can damage electronic components. Always wear an antistatic wriststrap if one is available. If not, after you have disconnected power from the server and removed the cover, touch a bare metal part of the chassis. Similarly, touch a bare metal part of the drive before installing it.

- 1. Assemble the necessary tools and materials:
 - Phillips screwdriver
 - Flat-bladed screwdriver (if your server uses slotted screws)
 - Torx screwdriver (if your server uses torx screws)
 - Your server manuals (for reference during installation)
- 2. Perform a normal system shutdown and turn off the server and any connected peripherals.
- 3. Remove the cover and front panel from the server, as detailed in your server's documentation.

As you work inside the server, you may have to disconnect other signal cables or power cables from other devices to maneuver the new drive into place. If you have to do this, make a note of their position and connections so you can put them back correctly later.

NOTE:

The server must provide forced cooling and be capable of drawing 6 cfm (0.17 m³/minute or 10.08 m³/hour) of air through the tape drive at up to 35 C ambient operation. This rises to 8 cfm for up to 40 C ambient operation. Ensure that empty bays have the appropriate blanking plates installed so that airflow is maintained.




Figure 4 Removing cover from ProLiant ML370 server

- 1. Release catch
- 2. Push cover back and lift off
- 4. Remove the filler panel from a spare 5¼-inch bay of your server, as described in your server's documentation. With some servers, such as the HP AlphaServer ES40, you must also remove the half-height device divider.
- 5. You are now ready to install your tape drive.

Attach mounting hardware

If your server requires special rails or other hardware to install the tape drive, mount them on the tape drive now.

If your server does not require special mounting hardware, proceed to Install drive now.

\triangle CAUTION:

The Ultrium half-height drive only allows 3 mm of the engagement of the screw into the drive. If you remove an existing drive, do not assume the screws that you remove are the correct length for your new Ultrium drive. Always use the screws supplied with your Ultrium drive.

HP ProLiant servers

PNOTE:

If mounting hardware is supplied with your tape drive, it may not be exactly the same as shown in the illustrations.

Different models of server require different mounting methods. The server may also incorporate a locking mechanism to hold the tape drive in place. See Secure the drive.

Please check your HP ProLiant server documentation to ascertain the correct method of mounting, and to check whether mounting hardware is provided with the server.

Mounting rails

Some HP ProLiant servers, such as ML570, require mounting rails. These may be metal or plastic rails attached to the server's drive bay filler panel.

Use a regular Phillips screwdriver to attach the appropriate rails. Use the M3 screws provided with the tape drive, in the screw pack labeled 'General Mounting Screws', as shown in Figure 5.




Figure 5 Attaching mounting rails in a typical HP ProLiant ML570


Ensure you do use the M3 screws provided. The rails may be attached to the filler panel by screws of a different thread/size type and these should not be used. If in doubt, refer to your HP ProLiant server documentation.

Mounting screws

Other HP ProLiant server models, such as ML350 and ML370, only require the use of special locating screws with no mounting rail.

Use a T8 Torx screwdriver to attach the appropriate screws. You may need to purchase the M3 screws separately. Position the screws, as shown in Figure 6.

- HP ProLiant ML350: Use M3 mounting screws. These have a thicker head than the general mounting screws.
- HP ProLiant ML350: Use the metal shims and screw pack labeled 'ProLiant 350'. These have a thicker head than the general mounting screws.
- HP ProLiant ML370: Use M3 offset mounting screws. These have a thick offset piece and a thicker head than the general mounting screws.
- HP ProLiant ML370: Use the metal shims and screw pack labeled 'ProLiant 370'. These have a thick offset piece and a thicker head than the general mounting screws.



- 1. Release catch
- 2. Push cover back and lift off

Figure 6 Attaching locating screws in a typical HP ProLiant 350 or 370

Other servers

Attach the appropriate mounting hardware. Refer to the manufacturer's documentation for instructions.

- If you are installing on a server that requires a tray, place the tape drive in the tray.
- Some servers have snap-on mounting rails attached to the filler panel. These can be removed and attached to the tape drive with screws.

Install drive

Slide the tape drive into the open bay, aligning the tray or rails with the slots in the bay, as shown in Figure 7.




Figure 7 Installing tape drive

If your server does not use mounting hardware, check that the holes in the chassis are aligned with the holes in the side of the tape drive.

Do not secure the drive at this point because you may have to move the drive to get the cables into place.

Attach power and SCSI cables

To support the high performance of the tape drive it is important that you connect to a recommended SCSI bus and use a suitably-rated SCSI cable, see Why is the SCSI bus type important?.


Electrical specifications are as follows.

	Ultrium 1840	Ultrium 960	Ultrium 460
Power consumption	13 Watts idle, 26 Watts typical, 40 Watts maximum	12 Watts idle, 30 Watts typical, 35 Watts maximum	 Watts idle, Watts typical, Watts maximum
Power requirements	+5V @ 1.9A typical +5V @ 3.9A maximum +12V @ 0.7A typical +12V @ 2.5A maximum	+5V @ 3.5A typical +5V @ 4.5A maximum +12V @ 1.0A typical +12V @ 2.0A maximum	+5V @ 3.5A typical +5V @ 4.0A maximum +12V @ 1.0A typical +12V @ 3.0A maximum

Table 4 Electrical specifications, internal drives

- 1. Check your server or HBA documentation to ensure that the SCSI bus and cabling supports the tape drive's bus speeds: Ultra320 for Ultrium 1840 and 960 tape drives, Ultra160 for Ultrium 460 tape drives.
- 2. Attach the SCSI ribbon cable supplied with the tape drive to the SCSI host bus adapter and connect it to the SCSI connector of the drive, as shown in Figure 8.
- **3.** Attach a spare power cable from the server's internal power supply to the power connector, as shown in Figure 8.
- 4. Attach a spare connector on the server's built-in SCSI bus or HBA's SCSI ribbon cable to the SCSI connector of the drive, as shown in Figure 8.
- 5. If the drive is the last device on the SCSI chain, make sure that the SCSI cable is terminated correctly.

Daisy-chaining two devices is not recommended. If you do so, do not mix drive families (only daisy-chain with other Ultrium tape drives) and do not daisy chain any Ultra320 devices. See also Table 2, "Supported SCSI bus types."



- 1 and 7 terminated SCSI cable
- 2 and 4 power cable
- 3 tape drive
- 5 server's power supply
- 6 SCSI controller

Figure 8 Connecting power and SCSI cables

Where should the SCSI terminator be?

Termination must be present at two and ONLY two positions on the SCSI bus—at the beginning of the SCSI bus and at the end of the SCSI bus. Termination is normally enabled by default on the HBA and most internal SCSI cables have a terminator attached. This will usually be a small, rectangular block of plastic attached to the cable end and marked 'SCSI Terminator'.

Therefore, assuming the HBA is the first device on the bus, you should check that the second terminator is placed after the last device, as shown in Figure 8, item 1.

Secure the drive


NOTE:

The server latches and side views of your server model may not be exactly the same as shown in the illustrations. Please refer also to you server documentation.

Mounting hardware used (HP ProLiant)

Ensure that you use the correct mounting rails or locating screws, as described in Attach mounting hardware. The server also incorporates a locking mechanism to hold the tape drive in place.

1. Push the server latch down to lock the tape drive into position, as shown in Figure 9.



- 1 Plastic rail
- 2 Server latch


Figure 9 Securing drive, mounting hardware used

2. Ensure blanking plates are in place over empty bays and replace the cover on the server.

No mounting hardware used

1. Use the M3 screws provided with the tape drive in the screw pack labeled 'General Mounting Screws'. Check that the holes in the chassis are aligned with the holes in the sides of the drive and use a regular Phillips screwdriver to secure the M3 screws, as shown in Figure 10.

If you cannot tighten the screws, use the washers provided in the pack.



1 M3 screws, supplied with tape drive

Figure 10 Securing drive, no mounting hardware used

2. Ensure blanking plates are in place over empty bays and replace the cover on the server.

4 Installing an external Ultrium tape drive

If you are installing an internal Ultrium tape drive, please refer to Installing an internal Ultrium tape drive.

If you are installing a removable Ultrium tape drive, please refer to Installing a removable Ultrium tape drive.

Check the drive's SCSI ID

Your HP StorageWorks Ultrium drive is shipped with a default SCSI ID of 3. Each device on the SCSI bus must have an unique SCSI ID number. The drive can be assigned any *unused* ID between 0 and 15. Do not use SCSI ID 7, which is reserved for the SCSI controller. SCSI ID 0 is typically assigned to the boot disk and should also not be used unless the tape drive is on a dedicated SCSI bus.




Figure 11 Setting the SCSI ID

1. Determine whether you need to change the SCSI ID from the default of 3.

For many operating systems you can install and run HP Library & Tape Tools from the HP StorageWorks Tape CD-ROM to check your server's current SCSI configuration. This will provide information about the SCSI bus and the SCSI IDs in use. To do this, select the 'troubleshoot with L&TT' option from the CD-ROM menu.

The UNIX Configuration Guide on the HP StorageWorks Tape CD-ROM also contains instructions on how to determine the SCSI IDs of existing devices on UNIX servers.

2. Change the tape drive's SCSI ID, if necessary.

Use a small screwdriver or a ball-point pen to press the indented SCSI ID selector buttons on the rear panel (see Figure 12) until the required value is displayed. Do not use a pencil because small bits of graphite could contaminate the drive.

NOTE:

The server and the tape drive SCSI IDs are only checked at power-on. To change the SCSI ID after installation, power down both the server and the tape drive, change the drive's SCSI ID, power up the tape drive, and then power up the server.


Connect the SCSI cable

A 68-pin, wide VHD-to-HD SCSI cable is provided to connect your HP StorageWorks Ultrium tape drive to a VHD SCSI port on an LVD SCSI bus. If your server has an HD SCSI port, you must either purchase and install a VHD-to-HD adapter or use an HD-to-HD cable instead of the supplied cable. Refer to our web site for recommended products: http://www.hp.com/go/connect.

\triangle CAUTION:

To avoid damaging the computer or tape drive, ensure that both are powered off while you attach the SCSI cable.

- 1. Make sure you are connecting to a recommended SCSI bus type. For optimum performance your tape drive should only be connected to a SCSI bus that can transfer data at a rate that supports the tape drive's maximum burst transfer speed. HP Ultrium 1840 and 960 tape drives should be connected to an Ultra320 SCSI bus. See alsoWhy is the SCSI bus type important?. Do not connect the tape drive to a single-ended SCSI bus or to RAID controller. For optimum performance, we recommend that your HP StorageWorks Ultrium drive is installed on a dedicated SCSI bus. If it is not, do not connect it to the same bus as your disk drive.
- 2. Perform a normal system shutdown and turn off the server and any connected peripherals.
- Attach the VHD connection on the SCSI cable to the server's external SCSI connector and secure it by tightening the screws.



1 Act TERM LED

2 Fan/Power LED

Figure 12 Connecting the SCSI cable

- Attach the HD connection on the SCSI cable to the SCSI-IN connector on the rear panel of the tape drive and secure it by tightening the screws. (See Figure 12.) Do not connect the cable to the SCSI-OUT connector.
- 5. The SCSI-OUT connector is only used when daisy-chaining two devices. This is not recommended. If you do so, do not mix drive families (only daisy-chain with other Ultrium tape drives) and do not put daisy chain Ultra320 tape drives. See also Table 2.

Does the tape drive need a terminator?

If the tape drive is on a dedicated SCSI bus, it does not require a terminator. When the cable is connected to the SCSI-IN connector, the enclosure provides active termination.

If it is not the only device on the SCSI bus, you must make sure that the SCSI bus is terminated. You can do this in two ways:

- Place the tape drive at the end of the chain and attach the HD connection on the SCSI cable to the SCSI-IN connector; the enclosure provides active termination.
- Attach the HD connection on the SCSI cable to the SCSI-IN connector and use the SCSI-OUT connector on the tape drive to connect to the next device in the chain. Make sure that the last device in the chain is terminated with an LVD multimode terminator

Connect the power cable


Electrical specification

No adjustment is needed. Electrical specifications are as follows.

Table 5 Electrical specifications, external drives

	Ultrium 1840	Ultrium 960	Ultrium 460
Power consumption	13 Watts idle,	12 Watts idle,	11 Watts idle,
	26 Watts typical,	30 Watts typical,	25 Watts typical,
	40 Watts maximum	35 Watts maximum	38 Watts maximum
Power requirements	100–240 VAC	100–240 VAC	100–240 VAC
	50-60 Hz, auto-ranging	50-60 Hz, auto-ranging	50-60 Hz, auto-ranging
	0.7A maximum	0.8A maximum	0.7A maximum

- 1. Plug the power cable securely into the socket on the rear panel of the drive.
- 2. Plug the other end of the power cable into the power outlet. The power on/off switch is on the front panel, see Figure 13.



- 1 Power cable
- 2 Power on/off switch

Figure 13 Connecting the power cable

5 Installing a removable Ultrium tape drive

If you are installing an internal Ultrium tape drive, please refer to Installing an internal Ultrium tape drive. If you are installing an external Ultrium tape drive, please refer to Installing an external Ultrium tape drive.

Which rackmount systems can I use?

HP StorageWorks Ultrium removable tape drives are used in conjunction with the HP Tape Array 5300 system, which can be used with both full-height and half-height tape drives. The tape array is designed to be installed into HP, IBM and other compatible 19" rackmount systems. It must be properly installed and configured. Refer to your tape array documentation for further details.

Electrical specification

Electrical specifications are as follows.

Table 6 Electrical specifications, removable drives

	Ultrium 1840	Ultrium 960	Ultrium 460
Power consumption	13 Watts idle, 26 Watts typical, 40 Watts maximum	12 Watts idle, 30 Watts typical, 35 Watts maximum	11 Watts idle, 25 Watts typical, 38 Watts maximum
Power requirements	100–240 VAC 50-60 Hz, auto-ranging 0.7A maximum	+5V @ 3.5A typical +5V @ 4.5A maximum +12V @ 1.0A typical +12V @ 2.0A typical	+5V @ 3.5A typical +5V @ 4.0A maximum +12V @ 1.0A typical +12V @ 3.0A typical

Airflow requirements

The HP Tape Array 5300 is designed to provide adequate airflow for up to two full-height tape drives (such as the Ultrium 1840, 960 or 460 tape drives) or up to four half-height tape drives. As long as the tape array is fully populated, it will provide adequate airflow for your HP StorageWorks Ultrium tape drives. If you have unused bays in the tape array, you must install the blanking plates provided with the tape array. This ensures that there is adequate airflow to the drives. See the documentation with the tape array for details on installing blanking plates.

You should ensure that ventilation is adequate at the front and rear of the tape array.

How do I connect the drive to my server?

The following guidelines apply:


- For optimum performance the drive should be the only device on the SCSI bus.
- If you daisy-chain devices, make sure that devices are of the same SCSI type and that each device on the same SCSI bus has a unique SCSI ID and is terminated appropriately. Do not daisy-chain more than two devices on the same SCSI bus.

- If you daisy-chain devices, make sure that devices are of the same SCSI type and that each device on the same SCSI bus has a unique SCSI ID and is terminated appropriately. Do not daisy-chain more than two devices on the same SCSI bus.
- Always terminate the SCSI bus.
- Do not attach the drive to the same SCSI bus as a your disk drive or to a RAID controller unless you are connecting to a ProLiant server with a Smart Array 6i RAID controller.

The individual tape drives are connected to their host server via the high density LVD/SE SCSI connectors on the back of the tape array. They do not require any SCSI cables to plug into the tape array. However, suitably-rated cabling and terminators are required to connect the tape array with the SCSI host.

Install the drive

1. Before installing a tape drive, make sure that the extractor lever is in the fully open position (pulled out).



1 Extractor lever, open

Figure 14 Extractor lever on tape drive fully open

\triangle CAUTION:

When handling a tape drive, hold the drive by the side carrier framework. To avoid possible damage, do not hold the body of the drive and do not push or pull on the tape drive's front panel.

2. Slide the tape drive into one of the open bays, ensuring that the guide rails on both sides of the drive locate into the slots on the partition wall. Carefully but firmly ensure the tape drive is pushed fully in so that the rear connectors are securely seated. The extractor level will close slightly.

NOTE:

Correct alignment of SCSI tape drives in the tape array is essential to ensure a secured connection is made between the interface of the drive and the interface of the array.

3. Push on the extractor lever to complete the insertion and to lock the tape drive in place.




Figure 15 Inserting the tape drive

4. If there are empty bays, insert a blanking plate. This is essential to ensure adequate airflow is maintained. Failure to do so may affect tape drive performance.

See the documentation with the tape array for details on installing blanking plates.

Set the drive's SCSI ID

To set the tape drive's SCSI ID you need to set the appropriate switch on the rear of the tape array. The number of address switches corresponds to the number of tape drives that can be inserted into the tape array.

Each device on the SCSI bus must have a unique SCSI ID.

- For HP ProLiant servers where the tape drive is connected to the built-in SCSI bus, we recommend that the tape drive is assigned a SCSI ID between 1 and 6.
- For all other servers and when used with separate HBAs, it can be assigned any *unused* ID between 0 and 15. Do not use SCSI ID 7, which is reserved for the SCSI controller. SCSI ID 0 is typically assigned to the boot disk and should also not be used unless the tape drive is on a dedicated SCSI bus.

Typically, the HP Tape Array may hold up to four tape drives where each drive is attached to a separate server. Under this configuration, the SCSI IDs of each tape drive will not conflict with each other as they are each installed onto a separate SCSI bus. This is the recommended configuration for Ultra320 devices, such as the Ultrium 1840 and Ultrium 960 tape drives.

If you daisy-chain devices make sure that the devices are of the same SCSI type and that each device on the same SCSI bus has a unique SCSI ID. Do not daisy-chain more than two devices on the same SCSI bus and make sure that the end device is terminated. Do not mix drive families (only daisy-chain with other Ultrium tape drives) and do not put Ultra160 drives on the same bus as any Ultra320 device.

1. Decide which SCSI ID to use.

For many operating systems you can install HP Library & Tape Tools from the HP StorageWorks Tape CD-ROM and run the "Install Check" to check your computer's current SCSI configuration (see Diagnostic tools). This will provide information about the SCSI bus and the SCSI IDs in use. The UNIX Configuration Guide on the HP StorageWorks Tape CD-ROM, also provides instructions on how to determine the SCSI IDs of existing devices.

2. Set the appropriate switch. Figure 16 shows the address switch on the back panel of the HP Tape Array 5300.

The HP Tape Array 5300 has four SCSI ID switches to enable the installation of up to four half-height drives. When installing two HP Ultrium full-height tape drives, use SCSI ID switches 1 and 2 only.




Figure 16 SCSI address switch on tape array

- Make sure that a SCSI terminator is attached to the appropriate SCSI-OUT connector on the back of the tape array.
- 4. Determine whether you need to change the SCSI ID from the default of 3.

Why does the tape drive need a terminator?

Terminators are essential, as they provide the correct voltages on the SCSI bus and prevent unwanted signal reflections from interfering with data transfers. The rule is:

There must be termination at both physical ends of the bus and only at the ends.

Normally the HBA forms one end of the SCSI bus and provides termination. You, therefore, need to ensure that the other end of the bus is terminated. Attach the terminator to the appropriate SCSI-OUT connector on the tape array.

Replacing the drive

HP StorageWorks Ultrium removable drives can be removed and replaced without powering down the tape array. However you should be aware of the following:

- If all drives in the tape array are powered up when the system is turned on, the host will be aware of those drives. You can remove any of those drives and replace it with another drive as long as there is no activity on the bus.
- Do not remove or add drives to a bus that already has drives connected and running, for example backing up or restoring data. Wait until there is no activity on the bus before removing or adding drives.
- If a drive is not powered up or you place a drive in an empty slot *after* the system has been powered up, the system will have to be reset before the host will recognize the drive.
- The SCSI IDs are controlled by the tape array, not by the drives themselves, so if you remove a drive and replace it with another the ID will not change.
- 1. Pull the extraction lever of the drive that you want to replace so that it is in the out position.




Figure 17 Extractor lever in out position

2. Using the extraction lever, pull the drive gently and firmly out of the tape array.




Figure 18 Removing the tape drive

3. To insert another drive, follow the instructions in Install the drive.

6 Verify installation

Once you have installed the drive hardware, check that drivers have been installed correctly and you have the correct version of backup software, and verify that the tape drive is functioning properly before you store your valuable data.

- 1. Switch on the drive and the server.
- 2. The tape drive will run its hardware self-test, which takes about 5 seconds. If self-test passes, the green Ready LED flashes and then shows steady green. If the test fails, the Drive Error and Tape Error LEDs flash, while the Ready and Clean LEDs are off. This continues until the drive is reset. See "Loading and unloading" on page 47 for more information about front panel lights.

• If you installed drivers before connecting the tape drive (Windows only)

The tape drive should be detected automatically and the correct drivers used. (See "Install drivers" on page 19.) If the Windows Found New Hardware wizard runs, cancel it - you can use Device Manager to check that the driver is installed.

Installing drivers after connecting the tape drive (Windows only)

If you have not already installed drivers, the Windows Found New Hardware wizard will run when you power on the server and tape drive. Either follow the on-screen instructions to search for the required driver on the HP StorageWorks CD-ROM or cancel the wizard and run the install package from the CD-ROM.

Installing drivers (other operating systems)

Drivers are included with the operating system and should be loaded automatically.

NOTE:

Certain backup applications require you to use their own Tape driver instead of the HP Ultrium Tape driver.

3. Verify that the tape drive installation was successful.

HP StorageWorks Library & Tape Tools (L&TT) is the recommended diagnostic and support tool for your HP tape drive. Use it to verify installation and confirm that your tape drive is functioning correctly before you use it for backup. It is available free at http://www.hp.com/support/tapetools.


- **4.** For all operating systems ensure that you have downloaded any upgrades necessary for your backup application. Check <u>http://www.hp.com/go/connect</u> for software compatibility and install any recommended upgrades.
- 5. Carry out a backup and restore test to check that the drive can write data to tape. Use a blank cartridge.

Windows Backup or Unix native backup applications can be used to check basic tape drive operation, but they will not support all the advanced features of your tape drive. We recommend that you upgrade your software application before running this test.

7 Understanding the LEDs

Your HP StorageWorks tape drive

See also "Understanding LED sequences" on page 43.



- 1. On/Off switch (external drives only)
- 2. Eject button

- 5. Drive LED
 6. Tape LED
- 3. Emergency reset button
- 4. Ready LED

- 7. Clean LED
- Figure 19 Front view of full-height Ultrium external tape drive

Understanding LED sequences

The meaning of different patterns of LEDs is as follows:

Table 7 LED sequences

LED Sequence	Cause	Action required
\bigcirc	Drive may not have power, may be faulty or may have been power cycled or reset during a firmware upgrade.	Make sure the drive is switched on.The power on/off switch on an external drive incorporates a green LED.
		Check the power cable connection and replace the cable if necessary. On external drives, you can use the power cable from your monitor or another device to check that the connection is working.
All LEDs OFF.		If the power supply is present and all LEDs remain off, power cycle or reset the drive (see "Problems with cartridges" on page 64). If it still fails, call for service.

LED Sequence	Cause	Action required
- - - - - - - - - - - - - - - - - - -	The drive has failed to execute power-on self test (POST).	Power cycle or reset the drive (see "Problems with cartridges" on page 64). If the error condition reappears, call for service.
 Ready is ON. 	The drive is ready for operation.	None. This is normal.
	The drive is carrying out a normal activity (read, write).	None. If the drive is upgrading firmware, do not reset or power cycle it.
	The drive is in OBDR mode.	See "Running HP OBDR" on page 56 for further details.
- - - - - - - - - - - - - -	The drive is downloading firmware.	None. Do not reset or power cycle the drive.

LED Sequence	Cause	Action required
•	Firmware is being reprogrammed.	None. Do not reset or power cycle the drive.
Ready is OFF, others are ON.		
 ○ ○ - ↓ Clean FLASHES. 	The drive requires cleaning.	Load the Ultrium cleaning cartridge. See "Cleaning cartridges" on page 49 for supported cartridges and instructions. If the Clean LED is still flashing when you load a new or known good data cartridge after cleaning, call for service.
	Cleaning is in progress.	None. The cleaning cartridge will eject on completion. The cleaning cycle can take up to 5 minutes to complete.
○ → → Tape FLASHES.	The drive believes the current tape or the tape just ejected is faulty.	Unload the tape cartridge. Make sure that you are using the correct format cartridge; an Ultrium data cartridge or Ultrium universal cleaning cartridge. (See "Use the correct media" on page 49.) Reload the cartridge. If the Tape LED still flashes or starts flashing during the next backup, load a new or known good cartridge. If the Tape LED is now off, discard the 'suspect' tape cartridge. If it is still on, call for service.
	The tape cartridge memory (CM) may be faulty.	Write-protect the cartridge by sliding the switch on the tape cartridge, see "Write protecting cartridges" on page 51. The tape can be loaded and the data read. Once the data is recovered, the cartridge must be discarded.


LED Sequence	Cause	Action required
 → → - → → → → - → → → → → → → - → → → → → → → → → → → → → → → → → → →	The drive mechanism has detected an error.	Load a new cartridge. If the error persists, power cycle or reset the drive. If the Drive LED remains on, call for service.
- - - - - - - - - - - - - - - - - - -	There is a firmware download problem.	Insert a cartridge to clear the LED sequence. If the condition persists, call for service.
 Orive and Ready ON with Tape and Clean OFF. Alternates repeatedly. 	The drive has a firmware error.	Power cycle or reset the drive. Upgrade the firmware. If the condition persists, call for service.

Table 8 Rear panel LED sequences

LED Sequence	Cause	Action required
All LEDs OFF.	The enclosure is not providing auto-termination.	Check that the drive's SCSI cable is connected to the SCSI-IN connector. Check whether a terminator or other SCSI cable is plugged into the SCSI-OUT connector. If a terminator is connected, remove it. If another SCSI cable is connected, make sure that the SCSI chain is terminated at the last device.
← → → → - → → - → - → - → - → - - → - - → - - - - - - - - - - - - -	There has been an enclosure failure or the cooling fan is not working correctly.	Call for service.

8 Operating your tape drive

Loading a cartridge



- 1. Arrow indicates leading direction
- 2. Label area

Figure 20 Inserting a cartridge


- 1. Insert the cartridge into the slot in the front of the drive with the white arrow uppermost and facing the drive door.
- 2. Apply gentle pressure until the drive takes the cartridge and loads it. (See Figure 20 on page 47.)
- 3. The Ready light flashes green while the drive performs its load sequence. When the cartridge is loaded, the Ready light shows steady green.

Unloading a cartridge

\triangle CAUTION:

Never try to remove a cartridge before it is fully ejected.

1. Press the Eject button on the front panel.



1. Eject button

Figure 21 Ejecting a cartridge

2. The drive will complete its current task, rewind the tape to the beginning, and eject the cartridge. The rewind process may take up to 10 minutes. The Ready light will flash to indicate that the unload is still in progress.

Removing power from the drive

To ensure reliable operation, do not remove power from the drive during read, write, fast-search, load and unload activities.

9 Use the correct media

For best performance we recommend HP branded media. Order online at: http://www.hp.com/go/storagemedia.

Cartridges

Cleaning cartridges

The recommended cleaning cartridges is the HP Ultrium universal cleaning cartridge, C7978A (Orange). This cleaning cartridge is designed to work with any Ultrium drive. It may be used for up to 50 cleans.

NOTE:

Do not use the earlier HP Ultrium cartridge, C7979A (Blue), or Ultrium cartridges from other manufacturers.

Data cartridges

HP StorageWorks Ultrium tape drives use Ultrium tape cartridges. These are single-reel cartridges that match your drive's format and are optimized for high capacity, throughput and reliability. Compatible media can be recognized by the Ultrium logo, which is the same as the logo on the front of your drive. Do not use other format cartridges in your tape drive and do not use Ultrium cartridges in other format tape drives.

For optimum performance always use a data cartridge that matches the specification of your tape drive, (see Table 9 on page 49). A lower specification will have a lower transfer speed and may not support write activities; a higher specification will not support read or write. HP recommends:

- Ultrium 1.6 TB RW* and Ultrium 1.6 TB* WORM tape cartridges for use with Ultrium 1840 tape drives.
- Ultrium 800 GB RW* and Ultrium 800 GB* WORM tape cartridges for use with Ultrium 960 tape drives.
- Ultrium 400 GB RW* and Ultrium 400 GB* WORM tape cartridges for use with Ultrium 460 tape drives.

Table 9	Data	cartridge	com	patibility	

Tape drive model	Ultrium 200 GB* data cartridge	Ultrium 400 GB* data cartridge	Ultrium 800 GB* and 800 GB* WORM data cartridge	Ultrium 1.6 TB* and 1.6 TB* WORM data cartridge
Ultrium 1840	not supported	read only	read/write	read/write (C7974A)write once/read many (C7974W)
Ultrium 960	read only	read/write	read/write (C7973A)write once/read many (C7973W)	not supported
Ultrium 460	read/write	read/write (C7972A)	not supported	not supported
	* Capacity assumes 2:1 compression.			

HP Ultrium WORM data cartridges

The HP StorageWorks Ultrium 1840 and 960 tape drive includes support for both re-writable and Write-Once, Read-Many, WORM, data cartridges. WORM cartridges provide for an enhanced level of data security against accidental or malicious alteration of data on the tape cartridge. The WORM data cartridge can be appended to maximize the full capacity of the tape cartridge, but the user will be unable to erase or overwrite data on the cartridge. Any attempt to modify a WORM cartridge to enable writing over existing data will result in the media becoming permanently write protected. It should still be readable in a WORM drive, depending upon the severity of the tampering, but no further appended backups will be possible.

WORM data cartridges are clearly identified by their distinctive, two-tone cartridge color. They can only be used with Ultrium tape drives that support the WORM feature.

To check whether your backup or archive software application supports WORM cartridges, refer to the following web site: <u>http://www.hp.com/go/connect</u>.

For information on how your HP Ultrium StorageWorks tape drive and WORM cartridge can help your business meet Information Lifecycle Management and regulatory compliance requirements, please refer to the HP Business Support Center at: <u>http://www.hp.com/go/bizsupport</u>.

Ultrium 1840 tape drives and encryption

Your Ultrium 1840 tape drive includes hardware capable of performing data encryption at full speed while writing data, and decrypting when reading.

Encryption is the process of changing data into a form that cannot be read until it is deciphered, protecting the data from unauthorized access and use. HP Ultrium 1840 tape drives use the strongest version of the industry-standard AES encrypting algorithm to protect your data. To make use of this feature you need:

- a backup application that supports hardware encryption
- Ultrium 1.6 TB media (C7974A or C7974W); no encryption will be performed when writing earlier generations of tape

When should I use encryption?

Your company policy will determine when you need to use encryption. For example, it may be mandatory for company confidential and financial data, but not for personal data. Company policy will also define how encryption keys should be generated and managed. Backup applications that support encryption will generate a key for you or allow you to enter a key manually.

NOTE:

Encryption with keys that are generated directly from passwords or passphrases may be less secure than encryption using truly random keys. Your application should explain the options and methods that are available. Please refer to your application's user documentation for more information.

How do I enable encryption?

Hardware encryption is turned off by default and is switched on by settings in your backup application, where you also generate and supply the encryption key. Your backup application must support hardware encryption for this feature to work. The software supplied with the tape drive provides this support. See http://www.hp.com/go/connect for an up-to-date list of other suitable backup software.

When will I be asked to enter the key?

Encryption is primarily designed to protect the media once it is offline and to prevent it being accessed from another machine. You will be able to read and append the encrypted media without being prompted for a key as long as it is being accessed by the machine and application that first encrypted it.

There are two main instances when you will need to know the key:

- If you try to import the media to another machine or another instance of the backup application
- If you are recovering your system after a disaster

What happens if I don't remember the key?

If you are unable to supply the key when requested to do so, neither you nor HP Support will be able to access the encrypted data.

This guarantees the security of your data, but also means that you must be careful in the management of the encryption key used to generate the tape.

▲ WARNING!

You should keep a record or backup of your encryption keys and store them in a secure place separate from the computer running the backup software.

Does encryption affect tape drive performance?

Hardware encryption can be used with or without compression and without speed or capacity penalties.

Does the tape drive encrypt media in an earlier Ultrium format?

No. Encryption is supported only on Ultrium 1.6 TB media (C7974A or C7974W).

Ultrium 1.6 TB tapes encrypted on an HP Ultrium 1840 drive can be read on any compatible Ultrium 1840 tape drive that supports hardware encryption.

HP Ultrium 1840 tape drives can read Ultrium 800 GB and Ultrium 400 GB media and write Ultrium 800 GB media, but hardware encryption is not supported on these formats.

Where can I get more information?

For more information about AES encryption, encryption keys, and using hardware encryption with your HP Ultrium 1840 tape drive, see the White Papers on http://h18006.www1.hp.com/storage/tapewhitepapers.html.

For detailed instructions about enabling encryption please refer to the documentation supplied with your backup application. This will also highlight any default states, for example when copying tapes, that may need changing if using encrypted tapes.


Write protecting cartridges

▲ WARNING!

Always remove the cartridge from the tape drive before you change the write protection.

If you want to protect the data on a cartridge from being altered or overwritten, you can write protect the cartridge.

- To write protect a cartridge, push the switch to the right to prevent any data recording on the cartridge. Note the padlock on the tab that indicates that the cartridge is protected.
- To write enable a cartridge, push the switch to the left to allow data recording on the cartridge. Figure 22 on page 52 illustrates the location of the write-protect tab.



1. Write-protect tab

Figure 22 Write protecting a cartridge

Write-protection will not protect your cartridges against magnets. Write-protection will not prevent a cartridge being erased by bulk-erasure or degaussing. Do **not** bulk erase Ultrium format cartridges. This will destroy pre-recorded servo information and make the cartridge unusable.

Cleaning the tape drive

You must use the Ultrium Universal cleaning cartridge with HP StorageWorks Ultrium tape drives, as other cleaning cartridges will not load and run.

To clean the tape drive:

HP StorageWorks Ultrium tape drives do not require regular cleaning. An Ultrium universal cleaning cartridge should only be used when the orange Clean LED is flashing.

- 1. Insert the Ultrium universal cleaning cartridge.
- The drive will carry out its cleaning cycle and eject the cartridge on completion (which can take up to 5 minutes). During the cleaning cycle the orange Clean LED will be on solidly and the green Ready LED will flash.

Each HP Ultrium universal cleaning cartridge cleaning cartridge (C7978A) can be used up to 50 times with Ultrium tape drives. If the cleaning cartridge is ejected immediately with the Tape LED on, it has expired.

Handling cartridges

- Do not touch the tape media.
- Do not attempt to clean the tape path or tape guides inside the cartridge.
- Do not leave cartridges in the drive. The tape loses tension in the power-off state, which can lead to problems, particularly if the drive has been moved.
- Do not leave cartridges in excessively dry or humid conditions.
- Do not leave cartridges in direct sunlight or in places where magnetic fields are present (for example, under telephones, next to monitors or near transformers).
- Do not drop cartridges or handle them roughly.
- Stick labels onto the label area only.
- Do not bulk erase (or degauss) Ultrium format cartridges because this will render them unusable.

Operating and storage environment

To prevent condensation and for long life, the cartridge should only be operated or stored as follows:

- Operation: 10 C to 45 C (50 F to 113 F)
- Day-to-day storage (in plastic container): 16 C to 32 C (60 F to 90 F)
- Non-condensing relative humidity: 10% to 80% (operating), 20% to 60% (non-operating)
- Wet bulb temperature should not exceed 26C (79F)

Tapes intended for long-term storage should be stored in the plastic containers, at temperatures between 5 C and 23 C (41 F and 73 F) and 20% to 60% relative humidity.

10 Using HP OBDR

Compatibility

HP One-Button Disaster Recovery is a standard feature on all HP StorageWorks Ultrium tape drives. However, it can only be used with specific configurations and will only recover the server to which the tape drive is directly connected.

To check whether your system (hardware, operating system and backup software) is OBDR-compatible, please refer to our World Wide Web site http://www.hp.com/go/connect.

For more specific information concerning the benefits of OBDR and the latest new features please refer to our World Wide Web site http://www.hp.com/go/obdr.

If your system does not support HP One-Button Disaster Recovery, you can still use your tape drive normally to back up and restore data. However, you must remember to create a separate set of emergency recovery disks for your operating system whenever you change your system configuration.

What does HP OBDR do?

Using just the tape drive and the most recent backup cartridge HP OBDR allows you to recover from the following types of system disaster:

- Hard disk failures, as long as the replacement hard disk is the same size or larger than the original and uses the same interface (for example, replace a SCSI hard disk with another SCSI disk)
- Hardware failures where the server is replaced by an identical component
- File corruption because of an operating system error
- File corruption because of an application software error
- Viruses that prevent you from booting your system correctly
- User errors that stop you from booting your system correctly

When you run HP One-Button Disaster Recovery, your tape drive goes through the following sequence:

- It goes into a special disaster recovery mode that enables it to restore your operating system and reboot. It acts like a bootable CD-ROM. (Your system's ability to boot from CD-ROM is normally enabled by default. If you have changed this setting, you will need to enable it again. Refer to your system BIOS manual for further details.)
- 2. It returns to normal tape drive mode and restores the data.

Remote disaster recovery (ProLiant servers only)

The HP Remote Insight Lights-Out Edition (RILOE) on ProLiant servers gives the IT Administrator the ability to completely recover a failed server at a remote location without physically traveling to where the server resides. The on-site non-technical person need only insert the bootable cartridge into the tape drive when asked to do so by the administrator.

Refer to the HP OBDR web site at <u>http://www.hp.com/go/obdr</u> for more information about using this feature and compatibility.

Testing for compatibility

We recommend that you perform a full backup and test disaster recovery as soon as possible after installation—if possible, onto a blank hard disk. If you do not have a blank hard disk and do not

want to overwrite your system, you can safely cancel the disaster recovery process at step 3 in the following procedure.

Refer to our connectivity web site (<u>http://www.hp.com/go/connect</u>) for more information about suitable backup applications.

Running HP OBDR

HP OBDR can only be used with backup applications that support one-button disaster recovery and methods of operating OBDR will vary between different software companies. Check our World Wide Web site (<u>http://www.hp.com/go/obdr</u>) for the latest information about software compatibility, firmware upgrades and troubleshooting before you use HP OBDR.

1. Insert the latest bootable cartridge in the tape drive. The cartridge must be written by a backup application that writes data to tape in CD-ROM format.





Figure 23 Inserting cartridge for OBDR

2. Hold down the eject button on the tape drive and keep it pressed down while power cycling the tape drive. This activates the HP One-Button Disaster Recovery process. Release the button as soon as the Ready LED on the front panel flashes in the OBDR sequence. This is a repeated pattern of: flashing-steady on-flashing.



1. **external drives only:** switch on tape drive before server

2. **all drives:** hold down eject button on tape drive and power on server

Figure 24 Keeping eject button pressed down, power on in OBDR mode

Keyboard shortcut for HP ProLiant servers

There is no need to press the Eject button. Just power on your server and press the [F8] function key during the Power On Self Test (POST). This invokes OBDR to restore your system. For more information and specific instructions please refer to our World Wide Web site at http://www.hp.com/go/obdr.

- 3. Follow the on-screen instructions to set up the operating system. Normally, you can accept the default response to all the prompts, for example just press <Enter>.
- 4. The LEDs will flash in OBDR mode (as described in step 2) while the tape drive restores your operating system to a state where it can run a normal data restore.
- 5. Once the operating system has been set up and rebooted, the Ready LED display on the tape drive changes to constant green and you can remove the backup cartridge, if you wish. You are now ready to run a normal data restore. Follow the normal process for your restore application.

If restore fails

If the restore fails for any reason, refer to our World Wide Web site (<u>http://www.hp.com/go/obdr</u>) and do a search on "OBDR" for detailed troubleshooting information.

11 Diagnostic Tools and Performance

Diagnostic tools

HP Library & Tape Tools

HP StorageWorks Library & Tape Tools is the recommended diagnostic and support tool for your HP tape storage product. It is available from a link on the CD shipped with your product or as a free download from the HP web site. It is supported on nearly all major operating systems.

HP recommends installation of Library & Tape Tools, so that it can be quickly accessed at any time. HP Support will also request that you use Library & Tape Tools should you need to contact them in the future, so it is a good idea to have it installed.

See <u>http://www.hp.com/support/tapetools</u> for compatibility information, updates and the latest version of the tool.

Troubleshooting with Library & Tape Tools

- 1. When Library & Tape Tools is first run, it will scan for HP tape drives and libraries on your system and ask you to select the one to work with. At this time you can see the HBA configuration of your server and how your devices are connected.
- 2. Once you have selected your device you have a number of choices for troubleshooting.
 - Device identification: shows part number, serial number and information about any cartridge loaded.
 - Firmware upgrade: allows you to locate and upgrade to the latest firmware. You will need to be connected to the internet for this.
 - Run tests: allows you to run proactive tests on your drive, such as the drive assessment test, which will verify the functionality of your drive in around 20 minutes. HP recommends running this test before calling HP Support. You will need to provide a 'trusted' cartridge that can be written to during this test.
 - Generate a support ticket: this is a full dump of the drive logs along with interpretation and is used by HP Support to learn about the condition of your drive. Most useful is the device analysis section which is the output from approximately 20 rules forming a comprehensive analysis of the health of your drive. These rules may give advice such as cleaning the head or trying a different tape if issues are found. The support ticket can be sent to HP Support for further analysis.
 - Run the performance tests: the tests to measure the write/read performance of your tape drive and the data generation rates of your disk subsystem are also integrated into Library & Tape Tools. Use these tests to find the performance bottleneck in your system.

Performance Assessment Tools

NOTE:

We strongly recommend that you check the information on our web site at http://www.hp.com/support/ pat. This contains detailed support information that will enable you to identify bottlenecks and take full advantage of the performance capabilities of the Ultrium family of tape drives. You can use our free, standalone performance assessment tools to check tape performance and test whether your disk subsystem can supply data at the maximum transfer rate.

The tools are located online at <u>http://www.hp.com/support/pat</u>. They are also integrated into HP Library & Tape Tools, which is available both online (<u>http://www.hp.com/support/tapetools</u>) and on the CD-ROM supplied with your tape drive.

Optimizing performance

Various factors can affect tape drive performance, particularly in a network environment. In nearly all cases when performance is not as expected, it is the data rates of the disk subsystem that cause the bottleneck.

If your tape drive is not performing as well as expected—for example, if backup windows are longer than expected—please try the tools and consider the following points before contacting HP Support at http://www.hp.com/support.

Can your system deliver the required performance?

- The Ultrium 1840 tape drive can write uncompressed data at up to 120 MB/s (432 GB/hour)
- The Ultrium 960 tape drive can write uncompressed data at up to 80 MB/s (288 GB/hour)
- The Ultrium 460 tape drive can write uncompressed data at up to 30 MB/s (108 GB/hour)

To obtain this performance it is essential that your whole system can deliver this performance. In most cases, the backup application will provide details of the average time taken at the end of the backup.

Typical areas where bottlenecks can occur are:

Disk subsystem

A single spindle disk will not be able to deliver good data throughput for an Ultrium 1840 or 960 tape drive at any compression ratio. To maximize the capability of these tape drives, utilize aggregated disk sources (RAID) with multiple disk spindles.

A single spindle disk may be sufficient for an Ultrium 460 tape drive, depending on your data's compressibility. Best practice to ensure good throughput is to utilize multiple disk spindles or data sources.

System architecture

Be aware of the architecture of your data protection environment; multiple clients backed up over a network may mean you are unable to take advantage of the Ultrium 1840 or 960 tape drive because the Ethernet infrastructure connecting such systems may limit performance.

For Ultrium 460 tape drives, the aggregation of multiple client sources over a network provides a good way of delivering good performance, but anything less than Gigabit Ethernet may limit performance.

Some enterprise class backup applications can be made to interleave data from multiple sources, such as clients or disks, to keep the tape drive working at optimum performance.

• Tape media type

The data cartridge should match the specification of the tape drive. A lower specification will have a lower transfer speed (see "Data cartridges" on page).

Use Ultrium 1.6 TB or Ultrium WORM 1.6 TB cartridges with Ultrium 1840 tape drives, Ultrium 800 GB or Ultrium WORM 800 GB cartridges with Ultrium 960 tape drives, and Ultrium 400 GB or Ultrium WORM 400 GB cartridges with Ultrium 460 tape drives.

Data and file types

The type of data being backed up or restored can affect performance. Typically, small files incur greater overhead in processing and access than large files. Equally, data that is not compressible

will always limit the speed at which the drive can write/read data. You will achieve no more than native rates with uncompressible data.

Examples of files that compress well are plain text files, spreadsheets; those that compress poorly are those that are either compressed as part of their format (such as, JPEG photographic files) or stored as compressed (such as, .ZIP files or .gz/.Z files on Unix platforms).

12 Troubleshooting

Many users can use HP Library & Tape Tools to help them diagnose problems, see "Diagnostic tools " on page 59. We also recommend the detailed troubleshooting guide at <u>http://www.hp.com/go/support</u> for comprehensive troubleshooting information.

General Procedure

If a problem occurs, the first step is to try to establish whether the problem lies with the cartridge, the drive, the host computer and connections, or the way the system is being operated.

Has the system just been installed?

There could be an installation problem:

- 1. Check through the information in the relevant installation chapter of this guide.
- 2. Check the power connectors and SCSI cabling.
- Is the SCSI ID correctly set? Is there a SCSI system conflict? Has the SCSI bus been corretly terminated? See also
- 4. Are appropriate drivers and application software installed on the host?
- 5. Check the environmental conditions against the specified limits.

Table 10 Environmental specifications for Ultrium tape drives

	Temperature range	Non-condensing humidity range	
Operating	50 to 95 F (10 to 40 C) at a minimum of 6 CFM airflow	20 to 80% RH (non-condensing)	
Storage	-40 to 151 F (-40 to 66 C)	10 to 95% RH (non-condensing)	

Are you using new cartridges or a different brand of cartridge? Have you been using the particular cartridge for a very long time?

The problem could lie with the cartridge:

- 1. Check through the media chapter on "Use the correct media" on page 49.
- 2. Check that you are using an Ultrium cartridge. Compatible media can be recognized by the Ultrium logo, which is the same as the logo on the front of your drive.
- **3.** Use the correct media type, for example:
 - Ultrium 1.6 TB RW* (C7974A) and Ultrium 1.6 TB* WORM (C7974W) tape cartridges for use with Ultrium 1840 tape drives.
 - Ultrium 800 GB RW* (C7973A) and Ultrium 800 GB* WORM (C7973W) tape cartridges for use with Ultrium 960 tape drives.
 - Ultrium 400 GB RW* (C7972A) tape cartridges for use with Ultrium 460 tape drives.
- 4. Has the cartridge been write-protected, see "Write protecting cartridges" on page 51?
- 5. Clean the tape heads with the cleaning cartridge, see "Cleaning cartridges" on page 49. Make sure you are using the HP Ultrium Universal cleaning cartridge, C7978A.
- 6. Try the operation again.
- 7. If the problem still occurs, try using a different cartridge.
- 8. If the problem is still there, the problem probably lies with the drive or the host computer.

Has the drive been moved recently? Have any cables been disconnected and reconnected? Has the environment changed—unusually hot, cold, damp or dry? Has there been dust or dirt near the drive. Have reasonable precautions against static been taken?

The problem could lie with the drive:

- 1. Check the cables and connectors.
- 2. Clean the tape heads with the cleaning cartridge.
- 3. If the problem persists, check the environmental conditions against the specified limits, see table above or refer to http://www.hp.com. Perhaps move the drive to a more suitable site.

Has a new operating system been installed in the host computer? Has new backup software been installed?

The problem could lie with the host or the software. Consult the computer's operating manuals, the software manual, or seek help from a service engineer.

Problems with cartridges

If you experience any problems using HP branded cartridges, check:

- The cartridge case is intact and that it contains no splits, cracks or damage.
- The cartridge has been stored at the correct temperature and humidity. This prevents condensation. See the insert included with the tape cartridge for storage conditions.
- The write-protect switch is fully operational. It should move from side to side with a positive click.
- The World Wide Web site for more detailed troubleshooting information: http://www.hp.com/support.

The cartridge is jammed

If the cartridge is jammed or the backup application is unable to eject it, you can force eject the cartridge. Once the cartridge is successfully ejected, it is good practice to run Library & Tape Tools to diagnose the problem and to upgrade the firmware. If the failure occurs regularly, contact customer service at http://www.hp.com/support.

- 1. Either press and hold the Eject button on the front of the tape drive for at least 10 seconds.
- 2. Wait for the cartridge to be ejected. This process may take up to 10 minutes (the maximum rewind time). It is important that you allow sufficient time for the drive to complete this process. If you interrupt it, you may damage the media or the tape drive. The drive is then reset as though you had turned the power off and then on again.

You may lose data if you force eject a cartridge. The tape may also become unreadable because an EOD (End of Data) mark may not be properly written.

3. If the cartridge is still jammed, the tape drive has failed. Contact customer service at http://www.hp.com/support.

Emergency reset

As a last resort, if the drive has disappeared from the system and appears to have failed, it can be reset by pressing the emergency reset button, Figure 1 on page 13. (Use the tip of a paperclip to press the button.) This will allow the drive to reset its internal hardware, including the SAS port, and potentially make it visible to a host again.

The reset process may take up to 10 minutes (the maximum rewind time) to complete.

NOTE:

This form of reset will clear the internal buffers and, therefore, lose any data in them. If the drive was writing at the time, data may be lost and the cartridge will not have an EOD, which means that subsequent restores are likely to fail. Discard the cartridge.

The drive will not accept the cartridge (or ejects it immediately)

The cartridge may have been damaged, for example dropped, or the drive may have a fault. If it is a cleaning cartridge, it has probably expired and should be discarded immediately. For data cartridges:

- 1. Check that the drive has power (the power cable is properly connected and the Ready LED is on).
- 2. Check that you are using the correct media. Use only Ultrium media, (see "Data cartridges" on page).
 - Ultrium 1.6 TB RW* (C7974A) and Ultrium 1.6 TB* WORM (C7974W) tape cartridges for use with Ultrium 1840 tape drives.
 - Ultrium 800 GB RW* (C7973A) and Ultrium 800 GB* WORM (C7973W) tape cartridges for use with Ultrium 960 tape drives.
 - Ultrium 400 GB RW* (C7972A) tape cartridges for use with Ultrium 460 tape drives.
- 3. Make sure that you have loaded the cartridge with the correct orientation (see "Loading and unloading" on page 47).
- 4. Check for damage to your media and discard it if it is damaged.
- 5. Use a new or known, good piece of media and see if it loads. If it does, the original cartridge is faulty and should be discarded.
- 6. Check if another Ultrium drive of the same model will accept the cartridge. If it does, the original drive may be faulty. Before calling customer service, please check that the tape drive is responding. See "Troubleshooting with Library & Tape Tools" on page 59.

13 Replacing a tape drive

If your tape drive proves to be faulty and cannot be repaired and it is still covered by the original warranty, it will be replaced. HP will provide a replacement tape drive free of charge. Based on availability and where geography permits, the replacement tape drive will be shipped for next business day delivery. Same day or four-hour delivery may be offered at an additional charge where geography permits. If you request HP to install the replacement tape drive, you will be charged for the travel and labor costs of this service.

To disconnect your drive

- 1. Unpack your replacement drive, and retain the packaging.
- 2. Power off the server and disconnect from the mains power supply.
- 3. Remove the cover from the server.
- 4. Observing normal anti-static precautions remove any screws that are holding the tape drive in place.
- 5. Disconnect the drive from the server's power and SAS cables and slide it carefully out of the mounting bay.
- 6. Put the drive into the packaging that contained the replacement drive.
- 7. Return the faulty drive to your local HP Service Center. Instructions on where to return faulty drives will be shipped with the replacement drive. You must ship the defective drive back to HP within a defined period of time, normally five (5) business days. The defective part must be returned with the associated documentation in the provided shipping material. Failure to return the defective part may result in HP billing you for the replacement. HP will pay all shipping and part return costs and determine the courier/carrier to be used.

NOTE:

If you are not replacing the drive immediately, you should insert a blanking plate into the empty bay. Replace the cover on the server and secure with screws, as appropriate.

To reconnect your tape drive

Follow the step-by-step instructions in this User Guide.

See complete HP limited warranty statement at: <u>http://h18006.www1.hp.com/products/storageworks/</u> warranty.html

A SCSI configuration guide

SCSI in HP StorageWorks Ultrium devices

HP StorageWorks Ultrium 1840 and 960 tape drives are high performance Ultra320 SCSI compatible devices; HP StorageWorks Ultrium 460 tape drives are high performance Ultra160 SCSI compatible devices.

They are designed to operate on a low voltage differential (LVD) SCSI interface and are not compatible with high voltage differential (HVD) SCSI devices.

Ultrium 1840 and 960 tape drives support a burst transfer rate of 320 MB/sec; Ultrium 460 tape drives support a burst transfer rate of 160 MB/sec.

To benefit from this level of performance, it is important to ensure that the drives are connected to a SCSI bus of a similar or higher specification. This means that you need:

 An Ultra320 bus for HP Ultrium 1840 and 960 tape drives. An Ultra160 or Ultra320 bus for HP Ultrium 460 tape drives.

If you attach the drive to a lower specification SCSI bus, it will still work but data may not be transferred as quickly. Ultra2 SCSI is also supported, but performance may be degraded.

• **LVD-rated SCSI cabling and terminators.** The LVD interface enables the data to be transferred at the drive's maximum rate and provides a maximum cable length of 12 meters.

Daisy chaining devices

NOTE:

We do not recommend daisy chaining the HP StorageWorks Ultrium 1840 and 960 tape drive with other devices.

If you need to connect multiple devices to the bus, performance may be restricted if there are too many devices on the bus that are accessed simultaneously. Connecting devices of lower SCSI specification, such as Ultra2 or Ultra SCSI, may also restrict performance to your tape drive. Using Single Ended 8-Bit SCSI devices on the same bus is not recommended, as performance will be severely impacted and complicated bus configuration is required to overcome bus termination issues.

Make sure that the last device on the SCSI bus is terminated. HP recommends that you do not attach the tape drive to the same SCSI bus as the disk drive. See <u>SCSI termination</u> for more information about terminating HP StorageWorks Ultrium tape drives.

SCSI terminology

SCSI is a bus interface: all the devices are connected to a single cable (some of this may be inside and some outside the host computer's case). The connection to the host itself is known as the Host Bus Adapter (HBA). You can have several HBAs in a single computer, each with its own SCSI bus: this is a common arrangement in high-performance servers. Some host bus adapters (such as the LSI Logic LSI22320-R) have more than one SCSI bus available on a single card.

Various terms are used when describing SCSI devices. These terms relate to the factors that affect performance and cable length:

- The speed of the data bus, which may be Fast, Ultra, Ultra2, Ultra3, Ultra160 or Ultra320.
- The width of the data bus, which may be Narrow or Wide (16-Bit or 8-Bit).

• The voltage level of the interface, which may be single-ended (SE) or low voltage differential (LVD).

Setting up the SCSI bus

Each device on a SCSI bus, including the SCSI host bus adapter (HBA), must be configured with a unique ID (identifier). The SCSI bus must be terminated.

NOTE:

HP recommends that a dedicated host bus adapter is used for the tape drive. A suitable adapter is available from HP as an accessory (see http://www.hp.com/go/connect.

SCSI ID numbers

For wide SCSI buses, the SCSI ID will be a number from 0 through 15, so a typical wide SCSI HBA can accommodate up to fifteen other devices. (On narrow SCSI buses, the SCSI ID is a number from 0 through 7.)

Narrow: 7 6 5 4 3 2 1 0 High _____ priority ____ Low Wide: 7 6 5 4 3 2 1 0 15 14 13 12 11 10 9 8

Each device must have a unique SCSI ID. The drive can be assigned any unused ID between 0 and 15. Do not use SCSI ID 7, which is reserved for the SCSI controller. SCSI ID 0 is typically assigned to the boot disk and should also not be used unless the tape drive is on a dedicated SCSI bus.

SCSI ID 7 is normally reserved for the HBA because it has the highest priority on the bus. On wide buses, the priority runs from 7 (highest) to 0, then 15 down to 8 (lowest).

NOTE:

As a general rule, avoid putting tape devices on the same bus as any hard disks.

Identifying SCSI IDs

If your computer already has devices connected to the SCSI bus, you will need to know their IDs to avoid any conflict with the new tape drive. Here are some methods of finding out the information:

- The fastest and easiest way is to run HP Library & Tape Tools from the HP StorageWorks CD-ROM. HP Library & Tape Tools will check your SCSI configuration, including the SCSI controller itself and any devices currently attached to it.
- Most computers display a list of SCSI devices and IDs during the boot-up process. This usually
 scrolls past very fast. If you press the [Pause] key, you should be able to halt the scrolling and
 view the list.
- On Windows systems, you can use Device Manager.
- If you have Novell NetWare installed, use its LIST DEVICES command.

If none of these is available to you, try the following sources of information:

- The details of all installed devices and settings may have been written down and stored with your computer's documentation (for new computers, this is often done by the supplier).
- Your HBA's documentation should tell you which settings it uses.
- Look at each device to find out its ID. This is usually easy with external devices. With internal
 devices, you will probably need the help of the device's documentation to identify the SCSI
 ID setting, which is usually set with jumpers.

Setting the SCSI ID on HP StorageWorks Ultrium drives

Note that host adapters check SCSI IDs only at power-on, so any changes will not take effect until the host system is power-cycled.

- On internal HP StorageWorks drives, set the SCSI ID by attaching or removing jumpers at the rear of the drive, see Check the drive SCSI ID.
- On external HP StorageWorks drives, the ID is displayed on the rear panel and can be set by
 pressing the little buttons above and below the number (using a ball point pen), see Check
 the drive's SCSI ID.
- On removable HP StorageWorks drives, the ID is set on the back of the tape array, see Set the drive's SCSI ID.

SCSI termination

Terminators are essential, as they provide the correct voltages on the SCSI bus and prevent unwanted signal reflections from interfering with data transfers. The rule is:

PNOTE:

There must be termination at both physical ends of the bus and only at the ends.

There are two main types of termination, active and passive. Active terminators reduce interference and allow faster data throughput. On devices with high transfer speeds, such as HP StorageWorks Ultrium devices, active termination is required, using an LVD or multimode active terminator. (Multimode terminators allow both LVD and single-ended devices to be connected to the same bus. They detect the type of bus and automatically supply the correct termination.)

Normally the HBA forms one end of the SCSI bus and provides termination. You only need to ensure that the other end of the bus is terminated.

Removable drives

For HP StorageWorks Ultrium removable tape drives, termination is provided by connecting a terminator to the spare SCSI connector on the rear of the tape array. There are two connectors for each bay in the tape array. It does not matter which is used for SCSI-IN and SCSI-OUT.

If you have each removable drive in the tape array attached to a separate bus, then, for each bay in use, you must attach a terminator to the spare connector for each device.

If you are using the removable drives to mirror backups, you can daisy-chain devices (but no more than two on each SCSI bus). Connect an LVD-rated cable from the spare SCSI connector for the first device to one of the SCSI connectors for the second device and attach the terminator to the spare SCSI connector for the second device.

Refer to your tape array documentation for detailed instructions.

Internal drives

HP StorageWorks Ultrium internal tape drives do not supply termination. A suitably terminated LVD internal ribbon cable is supplied with the tape drive. The terminator is usually a small, rectangular block of plastic attached to the cable end and marked 'SCSI Terminator'.




Figure 25 SCSI termination in internal drives

As long as this terminator is attached, you do not need to take any further action. However, if you have other devices attached to the cable, make sure that they have termination removed or disabled.

NOTE:

If you have an internal and external device attached to the same SCSI bus, the HBA will be in the middle of the cable and thus its termination must be disabled. See the host bus adapter's documentation for details of how to do this.

External drives

For HP StorageWorks Ultrium external tape drives the enclosure provides active termination.

As long as the drive is the only device on the SCSI chain, no terminators are required. The green ACT Term LED on the rear of the drive indicates whether auto-termination is active (on) or not (off).

Make sure the terminator is firmly attached to the SCSI-OUT connector on the rear of the device when you install it.




Figure 26 SCSI termination on a single Ultrium tape drive

If you have more than one device on the SCSI bus, daisy-chain them by connecting an LVD-rated cable from the SCSI-OUT connector on the first device to the SCSI-IN connector on the second device. Assuming you have two Ultrium tape drives connected, the enclosure on the second drive provides termination. The green ACT Term LED on the rear of the first drive will be off while on the rear of the second drive it will be on. If the second device is not an Ultrium external drive, make sure that it is terminated using an LVD-rated multimode terminator.




Figure 27 SCSI termination in daisy-chained external drives

SCSI cables

Cables matter in SCSI systems. There are two factors to consider: cable length and cable quality.

Cable length

- For LVD SCSI the maximum length for a single device is 25 meters. For multiple devices, the maximum combined internal/external length is 12 meters.
- If you have a combination of LVD and SE devices on the bus, the maximum cable length reverts to the SE specification. This is 3 meters for four or fewer devices, and 1.5 meters for more than four devices. See also note below on SE and LVD interfaces.
- For best performance, keep lengths to a minimum, but avoid very short overall lengths (less than 0.5 meters).

Cable quality

- It is important to use good quality cables. Generally speaking, cable quality affects performance and reliability. This is particularly true for external, shielded cables.
- Look after your SCSI cables. In particular, take care when connecting or disconnecting not to damage the high-density connectors. Avoid putting excessive twists in external shielded cables, as this can cause premature failure.

With internal devices

HP StorageWorks Ultrium tape drives have a 68-pin wide, high-density SCSI connector. A suitable cable with the correct termination is supplied with the tape drive. If you are using an HP StorageWorks Ultrium drive on an internal bus with other peripherals that run at Ultra2 speeds, it is important that a 68-pin LVD-compatible ribbon cable is used. Do not connect your tape drive to lower-rated SCSI or to narrow SCSI.

With external devices

The cable provided with all HP StorageWorks Ultrium external tape drives will attach to a computer with a wide, very high density (VHD), LVDS SCSI connector.

If your server or host bus adapter is equipped with a high density (HD) wide SCSI connector, you will need to order a 68-pin VHD-to-HD converter or 68-pin VHD-to-HD cable. See http://www.hp.com/go/connect.

With removable devices

For HP StorageWorks Ultrium removable tape drives, appropriate cables and terminators are provided with the tape array.

Note on SE and LVD interfaces

SE and LVD define how the signals are transmitted along the cable.

- With single-ended (SE) SCSI, each signal travels over a single wire and each signal's value is determined by comparing the signal to a paired ground wire. Signal quality tends to decrease over longer cable lengths or at increased signal speed.
- With low voltage differential (LVD) signaling, signals travel along two wires and the difference in voltage between the wire pairs determines the signal value. This enables faster data rates and longer cabling with less susceptibility to noise than SE signaling and reduced power consumption.

If you use LVD SCSI devices on the same bus as single-ended devices this will switch the LVD SCSI host adapter into single-ended mode and restrict cable length.

If you connect only LVD SCSI devices, the bus will operate in low voltage differential mode and Ultra160 and higher speeds will be enabled. If you use a combination of Ultra160 and Ultra2 devices, each device will operate at its optimum speed.