



Maintenance and Service Guide

8200 Elite Series Convertible Minitower

8200 Elite Series Microtower

8200 Elite Series Small Form Factor

8200 Elite Series Ultra-Slim Desktop

6200 Pro Series Microtower

6200 Pro Series Small Form Factor

© Copyright 2011 Hewlett-Packard Development Company, L.P. The information contained herein is subject to change without notice.

Microsoft and Windows are trademarks of Microsoft Corporation in the U.S. and other countries.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

This document contains proprietary information that is protected by copyright. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Hewlett-Packard Company.

HP Compaq Business PC Maintenance and Guide

8200 Elite Series Convertible Minitower

8200 Elite Series Microtower

8200 Elite Series Small Form Factor

8200 Elite Series Ultra-Slim Desktop


6200 Pro Series Microtower


6200 Pro Series Small Form Factor

First Edition (March 2011)

Document Part Number: 649701-001

About This Book

 **WARNING!** Text set off in this manner indicates that failure to follow directions could result in bodily harm or loss of life.

 **CAUTION:** Text set off in this manner indicates that failure to follow directions could result in damage to equipment or loss of information.

 **NOTE:** Text set off in this manner provides important supplemental information.

Table of contents

1 Installing and Customizing the Software	1
Installing the Windows Operating System	1
Downloading Microsoft Windows Updates	1
Installing or Upgrading Device Drivers (Windows systems)	2
Customizing the Monitor Display (Windows systems)	2
Launching Windows XP from Windows 7	2
Accessing Disk Image (ISO) Files	2
 2 Computer Setup (F10) Utility	 4
Computer Setup (F10) Utilities	4
Using Computer Setup (F10) Utilities	5
Computer Setup—File	6
Computer Setup—Storage	7
Computer Setup—Security	9
Computer Setup—Power	13
Computer Setup—Advanced	14
Recovering the Configuration Settings	16
 3 Illustrated parts catalog	 17
Convertible minitower (CMT) chassis spare parts	17
Computer system components	17
Cables	18
Misc parts	19
Drives	20
Misc boards	21
Sequential part number listing	21
Microtower (MT) chassis spare parts	27
Computer major components	27
Cables	29
Misc parts	30
Drives	31

Misc boards	31
Sequential part number listing	32
Ultra-Slim Desktop (USDT) chassis spare parts	38
Computer major components	38
Cables	39
Misc parts	40
Drives	41
Misc boards	42
Sequential part number listing	42
Small Form Factor (SFF) chassis spare parts	47
Computer major components	47
Cables	49
Misc parts	50
Drives	51
Misc boards	52
Sequential part number listing	53
4 Routine Care, SATA Drive Guidelines, and Disassembly Preparation	59
Electrostatic Discharge Information	60
Generating Static	60
Preventing Electrostatic Damage to Equipment	60
Personal Grounding Methods and Equipment	61
Grounding the Work Area	61
Recommended Materials and Equipment	61
Operating Guidelines	62
Routine Care	63
General Cleaning Safety Precautions	63
Cleaning the Computer Case	63
Cleaning the Keyboard	63
Cleaning the Monitor	64
Cleaning the Mouse	64
Service Considerations	64
Power Supply Fan	64
Tools and Software Requirements	65
Screws	65
Cables and Connectors	65
Hard Drives	65
Lithium Coin Cell Battery	66
SATA Hard Drives	67
SATA Hard Drive Cables	67
SATA Data Cable	67

SMART ATA Drives	67
Cable Management	67
Hard Drive Capacities	68
5 Configurations and Serial Number	69
Standard Configuration Features	69
Serial Number Location	71
6 Removal and Replacement Procedures – Convertible Minitower (CMT) Chassis	73
Preparation for Disassembly	73
Computer Access Panel	74
Front Bezel	75
Front Bezel Security	76
Bezel Blanks	77
System Board Connections	78
Memory	79
DIMMs	79
DDR3-SDRAM DIMMs	79
Populating DIMM Sockets	80
Installing DIMMs	81
Expansion Card	83
Drives	87
Drive Positions	88
Removing a Drive from a Drive Bay	89
Installing Drives	92
Installing a 5.25-inch Drive into a Drive Bay	93
Installing a Hard Drive into an Internal Drive Bay	95
Installing a 3.5-inch SATA Hard Drive into an Internal Drive Bay	100
Removing and Replacing a Removable 3.5-inch SATA Hard Drive	101
Hood Sensor	106
Front I/O, USB Assembly	107
Power Switch Assembly	109
Speaker	110
Rear Chassis Fan	111
Fan sink	112
Processor	114
Power Supply	117
System Board	118
Changing from a Minitower to a Desktop Configuration	120
Changing from a Desktop to a Minitower Configuration	122

7 Removal and Replacement Procedures – Microtower (MT) Chassis	125
Preparation for Disassembly	125
Computer Access Panel	126
Front Bezel	127
Bezel Blanks	128
System Board Connections	128
Memory	131
DIMMs	131
DDR3-SDRAM DIMMs	131
Populating DIMM Sockets	132
Installing DIMMs	132
Expansion Cards	134
Drive Positions	138
Drives	139
Removing a 5.25-inch or 3.5-inch Drive from a Drive Bay	141
Installing a 5.25-inch or 3.5-inch Drive into a Drive Bay	142
Removing a Hard Drive from a Drive Bay	144
Installing a Hard Drive into an Internal Drive Bay	145
Front Fan Assembly	149
Front I/O Assembly	151
Power Switch/LED Assembly	152
Heat sink	153
Processor	155
Speaker	158
Rear Chassis Fan	159
Power Supply	161
System Board	163
 8 Removal and Replacement Procedures – Small Form Factor (SFF) Chassis	 165
Preparation for Disassembly	165
Access Panel	166
Front Bezel	167
Bezel Blanks	168
Memory	168
DIMMs	168
DDR3-SDRAM DIMMs	169
Populating DIMM Sockets	169
Installing DIMMs	170
Expansion Card	172
System Board Connections	176
Drives	178

Drive Positions	179
Installing and Removing Drives	180
Removing a 5.25-inch Drive from a Drive Bay	181
Installing a 5.25-inch Drive into a Drive Bay	182
Removing a 3.5-inch Drive from a Drive Bay	183
Installing a 3.5-inch Drive into a Drive Bay	184
Removing and Replacing the Primary 3.5-inch Internal Hard Drive	186
Fan duct	189
Front Fan Assembly	190
Hood Sensor	192
Front I/O, Power Switch Assembly	193
Speaker	195
Heat sink	196
Processor	198
Power Supply	201
System Board	203
Using the Small Form Factor Computer in a Tower Orientation	205
9 Removal and Replacement Procedures – Ultra-Slim Desktop (USD) Chassis	206
Preparation for Disassembly	206
Access Panel	207
Front Bezel	208
Bezel Blank	209
System Board Connections	210
Memory	211
SODIMMs	211
DDR3-SDRAM SODIMMs	211
Populating SODIMM Sockets	212
Installing SODIMMs	213
Front Fan	215
Optical Drive	216
Removing the Optical Drive	216
Preparing the New Optical Drive	217
Installing the New Optical Drive	218
Hard Drive	219
Optical Drive Rail	223
Card Reader	224
Speaker	226
Heat sink	227
Processor	229
TV Tuner or WLAN Module	232

Hood Sensor	233
System Board	234
Rear Fan	236
Changing from Desktop to Tower Configuration	238
Port Cover	239
Power Supply, External	240
Appendix A Battery Replacement	241
Appendix B Power Cord Set Requirements	244
General Requirements	244
Japanese Power Cord Requirements	244
Country-Specific Requirements	245
Appendix C POST Error Messages	246
POST Numeric Codes and Text Messages	247
Interpreting POST Diagnostic Front Panel LEDs and Audible Codes	255
Appendix D Troubleshooting Without Diagnostics	259
Safety and Comfort	259
Before You Call for Technical Support	259
Helpful Hints	260
Solving General Problems	262
Solving Power Problems	266
Solving Diskette Problems	268
Solving Hard Drive Problems	271
Solving Media Card Reader Problems	274
Solving Display Problems	276
Solving Audio Problems	280
Solving Printer Problems	282
Solving Keyboard and Mouse Problems	284
Solving Hardware Installation Problems	286
Solving Network Problems	287
Solving Memory Problems	291
Solving Processor Problems	292
Solving CD-ROM and DVD Problems	293
Solving USB Flash Drive Problems	295
Solving Front Panel Component Problems	297
Solving Internet Access Problems	297
Solving Software Problems	300


Contacting Customer Support	301
Appendix E Password Security and Resetting CMOS	302
Resetting the Password Jumper	303
Clearing and Resetting the CMOS	304
Appendix F Drive Protection System (DPS)	306
Accessing DPS Through Computer Setup	307
Appendix G Computer Diagnostic Features	308
Hewlett-Packard Vision Diagnostics	308
Accessing HP Vision Diagnostics	308
Survey Tab	309
Test Tab	310
Status Tab	310
History Tab	311
Errors Tab	311
Help Tab	312
Saving and Printing Information in HP Vision Diagnostics	312
Downloading the Latest Version of HP Vision Diagnostics	312
Protecting the Software	313
Appendix H Backup and Recovery	314
Windows 7 – Backup and Recovery	314
Backing up your information	314
Performing a recovery	316
Using the Windows recovery tools	316
Using F11	317
Using a Windows 7 operating system DVD (purchased separately)	317
Windows Vista – Backup and Recovery	318
Backing up your information	318
Performing a recovery	319
Using the Windows recovery tools	320
Using F11	320
Using a Windows Vista operating system DVD (purchased separately)	321
Appendix I Specifications	322
CMT Specifications	322
MT Specifications	323
SFF Specifications	325


USDT Specifications 326


Index 327

1 Installing and Customizing the Software

If your computer was not shipped with a Microsoft operating system, some portions of this documentation do not apply. Additional information is available in online help after you install the operating system.


 **NOTE:** If the computer was shipped with Windows Vista or Windows 7 loaded, you will be prompted to register the computer with HP Total Care before installing the operating system. You will see a brief movie followed by an online registration form. Fill out the form, click the **Begin** button, and follow the instructions on the screen.


 **CAUTION:** Do not add optional hardware or third-party devices to the computer until the operating system is successfully installed. Doing so may cause errors and prevent the operating system from installing properly.

 **NOTE:** Be sure there is a 10.2-cm (4-inch) clearance at the back of the unit and above the monitor to permit the required airflow.

Installing the Windows Operating System

The first time you turn on the computer, the operating system is installed automatically. This process takes about 5 to 10 minutes, depending on which operating system is being installed. Carefully read and follow the instructions on the screen to complete the installation.

 **CAUTION:** Once the automatic installation has begun, **DO NOT TURN OFF THE COMPUTER UNTIL THE PROCESS IS COMPLETE**. Turning off the computer during the installation process may damage the software that runs the computer or prevent its proper installation.

 **NOTE:** If the computer shipped with more than one operating system language on the hard drive, the installation process could take up to 60 minutes.

If your computer was not shipped with a Microsoft operating system, some portions of this documentation do not apply. Additional information is available in online help after you install the operating system.

Downloading Microsoft Windows Updates

1. To set up your Internet connection, click **Start > Internet Explorer** and follow the instructions on the screen.
2. Once an Internet connection has been established, click the **Start** button.

3. Select the **All Programs** menu.
4. Click on the **Windows Update** link.

In Windows Vista and Windows 7, the **Windows Update** screen appears. Click **view available updates** and make sure all critical updates are selected. Click the **Install** button and follow the instructions on the screen.

In Windows XP, you will be directed to the **Microsoft Windows Update Web site**. If you see one or more pop-up windows that ask you to install a program from <http://www.microsoft.com>, click **Yes** to install the program. Follow the instructions on the Microsoft Web site to scan for updates and install critical updates and service packs.

It is recommended that you install all of the critical updates and service packs.

5. After the updates have been installed, Windows will prompt you to reboot the machine. Be sure to save any files or documents that you may have open before rebooting. Then select **Yes** to reboot the machine.

Installing or Upgrading Device Drivers (Windows systems)

When installing optional hardware devices after the operating system installation is complete, you must also install the drivers for each of the devices.

If prompted for the i386 directory, replace the path specification with `C:\i386`, or use the **Browse** button in the dialog box to locate the i386 folder. This action points the operating system to the appropriate drivers.

Obtain the latest support software, including support software for the operating system from <http://www.hp.com/support>. Select your country and language, select **Download drivers and software (and firmware)**, enter the model number of the computer, and press [Enter](#).

Customizing the Monitor Display (Windows systems)

If you wish, you can select or change the monitor model, refresh rates, screen resolution, color settings, font sizes, and power management settings. To do so, right-click on the Windows Desktop, then click **Personalize** in Windows Vista and Windows 7 or **Properties** in Windows XP to change display settings. For more information, refer to the online documentation provided with the graphics controller utility or the documentation that came with your monitor.

Launching Windows XP from Windows 7

Windows XP Mode for Windows 7 allows you to install and launch Windows XP applications from the Windows 7 taskbar. This feature is available on some computer models only.

To set up from a pre-installed Windows 7 desktop, click **Start > Windows Virtual PC > Virtual Windows XP** and follow the instructions on the screen.

Accessing Disk Image (ISO) Files

There are disk image files (ISO files) included on your PC that contain the installation software for additional software. These CD image files are located in the folder `C:\SWSetup\ISOs`. Each .iso file

can be burned to CD media to create an installation CD. It is recommended that these disks be created and the software installed in order to get the most from your PC. The software and image file names are:

- Corel WinDVD SD and BD – installation software for WinDVD – used to play DVD movies
- HP Insight Diagnostics OR Vision Diagnostics – software to perform diagnostic activities on your PC

2 Computer Setup (F10) Utility

Computer Setup (F10) Utilities

Use Computer Setup (F10) Utility to do the following:

- Change factory default settings.
- Set the system date and time.
- Set, view, change, or verify the system configuration, including settings for processor, graphics, memory, audio, storage, communications, and input devices.
- Modify the boot order of bootable devices such as hard drives, optical drives, or USB flash media devices.
- Enable Quick Boot, which is faster than Full Boot but does not run all of the diagnostic tests run during a Full Boot. You can set the system to:
 - ☐ always Quick Boot (default);
 - ☐ periodically Full Boot (from every 1 to 30 days); or
 - ☐ always Full Boot.
- Select Post Messages Enabled or Disabled to change the display status of Power-On Self-Test (POST) messages. Post Messages Disabled suppresses most POST messages, such as memory count, product name, and other non-error text messages. If a POST error occurs, the error is displayed regardless of the mode selected. To manually switch to Post Messages Enabled during POST, press any key (except **F1** through **F12**).
- Establish an Ownership Tag, the text of which is displayed each time the system is turned on or restarted.
- Enter the Asset Tag or property identification number assigned by the company to this computer.
- Enable the power-on password prompt during system restarts (warm boots) as well as during power-on.
- Establish a setup password that controls access to the Computer Setup (F10) Utility and the settings described in this section.
- Secure integrated I/O functionality, including the serial, USB, or parallel ports, audio, or embedded NIC, so that they cannot be used until they are unsecured.
- Enable or disable removable media boot ability.


- Solve system configuration errors detected but not automatically fixed during the Power-On Self-Test (POST).
- Replicate the system setup by saving system configuration information on a USB device and restoring it on one or more computers.
- Execute self-tests on a specified ATA hard drive (when supported by drive).
- Enable or disable DriveLock security (when supported by drive).

Using Computer Setup (F10) Utilities

Computer Setup can be accessed only by turning the computer on or restarting the system. To access the Computer Setup Utilities menu, complete the following steps:

1. Turn on or restart the computer. If you are in Microsoft Windows, click **Start > Shut Down > Restart**.
2. Press either **Esc** or **F10** while the “Press the ESC key for Startup Menu” message is displayed at the bottom of the screen.

Pressing **Esc** displays a menu that allows you to access different options available at startup.

 **NOTE:** If you do not press **Esc** or **F10** at the appropriate time, you must restart the computer and again press **Esc** or **F10** when the monitor light turns green to access the utility.

3. If you pressed **Esc**, press **F10** to enter Computer Setup.
4. A choice of five headings appears in the Computer Setup Utilities menu: File, Storage, Security, Power, and Advanced.
5. Use the arrow (left and right) keys to select the appropriate heading. Use the arrow (up and down) keys to select the option you want, then press **Enter**. To return to the Computer Setup Utilities menu, press **Esc**.
6. To apply and save changes, select **File > Save Changes and Exit**.
 - If you have made changes that you do not want applied, select **Ignore Changes and Exit**.
 - To reset to factory settings or previously saved default settings (some models), select **Apply Defaults and Exit**. This option will restore the original factory system defaults.


 **CAUTION:** Do NOT turn the computer power OFF while the BIOS is saving the Computer Setup (F10) changes because the CMOS could become corrupted. It is safe to turn off the computer only after exiting the F10 Setup screen.

Table 2-1 Computer Setup (F10) Utility

Heading	Table
File	Computer Setup—File on page 6
Storage	Computer Setup—Storage on page 7
Security	Computer Setup—Security on page 9
Power	Computer Setup—Power on page 13
Advanced	Computer Setup—Advanced on page 14

Computer Setup—File



NOTE: Support for specific Computer Setup options may vary depending on the hardware configuration.

Table 2-2 Computer Setup—File

Option	Description
System Information	Lists: <ul style="list-style-type: none">• Product name• SKU number (some models)• Processor type/speed/stepping• Cache size (L1/L2/L3) (dual core processors have this listed twice)• Installed memory size/speed, number of channels (single or dual) (if applicable)• Integrated MAC address for embedded, enabled NIC (if applicable)• System BIOS (includes family name and version)• Chassis serial number• Asset tracking number• ME firmware version• ME Management mode
About	Displays copyright notice.
Set Time and Date	Allows you to set system time and date.
Flash System ROM	Allows you to update the system ROM with a BIOS image file located on removable media.
Replicated Setup	Save to Removable Media <p>Saves system configuration, including CMOS, to a formatted USB flash media device.</p> Restore from Removable Media <p>Restores system configuration from a USB flash media device.</p>
Default Setup	Save Current Settings as Default <p>Saves the current system configuration settings as the default.</p> Restore Factory Settings as Default <p>Restores the factory system configuration settings as the default.</p>
Apply Defaults and Exit	Applies the currently selected default settings and clears any established passwords.
Ignore Changes and Exit	Exits Computer Setup without applying or saving any changes.
Save Changes and Exit	Saves changes to system configuration or default settings and exits Computer Setup.

Computer Setup—Storage



NOTE: Support for specific Computer Setup options may vary depending on the hardware configuration.

Table 2-3 Computer Setup—Storage

Option	Description
Device Configuration	<p>Lists all installed BIOS-controlled storage devices.</p> <p>When a device is selected, detailed information and options are displayed. The following options may be presented:</p> <p>CD-ROM: Size, model, firmware version, serial number, connector color (not included for USB CD-ROM).</p> <p>Hard Disk: Size, model, firmware version, serial number, connector color.</p> <ul style="list-style-type: none">• SMART (ATA disks only)• Translation mode (ATA disks only)• Connector color(ATA disks only) <p>Lets you select the translation mode to be used for the device. This enables the BIOS to access disks partitioned and formatted on other systems and may be necessary for users of older versions of UNIX (e.g., SCO UNIX version 3.2). Options are Automatic, Bit-Shift, LBA Assisted, User, and Off.</p> <p>Available only when the drive translation mode is set to User, allows you to specify the parameters (logical cylinders, heads, and sectors per track) used by the BIOS to translate disk I/O requests (from the operating system or an application) into terms the hard drive can accept. Logical cylinders may not exceed 1024. The number of heads may not exceed 256. The number of sectors per track may not exceed 63.</p> <p>CAUTION: Ordinarily, the translation mode selected automatically by the BIOS should not be changed. If the selected translation mode is not compatible with the translation mode that was active when the disk was partitioned and formatted, the data on the disk will be inaccessible.</p> <p>Diskette: Model and firmware version.</p> <p>NOTE: Displays for USB diskette drives.</p> <p>Default Values (ATA disks only)</p> <p>SATA Defaults</p> <p>See Translation Mode above for details.</p>

Table 2-3 Computer Setup—Storage (continued)

Storage Options	<div data-bbox="507 212 775 237">eSATA Port (some models)</div> <div data-bbox="507 262 1444 287">Allows you to set a SATA port as an eSATA port for use with an external drive. Default is enabled.</div> <div data-bbox="507 312 1444 390">This setting affects only the port with the black connector, labeled as eSATA on the system board. This port should have the eSATA back panel connector attached to use eSATA drives. For more information, see the eSATA white paper at www.hp.com.</div> <div data-bbox="507 415 676 441">SATA Emulation</div> <div data-bbox="507 466 1361 518">Allows you to choose how the SATA controller and devices are accessed by the operating system. There are three supported options: IDE, RAID, and AHCI (default).</div> <div data-bbox="507 543 1382 596">IDE - This is the most backwards-compatible setting of the three options. Operating systems usually do not require additional driver support in IDE mode.</div> <div data-bbox="507 621 1444 674">RAID - Allows DOS and boot access to RAID volumes. Use this mode with the RAID device driver loaded in the operating system to take advantage of RAID features.</div> <div data-bbox="507 699 1350 751">AHCI (default option) - Allows operating systems with AHCI device drivers loaded to take advantage of more advanced features of the SATA controller.</div> <div data-bbox="507 777 1444 879">NOTE: The RAID/AHCI device driver must be installed prior to attempting to boot from a RAID/AHCI volume. If you attempt to boot from a RAID/AHCI volume without the required device driver installed, the system will crash (blue screen). RAID volumes may become corrupted if they are booted to after disabling RAID.</div> <div data-bbox="507 905 979 930">NOTE: RAID is not available on USDT systems.</div> <div data-bbox="507 955 743 980">Removable Media Boot</div> <div data-bbox="507 1005 1321 1031">Enables/disables ability to boot the system from removable media. Default is enabled.</div> <div data-bbox="507 1056 844 1081">Max eSATA Speed (some models)</div> <div data-bbox="507 1106 1444 1159">Allows you to choose 1.5 Gbps or 3.0 Gbps as the maximum eSATA speed. By default, the speed is limited to 1.5 Gbps for maximum reliability.</div> <div data-bbox="507 1184 1444 1236">CAUTION: Consult your eSATA drive and cable manufacturer before enabling 3.0 Gbps speed. Some drive and cable combinations may not run reliably at 3.0 Gbps.</div> <div data-bbox="507 1262 995 1287">NOTE: eSATA is not available on USDT systems.</div>
------------------------	---

Table 2-3 Computer Setup—Storage (continued)

DPS Self-Test	<p>Allows you to execute self-tests on ATA hard drives capable of performing the Drive Protection System (DPS) self-tests.</p> <p>NOTE: This selection will only appear when at least one drive capable of performing the DPS self-tests is attached to the system.</p>
Boot Order	<p>Allows you to:</p> <ul style="list-style-type: none">Specify the order in which EFI boot sources (such as a internal hard drive, USB hard drive, USB optical drive, or internal optical drive) are checked for a bootable operating system image. Each device on the list may be individually excluded from or included for consideration as a bootable operating system source. <p>EFI boot sources always have precedence over legacy boot sources.</p> <ul style="list-style-type: none">Specify the order in which legacy boot sources (such as a network interface card, internal hard drive, USB optical drive, or internal optical drive) are checked for a bootable operating system image. Each device on the list may be individually excluded from or included for consideration as a bootable operating system source.Specify the order of attached hard drives. The first hard drive in the order will have priority in the boot sequence and will be recognized as drive C (if any devices are attached). <p>NOTE: You can use F5 to disable individual boot items, as well as disable EFI boot and/or legacy boot.</p> <p>NOTE: MS-DOS drive lettering assignments may not apply after a non-MS-DOS operating system has started.</p> <p>Shortcut to Temporarily Override Boot Order</p> <p>To boot one time from a device other than the default device specified in Boot Order, restart the computer and press Esc (to access the boot menu) and then F9 (Boot Order), or only F9 (skipping the boot menu) when the monitor light turns green. After POST is completed, a list of bootable devices is displayed. Use the arrow keys to select the preferred bootable device and press Enter. The computer then boots from the selected non-default device for this one time.</p>

Computer Setup—Security


 **NOTE:** Support for specific Computer Setup options may vary depending on the hardware configuration.

Table 2-4 Computer Setup—Security

Option	Description
Setup Password	<p>Allows you to set and enable a setup (administrator) password.</p> <p>NOTE: If the setup password is set, it is required to change Computer Setup options, flash the ROM, and make changes to certain plug and play settings under Windows.</p> <p>NOTE: This selection will only appear when at least one drive that supports the DriveLock feature is attached to the system.</p> <p>See the <i>Desktop Management Guide</i> for more information.</p>

Table 2-4 Computer Setup—Security (continued)

Power-On Password	<p>Allows you to set and enable a power-on password. The power-on password prompt appears after a power cycle. If the user does not enter the correct power-on password, the unit will not boot.</p> <p>NOTE: This selection will only appear when at least one drive that supports the DriveLock feature is attached to the system.</p> <p>See the <i>Desktop Management Guide</i> for more information.</p>
Password Options (This selection appears only if a power-on password or setup password is set.)	<p>Allows you to enable/disable:</p> <ul style="list-style-type: none">• Lock Legacy Resources (appears if a setup password is set). Default is enabled.• Setup Browse Mode (appears if a setup password is set) (allows viewing, but not changing, the F10 Setup Options without entering setup password). Default is enabled.• Password prompt on F9, F11, & F12 (allows access to menus without entering setup password). Default is enabled.• Network Server Mode (appears if a power-on password is set). Default is disabled. <p>See the <i>Desktop Management Guide</i> for more information.</p>
Smart Cover (some models)	<p>Allows you to:</p> <ul style="list-style-type: none">• Lock/unlock the Cover Lock.• Set the Cover Removal Sensor to Disable/Notify User/Setup Password. <p>NOTE: <i>Notify User</i> alerts the user that the sensor has detected that the cover has been removed. <i>Setup Password</i> requires that the setup password be entered to boot the computer if the sensor detects that the cover has been removed.</p> <p>This feature is supported on some models only. See the <i>Desktop Management Guide</i> for more information.</p>
Device Security	<p>Allows you to set Device Available/Device Hidden (default is Device Available) for:</p> <ul style="list-style-type: none">• Embedded security device (some models)• System audio• Serial ports (some models)• Parallel port (some models)• Network controller <p>NOTE: You must disable AMT before trying to hide the network controller.</p> <ul style="list-style-type: none">• SATA0• SATA1• SATA2 (some models)• SATA3 (some models)• SATA4 (some models)

Table 2-4 Computer Setup—Security (continued)

USB Security	<p>Allows you to set Enabled/Disabled (default is Enabled) for:</p> <ul style="list-style-type: none">• Front USB Ports<ul style="list-style-type: none">◦ USB Port 1◦ USB Port 2◦ USB Port 3◦ USB Port 4• Rear USB Ports<ul style="list-style-type: none">◦ USB Port 1◦ USB Port 2◦ USB Port 3◦ USB Port 4◦ USB Port 5◦ USB Port 6• Accessory USB Ports<ul style="list-style-type: none">◦ USB Port 1◦ USB Port 2 (some models)◦ USB Port 3 (some models)◦ USB Port 4 (some models)
Slot Security	<p>Allows you to disable any PCI or PCI Express slot. Default is enabled.</p>
Network Boot	<p>Enables/disables the computer's ability to boot from an operating system installed on a network server. (Feature available on NIC models only; the network controller must be either a PCI expansion card or embedded on the system board.) Default is enabled.</p>
System IDs	<p>Allows you to set:</p> <ul style="list-style-type: none">• Asset tag (18-byte identifier), a property identification number assigned by the company to the computer.• Ownership tag (80-byte identifier) displayed during POST.• Chassis serial number or Universal Unique Identifier (UUID) number. The UUID can only be updated if the current chassis serial number is invalid. (These ID numbers are normally set in the factory and are used to uniquely identify the system.)• Keyboard locale setting for System ID entry.

Table 2-4 Computer Setup—Security (continued)

System Security (some models: these options are hardware dependent)	Data Execution Prevention (enable/disable) - Helps prevent operating system security breaches. Default is enabled.
	Virtualization Technology (VTx)(some models) (enable/disable) - Controls the virtualization features of the processor. Changing this setting requires turning the computer off and then back on. Default is disabled.
	Virtualization Technology Directed I/O (VTd) (some models) (enable/disable) - Controls virtualization DMA remapping features of the chipset. Changing this setting requires turning the computer off and then back on. Default is disabled.
	Intel TXT (LT) Support (some models) (enable/disable) - Controls the underlying processor and chipset features needed to support a virtual appliance. Changing this setting requires turning the computer off and then back on. Default is disabled. To enable this feature you must enable the following features:
	<ul style="list-style-type: none">• Embedded Security Device Support• Virtualization Technology• Virtualization Technology Directed I/O
	Embedded Security Device Support (some models) (enable/disable) - Permits activation and deactivation of the Embedded Security Device. Changing this setting requires turning the computer off and then back on.
	NOTE: To configure the Embedded Security Device, a Setup password must be set.
	<ul style="list-style-type: none">• Reset to Factory Settings (some models) (Do not reset/Reset) - Resetting to factory defaults will erase all security keys. Changing this setting requires turning the computer off and then back on. Default is Do not reset.
	CAUTION: The embedded security device is a critical component of many security schemes. Erasing the security keys will prevent access to data protected by the Embedded Security Device. Choosing Reset to Factory Settings may result in significant data loss.
	OS management of Embedded Security Device (some models) (enable/disable) - This option allows the user to limit operating system control of the Embedded Security Device. Changing this setting requires turning the computer off and then back on. This option allows the user to limit OS control of the Embedded Security Device. Default is enabled.
DriveLock Security	Reset of Embedded Security Device through OS (some models) (enable/disable) - This option allows the user to limit the operating system ability to request a Reset to Factory Settings of the Embedded Security Device. Changing this setting requires turning the computer off and then back on. Default is disabled.
	NOTE: To enable this option, a Setup password must be set.
	Allows you to assign or modify a master or user password for hard drives. When this feature is enabled, the user is prompted to provide one of the DriveLock passwords during POST. If neither is successfully entered, the hard drive will remain inaccessible until one of the passwords is successfully provided during a subsequent cold-boot sequence.
	NOTE: This selection will only appear when at least one drive that supports the DriveLock feature is attached to the system.
	See the <i>Desktop Management Guide</i> for more information.

Computer Setup—Power



NOTE: Support for specific Computer Setup options may vary depending on the hardware configuration.

Table 2-5 Computer Setup—Power

Option	Description
OS Power Management	<ul style="list-style-type: none">• Runtime Power Management— Enable/Disable. Allows certain operating systems to reduce processor voltage and frequency when the current software load does not require the full capabilities of the processor. Default is enabled.• Idle Power Savings—Extended/Normal. Allows certain operating systems to decrease the processors power consumption when the processor is idle. Default is extended.• Unique Sleep State Blink Rates—Enable/Disable. This feature is designed to provide a visual indication of what sleep state the system is in. Each sleep state has a unique blink pattern. Default is disabled.<ul style="list-style-type: none">◦ S0 (On) = Solid green LED.◦ S3 (Stand By)= 3 blinks at 1Hz (50% duty cycle) followed by a pause of 2 seconds (green LED) — repeated cycles of 3 blinks and a pause.◦ S4 (Hibernation)= 4 blinks at 1Hz (50% duty cycle) followed by a pause of 2 seconds (green LED) — repeated cycles of 4 blinks and a pause.◦ S5 (Soft Off) = LED is off. <p>NOTE: If this feature is disabled, S4 and S5 both have the LED off. S1 (no longer supported) and S3 use 1 blink per second.</p>
Hardware Power Management	<p>SATA Power Management – Enables or disables SATA bus and/or device power management. Default is enabled.</p> <p>S5 Maximum Power Savings—Turns off power to all nonessential hardware when system is off to meet EUP Lot 6 requirement of less than 1 Watt power usage. Default is disabled.</p>
Thermal	<p>Fan idle mode—This bar graph controls the minimum permitted fan speed.</p> <p>NOTE: This setting only changes the minimum fan speed. The fans are still automatically controlled.</p>

Computer Setup—Advanced



NOTE: Support for specific Computer Setup options may vary depending on the hardware configuration.

Table 2-6 Computer Setup—Advanced (for advanced users)

Option	Heading
Power-On Options	<p>Allows you to set:</p> <ul style="list-style-type: none">• POST mode (QuickBoot, Clear Memory, FullBoot, or FullBoot Every x Days).<ul style="list-style-type: none">◦ QuickBoot (default) = Do not clear memory or perform a memory test.◦ FullBoot = Memory test (count) on cold boot. Clears memory on all boots.◦ Clear Memory = No memory count on cold boot. Clears memory on all boots.◦ FullBoot Every x Days = Memory count on 1st cold boot on or after the xth day. No more memory counts until 1st cold boot on or after x days. Clears memory on all boots.• POST messages (enable/disable). Default is disabled.• Press the ESC key for Startup Menu (Enable/Disable). Default is enabled.• Option ROM Prompt (enable/disable). Enabling this feature will cause the system to display a message before loading option ROMs. Default is enabled.• After Power Loss (off/on/previous state). Default is Power off. Setting this option to:<ul style="list-style-type: none">◦ Power off—causes the computer to remain powered off when power is restored.◦ Power on—causes the computer to power on automatically as soon as power is restored.◦ Previous state—causes the computer to power on automatically as soon as power is restored, if it was on when power was lost. <p>NOTE: If you turn off power to the computer using the switch on a power strip, you will not be able to use the suspend/sleep feature or the Remote Management features.</p> <ul style="list-style-type: none">• POST Delay (in seconds). Enabling this feature will add a user-specified delay to the POST process. This delay is sometimes needed for hard disks on some PCI cards that spin up very slowly, so slowly that they are not ready to boot by the time POST is finished. The POST delay also gives you more time to select F10 to enter Computer (F10) Setup. Default is None.• Remote Wakeup Boot Source (remote server/local hard drive). Default is Local hard drive.• System Recovery Boot Support (Enable/Disable). Provides the ability for the BIOS to redirect the boot to the recovery partition on the user hard drive, if present. Some versions of the recovery software honor the F11 key press even when this feature is disabled by the BIOS. Default is disabled.• Bypass F1 Prompt on Configuration Changes (Enable/Disable). Allows you to set the computer not to confirm when changes were made. Default is disabled.
BIOS Power-On	Allows you to set the computer to turn on automatically at a time you specify.
Onboard Devices	Allows you to set resources for or disable Legacy devices.

Table 2-6 Computer Setup—Advanced (for advanced users) (continued)

Bus Options	On some models, allows you to enable or disable: <ul style="list-style-type: none">• PCI SERR# Generation. Default is enabled.• PCI VGA Palette Snooping, which sets the VGA palette snooping bit in PCI configuration space; only needed when more than one graphics controller is installed. Default is disabled.
Device Options	Allows you to set: <ul style="list-style-type: none">• Turbo Mode (enable/disable). Allows you to enable and disable the Intel Turbo Mode feature, which allows one core of the system to run at a higher than standard frequency and power if other cores are idle. Default is enabled.• Printer mode (Bi-Directional, EPP + ECP, Output Only). Default is EPP+ECP.• Num Lock State at Power-On (off/on). Default is off.• Integrated Video (enable/disable). Use this option to disable the integrated video controller when another video controller is present in the system. Default is enabled.• Internal Speaker (some models) (does not affect external speakers). Default is enabled.• NIC Option ROM Download (PXE, iSCSI, disabled). The BIOS contains an embedded NIC option ROM to allow the unit to boot through the network to a PXE server. This is typically used to download a corporate image to a hard drive. The NIC option ROM takes up memory space below 1MB commonly referred to as DOS Compatibility Hole (DCH) space. This space is limited. This F10 option will allow users to disable the downloading of this embedded NIC option ROM thus giving more DCH space for additional PCI cards which may need option ROM space. The default will be to have the NIC option-ROM-enabled. Default is PXE.• Multi-Processor (enable/disable). Use this option to disable multi-processor support under the OS. Default is enabled.• Hyper-threading (enable/disable) (some models). Use this option to disable processor hyper-threading.
VGA Configuration	Displayed only if there is an add-in video card in the system. Allows you to specify which VGA controller will be the “boot” or primary VGA controller.
AMT Configuration	Allows you to set: <ul style="list-style-type: none">• AMT (enable/disable). Allows you to enable or disable functions of the embedded Management Engine (ME) such as Active Management Technology (AMT). If set to disable, the Management Engine is set to a temporarily disabled state and will not provide functions beyond necessary system configuration. Default is enabled.• Unconfigure AMT/ME (enable/disable). Allows you to unconfigure any provisioned management settings for AMT. The AMT settings are restored to factory defaults. This feature should be used with caution as AMT will not be able to provide any set AMT management functions once unconfigured. Default is disabled.• Watchdog Timer (enable/disable). Allows you to set amount of time for a operating system and BIOS watchdog alert to be sent if the timers are not deactivated. BIOS watchdog is deactivated by BIOS and would indicate that a halt occurred during execution if the alert is sent to the management console. An operating system alert is deactivated by the operating system image and would indicate that a hang occurred during its initialization. Default is enabled.

Recovering the Configuration Settings

This method of recovery requires that you first perform the **Save to Removable Media** command with the Computer Setup (F10) Utility before **Restore** is needed. (See [Save to Removable Media on page 6](#) in the Computer Setup—File table.)



NOTE: It is recommended that you save any modified computer configuration settings to a USB flash media device and save the device for possible future use.


To restore the configuration, insert the USB flash media device with the saved configuration and perform the **Restore from Removable Media** command with the Computer Setup (F10) Utility. (See [Restore from Removable Media on page 6](#) in the Computer Setup—File table.)

3 Illustrated parts catalog

This chapter provides spare part information for all chassis.

Convertible minitower (CMT) chassis spare parts


Computer system components



Item	Description	Spare part number
(1)	Front bezel	646822-001
(2)	Access panel	646819-001
(3)	Power supply	
	320W, 90% efficient	613764-001
	320W, standard	613765-001
(4)	System board (includes replacement thermal material)	

Item	Description	Spare part number
	Includes Trusted Platform Module (TPM)	611835-001
	Does not include TPM	649742-001
Memory modules (PC3-10600, 1333-MHz; not illustrated)		
	4-GB	585157-001
	2-GB	635803-001
	1-GB	635802-001
Processors (include replacement thermal material; not illustrated)		
	Intel Core i7 2600 (3.4-GHz, 8-MB L3 cache)	638632-001
	Intel Core i5 2500 (3.3-GHz, 6-MB L3 cache)	638631-001
	Intel Core i5 2400 (3.1-GHz, 6-MB L3 cache)	638630-001
	Intel Core i3 2120 (3.3-GHz, 3-MB L3 cache)	638629-001
	Intel Core i3 2100 (3.1-GHz, 3-MB L3 cache)	638628-001

Cables



Item	Description	Spare part number
(1)	Power switch/LED assembly	646820-001
(2)	SATA optical drive power cable	646832-001
(3)	Front I/O assembly	646821-001
(4)	SATA hard drive power cable	646831-001

Item	Description	Spare part number
	SATA cable , 18 inch, 1 straight end, 1 angled end (unlabeled; not illustrated)	639958-001
	SATA cable , 17.7 inch, 2 straight ends (not illustrated)	639959-001
	SATA cable , 18 inch, 1 straight end, 1 angled end (labeled; not illustrated)	646830-001
	DMS-59 to dual VGA cable	463023-001
	Adapter, DisplayPort to VGA	603250-001
	Adapter, DisplayPort to DVI	484156-001
	Adapter, DisplayPort to HDMI	617450-001
	DisplayPort cable	487562-001

Misc parts



Item	Description	Spare part number
(1)	Fan sink (includes replacement thermal material)	643907-001
(2)	Chassis fan , (92 mm x 92 mm)	643908-001
(3)	Speaker	645330-001
(4)	Solenoid lock	641498-001
(5)	Hood sensor	638816-001
	USB powered speakers (not illustrated)	636917-001
	Hard drive conversion bracket (not illustrated)	397117-001
	Clamp lock , includes universal cable (plate not included; not illustrated)	508987-001
	Antenna for use with 538048-001 (not illustrated)	583345-001

Item	Description	Spare part number
	Keyboard (not illustrated)	
	NOTE: For a list of supported countries and associated dash numbers, see Sequential part number listing on page 21 .	
	PS/2, basic	537745-xxx
	USB, basic	537746-xx1
	USB, mini	535873-xx1
	Washable	613125-xx1
	Smartcard	631411-xx4
	Mouse (not illustrated)	
	PS2, optical, jack black	537748-001
	USB, BFR-PVC	590270-001
	Washable	619580-001
	Optical, jack black	444740-001
	Laser, jack black	570580-001

Drives

Description	Spare part number
Hard drive	
1-TB, 7200-rpm	636930-001
750-GB, 7200-rpm	632938-001
500-GB, 7200-rpm	636929-001
320-GB, 7200-rpm, 2.5-inch	634824-001
300-GB, 10000-rpm, SATA3	639695-001
300-GB, 10000-rpm, SATA2	648963-001
250-GB, 7200-rpm	636927-001
160-GB, 10000-rpm	639694-001
160-GB, 10000-rpm, 2.5-inch	508312-001
160-GB Solid-state drive	646809-001
80-GB Solid-state drive	607817-001
Optical drive	
Blu-ray BD-RW SuperMulti DL Drive with LightScribe	617030-001
16X SATA DVD±RW drive with LightScribe	581600-001
16X SATA DVD-ROM drive	581599-001
Grommet , hard drive isolation, blue	594220-001

Misc boards

Description	Spare part number
Graphics cards	
nVidia Quadro NVS295 PCIe x16 graphics card, 256 MB	641462-001
nVidia Quadro NVS300 PCIe x16 graphics card, 512 MB	632486-001
nVidia GF405, DVI/VGA PCIe x16 graphics card, 512 MB	641732-001
ATI Radeon HD6350 PCIe x16 graphics card, 512 MB	637995-001
ATI Radeon HD6450 PCIe x16 graphics card, 512 MB	637996-001
ATI Radeon HD6570 PCIe x16 graphics card, 1 GB	637997-001
AMD FirePro 2270 PCIe x16 graphics card, 512 MB	637213-001
Intel PRO/1000CT NIC, includes bracket	635523-001
HP FireWire / IEEE 1394a PCIe x1 card	637591-001
Ports	
eSATA port assembly, PCI card	645558-001
USB 3.0 port, PCIe x1 card	616610-001
Serial port, PCI card	638815-001
Printer port, PCI card	638817-001
Other boards/cards	
HP WLAN 802.11b/g/n card	538048-001
Intel PRO/1000CT NIC, includes bracket	635523-001

Sequential part number listing

Spare part number	Description
397117-001	Hard drive conversion bracket
444740-001	Mouse, optical, jack black
463023-001	DMS-59 to dual VGA cable
484156-001	Adapter, DisplayPort to DVI
487562-001	DisplayPort cable
508312-001	160-GB, 10000-rpm, 2.5-inch hard drive
508987-001	Clamp lock, includes universal cable (plate not included)
535873-001	USB mini keyboard for use in the United States
535873-121	USB mini keyboard for use in the French Canada
537745-001	PS/2 basic keyboard for use in the United States

Spare part number	Description
537745-031	PS/2 basic keyboard for use in the United Kingdom
537745-041	PS/2 basic keyboard for use in Germany
537745-051	PS/2 basic keyboard for use in France
537745-061	PS/2 basic keyboard for use in Italy
537745-071	PS/2 basic keyboard for use in Spain
537745-081	PS/2 basic keyboard for use in Denmark
537745-091	PS/2 basic keyboard for use in Norway
537745-101	PS/2 basic keyboard for use in Sweden
537745-111	PS/2 basic keyboard for use in Switzerland
537745-121	PS/2 basic keyboard for use in French Canada
537745-131	PS/2 basic keyboard for use in Portugal
537745-141	PS/2 basic keyboard for use in Turkey
537745-151	PS/2 basic keyboard for use in Greece
537745-161	PS/2 basic keyboard for use in Latin America (Spanish)
537745-171	PS/2 basic keyboard for use in Saudi Arabia
537745-181	PS/2 basic keyboard for use in Belgium
537745-201	PS/2 basic keyboard for use in Brazil (Portuguese)
537745-211	PS/2 basic keyboard for use in Hungary
537745-221	PS/2 basic keyboard for use in the Czech Republic
537745-231	PS/2 basic keyboard for use in Slovakia
537745-251	PS/2 basic keyboard for use in Russia
537745-261	PS/2 basic keyboard for use in Bulgaria
537745-271	PS/2 basic keyboard for use in Romania
537745-281	PS/2 basic keyboard for use in Thailand
537745-291	PS/2 basic keyboard for use in Japan
537745-371	PS/2 basic keyboard for use with International English
537745-AA1	PS/2 basic keyboard for use in the People's Republic of China
537745-AB1	PS/2 basic keyboard for use in Taiwan
537745-BB1	PS/2 basic keyboard for use in Israel (Hebrew)
537745-DE1	PS/2 basic keyboard for use in Saudi Arabia
537745-KD1	PS/2 basic keyboard for use in South Korea
537745-L31	PS/2 basic keyboard for use with international English
537746-001	PS/2 basic keyboard for use in the United States
537746-031	PS/2 basic keyboard for use in the United Kingdom

Spare part number	Description
537746-041	PS/2 basic keyboard for use in Germany
537746-051	PS/2 basic keyboard for use in France
537746-061	PS/2 basic keyboard for use in Italy
537746-071	PS/2 basic keyboard for use in Spain
537746-081	PS/2 basic keyboard for use in Denmark
537746-091	PS/2 basic keyboard for use in Norway
537746-101	PS/2 basic keyboard for use in Sweden
537746-111	PS/2 basic keyboard for use in Switzerland
537746-121	PS/2 basic keyboard for use in French Canada
537746-131	PS/2 basic keyboard for use in Portugal
537746-141	PS/2 basic keyboard for use in Turkey
537746-151	PS/2 basic keyboard for use in Greece
537746-161	PS/2 basic keyboard for use in Latin America (Spanish)
537746-171	PS/2 basic keyboard for use in Saudi Arabia
537746-181	PS/2 basic keyboard for use in Belgium
537746-201	PS/2 basic keyboard for use in Brazil (Portuguese)
537746-211	PS/2 basic keyboard for use in Hungary
537746-221	PS/2 basic keyboard for use in the Czech Republic
537746-231	PS/2 basic keyboard for use in Slovakia
537746-251	PS/2 basic keyboard for use in Russia
537746-261	PS/2 basic keyboard for use in Bulgaria
537746-271	PS/2 basic keyboard for use in Romania
537746-281	PS/2 basic keyboard for use in Thailand
537746-291	PS/2 basic keyboard for use in Japan
537746-351	PS/2 basic keyboard for use in Finland
537746-371	PS/2 basic keyboard for use with International English
537746-AA1	PS/2 basic keyboard for use in the People's Republic of China
537746-AB1	PS/2 basic keyboard for use in Taiwan
537746-BB1	PS/2 basic keyboard for use in Israel (Hebrew)
537746-DE1	PS/2 basic keyboard for use in Saudi Arabia
537746-KD1	PS/2 basic keyboard for use in South Korea
537746-L31	PS/2 basic keyboard for use with international English
537748-001	Mouse, PS2, optical, jack black
538048-001	HP WLAN 802.11b/g/n card

Spare part number	Description
570580-001	Mouse, laser, jack black
581599-001	16X SATA DVD-ROM drive
581600-001	16X SATA DVD±RW drive with LightScribe
583345-001	Antenna for use with 538048-001
585157-001	Memory module, 4-GB, PC3 10600, 1333-MH
590270-001	Mouse, USB, BFR-PVC
594220-001	Grommet, hard drive isolation, blue
603250-001	Adapter, DisplayPort to VGA
607817-001	80-GB Solid-state drive
611835-001	System board, TPM (includes replacement thermal material)
613125-001	Washable keyboard for use in the United States
613125-111	Washable keyboard for use in Switzerland
613125-121	Washable keyboard for use in French Canada
613125-131	Washable keyboard for use in Portugal
613125-141	Washable keyboard for use in Turkey
613125-171	Washable keyboard for use in Saudi Arabia
613125-201	Washable keyboard for use in Brazil (Portuguese)
613125-211	Washable keyboard for use in Hungary
613125-221	Washable keyboard for use in the Czech Republic
613125-231	Washable keyboard for use in Slovakia
613125-251	Washable keyboard for use in Russia
613125-261	Washable keyboard for use in Bulgaria
613125-271	Washable keyboard for use in Romania
613125-351	Washable keyboard for use in Finland
613125-AA1	Washable keyboard for use in the People's Republic of China
613125-BB1	Washable keyboard for use in Israel (Hebrew)
613125-DE1	Washable keyboard for use in Saudi Arabia
613125-L31	Washable keyboard for use with international English
613764-001	320W, 90% efficient
613765-001	320W, standard
616610-001	USB 3.0 port, PCIe x1 card
617030-001	Blu-ray BD-RW SuperMulti DL Drive with LightScribe
617450-001	Adapter, DisplayPort to HDMI
619580-001	Mouse, washable


Spare part number	Description
631411-001	Smartcard keyboard for use in the United States
631411-031	Smartcard keyboard for use in the United Kingdom
631411-041	Smartcard keyboard for use in Germany
631411-051	Smartcard keyboard for use in France
631411-061	Smartcard keyboard for use in Italy
631411-071	Smartcard keyboard for use in Spain
631411-081	Smartcard keyboard for use in Denmark
631411-091	Smartcard keyboard for use in Norway
631411-101	Smartcard keyboard for use in Sweden
631411-111	Smartcard keyboard for use in Switzerland
631411-121	Smartcard keyboard for use in French Canada
631411-131	Smartcard keyboard for use in Portugal
631411-141	Smartcard keyboard for use in Turkey
631411-151	Smartcard keyboard for use in Greece
631411-161	Smartcard keyboard for use in Latin America (Spanish)
631411-171	Smartcard keyboard for use in Saudi Arabia
631411-181	Smartcard keyboard for use in Belgium
631411-201	Smartcard keyboard for use in Brazil (Portuguese)
631411-211	Smartcard keyboard for use in Hungary
631411-221	Smartcard keyboard for use in the Czech Republic
631411-231	Smartcard keyboard for use in Slovakia
631411-251	Smartcard keyboard for use in Russia
631411-281	Smartcard keyboard for use in Thailand
631411-291	Smartcard keyboard for use in Japan
631411-351	Smartcard keyboard for use in Finland
631411-371	Smartcard keyboard for use with International English
631411-AA1	Smartcard keyboard for use in the People's Republic of China
631411-AB1	Smartcard keyboard for use in Taiwan
631411-BB1	Smartcard keyboard for use in Israel (Hebrew)
631411-DE1	Smartcard keyboard for use in Saudi Arabia
631411-KD1	Smartcard keyboard for use in South Korea
631411-L31	Smartcard keyboard for use with international English
632486-001	nVidia Quadro NVS300 PCIe x16 graphics card, 512 MB
632938-001	750-GB, 7200 RPM hard drive

Spare part number	Description
634824-001	320-GB, 7200 RPM hard drive, 2.5-inch
635523-001	Intel PRO/1000CT NIC, includes bracket
635802-001	Memory module, 1-GB, PC3 10600, 1333-MHz
635803-001	Memory module, 2-GB, PC3 10600, 1333-MHz
636917-001	USB powered speakers
636927-001	250-GB, 7200 RPM hard drive
636929-001	500-GB, 7200 RPM hard drive
636930-001	1-TB hard drive
637213-001	AMD FirePro 2270 PCIe x16 graphics card, 512 MB
637591-001	HP FireWire / IEEE 1394a PCIe x1 card
637995-001	ATI Radeon HD6350 PCIe x16 graphics card, 512 MB
637996-001	ATI Radeon HD6450 PCIe x16 graphics card, 512 MB
637997-001	ATI Radeon HD6570 PCIe x16 graphics card, 1 GB
638628-001	Intel Core i3 2100 (3.1-GHz, 3-MB L3 cache)
638629-001	Intel Core i3 2120 (3.3-GHz, 3-MB L3 cache)
638630-001	Intel Core i5 2400 (3.1-GHz, 6-MB L3 cache)
638631-001	Intel Core i5 2500 (3.3-GHz, 6-MB L3 cache)
638632-001	Intel Core i7 2600 (3.4-GHz, 8-MB L3 cache)
638806-001	Hood sensor
638815-001	Serial port PCI card
638816-001	Hood sensor
638817-001	Printer port, PCI card
639694-001	160-GB, 10000 RPM hard drive
639695-001	300-GB, 10000 RPM, SATA3 hard drive
639958-001	SATA cable, 18 inch, 1 straight end, 1 angled end (unlabeled)
639959-001	SATA cable, 17.7 inch, 2 straight ends
641462-001	nVidia Quadro NVS295 PCIe x16 graphics card, 256 MB
641732-001	nVidia GF405, DVI/VGA PCIe x16 graphics card, 512 MB
641498-001	Solenoid lock
643907-001	Heat sink (includes replacement thermal material)
643908-001	Chassis fan
645330-001	Speaker
645558-001	eSATA port assembly, PCI card
646809-001	160-GB Solid-state drive

Spare part number	Description
646819-001	Access panel
646820-001	Power switch/LED with holder
646821-001	Front I/O assembly
646822-001	Front bezel
646830-001	SATA cable, 18 inch, 1 straight end, 1 angled end (labeled)
646831-001	Hard drive power cable
646832-001	SATA optical drive power cable
648963-001	300-GB, 10000 RPM, SATA2 hard drive
649742-001	System board, no TPM (includes replacement thermal material)

Microtower (MT) chassis spare parts


Computer major components



Item	Description	Spare part number
(1)	Front bezel	646826-001
(2)	Access panel	646825-001


Item	Description	Spare part number
(3)	Power supply	
	320W, 90% efficient	613764-001
	320W, standard	613765-001
(4)	System board (includes replacement thermal material)	
	For use in 8200 Elite Series models:	
	• Includes Trusted Platform Module (TPM)	611834-001
	• Does not include TPM	649741-001
	For use in 6200 Pro Series models:	
	• Includes Trusted Platform Module (TPM)	615114-001
	• Does not include TPM	649515-001
	Memory modules (PC3-10600, 1333-MHz; not illustrated)	
	4-GB	585157-001
	2-GB	635803-001
	1-GB	635802-001
	Processors (include replacement thermal material; not illustrated)	
	Intel Core i7 2600 (3.4-GHz, 8-MB L3 cache)	638632-001
	Intel Core i5 2500 (3.3-GHz, 6-MB L3 cache)	638631-001
	Intel Core i5 2400 (3.1-GHz, 6-MB L3 cache)	638630-001
	Intel Core i3 2120 (3.3-GHz, 3-MB L3 cache)	638629-001
	Intel Core i3 2100 (3.1-GHz, 3-MB L3 cache)	638628-001

Cables



Item	Description	Spare part number
(1)	Front I/O assembly	646827-001
(2)	SATA optical drive power cable	646834-001
(3)	SATA hard drive power cable	646833-001
(4)	Power switch/LED assembly	646828-001
(5)	SATA cable, 18 inch, 1 straight end, 1 angled end (unlabeled)	639958-001
(6)	SATA cable, 17.7 inch, 2 straight ends	639959-001
	SATA cable, 18 inch, 1 straight end, 1 angled end (labeled; not illustrated)	646830-001
	DMS-59 to dual VGA cable	463023-001
	Adapter, DisplayPort to VGA	603250-001
	Adapter, DisplayPort to DVI	484156-001
	Adapter, DisplayPort to HDMI	617450-001
	DisplayPort cable	487562-001

Misc parts



Item	Description	Spare part number
(1)	Heat sink (includes replacement thermal material)	645326-001
(2)	Fan with chassis with guard	585884-001
(3)	Hood sensor	638816-001
(4)	Speaker	645330-001
(5)	Solenoid lock	641498-001
(6)	Chassis fan, (92 mm x 92 mm)	636922-001
	Fan duct assembly (not illustrated)	646824-001
	Card reader, 22-in-1 (not illustrated)	636166-001
	USB powered speakers (not illustrated)	636917-001
	Hard drive conversion bracket (not illustrated)	397117-001
	Clamp lock, includes universal cable (plate not included; not illustrated)	508987-001
	Antenna for use with 538048-001 (not illustrated)	583345-001
	Keyboard (not illustrated)	
	NOTE: For a list of supported countries and associated dash numbers, see Sequential part number listing on page 32 .	
	PS/2, basic	537745-xxx
	USB, basic	537746-xx1
	Washable	613125-xx1
	Smartcard	631411-xx1
	Mouse (not illustrated)	
	PS2, optical, jack black	537748-001
	USB, BFR-PVC	590270-001

Item	Description	Spare part number
	Washable	619580-001
	Optical, jack black	444740-001
	Laser, jack black	570580-001
	Bezel blank (not illustrated)	
	5.25-inch	570838-001
	3.5-inch	583653-001

Drives

Description	Spare part number
Hard drive	
1-TB, 7200-rpm	636930-001
750-GB, 7200-rpm	632938-001
500-GB, 7200-rpm	636929-001
320-GB, 7200-rpm, 2.5-inch	634824-001
300-GB, 10000-rpm, SATA3	639695-001
300-GB, 10000-rpm, SATA2	648963-001
250-GB, 7200-rpm	636927-001
160-GB, 10000-rpm	639694-001
160-GB, 10000-rpm, 2.5-inch	508312-001
160-GB Solid-state drive	646809-001
80-GB Solid-state drive	607817-001
Optical drive	
Blu-ray BD-RW SuperMulti DL Drive with LightScribe	617030-001
16X SATA DVD±RW drive with LightScribe	581600-001
16X SATA DVD-ROM drive	581599-001
Grommet , hard drive isolation, blue	594220-001

Misc boards

Description	Spare part number
Graphics cards	
nVidia Quadro NVS295 PCIe x16 graphics card, 256 MB	641462-001
nVidia Quadro NVS300 PCIe x16 graphics card, 512 MB	632486-001
nVidia GF405, DVI/VGA PCIe x16 graphics card, 512 MB	641732-001

Description	Spare part number
ATI Radeon HD6350 PCIe x16 graphics card, 512 MB	637995-001
ATI Radeon HD6450 PCIe x16 graphics card, 512 MB	637996-001
ATI Radeon HD6570 PCIe x16 graphics card, 1 GB	637997-001
AMD FirePro 2270 PCIe x16 graphics card, 512 MB	637213-001
HP FireWire / IEEE 1394a PCIe x1 card	637591-001
Ports	
eSATA port assembly, PCI card	645558-001
USB 3.0 port, PCIe x1 card	616610-001
Serial port, PCI card	638815-001
Printer port, PCI card	638817-001
Other boards/cards	
HP WLAN 802.11b/g/n	538048-001
Intel PRO/1000CT NIC, includes bracket	635523-001

Sequential part number listing

Spare part number	Description
397117-001	Hard drive conversion bracket
444740-001	Mouse, optical, jack black
463023-001	DMS-59 to dual VGA cable
484156-001	Adapter, DisplayPort to DVI
487562-001	DisplayPort cable
508312-001	160-GB, 10000-rpm, 2.5-inch hard drive
508987-001	Clamp lock, includes universal cable (plate not included)
537745-001	PS/2 basic keyboard for use in the United States
537745-031	PS/2 basic keyboard for use in the United Kingdom
537745-041	PS/2 basic keyboard for use in Germany
537745-051	PS/2 basic keyboard for use in France
537745-061	PS/2 basic keyboard for use in Italy
537745-071	PS/2 basic keyboard for use in Spain
537745-081	PS/2 basic keyboard for use in Denmark
537745-091	PS/2 basic keyboard for use in Norway
537745-101	PS/2 basic keyboard for use in Sweden
537745-111	PS/2 basic keyboard for use in Switzerland

Spare part number	Description
537745-121	PS/2 basic keyboard for use in French Canada
537745-131	PS/2 basic keyboard for use in Portugal
537745-141	PS/2 basic keyboard for use in Turkey
537745-151	PS/2 basic keyboard for use in Greece
537745-161	PS/2 basic keyboard for use in Latin America (Spanish)
537745-171	PS/2 basic keyboard for use in Saudi Arabia
537745-181	PS/2 basic keyboard for use in Belgium
537745-201	PS/2 basic keyboard for use in Brazil (Portuguese)
537745-211	PS/2 basic keyboard for use in Hungary
537745-221	PS/2 basic keyboard for use in the Czech Republic
537745-231	PS/2 basic keyboard for use in Slovakia
537745-251	PS/2 basic keyboard for use in Russia
537745-261	PS/2 basic keyboard for use in Bulgaria
537745-271	PS/2 basic keyboard for use in Romania
537745-281	PS/2 basic keyboard for use in Thailand
537745-291	PS/2 basic keyboard for use in Japan
537745-371	PS/2 basic keyboard for use with International English
537745-AA1	PS/2 basic keyboard for use in the People's Republic of China
537745-AB1	PS/2 basic keyboard for use in Taiwan
537745-BB1	PS/2 basic keyboard for use in Israel (Hebrew)
537745-DE1	PS/2 basic keyboard for use in Saudi Arabia
537745-KD1	PS/2 basic keyboard for use in South Korea
537745-L31	PS/2 basic keyboard for use with international English
537746-001	PS/2 basic keyboard for use in the United States
537746-031	PS/2 basic keyboard for use in the United Kingdom
537746-041	PS/2 basic keyboard for use in Germany
537746-051	PS/2 basic keyboard for use in France
537746-061	PS/2 basic keyboard for use in Italy
537746-071	PS/2 basic keyboard for use in Spain
537746-081	PS/2 basic keyboard for use in Denmark
537746-091	PS/2 basic keyboard for use in Norway
537746-101	PS/2 basic keyboard for use in Sweden
537746-111	PS/2 basic keyboard for use in Switzerland
537746-121	PS/2 basic keyboard for use in French Canada

Spare part number	Description
537746-131	PS/2 basic keyboard for use in Portugal
537746-141	PS/2 basic keyboard for use in Turkey
537746-151	PS/2 basic keyboard for use in Greece
537746-161	PS/2 basic keyboard for use in Latin America (Spanish)
537746-171	PS/2 basic keyboard for use in Saudi Arabia
537746-181	PS/2 basic keyboard for use in Belgium
537746-201	PS/2 basic keyboard for use in Brazil (Portuguese)
537746-211	PS/2 basic keyboard for use in Hungary
537746-221	PS/2 basic keyboard for use in the Czech Republic
537746-231	PS/2 basic keyboard for use in Slovakia
537746-251	PS/2 basic keyboard for use in Russia
537746-261	PS/2 basic keyboard for use in Bulgaria
537746-271	PS/2 basic keyboard for use in Romania
537746-281	PS/2 basic keyboard for use in Thailand
537746-291	PS/2 basic keyboard for use in Japan
537746-351	PS/2 basic keyboard for use in Finland
537746-371	PS/2 basic keyboard for use with International English
537746-AA1	PS/2 basic keyboard for use in the People's Republic of China
537746-AB1	PS/2 basic keyboard for use in Taiwan
537746-BB1	PS/2 basic keyboard for use in Israel (Hebrew)
537746-DE1	PS/2 basic keyboard for use in Saudi Arabia
537746-KD1	PS/2 basic keyboard for use in South Korea
537746-L31	PS/2 basic keyboard for use with international English
537748-001	Mouse, PS2, optical, jack black
538048-001	HP WLAN 802.11b/g/n card
570580-001	Mouse, laser, jack black
570838-001	Bezel blank, 5.25-inch
581599-001	16X SATA DVD-ROM drive
581600-001	16X SATA DVD±RW drive with LightScribe
583345-001	Antenna for use with 538048-001
583653-001	Bezel blank, 3.5-inch
585157-001	Memory module, 4-GB, PC3 10600, 1333-MH
585884-001	Fan with chassis and guard
590270-001	Mouse, USB, BFR-PVC

Spare part number	Description
594220-001	Grommet, hard drive isolation, blue
603250-001	Adapter, DisplayPort to VGA
607817-001	80-GB Solid-state drive
611834-001	System board, TPM (includes replacement thermal material)
613125-001	Washable keyboard for use in the United States
613125-111	Washable keyboard for use in Switzerland
613125-121	Washable keyboard for use in French Canada
613125-131	Washable keyboard for use in Portugal
613125-141	Washable keyboard for use in Turkey
613125-171	Washable keyboard for use in Saudi Arabia
613125-201	Washable keyboard for use in Brazil (Portuguese)
613125-211	Washable keyboard for use in Hungary
613125-221	Washable keyboard for use in the Czech Republic
613125-231	Washable keyboard for use in Slovakia
613125-251	Washable keyboard for use in Russia
613125-261	Washable keyboard for use in Bulgaria
613125-271	Washable keyboard for use in Romania
613125-351	Washable keyboard for use in Finland
613125-AA1	Washable keyboard for use in the People's Republic of China
613125-BB1	Washable keyboard for use in Israel (Hebrew)
613125-DE1	Washable keyboard for use in Saudi Arabia
613125-L31	Washable keyboard for use with international English
613764-001	Power supply, 320W, 90% efficient
613765-001	Power supply, 320W, standard
615114-001	System board, includes TPM for use in 8200 Elite Series models (includes replacement thermal material)
616610-001	USB 3.0 port, PCIe x1 card
617030-001	Blu-ray BD-RW SuperMulti DL Drive with LightScribe
617450-001	Adapter, DisplayPort to HDMI
619580-001	Mouse, washable
631411-001	Smartcard keyboard for use in the United States
631411-031	Smartcard keyboard for use in the United Kingdom
631411-041	Smartcard keyboard for use in Germany
631411-051	Smartcard keyboard for use in France
631411-061	Smartcard keyboard for use in Italy


Spare part number	Description
631411-071	Smartcard keyboard for use in Spain
631411-081	Smartcard keyboard for use in Denmark
631411-091	Smartcard keyboard for use in Norway
631411-101	Smartcard keyboard for use in Sweden
631411-111	Smartcard keyboard for use in Switzerland
631411-121	Smartcard keyboard for use in French Canada
631411-131	Smartcard keyboard for use in Portugal
631411-141	Smartcard keyboard for use in Turkey
631411-151	Smartcard keyboard for use in Greece
631411-161	Smartcard keyboard for use in Latin America (Spanish)
631411-171	Smartcard keyboard for use in Saudi Arabia
631411-181	Smartcard keyboard for use in Belgium
631411-201	Smartcard keyboard for use in Brazil (Portuguese)
631411-211	Smartcard keyboard for use in Hungary
631411-221	Smartcard keyboard for use in the Czech Republic
631411-231	Smartcard keyboard for use in Slovakia
631411-251	Smartcard keyboard for use in Russia
631411-281	Smartcard keyboard for use in Thailand
631411-291	Smartcard keyboard for use in Japan
631411-351	Smartcard keyboard for use in Finland
631411-371	Smartcard keyboard for use with International English
631411-AA1	Smartcard keyboard for use in the People's Republic of China
631411-AB1	Smartcard keyboard for use in Taiwan
631411-BB1	Smartcard keyboard for use in Israel (Hebrew)
631411-DE1	Smartcard keyboard for use in Saudi Arabia
631411-KD1	Smartcard keyboard for use in South Korea
631411-L31	Smartcard keyboard for use with international English
632486-001	nVidia Quadro NVS300 PCIe x16 graphics card, 512 MB
632938-001	750-GB, 7200 RPM hard drive
634824-001	320-GB, 7200 RPM hard drive, 2.5-inch
635523-001	Intel PRO/1000CT NIC, includes bracket
635802-001	Memory module, 1-GB, PC3 10600, 1333-MHz
635803-001	Memory module, 2-GB, PC3 10600, 1333-MHz
636166-001	Card reader, 22-in-1

Spare part number	Description
636917-001	USB powered speakers
636922-001	Chassis fan
636927-001	250-GB, 7200 RPM hard drive
636929-001	500-GB, 7200 RPM hard drive
636930-001	1-TB hard drive
637213-001	AMD FirePro 2270 PCIe x16 graphics card, 512 MB
637591-001	HP FireWire / IEEE 1394a PCIe x1 card
637995-001	ATI Radeon HD6350 PCIe x16 graphics card, 512 MB
637996-001	ATI Radeon HD6450 PCIe x16 graphics card, 512 MB
637997-001	ATI Radeon HD6570 PCIe x16 graphics card, 1 GB
638628-001	Intel Core i3 2100 (3.1-GHz, 3-MB L3 cache)
638629-001	Intel Core i3 2120 (3.3-GHz, 3-MB L3 cache)
638630-001	Intel Core i5 2400 (3.1-GHz, 6-MB L3 cache)
638631-001	Intel Core i5 2500 (3.3-GHz, 6-MB L3 cache)
638632-001	Intel Core i7 2600 (3.4-GHz, 8-MB L3 cache)
638806-001	Hood sensor
638815-001	Serial port PCI card
638816-001	Hood sensor
638817-001	Printer port, PCI card
639694-001	160-GB, 10000 RPM hard drive
639695-001	300-GB, 10000 RPM, SATA3 hard drive
639958-001	SATA cable, 18 inch, 1 straight end, 1 angled end (unlabeled)
639959-001	SATA cable, 17.7 inch, 2 straight ends
641462-001	nVidia Quadro NVS295 PCIe x16 graphics card, 256 MB
641498-001	Solenoid lock
641732-001	nVidia GF405, DVI/VGA PCIe x16 graphics card, 512 MB
645326-001	Heat sink (includes replacement thermal material)
645330-001	Speaker
645558-001	eSATA port assembly, PCI card
646809-001	160-GB Solid-state drive
646824-001	Fan duct assembly
646825-001	Access panel
646826-001	Front bezel
646827-001	Front I/O assembly

Spare part number	Description
646828-001	Power switch/LED with holder
646830-001	SATA cable, 18 inch, 1 straight end, 1 angled end (labeled)
646833-001	Hard drive power cable
646834-001	SATA optical drive power cable
648963-001	300-GB, 10000 RPM, SATA2 hard drive
649515-001	System board, without TPM for use in 8200 Elite Series models (includes replacement thermal material)
649741-001	System board, without TPM for use in 8200 Elite Series models (includes replacement thermal material)

Ultra-Slim Desktop (USDT) chassis spare parts


Computer major components



Item	Description	Spare part number
(1)	Access panel	646816-001
	AC adapter	
	180W	613766-001
	135W	648964-001
(2)	System board (includes replacement thermal material)	
	Includes Trusted Platform Module (TPM)	611836-001
	Does not include TPM	649743-001

Item	Description	Spare part number
(3)	Front bezel	646817-001
	Memory modules (PC3-10600, 1333-MHz; not illustrated)	
	4-GB	646801-001
	2-GB	646800-001
	1-GB	646808-001
	Processors (include replacement thermal material; not illustrated)	
	Intel Core i7 2600S (2.8-GHz, 8-MB L3 cache)	638419-001
	Intel Core i5 2500S (2.7-GHz, 6-MB L3 cache)	638420-001
	Intel Core i5 2400S (2.5-GHz, 6-MB L3 cache)	640953-001
	Intel Core i3 2120 (3.3-GHz, 3-MB L3 cache)	638629-001
	Intel Core i3 2100 (3.1-GHz, 3-MB L3 cache)	638628-001

Cables



Item	Description	Spare part number
(1)	Optical drive cable/connector	605163-001
	Adapter, DisplayPort to VGA	603250-001
	Adapter, DisplayPort to DVI	484156-001
	Adapter, DisplayPort to HDMI	617450-001
	DisplayPort cable	487562-001

Misc parts



Item	Description	Spare part number
Heat sink (includes replacement thermal material)		
(1)	For the processor	587456-001
(2)	For the MXM graphics card	646807-001
	For UMA graphics (not illustrated)	625256-001
(3)	Fan, rear	605155-001
(4)	Card reader	593235-001
(5)	Speaker	647447-001
(6)	Front I/O panel	587458-001

Item	Description	Spare part number
(7)	Rear port cover	646818-001
(8)	Chassis fan, front	646813-001
	Optical drive rail (green plastic piece on drive; not illustrated)	594219-001
	USB powered speakers (not illustrated)	636917-001
	Clamp lock , includes universal cable (plate not included; not illustrated)	508987-001
	Hood sensor	638816-001
	WLAN Antenna Hardware Kit	646811-001
	Keyboard (not illustrated)	
	NOTE: For a list of supported countries and associated dash numbers, see Sequential part number listing on page 53 .	
	PS/2, basic	537745-xxx
	USB, basic	537746-xx1
	Washable	613125-xx1
	Smartcard	631411-xx1
	Mouse (not illustrated)	
	PS2, optical, jack black	537748-001
	USB, BFR-PVC	590270-001
	Washable	619580-001
	Optical, jack black	444740-001
	Laser, jack black	570580-001
	Bezel blank (not illustrated)	593230-001
	Stand	612496-001

Drives

Description	Spare part number
Hard drive	
320-GB, 7200-rpm, 2.5-inch	634824-001
320-GB, 7200-rpm	639135-001
250-GB, 7200-rpm	608746-001
160-GB, 7200-rpm	608745-001
160-GB Solid-state drive	646809-001
80-GB Solid-state drive	607817-001
Optical drive	
Blu-ray BD-RW SuperMulti DL Drive with LightScribe	646810-001

Description	Spare part number
DVD±RW and CD-RW Super Multi Double-Layer Combo Drive with LightScribe.	595115-001
DVD-ROM drive	608394-001
Grommet , hard drive isolation, blue	594220-001

Misc boards

Description	Spare part number
ATI Radeon HD5450M graphics card, 512 MB (without plate)	646812-001
WLAN 802.11a/b/g/n card	631954-001
HP TV Tuner Kit (includes hardware)	613990-001

Sequential part number listing

Spare part number	Description
444740-001	Mouse, optical, jack black
484156-001	Adapter, DisplayPort to DVI
487562-001	DisplayPort cable
508987-001	Clamp lock, includes universal cable (plate not included)
537745-001	PS/2 basic keyboard for use in the United States
537745-031	PS/2 basic keyboard for use in the United Kingdom
537745-041	PS/2 basic keyboard for use in Germany
537745-051	PS/2 basic keyboard for use in France
537745-061	PS/2 basic keyboard for use in Italy
537745-071	PS/2 basic keyboard for use in Spain
537745-081	PS/2 basic keyboard for use in Denmark
537745-091	PS/2 basic keyboard for use in Norway
537745-101	PS/2 basic keyboard for use in Sweden
537745-111	PS/2 basic keyboard for use in Switzerland
537745-121	PS/2 basic keyboard for use in French Canada
537745-131	PS/2 basic keyboard for use in Portugal
537745-141	PS/2 basic keyboard for use in Turkey
537745-151	PS/2 basic keyboard for use in Greece
537745-161	PS/2 basic keyboard for use in Latin America (Spanish)
537745-171	PS/2 basic keyboard for use in Saudi Arabia

Spare part number	Description
537745-181	PS/2 basic keyboard for use in Belgium
537745-201	PS/2 basic keyboard for use in Brazil (Portuguese)
537745-211	PS/2 basic keyboard for use in Hungary
537745-221	PS/2 basic keyboard for use in the Czech Republic
537745-231	PS/2 basic keyboard for use in Slovakia
537745-251	PS/2 basic keyboard for use in Russia
537745-261	PS/2 basic keyboard for use in Bulgaria
537745-271	PS/2 basic keyboard for use in Romania
537745-281	PS/2 basic keyboard for use in Thailand
537745-291	PS/2 basic keyboard for use in Japan
537745-371	PS/2 basic keyboard for use with International English
537745-AA1	PS/2 basic keyboard for use in the People's Republic of China
537745-AB1	PS/2 basic keyboard for use in Taiwan
537745-BB1	PS/2 basic keyboard for use in Israel (Hebrew)
537745-DE1	PS/2 basic keyboard for use in Saudi Arabia
537745-KD1	PS/2 basic keyboard for use in South Korea
537745-L31	PS/2 basic keyboard for use with international English
537746-001	PS/2 basic keyboard for use in the United States
537746-031	PS/2 basic keyboard for use in the United Kingdom
537746-041	PS/2 basic keyboard for use in Germany
537746-051	PS/2 basic keyboard for use in France
537746-061	PS/2 basic keyboard for use in Italy
537746-071	PS/2 basic keyboard for use in Spain
537746-081	PS/2 basic keyboard for use in Denmark
537746-091	PS/2 basic keyboard for use in Norway
537746-101	PS/2 basic keyboard for use in Sweden
537746-111	PS/2 basic keyboard for use in Switzerland
537746-121	PS/2 basic keyboard for use in French Canada
537746-131	PS/2 basic keyboard for use in Portugal
537746-141	PS/2 basic keyboard for use in Turkey
537746-151	PS/2 basic keyboard for use in Greece
537746-161	PS/2 basic keyboard for use in Latin America (Spanish)
537746-171	PS/2 basic keyboard for use in Saudi Arabia
537746-181	PS/2 basic keyboard for use in Belgium

Spare part number	Description
537746-201	PS/2 basic keyboard for use in Brazil (Portuguese)
537746-211	PS/2 basic keyboard for use in Hungary
537746-221	PS/2 basic keyboard for use in the Czech Republic
537746-231	PS/2 basic keyboard for use in Slovakia
537746-251	PS/2 basic keyboard for use in Russia
537746-261	PS/2 basic keyboard for use in Bulgaria
537746-271	PS/2 basic keyboard for use in Romania
537746-281	PS/2 basic keyboard for use in Thailand
537746-291	PS/2 basic keyboard for use in Japan
537746-351	PS/2 basic keyboard for use in Finland
537746-371	PS/2 basic keyboard for use with International English
537746-AA1	PS/2 basic keyboard for use in the People's Republic of China
537746-AB1	PS/2 basic keyboard for use in Taiwan
537746-BB1	PS/2 basic keyboard for use in Israel (Hebrew)
537746-DE1	PS/2 basic keyboard for use in Saudi Arabia
537746-KD1	PS/2 basic keyboard for use in South Korea
537746-L31	PS/2 basic keyboard for use with international English
537748-001	Mouse, PS2, optical, jack black
570580-001	Mouse, laser, jack black
587456-001	Heat sink – processor (includes replacement thermal material)
587458-001	Front I/O panel
590270-001	Mouse, USB, BFR-PVC
593230-001	Bezel blank
593235-001	Card reader
594219-001	Optical drive rail and cable kit
594220-001	Grommet, hard drive isolation, blue
595115-001	DVD±RW and CD-RW Super Multi Double-Layer Combo Drive with LightScribe.
603250-001	Adapter, DisplayPort to VGA
605155-001	Fan, rear
605163-001	Optical drive cable/connector
607817-001	80-GB Solid-state drive
608394-001	DVD-ROM drive
608745-001	160-GB, 7200-rpm hard drive
608746-001	250-GB, 7200 RPM hard drive


Spare part number	Description
611836-001	System board, TPM (includes replacement thermal material)
612496-001	Stand
613125-001	Washable keyboard for use in the United States
613125-111	Washable keyboard for use in Switzerland
613125-121	Washable keyboard for use in French Canada
613125-131	Washable keyboard for use in Portugal
613125-141	Washable keyboard for use in Turkey
613125-171	Washable keyboard for use in Saudi Arabia
613125-201	Washable keyboard for use in Brazil (Portuguese)
613125-211	Washable keyboard for use in Hungary
613125-221	Washable keyboard for use in the Czech Republic
613125-231	Washable keyboard for use in Slovakia
613125-251	Washable keyboard for use in Russia
613125-261	Washable keyboard for use in Bulgaria
613125-271	Washable keyboard for use in Romania
613125-351	Washable keyboard for use in Finland
613125-AA1	Washable keyboard for use in the People's Republic of China
613125-BB1	Washable keyboard for use in Israel (Hebrew)
613125-DE1	Washable keyboard for use in Saudi Arabia
613125-L31	Washable keyboard for use with international English
613766-001	AC adapter, 180W
613990-001	HP TV Tuner Kit (includes hardware)
617450-001	Adapter, DisplayPort to HDMI
619580-001	Mouse, washable
625256-001	Heat sink for use with UMA graphics
631411-001	Smartcard keyboard for use in the United States
631411-031	Smartcard keyboard for use in the United Kingdom
631411-041	Smartcard keyboard for use in Germany
631411-051	Smartcard keyboard for use in France
631411-061	Smartcard keyboard for use in Italy
631411-071	Smartcard keyboard for use in Spain
631411-081	Smartcard keyboard for use in Denmark
631411-091	Smartcard keyboard for use in Norway
631411-101	Smartcard keyboard for use in Sweden

Spare part number	Description
631411-111	Smartcard keyboard for use in Switzerland
631411-121	Smartcard keyboard for use in French Canada
631411-131	Smartcard keyboard for use in Portugal
631411-141	Smartcard keyboard for use in Turkey
631411-151	Smartcard keyboard for use in Greece
631411-161	Smartcard keyboard for use in Latin America (Spanish)
631411-171	Smartcard keyboard for use in Saudi Arabia
631411-181	Smartcard keyboard for use in Belgium
631411-201	Smartcard keyboard for use in Brazil (Portuguese)
631411-211	Smartcard keyboard for use in Hungary
631411-221	Smartcard keyboard for use in the Czech Republic
631411-231	Smartcard keyboard for use in Slovakia
631411-251	Smartcard keyboard for use in Russia
631411-281	Smartcard keyboard for use in Thailand
631411-291	Smartcard keyboard for use in Japan
631411-351	Smartcard keyboard for use in Finland
631411-371	Smartcard keyboard for use with International English
631411-AA1	Smartcard keyboard for use in the People's Republic of China
631411-AB1	Smartcard keyboard for use in Taiwan
631411-BB1	Smartcard keyboard for use in Israel (Hebrew)
631411-DE1	Smartcard keyboard for use in Saudi Arabia
631411-KD1	Smartcard keyboard for use in South Korea
631411-L31	Smartcard keyboard for use with international English
631954-001	WLAN 802.11a/b/g/n card
634824-001	320-GB, 7200 RPM hard drive, 2.5-inch
636917-001	USB powered speakers
638419-001	Intel Core i7 2600S (2.8-GHz, 8-MB L3 cache)
638420-001	Intel Core i5 2500S (2.5-GHz, 6-MB L3 cache)
638628-001	Intel Core i3 2100 (3.1-GHz, 3-MB L3 cache)
638629-001	Intel Core i3 2120 (3.3-GHz, 3-MB L3 cache)
638816-001	Hood sensor
639135-001	320-GB, 7200 RPM
640953-001	Intel Core i5 2400S (2.5-GHz, 6-MB L3 cache)
646800-001	Memory module, 2-GB, PC3 10600, 1333-MHz

Spare part number	Description
646801-001	Memory module, 4-GB, PC3 10600, 1333-MH
646807-001	Heat sink for use on the MXM graphics card
646808-001	Memory module, 1-GB, PC3 10600, 1333-MHz
646809-001	160-GB Solid-state drive
646810-001	Blu-ray BD-RW SuperMulti DL Drive with LightScribe
646811-001	Antenna for use with 538048-001
646812-001	ATI Radeon HD5450M graphics card, 512 MB (without plate)
646813-001	Fan, front
646816-001	Access panel
646817-001	Front bezel
646818-001	Rear port cover
647447-001	Speaker
648964-001	AC adapter, 135W
649743-001	System board, no TPM (includes replacement thermal material)


Small Form Factor (SFF) chassis spare parts

Computer major components




Item	Description	Spare part number
(1)	Front bezel	646814-001
(2)	Power supply	
	90% efficient	613762-001
	Standard	613763-001
(3)	System board (includes replacement thermal material)	
	For use in 8200 Pro Series models:	
	• Includes Trusted Platform Module (TPM)	611834-001
	• Does not include TPM	649741-001
	For use in 6200 Pro Series models:	
	• Includes Trusted Platform Module (TPM)	615114-001
	• Does not include TPM	649515-001
(4)	Access panel	646815-001
	Memory modules (PC3-10600, 1333-MHz; not illustrated)	
	4-GB	585157-001
	2-GB	635803-001
	1-GB	635802-001
	Processors (include replacement thermal material; not illustrated)	
	Intel Core i7 2600 (3.4-GHz, 8-MB L3 cache)	638632-001
	Intel Core i5 2500 (3.3-GHz, 6-MB L3 cache)	638631-001
	Intel Core i5 2400 (3.1-GHz, 6-MB L3 cache)	638630-001
	Intel Core i3 2120 (3.3-GHz, 3-MB L3 cache)	638629-001
	Intel Core i3 2100 (3.1-GHz, 3-MB L3 cache)	638628-001

Cables



Item	Description	Spare part number
(1)	Front I/O and power switch assembly	636926-001
(2)	SATA cable, 19.5 inch, 2 straight ends	638813-001
(3)	SATA drive power cable	636923-001
	SATA cable, 25.2 inch, 1 straight end, 1 angled end (not illustrated)	638814-001
	DMS-59 to dual VGA cable	463023-001
	Adapter, DisplayPort to VGA	603250-001
	Adapter, DisplayPort to DVI	484156-001
	Adapter, DisplayPort to HDMI	617450-001
	DisplayPort cable	487562-001

Misc parts



Item	Description	Spare part number
(1)	Chassis fan	645327-001
(2)	Fan duct (not illustrated)	636921-001
(3)	Heat sink (includes replacement thermal material)	645326-001
(4)	Speaker	636925-001
(5)	Solenoid lock	641498-001
(6)	Hood sensor	638816-001
	Card reader, 22-in-1 (not illustrated)	636166-001
	USB powered speakers (not illustrated)	636917-001
	Clamp lock, includes universal cable (plate not included; not illustrated)	508987-001
	Keyboard (not illustrated)	
	NOTE: For a list of supported countries and associated dash numbers, see Sequential part number listing on page 42 .	
	PS/2, basic	537745-xxx
	USB, basic	537746-xx1

Item	Description	Spare part number
	USB mini	611375x-xx1
	Washable	613125-xx1
	Smartcard	631411-xx4
	Mouse (not illustrated)	
	PS2, optical, jack black	537748-001
	USB, BFR-PVC	590270-001
	Washable	619580-001
	Optical, jack black	444740-001
	Laser, jack black	570580-001

Drives

Description	Spare part number
Hard drive	
1-TB, 7200-rpm	636930-001
750-GB, 7200-rpm	632938-001
500-GB, 7200-rpm	636929-001
320-GB, 7200-rpm, 2.5-inch	634824-001
300-GB, 10000-rpm, SATA3	639695-001
300-GB, 10000-rpm, SATA2	648963-001
250-GB, 7200-rpm	636927-001
160-GB, 10000-rpm	639694-001
160-GB, 10000-rpm, 2.5-inch	508312-001
160-GB Solid-state drive	646809-001
80-GB Solid-state drive	607817-001
Optical drive	
Blu-ray BD-RW SuperMulti DL Drive with LightScribe	617030-001
16X SATA DVD±RW drive with LightScribe	581600-001
16X SATA DVD-ROM drive	581599-001
Grommet , hard drive isolation, blue	594220-001

Misc boards

Description	Spare part number
Graphics cards	
nVidia Quadro NVS295 PCIe x16 graphics card, 256 MB	641462-001
nVidia Quadro NVS300 PCIe x16 graphics card, 512 MB	632486-001
ATI Radeon HD6350 PCIe x16 graphics card, 512 MB	637995-001
ATI Radeon HD6450 PCIe x16 graphics card, 512 MB	637996-001
AMD FirePro 2270 PCIe x16 graphics card, 512 MB	637213-001
HP FireWire / IEEE 1394a PCIe x1 card	637591-001
Ports	
eSATA port assembly, PCI card	645558-001
USB 3.0 port, PCIe x1 card	616610-001
Serial port, PCI card	638815-001
Printer port, PCI card	638817-001
Other boards/cards	
HP WLAN 802.11b/g/n	538048-001
Antenna for use with 538048-001	583345-001
Intel PRO/1000CT NIC, includes bracket	635523-001

Sequential part number listing

Spare part number	Description
444740-001	Mouse, optical, jack black
463023-001	DMS-59 to dual VGA cable
484156-001	Adapter, DisplayPort to DVI
487562-001	DisplayPort cable
508312-001	160-GB, 10000-rpm, 2.5-inch hard drive
508987-001	Clamp lock, includes universal cable (plate not included)
537745-001	PS/2 basic keyboard for use in the United States
537745-031	PS/2 basic keyboard for use in the United Kingdom
537745-041	PS/2 basic keyboard for use in Germany
537745-051	PS/2 basic keyboard for use in France
537745-061	PS/2 basic keyboard for use in Italy
537745-071	PS/2 basic keyboard for use in Spain
537745-081	PS/2 basic keyboard for use in Denmark
537745-091	PS/2 basic keyboard for use in Norway
537745-101	PS/2 basic keyboard for use in Sweden
537745-111	PS/2 basic keyboard for use in Switzerland
537745-121	PS/2 basic keyboard for use in French Canada
537745-131	PS/2 basic keyboard for use in Portugal
537745-141	PS/2 basic keyboard for use in Turkey
537745-151	PS/2 basic keyboard for use in Greece
537745-161	PS/2 basic keyboard for use in Latin America (Spanish)
537745-171	PS/2 basic keyboard for use in Saudi Arabia
537745-181	PS/2 basic keyboard for use in Belgium
537745-201	PS/2 basic keyboard for use in Brazil (Portuguese)
537745-211	PS/2 basic keyboard for use in Hungary
537745-221	PS/2 basic keyboard for use in the Czech Republic
537745-231	PS/2 basic keyboard for use in Slovakia
537745-251	PS/2 basic keyboard for use in Russia
537745-261	PS/2 basic keyboard for use in Bulgaria
537745-271	PS/2 basic keyboard for use in Romania
537745-281	PS/2 basic keyboard for use in Thailand
537745-291	PS/2 basic keyboard for use in Japan

Spare part number	Description
537745-371	PS/2 basic keyboard for use with International English
537745-AA1	PS/2 basic keyboard for use in the People's Republic of China
537745-AB1	PS/2 basic keyboard for use in Taiwan
537745-BB1	PS/2 basic keyboard for use in Israel (Hebrew)
537745-DE1	PS/2 basic keyboard for use in Saudi Arabia
537745-KD1	PS/2 basic keyboard for use in South Korea
537745-L31	PS/2 basic keyboard for use with international English
537746-001	PS/2 basic keyboard for use in the United States
537746-031	PS/2 basic keyboard for use in the United Kingdom
537746-041	PS/2 basic keyboard for use in Germany
537746-051	PS/2 basic keyboard for use in France
537746-061	PS/2 basic keyboard for use in Italy
537746-071	PS/2 basic keyboard for use in Spain
537746-081	PS/2 basic keyboard for use in Denmark
537746-091	PS/2 basic keyboard for use in Norway
537746-101	PS/2 basic keyboard for use in Sweden
537746-111	PS/2 basic keyboard for use in Switzerland
537746-121	PS/2 basic keyboard for use in French Canada
537746-131	PS/2 basic keyboard for use in Portugal
537746-141	PS/2 basic keyboard for use in Turkey
537746-151	PS/2 basic keyboard for use in Greece
537746-161	PS/2 basic keyboard for use in Latin America (Spanish)
537746-171	PS/2 basic keyboard for use in Saudi Arabia
537746-181	PS/2 basic keyboard for use in Belgium
537746-201	PS/2 basic keyboard for use in Brazil (Portuguese)
537746-211	PS/2 basic keyboard for use in Hungary
537746-221	PS/2 basic keyboard for use in the Czech Republic
537746-231	PS/2 basic keyboard for use in Slovakia
537746-251	PS/2 basic keyboard for use in Russia
537746-261	PS/2 basic keyboard for use in Bulgaria
537746-271	PS/2 basic keyboard for use in Romania
537746-281	PS/2 basic keyboard for use in Thailand
537746-291	PS/2 basic keyboard for use in Japan
537746-351	PS/2 basic keyboard for use in Finland

Spare part number	Description
537746-371	PS/2 basic keyboard for use with International English
537746-AA1	PS/2 basic keyboard for use in the People's Republic of China
537746-AB1	PS/2 basic keyboard for use in Taiwan
537746-BB1	PS/2 basic keyboard for use in Israel (Hebrew)
537746-DE1	PS/2 basic keyboard for use in Saudi Arabia
537746-KD1	PS/2 basic keyboard for use in South Korea
537746-L31	PS/2 basic keyboard for use with international English
537748-001	Mouse, PS2, optical, jack black
538048-001	HP WLAN 802.11b/g/n card
570580-001	Mouse, laser, jack black
581599-001	16X SATA DVD-ROM drive
581600-001	16X SATA DVD±RW drive with LightScribe
583345-001	Antenna for use with 538048-001
585157-001	Memory module, 4-GB, PC3 10600, 1333-MH
590270-001	Mouse, USB, BFR-PVC
594220-001	Grommet, hard drive isolation, blue
603250-001	Adapter, DisplayPort to VGA
607817-001	80-GB Solid-state drive
611375-001	USB mini keyboard for use in the United States
611375-121	USB mini keyboard for use in the French Canada
611834-001	System board, includes TPM for use in 8200 Elite Series models (includes replacement thermal material)
613125-001	Washable keyboard for use in the United States
613125-111	Washable keyboard for use in Switzerland
613125-121	Washable keyboard for use in French Canada
613125-131	Washable keyboard for use in Portugal
613125-141	Washable keyboard for use in Turkey
613125-171	Washable keyboard for use in Saudi Arabia
613125-201	Washable keyboard for use in Brazil (Portuguese)
613125-211	Washable keyboard for use in Hungary
613125-221	Washable keyboard for use in the Czech Republic
613125-231	Washable keyboard for use in Slovakia
613125-251	Washable keyboard for use in Russia
613125-261	Washable keyboard for use in Bulgaria
613125-271	Washable keyboard for use in Romania


Spare part number	Description
613125-351	Washable keyboard for use in Finland
613125-AA1	Washable keyboard for use in the People's Republic of China
613125-BB1	Washable keyboard for use in Israel (Hebrew)
613125-DE1	Washable keyboard for use in Saudi Arabia
613125-L31	Washable keyboard for use with international English
613762-001	Power supply, 90% efficient
613763-001	Power supply, standard
615114-001	System board, includes TPM for use in 6200 Pro Series models (includes replacement thermal material)
616610-001	USB 3.0 port, PCIe x1 card
617030-001	Blu-ray BD-RW SuperMulti DL Drive with LightScribe
617450-001	Adapter, DisplayPort to HDMI
619580-001	Mouse, washable
631411-001	Smartcard keyboard for use in the United States
631411-031	Smartcard keyboard for use in the United Kingdom
631411-041	Smartcard keyboard for use in Germany
631411-051	Smartcard keyboard for use in France
631411-061	Smartcard keyboard for use in Italy
631411-071	Smartcard keyboard for use in Spain
631411-081	Smartcard keyboard for use in Denmark
631411-091	Smartcard keyboard for use in Norway
631411-101	Smartcard keyboard for use in Sweden
631411-111	Smartcard keyboard for use in Switzerland
631411-121	Smartcard keyboard for use in French Canada
631411-131	Smartcard keyboard for use in Portugal
631411-141	Smartcard keyboard for use in Turkey
631411-151	Smartcard keyboard for use in Greece
631411-161	Smartcard keyboard for use in Latin America (Spanish)
631411-171	Smartcard keyboard for use in Saudi Arabia
631411-181	Smartcard keyboard for use in Belgium
631411-201	Smartcard keyboard for use in Brazil (Portuguese)
631411-211	Smartcard keyboard for use in Hungary
631411-221	Smartcard keyboard for use in the Czech Republic
631411-231	Smartcard keyboard for use in Slovakia
631411-251	Smartcard keyboard for use in Russia

Spare part number	Description
631411-281	Smartcard keyboard for use in Thailand
631411-291	Smartcard keyboard for use in Japan
631411-351	Smartcard keyboard for use in Finland
631411-371	Smartcard keyboard for use with International English
631411-AA1	Smartcard keyboard for use in the People's Republic of China
631411-AB1	Smartcard keyboard for use in Taiwan
631411-BB1	Smartcard keyboard for use in Israel (Hebrew)
631411-DE1	Smartcard keyboard for use in Saudi Arabia
631411-KD1	Smartcard keyboard for use in South Korea
631411-L31	Smartcard keyboard for use with international English
632486-001	nVidia Quadro NVS300 PCIe x16 graphics card, 512 MB
632938-001	750-GB, 7200 RPM hard drive
634824-001	320-GB, 7200 RPM hard drive, 2.5-inch
635523-001	Intel PRO/1000CT NIC, includes bracket
635802-001	Memory module, 1-GB, PC3 10600, 1333-MHz
635803-001	Memory module, 2-GB, PC3 10600, 1333-MHz
636166-001	Card reader, 22-in-1
636917-001	USB powered speakers
636921-001	Fan duct
636923-001	SATA drive power cable
636925-001	Speaker
636926-001	Front I/O assembly
636927-001	250-GB, 7200 RPM hard drive
636929-001	500-GB, 7200 RPM hard drive
636930-001	1-TB hard drive
637213-001	AMD FirePro 2270 PCIe x16 graphics card, 512 MB
637591-001	HP FireWire / IEEE 1394a PCIe x1 card
637995-001	ATI Radeon HD6350 PCIe x16 graphics card, 512 MB
637996-001	ATI Radeon HD6450 PCIe x16 graphics card, 512 MB
638628-001	Intel Core i3 2100 (3.1-GHz, 3-MB L3 cache)
638629-001	Intel Core i3 2120 (3.3-GHz, 3-MB L3 cache)
638630-001	Intel Core i5 2400 (3.1-GHz, 6-MB L3 cache)
638631-001	Intel Core i5 2500 (3.3-GHz, 6-MB L3 cache)
638632-001	Intel Core i7 2600 (3.4-GHz, 8-MB L3 cache)

Spare part number	Description
638806-001	Hood sensor
638813-001	SATA cable, 19.5 inch, 2 straight ends
638814-001	SATA cable, 25.2 inch, 1 straight end, 1 angled end
638815-001	Serial port PCI card
638816-001	Hood sensor
638817-001	Printer port, PCI card
639694-001	160-GB, 10000 RPM hard drive
639695-001	300-GB, 10000 RPM, SATA3 hard drive
641462-001	nVidia Quadro NVS295 PCIe x16 graphics card, 256 MB
641498-001	Solenoid lock
645326-001	Heat sink (includes replacement thermal material)
645327-001	Chassis fan
645558-001	eSATA port assembly, PCI card
646809-001	160-GB Solid-state drive
646815-001	Access panel
646814-001	Front bezel
648963-001	300-GB, 10000 RPM, SATA2 hard drive
649515-001	System board, without TPM for use in 6200 Pro Series models (includes replacement thermal material)
649741-001	System board, without TPM for use in 8200 Elite Series models (includes replacement thermal material)

4 Routine Care, SATA Drive Guidelines, and Disassembly Preparation

This chapter provides general service information for the computer. Adherence to the procedures and precautions described in this chapter is essential for proper service.

 **CAUTION:** When the computer is plugged into an AC power source, voltage is always applied to the system board. You must disconnect the power cord from the power source before opening the computer to prevent system board or component damage.

Electrostatic Discharge Information

A sudden discharge of static electricity from your finger or other conductor can destroy static-sensitive devices or microcircuitry. Often the spark is neither felt nor heard, but damage occurs. An electronic device exposed to electrostatic discharge (ESD) may not appear to be affected at all and can work perfectly throughout a normal cycle. The device may function normally for a while, but it has been degraded in the internal layers, reducing its life expectancy.


Networks built into many integrated circuits provide some protection, but in many cases, the discharge contains enough power to alter device parameters or melt silicon junctions.

Generating Static

The following table shows that:

- Different activities generate different amounts of static electricity.
- Static electricity increases as humidity decreases.

Event	Relative Humidity		
	55%	40%	10%
Walking across carpet	7,500 V	15,000 V	35,000 V
Walking across vinyl floor	3,000 V	5,000 V	12,000 V
Motions of bench worker	400 V	800 V	6,000 V
Removing DIPs from plastic tube	400 V	700 V	2,000 V
Removing DIPs from vinyl tray	2,000 V	4,000 V	11,500 V
Removing DIPs from Styrofoam	3,500 V	5,000 V	14,500 V
Removing bubble pack from PCB	7,000 V	20,000 V	26,500 V
Packing PCBs in foam-lined box	5,000 V	11,000 V	21,000 V
These are then multi-packaged inside plastic tubes, trays, or Styrofoam.			

 **NOTE:** 700 volts can degrade a product.

Preventing Electrostatic Damage to Equipment

Many electronic components are sensitive to ESD. Circuitry design and structure determine the degree of sensitivity. The following packaging and grounding precautions are necessary to prevent damage to electric components and accessories.

- To avoid hand contact, transport products in static-safe containers such as tubes, bags, or boxes.
- Protect all electrostatic parts and assemblies with conductive or approved containers or packaging.
- Keep electrostatic sensitive parts in their containers until they arrive at static-free stations.
- Place items on a grounded surface before removing them from their container.

- Always be properly grounded when touching a sensitive component or assembly.
- Avoid contact with pins, leads, or circuitry.
- Place reusable electrostatic-sensitive parts from assemblies in protective packaging or conductive foam.

Personal Grounding Methods and Equipment

Use the following equipment to prevent static electricity damage to equipment:

- **Wrist straps** are flexible straps with a maximum of one-megohm \pm 10% resistance in the ground cords. To provide proper ground, a strap must be worn snug against bare skin. The ground cord must be connected and fit snugly into the banana plug connector on the grounding mat or workstation.
- **Heel straps/Toe straps/Boot straps** can be used at standing workstations and are compatible with most types of shoes or boots. On conductive floors or dissipative floor mats, use them on both feet with a maximum of one-megohm \pm 10% resistance between the operator and ground.

Static Shielding Protection Levels	
Method	Voltage
Antistatic plastic	1,500
Carbon-loaded plastic	7,500
Metallized laminate	15,000

Grounding the Work Area

To prevent static damage at the work area, use the following precautions:

- Cover the work surface with approved static-dissipative material. Provide a wrist strap connected to the work surface and properly grounded tools and equipment.
- Use static-dissipative mats, foot straps, or air ionizers to give added protection.
- Handle electrostatic sensitive components, parts, and assemblies by the case or PCB laminate. Handle them only at static-free work areas.
- Turn off power and input signals before inserting and removing connectors or test equipment.
- Use fixtures made of static-safe materials when fixtures must directly contact dissipative surfaces.
- Keep work area free of nonconductive materials such as ordinary plastic assembly aids and Styrofoam.
- Use field service tools, such as cutters, screwdrivers, and vacuums, that are conductive.

Recommended Materials and Equipment

Materials and equipment that are recommended for use in preventing static electricity include:

- Antistatic tape
- Antistatic smocks, aprons, or sleeve protectors

- Conductive bins and other assembly or soldering aids
- Conductive foam
- Conductive tabletop workstations with ground cord of one-megohm +/- 10% resistance
- Static-dissipative table or floor mats with hard tie to ground
- Field service kits
- Static awareness labels
- Wrist straps and footwear straps providing one-megohm +/- 10% resistance
- Material handling packages
- Conductive plastic bags
- Conductive plastic tubes
- Conductive tote boxes
- Opaque shielding bags
- Transparent metallized shielding bags
- Transparent shielding tubes

Operating Guidelines

To prevent overheating and to help prolong the life of the computer:

- Keep the computer away from excessive moisture, direct sunlight, and extremes of heat and cold.
- Operate the computer on a sturdy, level surface. Leave a 10.2-cm (4-inch) clearance on all vented sides of the computer and above the monitor to permit the required airflow.
- Never restrict the airflow into the computer by blocking any vents or air intakes. Do not place the keyboard, with the keyboard feet down, directly against the front of the desktop unit as this also restricts airflow.
- Occasionally clean the air vents on all vented sides of the computer. Lint, dust, and other foreign matter can block the vents and limit the airflow. Be sure to unplug the computer before cleaning the air vents.
- Never operate the computer with the cover or side panel removed.
- Do not stack computers on top of each other or place computers so near each other that they are subject to each other's re-circulated or preheated air.
- If the computer is to be operated within a separate enclosure, intake and exhaust ventilation must be provided on the enclosure, and the same operating guidelines listed above will still apply.
- Keep liquids away from the computer and keyboard.

- Never cover the ventilation slots on the monitor with any type of material.
- Install or enable power management functions of the operating system or other software, including sleep states.

Routine Care

General Cleaning Safety Precautions

1. Never use solvents or flammable solutions to clean the computer.
2. Never immerse any parts in water or cleaning solutions; apply any liquids to a clean cloth and then use the cloth on the component.
3. Always unplug the computer when cleaning with liquids or damp cloths.
4. Always unplug the computer before cleaning the keyboard, mouse, or air vents.
5. Disconnect the keyboard before cleaning it.
6. Wear safety glasses equipped with side shields when cleaning the keyboard.

Cleaning the Computer Case

Follow all safety precautions in [General Cleaning Safety Precautions on page 63](#) before cleaning the computer.

To clean the computer case, follow the procedures described below:


- To remove light stains or dirt, use plain water with a clean, lint-free cloth or swab.
- For stronger stains, use a mild dishwashing liquid diluted with water. Rinse well by wiping it with a cloth or swab dampened with clear water.
- For stubborn stains, use isopropyl (rubbing) alcohol. No rinsing is needed as the alcohol will evaporate quickly and not leave a residue.
- After cleaning, always wipe the unit with a clean, lint-free cloth.
- Occasionally clean the air vents on the computer. Lint and other foreign matter can block the vents and limit the airflow.

Cleaning the Keyboard


Follow all safety precautions in [General Cleaning Safety Precautions on page 63](#) before cleaning the keyboard.

To clean the tops of the keys or the keyboard body, follow the procedures described in [Cleaning the Computer Case on page 63](#).

When cleaning debris from under the keys, review all rules in [General Cleaning Safety Precautions on page 63](#) before following these procedures:

 **CAUTION:** Use safety glasses equipped with side shields before attempting to clean debris from under the keys.

- Visible debris underneath or between the keys may be removed by vacuuming or shaking.
- Canned, pressurized air may be used to clean debris from under the keys. Caution should be used as too much air pressure can dislodge lubricants applied under the wide keys.
- If you remove a key, use a specially designed key puller to prevent damage to the keys. This tool is available through many electronic supply outlets.

 **CAUTION:** Never remove a wide leveled key (like the space bar) from the keyboard. If these keys are improperly removed or installed, the keyboard may not function properly.

- Cleaning under a key may be done with a swab moistened with isopropyl alcohol and squeezed out. Be careful not to wipe away lubricants necessary for proper key functions. Use tweezers to remove any fibers or dirt in confined areas. Allow the parts to air dry before reassembly.

Cleaning the Monitor

- Wipe the monitor screen with a clean cloth moistened with water or with a towelette designed for cleaning monitors. Do not use sprays or aerosols directly on the screen; the liquid may seep into the housing and damage a component. Never use solvents or flammable liquids on the monitor.
- To clean the monitor body follow the procedures in [Cleaning the Computer Case on page 63](#).

Cleaning the Mouse

Before cleaning the mouse, ensure that the power to the computer is turned off.


- Clean the mouse ball by first removing the retaining plate and the ball from the housing. Pull out any debris from the ball socket and wipe the ball with a clean, dry cloth before reassembly.
- To clean the mouse body, follow the procedures in [Cleaning the Computer Case on page 63](#).

Service Considerations

Listed below are some of the considerations that you should keep in mind during the disassembly and assembly of the computer.

Power Supply Fan

The power supply fan is a variable-speed fan based on the temperature in the power supply.

 **CAUTION:** The cooling fan is always on when the computer is in the “On” mode. The cooling fan is off when the computer is in “Standby,” “Suspend,” or “Off” modes.

You must disconnect the power cord from the power source before opening the computer to prevent system board or component damage.


Tools and Software Requirements

To service the computer, you need the following:

- Torx T-15 screwdriver (HP screwdriver with bits, PN 161946-001)
- Torx T-15 screwdriver with small diameter shank (for certain front bezel removal)
- Flat-bladed screwdriver (may sometimes be used in place of the Torx screwdriver)
- Phillips #2 screwdriver
- Diagnostics software
- HP tamper-resistant T-15 wrench (Smart Cover FailSafe Key, PN 166527-001) or HP tamper-resistant bits (Smart Cover FailSafe Key, PN 166527-002)

Screws


The screws used in the computer are not interchangeable. They may have standard or metric threads and may be of different lengths. If an incorrect screw is used during the reassembly process, it can damage the unit. HP strongly recommends that all screws removed during disassembly be kept with the part that was removed, then returned to their proper locations.

 **CAUTION:** Metric screws have a black finish. U.S. screws have a silver finish and are used on hard drives only.

CAUTION: As each subassembly is removed from the computer, it should be placed away from the work area to prevent damage.

Cables and Connectors

Most cables used throughout the unit are flat, flexible cables. These cables must be handled with care to avoid damage. Apply only the tension required to seat or unseat the cables during insertion or removal from the connector. Handle cables by the connector whenever possible. In all cases, avoid bending or twisting the cables, and ensure that the cables are routed in such a way that they cannot be caught or snagged by parts being removed or replaced.

 **CAUTION:** When servicing this computer, ensure that cables are placed in their proper location during the reassembly process. Improper cable placement can damage the computer.

Hard Drives

Handle hard drives as delicate, precision components, avoiding all physical shock and vibration. This applies to failed drives as well as replacement spares.


- If a drive must be mailed, place the drive in a bubble-pack mailer or other suitable protective packaging and label the package “Fragile: Handle With Care.”
- Do not remove hard drives from the shipping package for storage. Keep hard drives in their protective packaging until they are actually mounted in the CPU.
- Avoid dropping drives from any height onto any surface.
- If you are inserting or removing a hard drive, turn off the computer. Do not remove a hard drive while the computer is on or in standby mode.


- Before handling a drive, ensure that you are discharged of static electricity. While handling a drive, avoid touching the connector. For more information about preventing electrostatic damage, refer to [Electrostatic Discharge Information on page 60](#)
- Do not use excessive force when inserting a drive.
- Avoid exposing a hard drive to liquids, temperature extremes, or products that have magnetic fields such as monitors or speakers.

Lithium Coin Cell Battery

The battery that comes with the computer provides power to the real-time clock and has a minimum lifetime of about three years.

See the appropriate removal and replacement chapter for the chassis you are working on in this guide for instructions on the replacement procedures.

 **WARNING!** This computer contains a lithium battery. There is a risk of fire and chemical burn if the battery is handled improperly. Do not disassemble, crush, puncture, short external contacts, dispose in water or fire, or expose it to temperatures higher than 140°F (60°C). Do not attempt to recharge the battery.

 **NOTE:** Batteries, battery packs, and accumulators should not be disposed of together with the general household waste. In order to forward them to recycling or proper disposal, please use the public collection system or return them to HP, their authorized partners, or their agents.

SATA Hard Drives

Serial ATA Hard Drive Characteristics	
Number of pins/conductors in data cable	7/7
Number of pins in power cable	15
Maximum data cable length	39.37 in (100 cm)
Data interface voltage differential	400-700 mV
Drive voltages	3.3 V, 5 V, 12 V
Jumpers for configuring drive	N/A
Data transfer rate	3.0 Gb/s

SATA Hard Drive Cables

SATA Data Cable

Always use an HP approved SATA 3.0 Gb/s cable as it is fully backwards compatible with the SATA 1.5 Gb/s drives.

Current HP desktop products ship with SATA 3.0 Gb/s hard drives.

SATA data cables are susceptible to damage if overflexed. Never crease a SATA data cable and never bend it tighter than a 30 mm (1.18 in) radius.

The SATA data cable is a thin, 7-pin cable designed to transmit data for only a single drive.

SMART ATA Drives

The Self Monitoring Analysis and Recording Technology (SMART) ATA drives for the HP Personal Computers have built-in drive failure prediction that warns the user or network administrator of an impending failure or crash of the hard drive. The SMART drive tracks fault prediction and failure indication parameters such as reallocated sector count, spin retry count, and calibration retry count. If the drive determines that a failure is imminent, it generates a fault alert.

Cable Management

Always follow good cable management practices when working inside the computer.

- Keep cables away from major heat sources like the heat sink.
- Do not jam cables on top of expansion cards or memory modules. Printed circuit cards like these are not designed to take excessive pressure on them.
- Keep cables clear of sliding or moveable parts to prevent them from being cut or crimped when the parts are moved.
- When folding a flat ribbon cable, never fold to a sharp crease. Sharp creases may damage the wires.

- Some flat ribbon cables come prefolded. Never change the folds on these cables.
- Do not bend any cable sharply. A sharp bend can break the internal wires.
- Never bend a SATA data cable tighter than a 30 mm (1.18 in) radius.
- Never crease a SATA data cable.
- Do not rely on components like the drive cage, power supply, or computer cover to push cables down into the chassis. Always position the cables to lay properly by themselves.

Hard Drive Capacities

The combination of the file system and the operating system used in the computer determines the maximum usable size of a drive partition. A drive partition is the largest segment of a drive that may be properly accessed by the operating system. A single hard drive may therefore be subdivided into a number of unique drive partitions in order to make use of all of its space.

Because of the differences in the way that drive sizes are calculated, the size reported by the operating system may differ from that marked on the hard drive or listed in the computer specification. Drive size calculations by drive manufacturers are bytes to the base 10 while calculations by Microsoft are bytes to the base 2.

Drive/Partition Capacity Limits				
			Maximum Size	
File System	Controller Type	Operating System	Partition	Drive
FAT 32	ATA	Windows XP/Windows Vista/Windows 7	32 GB	2 TB
NTFS	ATA	Windows XP/Windows Vista/Windows 7	2 TB	2 TB

5 Configurations and Serial Number

Standard Configuration Features

Features may vary depending on the model. For a complete listing of the hardware and software installed in the computer, run the diagnostic utility (included on some computer models only).

Figure 5-1 Convertible Minitower Configuration




 **NOTE:** The HP Compaq Convertible Minitower computer can be easily converted to a desktop. For more information, see [Changing from a Minitower to a Desktop Configuration on page 120](#) in this guide.

Figure 5-2 Microtower Configuration



Figure 5-3 Small Form Factor Configuration




 **NOTE:** The Small Form Factor computer can also be used in a tower orientation. For more information, see [Using the Small Form Factor Computer in a Tower Orientation on page 205](#) in this guide.

Figure 5-4 Ultra-Slim Desktop Configuration



Serial Number Location

Each computer has a unique serial number and a product ID number that are located on the top cover of the computer. Keep these numbers available for use when contacting customer service for assistance.

Figure 5-5 Convertible Minitower Serial Number and Product ID Location



Figure 5-6 Microtower Serial Number and Product ID Location



Figure 5-7 Small Form Factor Serial Number and Product ID Location



Figure 5-8 Ultra-Slim Desktop (USD) Serial Number and Product ID Location



6 Removal and Replacement Procedures – Convertible Minitower (CMT) Chassis

Adherence to the procedures and precautions described in this chapter is essential for proper service. After completing all necessary removal and replacement procedures, run the Diagnostics utility to verify that all components operate properly.



NOTE: Not all features listed in this guide are available on all computers.

Preparation for Disassembly

See [Routine Care, SATA Drive Guidelines, and Disassembly Preparation on page 59](#) for initial safety procedures.

1. Remove/disengage any security devices that prohibit opening the computer.
2. Close any open software applications.
3. Exit the operating system.
4. Remove any diskette, compact disc, or media card from the computer.
5. Turn off the computer and any peripheral devices that are connected to it.



CAUTION: Turn off the computer before disconnecting any cables.

Regardless of the power-on state, voltage is always present on the system board as long as the system is plugged into an active AC outlet. In some systems the cooling fan is on even when the computer is in the “Standby,” or “Suspend” modes. The power cord should always be disconnected before servicing a unit.

6. Disconnect the power cord from the electrical outlet and then from the computer.
7. Disconnect all peripheral device cables from the computer.
8. As applicable, lay the computer down on its side to achieve a safe working position.



NOTE: During disassembly, label each cable as you remove it, noting its position and routing. Keep all screws with the units removed.




CAUTION: The screws used in the computer are of different thread sizes and lengths; using the wrong screw in an application may damage the unit.

Computer Access Panel

Description	Spare part number
Access panel	646819-001

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#))
2. Lay the computer down on its large base for greater stability.
3. Lift up on the access panel handle **(1)** then lift the access panel off the computer **(2)**.

Figure 6-1 Removing the Computer Access Panel




To install the access panel, reverse the removal procedure.

Front Bezel

Description	Spare part number
Front bezel	646822-001

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the computer access panel ([Computer Access Panel on page 74](#)).
3. Lift up the three tabs on the side of the bezel (1), then rotate the bezel off the chassis (2).

Figure 6-2 Removing the Front Bezel




To install the front bezel, reverse the removal procedure.

Front Bezel Security

The front bezel can be locked in place by installing a security screw provided by HP. To install the security screw:


1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the computer access panel ([Computer Access Panel on page 74](#)).
3. Remove the front bezel ([Front Bezel on page 75](#)).
4. Remove the security screw from the inside of the front bezel.

Figure 6-3 Retrieving the Front Bezel Security Screw



5. Replace the front bezel.
6. Install the screw through the interior of the front of the chassis into the front bezel. The screw hole is located on the left edge of the chassis next to the top hard drive bay.

Figure 6-4 Installing the Front Bezel Security Screw




7. Replace the access panel.
8. Reconnect the power cord and turn on the computer.
9. Lock any security devices that were disengaged when the access panel was removed.

Bezel Blanks

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the computer access panel ([Computer Access Panel on page 74](#)).
3. Remove the front bezel ([Front Bezel on page 75](#)).
4. Gently pull the subpanel, with the bezel blanks secured in it, away from the front bezel, then remove the desired bezel blank.

CAUTION: Hold the subpanel straight when you pull it away from the front bezel. Pulling the subpanel away at an angle could damage the pins that align it within the front bezel.

Figure 6-5 Removing Bezel Blanks from the Subpanel (Desktop Shown)



NOTE: When replacing the subpanel, ensure that the aligning pins and any remaining bezel blanks are in their proper orientation. The logo on the subpanel should be located at the bottom of the subpanel when properly oriented.

System Board Connections

Refer to the following illustration and table to identify the system board connectors.

Figure 6-6 System Board Connections




Table 6-1 System Board Connections

No.	System Board Connector	System Board Label	Color	Component
1	PCI	PCI3	white	Expansion Card
2	PCI	PCI2	white	Expansion Card
3	PCI	PCI1	white	Expansion Card
4	Parallel Port	PAR	black	Parallel Port
5	PCI Express x16 downshifted to a x4	X4PCIEXP	white	Expansion Card
6	PCI Express x16	X16PCIEXP	black	Expansion Card
7	PCI Express x1	X1PCIEXP1	black	Expansion Card
8	Hood Lock	HLCK	black	Hood Lock
9	Hood Sensor	HSENSE	white	Hood Sensor
10	DIMM4 (Channel A)	DIMM4	white	Memory Module
11	DIMM3 (Channel A)	DIMM3	black	Memory Module
12	DIMM2 (Channel B)	DIMM2	white	Memory Module
13	DIMM1 (Channel B)	DIMM1	black	Memory Module
14	Power	SATA PWR1	black	SATA Optical Drives
15	Power	SATA PWR0	black	SATA Hard Drives
16	USB	MEDIA	black	USB Device, such as a Media Card Reader

Table 6-1 System Board Connections (continued)

No.	System Board Connector	System Board Label	Color	Component
17	USB	MEDIA2	black	USB Device, such as a Media Card Reader
18	SATA 2.0	SATA2	white	3rd Hard Drive, or 1st Optical Drive if no 3rd Hard Drive
19	SATA 3.0	SATA0	dark blue	1st Hard Drive
20	SATA 3.0	SATA1	light blue	2nd Hard Drive
21	SATA 2.0	SATA3	white	2nd Optical Drive, or 1st Optical Drive if a 3rd Hard Drive exists
22	eSATA	ESATA	black	eSATA Adapter Cable, or 2nd Optical Drive if a 3rd Hard Drive exists
23	Serial Port	COMB	black	Serial Port

Memory

Description	Spare part number
4-GB, PC3-10600	585157-001
2-GB, PC3-10600	635803-001
1-GB, PC3-10600	635802-001

The computer comes with double data rate 3 synchronous dynamic random access memory (DDR3-SDRAM) dual inline memory modules (DIMMs).

DIMMs

The memory sockets on the system board can be populated with up to four industry-standard DIMMs. These memory sockets are populated with at least one preinstalled DIMM. To achieve the maximum memory support, you can populate the system board with up to 16-GB of memory configured in a high-performing dual channel mode.

DDR3-SDRAM DIMMs

CAUTION: This product DOES NOT support DDR3 Ultra Low Voltage (DDR3U) memory. The processor is not compatible with DDR3U memory and if you plug DDR3U memory into the system board, it can cause the physical damage to the DIMM or invoke system malfunction.

For proper system operation, the DDR3-SDRAM DIMMs must be:

- industry-standard 240-pin
- unbuffered non-ECC PC3-8500 DDR3-1066 MHz-compliant or PC3-10600 DDR3-1333 MHz-compliant
- 1.5 volt DDR3-SDRAM DIMMs

The DDR3-SDRAM DIMMs must also:

- support CAS latency 7 DDR3 1066 MHz (7-7-7 timing) and CAS latency 9 DDR3 1333 MHz (9-9-9 timing)
- contain the mandatory JEDEC SPD information

In addition, the computer supports:

- 512-Mbit, 1-Gbit, and 2-Gbit non-ECC memory technologies
- single-sided and double-sided DIMMs
- DIMMs constructed with x8 and x16 DDR devices; DIMMs constructed with x4 SDRAM are not supported



NOTE: The system will not operate properly if you install unsupported DIMMs.

Populating DIMM Sockets

There are four DIMM sockets on the system board, with two sockets per channel. The sockets are labeled DIMM1, DIMM2, DIMM3, and DIMM4. Sockets DIMM1 and DIMM2 operate in memory channel B. Sockets DIMM3 and DIMM4 operate in memory channel A.

The system will automatically operate in single channel mode, dual channel mode, or flex mode, depending on how the DIMMs are installed.

- The system will operate in single channel mode if the DIMM sockets are populated in one channel only.
- The system will operate in a higher-performing dual channel mode if the total memory capacity of the DIMMs in Channel A is equal to the total memory capacity of the DIMMs in Channel B. The technology and device width can vary between the channels. For example, if Channel A is populated with two 1-GB DIMMs and Channel B is populated with one 2-GB DIMM, the system will operate in dual channel mode.
- The system will operate in flex mode if the total memory capacity of the DIMMs in Channel A is not equal to the total memory capacity of the DIMMs in Channel B. In flex mode, the channel populated with the least amount of memory describes the total amount of memory assigned to dual channel and the remainder is assigned to single channel. For optimal speed, the channels should be balanced so that the largest amount of memory is spread between the two channels. If one channel will have more memory than the other, the larger amount should be assigned to Channel A. For example, if you are populating the sockets with one 2-GB DIMM, and three 1-GB DIMMs, Channel A should be populated with the 2-GB DIMM and one 1-GB DIMM, and Channel B should be populated with the other two 1-GB DIMMs. With this configuration, 4-GB will run as dual channel and 1-GB will run as single channel.
- In any mode, the maximum operational speed is determined by the slowest DIMM in the system.

Installing DIMMs

⚠ CAUTION: You must disconnect the power cord and wait approximately 30 seconds for the power to drain before adding or removing memory modules. Regardless of the power-on state, voltage is always supplied to the memory modules as long as the computer is plugged into an active AC outlet. Adding or removing memory modules while voltage is present may cause irreparable damage to the memory modules or system board.


The memory module sockets have gold-plated metal contacts. When upgrading the memory, it is important to use memory modules with gold-plated metal contacts to prevent corrosion and/or oxidation resulting from having incompatible metals in contact with each other.

Static electricity can damage the electronic components of the computer or optional cards. Before beginning these procedures, ensure that you are discharged of static electricity by briefly touching a grounded metal object. For more information, refer to [Electrostatic Discharge Information on page 60](#).

When handling a memory module, be careful not to touch any of the contacts. Doing so may damage the module.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the computer access panel ([Computer Access Panel on page 74](#)).
3. Open both latches of the memory module socket (1), and insert the memory module into the socket (2).

Figure 6-7 Installing a DIMM



NOTE: A memory module can be installed in only one way. Match the notch on the module with the tab on the memory socket.

Populate the black DIMM sockets before the white DIMM sockets.

For maximum performance, populate the sockets so that the memory capacity is spread as equally as possible between Channel A and Channel B. Refer to [Populating DIMM Sockets on page 80](#) for more information.

4. Push the module down into the socket, ensuring that the module is fully inserted and properly seated. Make sure the latches are in the closed position (3).

5. Repeat steps 3 and 4 to install any additional modules.
6. Replace the computer access panel.
7. Reconnect the power cord and turn on the computer.
8. Lock any security devices that were disengaged when the access panel was removed.

The computer should automatically recognize the additional memory the next time you turn on the computer.

Expansion Card

Description	Spare part number
nVidia Quadro NVS295 PCIe x16 graphics card, 256 MB	641462-001
nVidia Quadro NVS300 PCIe x16 graphics card, 512 MB	632486-001
nVidia GF405, DVI/VGA PCIe x16 graphics card, 512 MB	641732-001
ATI Radeon HD6350 PCIe x16 graphics card, 512 MB	637995-001
ATI Radeon HD6450 PCIe x16 graphics card, 512 MB	637996-001
ATI Radeon HD6570 PCIe x16 graphics card, 1 GB	637997-001
AMD FirePro 2270 PCIe x16 graphics card, 512 MB	637213-001
Intel PRO/1000CT NIC, includes bracket	635523-001
HP FireWire / IEEE 1394a PCIe x1 Card	637591-001
Serial port, PCI card	638815-001
Printer port, PCI card	638817-001
USB 3.0 port, PCIe x1 card	616610-001
eSATA port assembly, PCI card	645558-001

The computer has three standard full-height PCI expansion slots, one PCI Express x1 expansion slot, one PCI Express x16 expansion slot, and one PCI Express x16 expansion slot that is downshifted to a x4 slot.



NOTE: You can install a PCI Express x1, x8, or x16 expansion card in the PCI Express x16 slots.


For dual graphics card configurations, the first (primary) card must be installed in the PCI Express x16 slot that is NOT downshifted to a x4 slot.

To remove, replace, or add an expansion card:


1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the computer access panel ([Computer Access Panel on page 74](#)).
3. Locate the correct vacant expansion socket on the system board and the corresponding expansion slot on the back of the computer chassis.

4. Press straight down on the two green thumb tabs inside the chassis (1) and rotate the expansion card retention latch up (2).

Figure 6-8 Opening the Expansion Slot Retainer




5. Before installing an expansion card, remove the expansion slot cover or the existing expansion card.

 **NOTE:** Before removing an installed expansion card, disconnect any cables that may be attached to the expansion card.


- a. If you are installing an expansion card in a vacant socket, remove the appropriate expansion slot cover on the back of the chassis. Lift the expansion slot cover from the expansion slot.

Figure 6-9 Removing an Expansion Slot Cover




- b. If you are removing a standard PCI card or PCI Express x1 card, hold the card at each end and carefully rock it back and forth until the connectors pull free from the socket. Lift the card straight up to remove it. Be sure not to scrape the card against other components.

Figure 6-10 Removing a Standard PCI Expansion Card



- c. If you are removing a PCI Express x16 card, pull the retention arm on the back of the expansion socket away from the card and carefully rock the card back and forth until the connectors pull free from the socket. Lift the card straight up to remove it. Be sure not to scrape the card against other components.

Figure 6-11 Removing a PCI Express x16 Expansion Card




- 6. Store the removed card in anti-static packaging.

7. If you are not installing a new expansion card, install an expansion slot cover to close the open slot.

CAUTION: After removing an expansion card, you must replace it with a new card or expansion slot cover for proper cooling of internal components during operation.

8. To install a new expansion card, slide the bracket on the end of the card down into the slot on the back of the chassis and press the card down firmly into the socket on the system board.

Figure 6-12 Installing an Expansion Card



NOTE: When installing an expansion card, press firmly on the card so that the whole connector seats properly in the expansion card slot.

9. Close the expansion card retention latch, making sure that it snaps firmly into place.
10. Connect external cables to the installed card, if needed. Connect internal cables to the system board, if needed.
11. Replace the computer access panel.
12. Reconnect the power cord and turn on the computer.
13. Lock any security devices that were disengaged when the computer access panel was removed.
14. Reconfigure the computer, if necessary.

Drives

Description	Spare part number
16X SATA DVD±RW drive with LightScribe	581600-001
16X SATA DVD-ROM drive	581599-001
Blu-ray BD-RW SuperMulti DL Drive with LightScribe	617030-001
1 TB, 7200 rpm SATA hard drive	636930-001
750 GB, 7200 rpm SATA hard drive	632938-001
500 GB, 7200 rpm SATA hard drive	636929-001
320 GB, 7200 rpm SATA hard drive, 2.5-inch	634824-001
300 GB, 10000-RPM SATA3 hard drive	639695-001
300 GB, 10000-RPM SATA2 hard drive	648963-001
250 GB, 7200 rpm SATA hard drive	636927-001
160 GB, 10000-RPM SATA hard drive	639694-001
160 GB, 10000-RPM SATA hard drive, 2.5-inch	508312-001
160 GB Solid State Drive (SSD)	646809-001
80 GB Solid State Drive (SSD)	607817-001

Drive Positions

Figure 6-13 Drive Positions (Minitower Configuration Shown)




Table 6-2 Drive Positions

1	Three 5.25-inch drive bays for optional drives (optical drives and media card reader shown)
2	Three 3.5-inch internal hard drive bays

NOTE: The drive configuration on your computer may be different than the drive configuration shown above.

The bottom 5.25-inch drive bay has a shorter depth than the upper two bays. The bottom bay supports a half-height drive or other device that is no more than 14.5 cm (5.7 inches) in depth. Do not try to force a larger drive, such as an optical drive, into the bottom bay. This could cause damage to the drive and the system board. The use of unnecessary force when installing any drive into the drive bay may result in damage to the drive.

To verify the type and size of the storage devices installed in the computer, run Computer Setup.

Removing a Drive from a Drive Bay


CAUTION: All removable media should be taken out of a drive before removing the drive from the computer.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the computer access panel ([Computer Access Panel on page 74](#)).
3. Remove the front bezel ([Front Bezel on page 75](#)).
4. Disconnect the drive cables, as indicated in the following illustrations:

CAUTION: When removing the cables, pull the tab or connector instead of the cable itself to avoid damaging the cable.

- If you are removing an optical drive, disconnect the power cable and data cable from the back of the drive.
- If you are removing a media card reader, disconnect the USB cable from the system board.

Figure 6-14 Disconnecting the Media Card Reader USB Cable




- If you are removing a hard drive, disconnect the power cable and data cable from the back of the drive.

5. Remove the drive from the drive bay as follows:

- To remove a 5.25-inch drive in the desktop configuration, press down on the yellow drivelock mechanism (1) and slide the drive from the drive bay (2).


CAUTION: When the yellow drivelock is pressed, all the 5.25-inch drives are released so do not tilt the unit and allow the drives to fall out.

Figure 6-15 Removing a 5.25-inch Drive in the Desktop Configuration (Optical Drive shown)




- To remove a 5.25-inch drive in the minitower configuration, pull up on the green drivelock mechanism (1) for that specific drive and slide the drive from the drive bay (2).

Figure 6-16 Removing a 5.25-inch Drive in the Minitower Configuration (Optical Drive shown)




- To remove a hard drive from one of the two lower internal hard drive bays, pull up on the green hard drive drivelock mechanism **(1)** for that drive and slide the drive from the drive bay **(2)**.

Figure 6-17 Removing a Hard Drive from the Lower Two Bays



- To remove a hard drive from the upper internal hard drive bay, remove the screw on the side of the bay that secures the drive in place **(1)**, then slide the drive out of the bay **(2)**.

Figure 6-18 Removing a Hard Drive from the Upper Bay




Installing Drives

When installing drives, follow these guidelines:

- The primary Serial ATA (SATA) hard drive must be connected to the dark blue SATA connector on the system board labeled SATA0. If you are adding a second hard drive, connect it to the light blue SATA1 connector.
- Connect the first SATA optical drive to the white SATA connector on the system board labeled SATA2. If you are adding a second optical drive, connect it to the white SATA3 connector.
- Connect an optional eSATA adapter cable to the black SATA connector on the system board labeled ESATA.
- Connect a media card reader USB cable to the USB connector on the system board labeled MEDIA.
- The power cable for the SATA optical drives is a two-headed cable this is plugged into the system board with the first connector routed to the middle 5.25-inch bay and the second connector routed to the top 5.25-inch bay.
- The power cable for the SATA hard drives is a three-headed cable this is plugged into the system board with the first connector routed to the bottom 3.5-inch bay, the second connector routed to the middle 3.5-inch bay, and the third connector routed to the top 3.5-inch bay.
- The system does not support Parallel ATA (PATA) optical drives or PATA hard drives.
- You must install guide screws to ensure the drive will line up correctly in the drive cage and lock in place. HP has provided extra guide screws installed on the chassis. The hard drive uses 6-32 isolation mounting guide screws in the lower two bays and standard 6-32 screws in the upper bay. Four of each are installed on the hard drive bracket under the access panel. All other drives use M3 metric screws, eight of which are installed on the optical drive bracket under the access panel. The HP-supplied metric guide screws are black. The HP-supplied 6-32 isolation mounting guide screws are silver and blue. The HP-supplied standard 6-32 screws are silver. If you are replacing the primary hard drive, you must remove the four silver and blue 6-32 isolation mounting guide screws from the old hard drive and install them in the new hard drive.

Figure 6-19 Extra Guide Screw Locations



No.	Guide Screw	Device
1	Black M3 Metric Screws	5.25-inch Drives
2	Silver 6-32 Standard Screws	3.5-inch Hard Drive in the Top Drive Bay (Bay 4)
3	Silver and Blue 6-32 Isolation Mounting Screws	3.5-inch Hard Drives in the Middle and Bottom Drive Bays (Bays 5 and 6)

⚠ CAUTION: To prevent loss of work and damage to the computer or drive:

If you are inserting or removing a drive, shut down the operating system properly, turn off the computer, and unplug the power cord. Do not remove a drive while the computer is on or in standby mode.

Before handling a drive, ensure that you are discharged of static electricity. While handling a drive, avoid touching the connector. For more information about preventing electrostatic damage, refer to [Electrostatic Discharge Information on page 60](#).

Handle a drive carefully; do not drop it.

Do not use excessive force when inserting a drive.


Avoid exposing a hard drive to liquids, temperature extremes, or products that have magnetic fields such as monitors or speakers.

If a drive must be mailed, place the drive in a bubble-pack mailer or other protective packaging and label the package "Fragile: Handle With Care."

Installing a 5.25-inch Drive into a Drive Bay

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the computer access panel ([Computer Access Panel on page 74](#)).
3. Remove the front bezel ([Front Bezel on page 75](#)).
4. If you are installing a drive in a bay covered by a bezel blank, remove the bezel blank. See [Bezel Blanks on page 77](#) for more information.

5. Install four M3 metric guide screws in the lower holes on each side of the drive (1). HP has provided four extra M3 metric guide screws on the 5.25-inch drive bracket under the access panel. The M3 metric guide screws are black. Refer to [Installing Drives on page 92](#) for an illustration of the extra M3 metric guide screws location.

 **NOTE:** When replacing the drive, transfer the four M3 metric guide screws from the old drive to the new one.




 **CAUTION:** Use only 5-mm long screws as guide screws. Longer screws can damage the internal components of the drive.


Figure 6-20 Installing a 5.25-Inch Drive in a Minitower (top) and Desktop (bottom)



6. Install the drive in the desired drive bay by sliding it all the way into the front of the drive cage until it locks (2). The drivelock automatically secures the drive in the bay.


 **CAUTION:** The bottom 5.25-inch drive bay has a shorter depth than the upper two bays. The bottom bay supports a half-height drive or other device that is no more than 14.5 cm (5.7 inches) in depth. Do not try to force a larger drive, such as an optical drive, into the bottom bay. This could cause damage to the drive and the system board. The use of unnecessary force when installing any drive into the drive bay may result in damage to the drive.

7. Connect the power and data cables to the drive as indicated in the following illustrations.
 - a. If you are installing an optical drive, connect the power cable and data cable to the back of the drive.


 **NOTE:** The power cable for the optical drives is a two-headed cable that is routed from the system board to the rear of the optical drive bays.

- b. If you are installing a media card reader, connect the USB cable to the USB system board connector labeled MEDIA.

Figure 6-21 Connecting the Media Card Reader USB Cable




8. If you are installing a new drive, connect the opposite end of the data cable to the appropriate system board connector.

 **NOTE:** If you are installing a new SATA optical drive, connect the data cable for the first optical drive to the white SATA connector on the system board labeled SATA2. Connect the data cable for a second optical drive to the white SATA connector on the system board labeled SATA3.

Refer to [System Board Connections on page 78](#) for an illustration of the system board drive connectors.

9. Replace the front bezel and computer access panel.
10. Reconnect the power cord and turn on the computer.
11. Lock any security devices that were disengaged when the computer access panel was removed.

Installing a Hard Drive into an Internal Drive Bay


 **NOTE:** The system does not support Parallel ATA (PATA) hard drives.

Before you remove the old hard drive, be sure to back up the data from the old hard drive so that you can transfer the data to the new hard drive.

To install a hard drive in a 3.5-inch internal drive bay:

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the computer access panel ([Computer Access Panel on page 74](#)).


3. Install guide screws on the sides of the drive. The type of screws used depends on which drive bay is being used to house the drive. If you are installing a 2.5-inch drive, you must install the drive in an adapter bracket.

 **NOTE:** Extra guide screws are installed on the hard drive bracket under the access panel. Refer to [Installing Drives on page 92](#) for an illustration of the extra guide screw locations.

If you are replacing a drive, transfer the guides screws from the old drive to the new one.


- If you are installing a 3.5-inch drive in either of the lower two bays (bays 5 and 6), install four 6-32 silver and blue isolation mounting guide screws (two on each side of the drive).

Figure 6-22 Installing Isolation Mounting Guide Screws in a 3.5-inch Hard Drive




- If you are installing a 2.5-inch hard drive into either of the lower two bays (bays 5 and 6), do the following:
 - Install four 6-32 silver and blue isolation mounting guide screws in the adapter bracket (two on each side of the bracket).

Figure 6-23 Installing Isolation Mounting Guide Screws in the 2.5-inch Adapter Bracket




- Install the drive into the slot on the adapter bracket with the PCA side facing down, aligning the three tabs on the bracket with the drive. Ensure that the power and data connectors on the drive are properly oriented.

Figure 6-24 Installing the Drive in the Adapter Bracket



- Hold the drive and bracket firmly together and turn the assembly over. Install four M3 screws to secure the drive to the bracket.

Figure 6-25 Securing the Drive in the Adapter Bracket



- If you are installing the drive in the upper bay (bay 4), install three standard 6-32 silver guide screws (two on the right side and one on the left side in the screw hole closest to the power and data connectors).

Figure 6-26 Installing Standard Guide Screws




4. Insert the hard drive into the bay as follows:

CAUTION: Make sure the guide screws line up with the guide slots in the drive cage. The use of unnecessary force when installing any drive into the drive bay may result in damage to the drive.


- If you are installing a hard drive into one of the lower two bays (bays 5 and 6), slide the hard drive into the drive bay until it locks. The drivelock automatically secures the drive in the bay.

Figure 6-27 Installing a Hard Drive into the Lower Two Bays




- If you are installing a hard drive into the upper bay (bay 4), slide the hard drive into the drive bay **(1)** then secure the drive in place with a standard 6-32 screw **(2)**.


Figure 6-28 Installing a Hard Drive into the Upper Bay



5. Connect the power cable and data cable to the rear of the hard drive.


 **NOTE:** The power cable for the hard drives is a three-headed cable that is routed from the system board to the rear of the hard drive bays.

6. Connect the opposite end of the data cable to the appropriate system board connector.

 **NOTE:** If your system has only one SATA hard drive, you must connect the hard drive data cable to the dark blue connector labeled SATA0 to avoid any hard drive performance problems. If you are adding a second hard drive, connect the data cable to the light blue connector labeled SATA1.

7. Replace the computer access panel.
8. Reconnect the power cord and turn on the computer.
9. Lock any security devices that were disengaged when the computer access panel was removed.

Installing a 3.5-inch SATA Hard Drive into an Internal Drive Bay

 **NOTE:** The system does not support Parallel ATA (PATA) hard drives.


Before you remove the old hard drive, be sure to back up the data from the old hard drive so that you can transfer the data to the new hard drive.

To install a hard drive in a 3.5-inch internal drive bay:

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the computer access panel ([Computer Access Panel on page 74](#)).
3. Install four 6-32 isolation mounting guide screws, two on each side of the drive.

Figure 6-29 Installing the Hard Drive Guide Screws





 **NOTE:** The hard drive uses 6-32 isolation mounting guide screws. Eight extra guide screws are installed on the hard drive bracket under the access panel. The HP-supplied isolation mounting guide screws are silver and blue.


If you are replacing a drive, transfer the guide screws from the old drive to the new one.

4. Slide the hard drive down into the drive cage until it locks. The drivelock automatically secures the drive in the bay.

Figure 6-30 Installing a Hard Drive into the Hard Drive Bay




 **CAUTION:** Make sure the guide screws line up with the guide slots in the drive cage. The use of unnecessary force when installing any drive into the drive bay may result in damage to the drive.

5. Connect the power cable and data cable to the rear of the hard drive.
 6. Connect the opposite end of the data cable to the appropriate system board connector.
-
-  **NOTE:** If your system has only one SATA hard drive, you must connect the hard drive data cable to the dark blue connector labeled SATA0 to avoid any hard drive performance problems. If you are adding a second hard drive, connect the data cable to the next available (unpopulated) SATA connector on the system board in the following order: SATA0, SATA1, SATA2, SATA3.
-
7. Replace the computer access panel.
 8. Reconnect the power cord and turn on the computer.
 9. Lock any security devices that were disengaged when the computer access panel was removed.
 10. Reconfigure the computer, if necessary.


Removing and Replacing a Removable 3.5-inch SATA Hard Drive

Some models are equipped with a Removable SATA Hard Drive Enclosure in the 5.25-inch external drive bay. The hard drive is housed in a carrier that can be quickly and easily removed from the drive bay. To remove and replace a drive in the carrier:

 **NOTE:** Before you remove the old hard drive, be sure to back up the data from the old hard drive so that you can transfer the data to the new hard drive.


1. Unlock the hard drive carrier with the key provided and slide the carrier out of the enclosure.
2. Remove the screw from the rear of the carrier (1) and slide the top cover off the carrier (2).

Figure 6-31 Removing the Carrier Cover




3. Remove the adhesive strip that secures the thermal sensor to the top of the hard drive (1) and move the thermal sensor away from the carrier (2).

Figure 6-32 Removing the Thermal Sensor




4. Remove the four screws from the bottom of the hard drive carrier.

Figure 6-33 Removing the Security Screws




5. Slide the hard drive back to disconnect it from the carrier then lift it up and out of the carrier.

Figure 6-34 Removing the Hard Drive




6. Place the new hard drive in the carrier then slide the hard drive back so that it seats in the SATA connector on the carrier's circuit board. Be sure the connector on the hard drive is pressed all the way into the connector on the carrier's circuit board.

Figure 6-35 Replacing the Hard Drive




7. Replace the four screws in the bottom of the carrier to hold the drive securely in place.

Figure 6-36 Replacing the Security Screws




8. Place the thermal sensor on top of the hard drive in a position that does not cover the label (1) and attach the thermal sensor to the top of the hard drive with the adhesive strip (2).

Figure 6-37 Replacing the Thermal Sensor



9. Slide the cover on the carrier (1) and replace the screw on the rear of the carrier to secure the cover in place (2).

Figure 6-38 Replacing the Carrier Cover



10. Slide the hard drive carrier into the enclosure on the computer and lock it with the key provided.



NOTE: The carrier must be locked for power to be supplied to the hard drive.


Hood Sensor

Description	Spare part number
Hood sensor	638816-001

The hood sensor is located on the top of the rear chassis panel.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the computer access panel ([Computer Access Panel on page 74](#)).
3. Unplug the hood sensor cable from the connector labeled HSENSE on the system board (1).
4. Slide the hood sensor straight out of the slot in the chassis (2).

Figure 6-39 Removing the hood sensor



To reinstall the hood sensor, reverse the removal procedure.

Front I/O, USB Assembly


Description	Spare part number
Front I/O and USB assembly	646821-001

The front I/O, USB assembly is mounted to the front of the chassis and is removed by pulling it away from the chassis.


1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the computer access panel ([Computer Access Panel on page 74](#)).
3. Remove the front bezel ([Front Bezel on page 75](#)).
4. Disconnect the three cables from the following system board connectors:
 - Yellow connector labeled FRONT USB
 - Green connector labeled FRONT USB2
 - Blue connector labeled FRONT AUD



NOTE: The blue FRONT AUD connector is not located near the other two connectors used for the front I/O assembly. See the following image for its location.



5. Remove the screw that secures the assembly to the front of the chassis.



6. Rotate the right side of the assembly away from the chassis.

Figure 6-40 Removing the front I/O, USB, power switch assembly



7. Pull the assembly toward the right and away from the chassis while threading the wires through the slot between the drive cage and chassis front and the hole in the front of the chassis.

To reinstall the assembly, reverse the removal procedure.


Power Switch Assembly

Description	Spare part number
Power switch/LED assembly	646820-001

The power switch assembly is mounted to the front of the chassis and removed by pulling it away from the chassis.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the computer access panel ([Computer Access Panel on page 74](#)).
3. Remove the computer access panel ([Front Bezel on page 75](#)).
4. Disconnect the cable from the black system board connector labeled PB/LED.
5. Press downward on the tabs **(1)** at the top of the assembly.
6. Rotate the top of the assembly downward **(2)**, and then pull it away from the chassis while threading the wires through the hole in the front of the chassis.

Figure 6-41 Removing the power switch assembly



To install the power switch assembly, reverse the removal procedure.


Speaker

Description	Spare part number
Speaker	645330-001

The speaker is mounted to the inside front of the chassis with two screws.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the computer access panel ([Computer Access Panel on page 74](#)).
3. Disconnect the speaker wire from the white system board connector labeled SPKR (1).
4. From the inside of the unit, remove the two screws (2) that secure the speaker to the front of the chassis.
5. Rotate the top of the speaker downward slightly, and then remove it from the chassis (3).

Figure 6-42 Removing the speaker



To install the speaker, reverse the removal procedures.


Rear Chassis Fan

Description	Spare part number
Rear chassis fan	643908-001

The rear fan is mounted to the rear chassis wall and secured by four Phillips screws.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the computer access panel ([Computer Access Panel on page 74](#)).
3. Disconnect the fan control cable (1) from the red/brown system board labeled CHFAN2.
4. Remove the four screws (2) that secure the fan housing to the chassis.
5. Remove the fan from the chassis (3).

Figure 6-43 Removing the rear chassis fan



To install the fan, reverse the removal procedure. Be sure to orient the air flow out of the unit.

Fan sink

Description	Spare part number
Fan sink	643907-001

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the computer access panel ([Computer Access Panel on page 74](#)).
3. In the order indicated, loosen the four captive screws that secure the fan sink to the system board.

CAUTION: Fan sink retaining screws should be removed in diagonally opposite pairs (as in an X) to even the downward forces on the processor. This is especially important as the pins on the socket are very fragile and any damage to them may require replacing the system board.


Figure 6-44 Loosening the fan sink screws



4. Disconnect the fan cable from the white system board connector labeled CPUFAN (1).

5. Lift the fan sink from the processor (2).

Figure 6-45 Removing the fan sink



When reinstalling the fan sink, make sure that its bottom has been cleaned with an alcohol wipe and fresh thermal grease has been applied to the top of the processor.

CAUTION: Fan sink retaining screws should be tightened in diagonally opposite pairs (as in an X) to evenly seat the fan sink on the processor. Failure to do so could result in damage that requires replacing the system board.

Processor

Description	Spare part number
Intel Core i7 processor	
2600, 3.4 GHz, 8-MB L3 cache, 95W	638632-001
Intel Core i5 processors	
2500, 3.3 GHz, 6-MB L3 cache, 95W	638631-001
2400, 3.1 GHz, 6-MB L3 cache, 95W	638630-001
Intel Core i3 processors	
2120, 3.3 GHz, 3-MB L3 cache, 65W	638629-001
2100, 3.1 GHz, 3-MB L3 cache, 65W	638628-001


1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the computer access panel ([Computer Access Panel on page 74](#)).
3. Remove the heat sink ([Fan sink on page 112](#)).
4. Rotate the locking lever to its full open position **(1)**.
5. Raise and rotate the microprocessor retainer to its fully open position **(2)**.

6. Carefully lift the processor from the socket (3).

⚠ CAUTION: Do NOT handle the pins in the processor socket. These pins are very fragile and handling them could cause irreparable damage. Once pins are damaged it may be necessary to replace the system board.

The heat sink must be installed within 24 hours of installing the processor to prevent damage to the processor's solder connections.

Figure 6-46 Removing the processor




To install a new processor:

1. Place the processor in its socket and close the retainer. Make sure the slot in the processor fits into the post on the socket.

2. Secure the locking lever.

Figure 6-47 Installing the processor



If reusing the existing heat sink, go to step 3.

If using a new heat sink, go to step 5.

3. If reusing the existing heat sink, apply the thermal grease provided in the spares kit to the top of the processor.
4. Clean the bottom of the heat sink with the provided alcohol pad and place it atop the processor.
5. If using a new heat sink, remove the protective covering from the bottom of the heat sink and place it in position atop the processor.
6. Secure the heat sink to the system board and system board tray.

CAUTION: Heat sink retaining screws should be tightened in diagonally opposite pairs (as in an X) to evenly seat the heat sink on the processor. This is especially important as the pins on the socket are very fragile and any damage to them may require replacing the system board.

NOTE: After installing a new processor onto the system board, always update the system ROM to ensure that the latest version of the BIOS is being used on the computer. The latest system BIOS can be found on the Web at: <http://h18000.www1.hp.com/support/files>.

Power Supply


Description	Spare part number
Power supply, 320W, 90% efficient	613764-001
Power supply, 320W	613765-001

⚠ WARNING! To reduce potential safety issues, only the power supply provided with the computer, a replacement power supply provided by HP, or a power supply purchased as an accessory from HP should be used with the computer.

The power supply is secured to the rear of the chassis by four Torx screws. A lever on the chassis floor also holds the power supply in place.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the computer access panel ([Computer Access Panel on page 74](#)).
3. Disconnect all power cables from the system board as follows:
 - white 4-pin PWRCPU
 - white 4-pin PWR
 - white 6-pin PWRCMD
4. Remove the power cables from the white plastic clamp on the chassis floor.
5. Remove the four Torx screws (1) that secure the power supply to the chassis.
6. Press the tab (2) in front of the power supply, slide the power supply toward the front of the computer, and then lift the power supply out of the chassis (3).

Figure 6-48 Removing the power supply




To install the power supply, reverse the removal procedure.


System Board


Description	Spare part number
System board, includes Trusted Platform Module (TPM) (includes replacement thermal material)	611835-001
System board, does not include Trusted Platform Module (includes replacement thermal material)	649742-001

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the computer access panel ([Computer Access Panel on page 74](#)).
3. When replacing the system board, make sure the following components are removed from the defective system board and installed on the replacement system board:
 - Memory modules (see [Memory on page 79](#))
 - Expansion cards ([Expansion Card on page 83](#))
 - Fan sink ([Fan sink on page 112](#)).
 - Processor ([Processor on page 114](#))
4. Remove the computer access panel ([Computer Access Panel on page 74](#)).
5. Disconnect all cables connected to the system board, noting their location for reinstallation.
6. Remove the 10 screws **(1)** that secure the system board to the chassis.
7. Slide the system board toward the front of the computer so that the connectors loosen from the rear of the chassis, and then lift the system board out of the computer **(2)**.

Figure 6-49 Removing the system board




 **NOTE:** When replacing the system board, you must also change the chassis serial number in the BIOS.

 **CAUTION:** Before reinstalling the fan sink you must clean the top of the processor and the bottom of the heat sink with an alcohol pad supplied in the spares kit. After the alcohol has evaporated, apply thermal grease to the top of the processor from the syringe supplied in the spares kit.

Changing from a Minitower to a Desktop Configuration


1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the computer access panel ([Computer Access Panel on page 74](#)).
3. Remove the front bezel ([Front Bezel on page 75](#)).
4. Disconnect all power and data cables from the back of the drives in the 5.25-inch drive bays.
5. To release the drives from the 5.25-inch drive bay, lift the release tab on the green latch drive bracket for the drive (1). While lifting the release tab, slide the drive from its drive bay (2). Repeat this step for each 5.25-inch drive.

Figure 6-50 Releasing the 5.25-inch Drives from the Drive Bays (Minitower)



6. Gently slide the drive into the uppermost available bay until it snaps into place. When the drive is properly inserted, the drivelock will secure it. Repeat this step for each drive.

Figure 6-51 Installing a Drive in the Desktop Configuration



⚠ CAUTION: The bottom 5.25-inch drive bay has a shorter depth than the upper two bays. The bottom bay supports a half-height drive or other device that is no more than 14.5 cm (5.7 inches) in depth. Do not try to force a larger drive, such as an optical drive, into the bottom bay. This could cause damage to the drive and the system board. The use of unnecessary force when installing any drive into the drive bay may result in damage to the drive.


7. Reconnect all power and data cables to the drives in the 5.25-inch drive bays.
8. Remove the bezel subpanel as described in [Bezel Blanks on page 77](#).

⚠ CAUTION: Hold the subpanel straight when you pull it away from the front bezel. Pulling the subpanel away at an angle could damage the pins that align it within the front bezel.

9. Reposition the bezel blanks within the subpanel in the proper orientation for the desktop configuration.

10. Reposition the subpanel (rotate it 90°) with the logo at the bottom, then snap it back into the bezel.

Figure 6-52 Changing from a Minitower to a Desktop Configuration




11. Replace the front bezel and computer access panel.
12. Reconnect the power cord and turn on the computer.
13. Lock any security devices that were disengaged when the computer access panel was removed.

Changing from a Desktop to a Minitower Configuration

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the computer access panel ([Computer Access Panel on page 74](#)).
3. Remove the front bezel ([Front Bezel on page 75](#)).
4. Disconnect all power and data cables from the back of the drives in the 5.25-inch drive bays.


5. To release the drives from the 5.25-inch drive bay, press down on the short yellow drivelock as shown (1). While pressing the drivelock, pull the drives out of the drive bay (2).

Figure 6-53 Releasing the 5.25-inch Drives from the Drive Bays (Desktop)



6. Gently slide the drive into the uppermost available bay until it snaps into place. When the drive is properly inserted, the drivelock will secure it. Repeat this step for each drive.

Figure 6-54 Installing a Drive in the Minitower Configuration




CAUTION: The bottom 5.25-inch drive bay has a shorter depth than the upper two bays. The bottom bay supports a half-height drive or other device that is no more than 14.5 cm (5.7 inches) in depth. Do not try to force a larger drive, such as an optical drive, into the bottom bay. This could cause damage to the drive and the system board. The use of unnecessary force when installing any drive into the drive bay may result in damage to the drive.

7. Reconnect all power and data cables to the drives in the 5.25-inch drive bays.
8. Remove the bezel subpanel as described in the [Bezel Blanks on page 77](#) section.

CAUTION: Hold the subpanel straight when you pull it away from the front bezel. Pulling the subpanel away at an angle could damage the pins that align it within the front bezel.

9. Reposition the bezel blanks within the subpanel in the proper orientation for the minitower configuration.
10. Reposition the subpanel (rotate it 90°) with the logo at the bottom, then snap it back into the bezel.


Figure 6-55 Changing from a Desktop to a Minitower Configuration



11. Replace the front bezel and computer access panel.
12. Reconnect the power cord and turn on the computer.
13. Lock any security devices that were disengaged when the computer access panel was removed.

7 Removal and Replacement Procedures – Microtower (MT) Chassis


Adherence to the procedures and precautions described in this chapter is essential for proper service. After completing all necessary removal and replacement procedures, run the Diagnostics utility to verify that all components operate properly.

 **NOTE:** Not all features listed in this guide are available on all computers.

Preparation for Disassembly


See [Routine Care, SATA Drive Guidelines, and Disassembly Preparation on page 59](#) for initial safety procedures.


1. Remove/disengage any security devices that prohibit opening the computer.
2. Close any open software applications.
3. Exit the operating system.
4. Remove any diskette, compact disc, or media card from the computer.
5. Turn off the computer and any peripheral devices that are connected to it.

 **CAUTION:** Turn off the computer before disconnecting any cables.

Regardless of the power-on state, voltage is always present on the system board as long as the system is plugged into an active AC outlet. In some systems the cooling fan is on even when the computer is in the “Standby,” or “Suspend” modes. The power cord should always be disconnected before servicing a unit.

6. Disconnect the power cord from the electrical outlet and then from the computer.
7. Disconnect all peripheral device cables from the computer.
8. As applicable, lay the computer down on its side to achieve a safe working position.

 **NOTE:** During disassembly, label each cable as you remove it, noting its position and routing. Keep all screws with the units removed.

 **CAUTION:** The screws used in the computer are of different thread sizes and lengths; using the wrong screw in an application may damage the unit.

Computer Access Panel

Description	Spare part number
Access panel	646825-001

To access internal components, you must remove the access panel:

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 125](#))
2. Loosen the two captive thumbscrews **(1)** that secure the access panel to the computer chassis.
3. Use the handle located between the thumbscrews to lift the access panel off the unit **(2)**.



 **NOTE:** You may want to lay the computer on its side to install internal parts. Be sure the side with the access panel is facing up.

Figure 7-1 Removing the Computer Access Panel




Front Bezel

Description	Spare part number
Front bezel	646826-001

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 125](#))
2. Remove the access panel ([Computer Access Panel on page 126](#))
3. Lift up the three tabs on the side of the bezel (1), then rotate the bezel off the chassis (2).

Figure 7-2 Removing the Front Bezel




Bezel Blanks

Description	Spare part number
3.5-inch bezel blank, jack black	583653-001
5.25-inch bezel blank, jack black	570838-001

On some models, there are bezel blanks covering the 3.5-inch and 5.25-inch drive bays that need to be removed before installing a drive. To remove a bezel blank:

1. Remove the access panel ([Computer Access Panel on page 126](#))
2. Remove the front bezel ([Front Bezel on page 127](#))
3. To remove a bezel blank, push the two retaining tabs that hold the bezel blank in place towards the outer right edge of the bezel (1) and slide the bezel blank back and to the right to remove it (2).

Figure 7-3 Removing a Bezel Blank



System Board Connections

Refer to the following illustrations and tables to identify the system board connectors for your model.

Figure 7-4 8200 Elite Series System Board Connections




Table 7-1 8200 Elite Series System Board Connections

No.	System Board Connector	System Board Label	Color	Component
1	DIMM4 (Channel A)	DIMM4	white	Memory Module
2	DIMM3 (Channel A)	DIMM3	black	Memory Module
3	DIMM2 (Channel B)	DIMM2	white	Memory Module
4	DIMM1 (Channel B)	DIMM1	black	Memory Module
5	Power	SATAPWR0	black	SATA Optical Drives
6	Power	SATAPWR1	black	SATA Hard Drives
7	SATA 3.0	SATA0	dark blue	1st Hard Drive
8	SATA 3.0	SATA1	light blue	2nd Hard Drive, or 2nd Optical Drive if an eSATA Adapter Cable exists
9	SATA 2.0	SATA2	white	1st Optical Drive
10	eSATA	ESATA	black	eSATA Adapter Cable, or 2nd Optical Drive
11	Parallel Port	PAR	black	Parallel Port
12	Serial Port	COMB	black	Serial Port
13	USB	MEDIA	black	USB Device, such as a Media Card Reader
14	Hood Lock	HLCK	black	USB Device, such as a Media Card Reader
15	USB	MEDIA2	black	Second Media Card Reader
16	Hood Sensor	HSENSE	white	Hood Sensor
17	PCI Express x1	X1PCIEXP1	black	Expansion Card
18	PCI Express x16 downshifted to a x4	X4PCIEXP	white	Expansion Card
19	PCI Express x16	X16PCIEXP	black	Expansion Card
20	PCI	PCI	white	Expansion Card

Figure 7-5 6200 Pro Series System Board Connections




Table 7-2 6200 Pro Series System Board Connections

No.	System Board Connector	System Board Label	Color	Component
1	DIMM4 (Channel A)	DIMM4	white	Memory Module
2	DIMM3 (Channel A)	DIMM3	black	Memory Module
3	DIMM2 (Channel B)	DIMM2	white	Memory Module
4	DIMM1 (Channel B)	DIMM1	black	Memory Module
5	Power	SATAPWR0	black	SATA Optical Drives
6	Power	SATAPWR1		SATA Hard Drives
7	SATA 3.0	SATA0	dark blue	1st Hard Drive
8	SATA 2.0	SATA1	white	2nd Hard Drive, or 2nd Optical Drive if an eSATA Adapter Cable exists
9	SATA 2.0	SATA2	white	1st Optical Drive
10	eSATA	ESATA	black	eSATA Adapter Cable, or 2nd Optical Drive
11	Parallel Port	PAR	black	Parallel Port
12	Serial Port	COMB	black	Serial Port
13	USB	MEDIA	black	USB Device, such as a Media Card Reader
14	Hood Lock	HLCK	black	Hood Lock
15	USB	MEDIA2	black	USB Device, such as a Media Card Reader
16	Hood Sensor	HSENSE	white	Hood Sensor
17	PCI Express x1	X1PCIEXP1	black	Expansion Card
18	PCI Express x1	X4PCIEXP	black	Expansion Card
19	PCI Express x16	X16PCIEXP	black	Expansion Card
20	PCI	PCI	white	Expansion Card

Memory


Description	Spare part number
4-GB, PC3-10600	585157-001
2-GB, PC3-10600	635803-001
1-GB, PC3-10600	635802-001

The computer comes with double data rate 3 synchronous dynamic random access memory (DDR3-SDRAM) dual inline memory modules (DIMMs).

DIMMs

The memory sockets on the system board can be populated with up to four industry-standard DIMMs. These memory sockets are populated with at least one preinstalled DIMM. To achieve the maximum memory support, you can populate the system board with up to 16-GB of memory configured in a high-performing dual channel mode.

DDR3-SDRAM DIMMs

 **CAUTION:** This product DOES NOT support DDR3 Ultra Low Voltage (DDR3U) memory. The processor is not compatible with DDR3U memory and if you plug DDR3U memory into the system board, it can cause the physical damage to the DIMM or invoke system malfunction.

For proper system operation, the DDR3-SDRAM DIMMs must be:


- industry-standard 240-pin
- unbuffered non-ECC PC3-8500 DDR3-1066 MHz-compliant or PC3-10600 DDR3-1333 MHz-compliant
- 1.5 volt DDR3-SDRAM DIMMs

The DDR3-SDRAM DIMMs must also:

- support CAS latency 7 DDR3 1066 MHz (7-7-7 timing) and CAS latency 9 DDR3 1333 MHz (9-9-9 timing)
- contain the mandatory JEDEC SPD information

In addition, the computer supports:

- 512-Mbit, 1-Gbit, and 2-Gbit non-ECC memory technologies
- single-sided and double-sided DIMMs
- DIMMs constructed with x8 and x16 DDR devices; DIMMs constructed with x4 SDRAM are not supported

 **NOTE:** The system will not operate properly if you install unsupported DIMMs.


Populating DIMM Sockets

There are four DIMM sockets on the system board, with two sockets per channel. The sockets are labeled DIMM1, DIMM2, DIMM3, and DIMM4. Sockets DIMM1 and DIMM2 operate in memory channel B. Sockets DIMM3 and DIMM4 operate in memory channel A.

The system will automatically operate in single channel mode, dual channel mode, or flex mode, depending on how the DIMMs are installed.

- The system will operate in single channel mode if the DIMM sockets are populated in one channel only.
- The system will operate in a higher-performing dual channel mode if the total memory capacity of the DIMMs in Channel A is equal to the total memory capacity of the DIMMs in Channel B. The technology and device width can vary between the channels. For example, if Channel A is populated with two 1-GB DIMMs and Channel B is populated with one 2-GB DIMM, the system will operate in dual channel mode.
- The system will operate in flex mode if the total memory capacity of the DIMMs in Channel A is not equal to the total memory capacity of the DIMMs in Channel B. In flex mode, the channel populated with the least amount of memory describes the total amount of memory assigned to dual channel and the remainder is assigned to single channel. For optimal speed, the channels should be balanced so that the largest amount of memory is spread between the two channels. If one channel will have more memory than the other, the larger amount should be assigned to Channel A. For example, if you are populating the sockets with one 2-GB DIMM, and three 1-GB DIMMs, Channel A should be populated with the 2-GB DIMM and one 1-GB DIMM, and Channel B should be populated with the other two 1-GB DIMMs. With this configuration, 4-GB will run as dual channel and 1-GB will run as single channel.
- In any mode, the maximum operational speed is determined by the slowest DIMM in the system.

Installing DIMMs

 **CAUTION:** You must disconnect the power cord and wait approximately 30 seconds for the power to drain before adding or removing memory modules. Regardless of the power-on state, voltage is always supplied to the memory modules as long as the computer is plugged into an active AC outlet. Adding or removing memory modules while voltage is present may cause irreparable damage to the memory modules or system board.

The memory module sockets have gold-plated metal contacts. When upgrading the memory, it is important to use memory modules with gold-plated metal contacts to prevent corrosion and/or oxidation resulting from having incompatible metals in contact with each other.


Static electricity can damage the electronic components of the computer or optional cards. Before beginning these procedures, ensure that you are discharged of static electricity by briefly touching a grounded metal object. For more information, refer to [Electrostatic Discharge Information on page 60](#).

When handling a memory module, be careful not to touch any of the contacts. Doing so may damage the module.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 125](#))
2. Remove the access panel ([Computer Access Panel on page 126](#))

3. Open both latches of the memory module socket (1), and insert the memory module into the socket (2).

Figure 7-6 Installing a DIMM



NOTE: A memory module can be installed in only one way. Match the notch on the module with the tab on the memory socket.

Populate the black DIMM sockets before the white DIMM sockets.

For maximum performance, populate the sockets so that the memory capacity is spread as equally as possible between Channel A and Channel B. Refer to [Populating DIMM Sockets on page 132](#) for more information.

4. Push the module down into the socket, ensuring that the module is fully inserted and properly seated. Make sure the latches are in the closed position (3).
5. Repeat steps 3 and 4 to install any additional modules.
6. Replace the computer access panel.
7. Reconnect the power cord and turn on the computer.
8. Lock any security devices that were disengaged when the access panel was removed.

The computer should automatically recognize the additional memory the next time you turn on the computer.

Expansion Cards

Description	Spare part number
nVidia Quadro NVS295 PCIe x16 graphics card, 256 MB	641462-001
nVidia Quadro NVS300 PCIe x16 graphics card, 512 MB	632486-001
nVidia GF405, DVI/VGA PCIe x16 graphics card, 512 MB	641732-001
ATI Radeon HD6350 PCIe x16 graphics card, 512 MB	637995-001
ATI Radeon HD6450 PCIe x16 graphics card, 512 MB	637996-001
ATI Radeon HD6570 PCIe x16 graphics card, 1 GB	637997-001
AMD FirePro 2270 PCIe x16 graphics card, 512 MB	637213-001
Intel PRO/1000CT NIC, includes bracket	635523-001
HP FireWire / IEEE 1394a PCIe x1 Card	637591-001
Serial port, PCI card	638815-001
Printer port, PCI card	638817-001
USB 3.0 port, PCIe x1 card	616610-001
eSATA port assembly, PCI card	645558-001

The 8200 Elite computer has one PCI expansion slot, one PCI Express x1 expansion slot, one PCI Express x16 expansion slot, and one PCI Express x16 expansion slot that is downshifted to a x4 slot.

The 6200 Pro computer has one PCI expansion slot, two PCI Express x1 expansion slots, and one PCI Express x16 expansion slot.



NOTE: You can install a PCI Express x1, x4, x8, or x16 expansion card in the PCI Express x16 slot.


For dual graphics card configurations, the first (primary) card must be installed in the PCI Express x16 slot that is NOT downshifted to a x4 slot (8200 Elite models).

To remove, replace, or add an expansion card:


1. Prepare the computer for disassembly ([Preparation for Disassembly on page 125](#))
2. Remove the access panel ([Computer Access Panel on page 126](#))
3. Locate the correct vacant expansion socket on the system board and the corresponding expansion slot on the back of the computer chassis.

4. Release the slot cover retention latch that secures the PCI slot covers by lifting the green tab on the latch and rotating the latch to the open position.

Figure 7-7 Opening the Expansion Slot Retainer




5. Before installing an expansion card, remove the expansion slot cover or the existing expansion card.

 **NOTE:** Before removing an installed expansion card, disconnect any cables that may be attached to the expansion card.


- a. If you are installing an expansion card in a vacant socket, remove the appropriate expansion slot cover on the back of the chassis. Pull the slot cover straight up then away from the inside of the chassis.

Figure 7-8 Removing an Expansion Slot Cover




- b. If you are removing a standard PCI card or PCI Express x1 card, hold the card at each end, and carefully rock it back and forth until the connectors pull free from the socket. Pull the expansion card straight up from the socket then away from the inside of the chassis to release it from the chassis frame. Be sure not to scrape the card against the other components.

Figure 7-9 Removing a Standard PCI Expansion Card



- c. If you are removing a PCI Express x16 card, pull the retention arm on the back of the expansion socket away from the card and carefully rock the card back and forth until the connectors pull free from the socket. Pull the expansion card straight up from the socket then away from the inside of the chassis to release it from the chassis frame. Be sure not to scrape the card against the other components.

Figure 7-10 Removing a PCI Express x16 Expansion Card




- 6. Store the removed card in anti-static packaging.

7. If you are not installing a new expansion card, install an expansion slot cover to close the open slot.

CAUTION: After removing an expansion card, you must replace it with a new card or expansion slot cover for proper cooling of internal components during operation.

8. To install a new expansion card, hold the card just above the expansion socket on the system board then move the card toward the rear of the chassis so that the bracket on the card is aligned with the open slot on the rear of the chassis. Press the card straight down into the expansion socket on the system board.


Figure 7-11 Installing an Expansion Card



NOTE: When installing an expansion card, press firmly on the card so that the whole connector seats properly in the expansion card slot.

9. Rotate the slot cover retention latch back in place to secure the expansion card.

Figure 7-12 Closing the Expansion Slot Retainer



10. Connect external cables to the installed card, if needed. Connect internal cables to the system board, if needed.

11. Replace the computer access panel.
12. Reconnect the power cord and turn on the computer.
13. Lock any security devices that were disengaged when the access panel was removed.
14. Reconfigure the computer, if necessary.

Drive Positions

Figure 7-13 Drive Positions




Table 7-3 Drive Positions

1	Two 5.25-inch drive bays for optional drives (optical drives shown)
2	One 3.5-inch drive bay for optional drive (media card reader shown)
3	Secondary 3.5-inch internal hard drive bay for optional hard drive
4	Primary 3.5-inch internal hard drive bay

NOTE: The drive configuration on your computer may be different than the drive configuration shown above.

To verify the type and size of the storage devices installed in the computer, run Computer Setup.

Drives


Description	Spare part number
16X SATA DVD±RW drive with LightScribe	581600-001
16X SATA DVD-ROM drive	581599-001
Blu-ray BD-RW SuperMulti DL Drive with LightScribe	617030-001
1 TB, 7200 rpm SATA hard drive	636930-001
750 GB, 7200 rpm SATA hard drive	632938-001
500 GB, 7200 rpm SATA hard drive	636929-001
320 GB, 7200 rpm SATA hard drive, 2.5-inch	634824-001
300 GB, 10000-RPM SATA3 hard drive	639695-001
300 GB, 10000-RPM SATA2 hard drive	648963-001
250 GB, 7200 rpm SATA hard drive	636927-001
160 GB, 10000-RPM SATA hard drive	639694-001
160 GB, 10000-RPM SATA hard drive, 2.5-inch	508312-001
160 GB Solid State Drive (SSD)	646809-001
80 GB Solid State Drive (SSD)	607817-001

When installing drives, follow these guidelines:

- The primary Serial ATA (SATA) hard drive must be connected to the dark blue primary SATA connector on the system board labeled SATA0. If you are adding a second hard drive, connect it to the light blue connector (8200 Elite models) or the white connector (6200 Pro models) on the system board labeled SATA1.
- Connect the first SATA optical drive to the white SATA connector on the system board labeled SATA2. If you are adding a second optical drive connect it to the black SATA connector on the system board labeled ESATA. If the ESATA connector is already populated, connect the second optical drive to the light blue connector on the system board labeled SATA1 (8200 Elite models) or the white connector labeled SATA1 (6200 Pro models).
- Connect an optional eSATA adapter cable to the black SATA connector on the system board labeled ESATA.
- Connect a media card reader USB cable to the USB connector on the system board labeled MEDIA.
- The power cable for the SATA optical drives is a two-headed cable this is plugged into the system board with the first connector routed to the top 5.25-inch bay and the second connector routed to the bottom 5.25-inch bay.
- The power cable for the SATA hard drives is a two-headed cable this is plugged into the system board with the first connector routed to the bottom 3.5-inch bay and the second connector routed to the top 3.5-inch bay.

- The system does not support Parallel ATA (PATA) optical drives or PATA hard drives.
- You must install guide screws to ensure the drive will line up correctly in the drive cage and lock in place. HP has provided extra guide screws for the drive bays (four 6-32 isolation mounting guide screws and eight M3 metric guide screws), installed on the side of the drive bays. The 6-32 isolation mounting screws are required for a secondary hard drive. All other drives (except the primary hard drive) use M3 metric screws. The HP-supplied metric screws are black and the HP-supplied isolation mounting screws are silver and blue. If you are replacing the primary hard drive, you must remove the four silver and blue 6-32 isolation mounting guide screws from the old hard drive and install them in the new hard drive.

Figure 7-14 Extra Guide Screw Locations



No.	Guide Screw	Device
1	Black M3 Metric Screws	All Drives (except hard drives)
2	Silver and Blue 6-32 Isolation Mounting Screws	Secondary Hard Drive

CAUTION: To prevent loss of work and damage to the computer or drive:

If you are inserting or removing a drive, shut down the operating system properly, turn off the computer, and unplug the power cord. Do not remove a drive while the computer is on or in standby mode.

Before handling a drive, ensure that you are discharged of static electricity. While handling a drive, avoid touching the connector.

Handle a drive carefully; do not drop it.

Do not use excessive force when inserting a drive.

Avoid exposing a hard drive to liquids, temperature extremes, or products that have magnetic fields such as monitors or speakers.

If a drive must be mailed, place the drive in a bubble-pack mailer or other protective packaging and label the package "Fragile: Handle With Care."

Removing a 5.25-inch or 3.5-inch Drive from a Drive Bay


CAUTION: All removable media should be taken out of a drive before removing the drive from the computer.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 125](#))
2. Remove the access panel ([Computer Access Panel on page 126](#))
3. Remove the front bezel ([Front Bezel on page 127](#))
4. Disconnect the drive cables, as indicated in the following illustrations.

CAUTION: When removing the cables, pull the tab or connector instead of the cable itself to avoid damaging the cable.


- a. If you are removing an optical drive, disconnect the power cable and data cable from the back of the drive.
- b. If you are removing a media card reader, disconnect the USB cable from the system board.

Figure 7-15 Disconnecting the Media Card Reader USB Cable



5. A latch drive bracket with release tabs secures the drives in the drive bay. Lift the release tab on the latch drive bracket (1) for the drive you want to remove, then slide the drive from its drive bay (2).


Figure 7-16 Removing the Drives



Installing a 5.25-inch or 3.5-inch Drive into a Drive Bay

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 125](#))
2. Remove the access panel ([Computer Access Panel on page 126](#))
3. Remove the front bezel ([Front Bezel on page 127](#))
4. If you are installing a drive in a bay covered by a bezel blank, remove the bezel blank. See [Bezel Blanks on page 128](#) for more information.

5. Install four M3 metric guide screws in the lower holes on each side of the drive. HP has provided eight extra M3 metric guide screws on the front of the chassis, under the front bezel. The M3 metric guide screws are black. Refer to [Drives on page 139](#) for an illustration of the extra M3 metric guide screws location.

 **NOTE:** When replacing the drive, transfer the four M3 metric guide screws from the old drive to the new one.


 **CAUTION:** Use only 5-mm long screws as guide screws. Longer screws can damage the internal components of the drive.

Figure 7-17 Installing Guide Screws (Optical Drive Shown)




6. Slide the drive into the drive bay, making sure to align the guide screws with the guide slots, until the drive snaps into place.

Figure 7-18 Sliding the Drives into the Drive Cage




7. Connect the power and data cables to the drive as indicated in the following illustrations.
 - a. If you are installing an optical drive, connect the power cable and data cable to the back of the drive.


 **NOTE:** The power cable for the optical drives is a two-headed cable that is routed from the system board to the rear of the optical drive bays.

- b. If you are installing a media card reader, connect the USB cable to the USB system board connector labeled MEDIA.

Figure 7-19 Connecting the Media Card Reader USB Cable




8. If installing a new drive, connect the opposite end of the data cable to the appropriate system board connector.

 **NOTE:** If you are installing a new SATA optical drive, connect the data cable for the first optical drive to the white SATA connector on the system board labeled SATA2. Connect the data cable for a second optical drive to the black SATA connector on the system board labeled ESATA. If the ESATA connector is already populated, connect the second optical drive to the light blue connector (8200 Elite models) or the white connector (6200 Pro models) labeled SATA1.

Refer to [System Board Connections on page 128](#) for an illustration of the system board drive connectors.

9. Replace the front bezel and computer access panel.
10. Reconnect the power cord and any external devices, then turn on the computer.
11. Lock any security devices that were disengaged when the access panel was removed.


Removing a Hard Drive from a Drive Bay

 **NOTE:** Before you remove the old hard drive, be sure to back up the data from the old hard drive so that you can transfer the data to the new hard drive.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 125](#))
2. Remove the access panel ([Computer Access Panel on page 126](#))
3. Disconnect the power cable and data cable from the back of the hard drive.


4. Release the drive by pulling the release tab away from the drive (1) and sliding the drive out of the bay (2).

Figure 7-20 Removing a Hard Drive




5. Remove the four guide screws (two on each side) from the old drive. You will need these screws to install a new drive.

Installing a Hard Drive into an Internal Drive Bay

 **NOTE:** The system does not support Parallel ATA (PATA) hard drives.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 125](#))
2. Remove the access panel ([Computer Access Panel on page 126](#))
3. Install guide screws on the sides of the drive. If you are installing a 2.5-inch drive, you must install the drive in an adapter bracket.

 **NOTE:** The hard drive uses 6-32 isolation mounting guide screws. Four extra guide screws are installed on the exterior of the hard drive bays. The HP-supplied isolation mounting guide screws are silver and blue. Refer to [Drives on page 139](#) for an illustration of the extra 6-32 isolation mounting guide screws location.

If you are replacing a drive, transfer the guides screws from the old drive to the new one.


- If you are installing a 3.5-inch hard drive, install four isolation mounting guide screws (two on each side of the drive).

Figure 7-21 Installing Isolation Mounting Guide Screws in a 3.5-inch Drive




- If you are installing a 2.5-inch hard drive:
 - Install four 6-32 silver and blue isolation mounting guide screws in the adapter bracket (two on each side of the bracket).

Figure 7-22 Installing Isolation Mounting Guide Screws in the 2.5-inch Adapter Bracket




- Install the drive into the slot on the adapter bracket with the PCA side facing down, aligning the three tabs on the bracket with the drive. Ensure that the power and data connectors on the drive are properly oriented.

Figure 7-23 Installing the Drive in the Adapter Bracket




- Hold the drive and bracket firmly together and turn the assembly over. Install four M3 screws to secure the drive to the bracket.

Figure 7-24 Securing the Drive in the Adapter Bracket



4. Slide the drive into the drive bay, making sure to align the guide screws with the guide slots, until the drive snaps into place. The bottom bay is for the primary hard drive. The upper bay is for an optional secondary hard drive.

Figure 7-25 Sliding a Hard Drive into the Drive Bay



5. Connect the power cable and data cable to the back of the hard drive.



NOTE: The power cable for the hard drives is a two-headed cable that is routed from the system board to the rear of the hard drive bays.

6. If installing a new drive, connect the opposite end of the data cable to the appropriate system board connector.



NOTE: If your system has only one SATA hard drive, you must connect the hard drive data cable to the dark blue connector labeled SATA0 to avoid any hard drive performance problems. If you are adding a second hard drive, connect the data cable to the light blue connector (8200 Elite models) or the white connector (6200 Pro models) labeled SATA1.


7. Route the power and data cables in their cable retainers.
8. Replace the computer access panel.
9. Reconnect the power cord and any external devices, then turn on the computer.
10. Lock any security devices that were disengaged when the access panel was removed.

Front Fan Assembly

Description	Spare part number
Front fan assembly	585884-001

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the access panel ([Computer Access Panel on page 126](#)).
3. Remove the cables from the clip on the top of the fan assembly.


Figure 7-26 Removing the cables from atop the front fan assembly



4. Unplug the fan cable from the system board connector labeled CHFAN.

5. Press the lever that secures the assembly to the chassis (1), pivot the assembly forward toward the front of the computer (2), and then lift the assembly straight up and out of the computer (3).

Figure 7-27 Removing the front fan assembly




To reinstall the front fan, reverse the removal procedure.

Front I/O Assembly

Description	Spare part number
Front I/O assembly	646827-001


1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the computer access panel ([Computer Access Panel on page 126](#)).
3. Remove the front bezel ([Front Bezel on page 127](#)).
4. Remove the front fan ([Front Fan Assembly on page 149](#)).
5. Disconnect the three front I/O cables (yellow, green, and blue) from the system board connectors (FRONT USB1, FRONT USB2, and FRONT AUD).
6. Remove the Torx screw that secures the assembly to the chassis.

Figure 7-28 Removing the front I/O assembly screw



7. Rotate the left side of the assembly to the right .

Figure 7-29 Removing the front I/O assembly



8. Pull the assembly away from the computer while threading the wires through the hole in the front of the chassis.


To reinstall the assembly, reverse the removal procedure.

Power Switch/LED Assembly

Description	Spare part number
Power switch/LED assembly	646828-001

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the access panel ([Computer Access Panel on page 126](#)).
3. Remove the front bezel ([Front Bezel on page 127](#)).
4. Remove the front fan ([Front Fan Assembly on page 149](#)).
5. Disconnect the cable from the system board connector labeled PB/LED.
6. With the computer on its side, press on the tabs on the bottom of the assembly (1) to disengage the assembly from the chassis, and then rotate the bottom of the assembly upward (2) to remove it from the chassis.

Figure 7-30 Removing the power switch/LED



7. Pull the assembly away from the chassis while threading the cable through the hole in front of the chassis.

Heat sink

Description	Spare part number
Heat sink	645326-001


⚠ WARNING! To reduce risk of personal injury from hot surfaces, allow the internal system components to cool before touching.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the computer access panel ([Computer Access Panel on page 126](#)).
3. Remove the front fan ([Front Fan Assembly on page 149](#)).
4. Loosen the four silver captive Torx screws that secure the heat sink to the system board.

⚠ CAUTION: Remove heat sink retaining screws in diagonally opposite pairs (as in an X) to even the downward forces on the processor. The pins on the socket are very fragile and any damage to them may require replacing the system board.



5. Lift the heat sink from atop the processor.



When reinstalling the heat sink, make sure that its bottom has been cleaned with an alcohol wipe and fresh thermal grease has been applied to the top of the processor.

CAUTION: Heat sink retaining screws should be tightened in diagonally opposite pairs (as in an X) to evenly seat the heat sink on the processor. This is especially important as the pins on the socket are very fragile and any damage to them may require replacing the system board.

Processor


Description	Spare part number
Intel Core i7 processor	
2600, 3.4 GHz, 8-MB L3 cache, 95W	638632-001
Intel Core i5 processors	
2500, 3.3 GHz, 6-MB L3 cache, 95W	638631-001
2400, 3.1 GHz, 6-MB L3 cache, 95W	638630-001
Intel Core i3 processors	
2120, 3.3 GHz, 3-MB L3 cache, 65W	638629-001
2100, 3.1 GHz, 3-MB L3 cache, 65W	638628-001

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the access panel ([Computer Access Panel on page 126](#)).
3. Remove the heat sink ([Heat sink on page 153](#)).
4. Rotate the locking lever to its full open position **(1)**.
5. Raise and rotate the microprocessor retainer to its fully open position **(2)**.

6. Carefully lift the processor from the socket (3).


⚠ CAUTION: Do NOT handle the pins in the processor socket. These pins are very fragile and handling them could cause irreparable damage. Once pins are damaged it may be necessary to replace the system board.

The heat sink must be installed within 24 hours of installing the processor to prevent damage to the processor's solder connections.



To install a new processor:

1. Place the processor in its socket and close the retainer.



2. Secure the locking lever.

If reusing the existing heat sink, go to step 3.

If using a new heat sink, go to step 5.

3. If reusing the existing heat sink, apply the thermal grease provided in the spares kit to the top of the processor.
4. Clean the bottom of the heat sink with the provided alcohol pad and place it atop the processor.
5. If using a new heat sink, remove the protective covering from the bottom of the heat sink and place it in position atop the processor.
6. Secure the heat sink to the system board and system board tray with the four captive screws and attach the heat sink control cable to the system board.

CAUTION: Heat sink retaining screws should be tightened in diagonally opposite pairs (as in an X) to evenly seat the heat sink on the processor. This is especially important as the pins on the socket are very fragile and any damage to them may require replacing the system board.


NOTE: After installing a new processor onto the system board, always update the system ROM to ensure that the latest version of the BIOS is being used on the computer. The latest system BIOS can be found on the Web at: <http://h18000.www1.hp.com/support/files>.

Speaker

Description	Spare part number
Speaker	645330-001

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the access panel ([Computer Access Panel on page 126](#)).
3. Remove the front fan assembly ([Front Fan Assembly on page 149](#)).
4. Disconnect the speaker wire from the system board connector labeled SPKR.
5. From the inside of the chassis, remove the two silver Torx screws (1) that secure the speaker to the chassis.
6. Rotate the top of the speaker downward (2), and then remove it from the chassis.

Figure 7-31 Removing the speaker



To replace the speaker, reverse the removal procedures.

Rear Chassis Fan

Description	Spare part number
Rear chassis fan	636922-001

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the access panel ([Computer Access Panel on page 126](#)).
3. Remove the four silver Phillips screws that secure the fan to the chassis.


Figure 7-32 Rear fan screws



4. Disconnect the fan control cable (1) from the system board connector labeled CHFAN2.

5. Lift the fan out of the chassis (2).

Figure 7-33 Removing the rear fan



To install the fan assembly, reverse the removal procedure. Be sure to orient the air flow out of the unit.

Power Supply

Description	Spare part number
Power supply, 320W, 90% efficient	613764-001
Power supply, 320W	613765-001

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the access panel ([Computer Access Panel on page 126](#)).
3. Disconnect the power cables from the white 6-pin system board connector labeled PWR and the 4-pin white system board connector labeled P3.
4. Remove the power cables from the clip on the base pan.
5. Remove the four silver Torx screws that connect the power supply to the chassis.


Figure 7-34 Power supply screws



6. Press the tab (1) on the base pan in front of the power supply that holds it in place.

7. Slide the power supply toward the front of the computer (2), rotate toward the fan so the power supply clears the lip on the top of the chassis, and then lift the power supply out of the chassis (3).

Figure 7-35 Removing the power supply



To install the power supply, reverse the removal procedure.


System Board

Description	Spare part number
For use in 8200 Elite Series models:	
System board, includes Trusted Platform Module (TPM) (includes thermal material)	611834-001
System board, does not include Trusted Platform Module (TPM)	649741-001
For use in 6200 Pro Series models:	
System board, includes Trusted Platform Module (TPM) (includes thermal material)	615114-001
System board, does not include Trusted Platform Module (TPM)	649515-001

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 73](#)).
2. Remove the access panel ([Computer Access Panel on page 126](#)).
3. Remove the front fan assembly ([Front Fan Assembly on page 149](#)).
4. When replacing the system board, make sure the following components are removed from the defective system board and installed on the replacement system board:
 - Memory modules ([Memory on page 131](#))
 - Expansion cards ([Expansion Cards on page 134](#))
 - Heat sink ([Heat sink on page 153](#)).
 - Processor ([Processor on page 155](#))
5. Remove all expansion boards ([Expansion Cards on page 134](#)).
6. Disconnect all cables connected to the system board, noting their location for reinstallation.


7. Remove the eight screws that secure the system board to the chassis.

Figure 7-36 System board screws



8. Slide the system board toward the front of the computer to disengage the I/O panel (1), lift the rear of the system board up at an angle (2), and then lift the system board out of the computer (3).

Figure 7-37 Removing the system board



When reinstalling the system board, first insert the I/O panel back into the slots in the rear of the chassis, and then align the board with the chassis screw holes.



NOTE: When replacing the system board, you must change the chassis serial number in the BIOS.

8 Removal and Replacement Procedures – Small Form Factor (SFF) Chassis

Adherence to the procedures and precautions described in this chapter is essential for proper service. After completing all necessary removal and replacement procedures, run the Diagnostics utility to verify that all components operate properly.



NOTE: Not all features listed in this guide are available on all computers.

Preparation for Disassembly

See [Routine Care, SATA Drive Guidelines, and Disassembly Preparation on page 59](#) for initial safety procedures.

1. Remove/disengage any security devices that prohibit opening the computer.
2. Close any open software applications.
3. Exit the operating system.
4. Remove any compact disc or media card from the computer.
5. Turn off the computer and any peripheral devices that are connected to it.



CAUTION: Turn off the computer before disconnecting any cables.

Regardless of the power-on state, voltage is always present on the system board as long as the system is plugged into an active AC outlet. In some systems the cooling fan is on even when the computer is in the “Standby,” or “Suspend” modes. The power cord should always be disconnected before servicing a unit.

6. Disconnect the power cord from the electrical outlet and then from the computer.
7. Disconnect all peripheral device cables from the computer.



NOTE: During disassembly, label each cable as you remove it, noting its position and routing. Keep all screws with the units removed.




CAUTION: The screws used in the computer are of different thread sizes and lengths; using the wrong screw in an application may damage the unit.

Access Panel

Description	Spare part number
Access panel	646815-001

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 165](#)).
2. If the computer is on a stand, remove the computer from the stand.
3. Lift up on the access panel handle **(1)** then lift the access panel off the computer **(2)**.

Figure 8-1 Removing the access panel




To install the access panel, reverse the removal procedure.

Front Bezel

Description	Spare part number
Front bezel	646814-001

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 165](#)).
2. Remove the access panel ([Access Panel on page 166](#)).
3. Lift up the three tabs on the side of the bezel (1), then rotate the bezel off the chassis (2).

Figure 8-2 Removing the front bezel




To install the front bezel, reverse the removal procedure.

Bezel Blanks

On some models, there are bezel blanks covering the 3.5-inch and 5.25-inch external drive bays that need to be removed before installing a drive. To remove a bezel blank:

- 1. Remove the access panel ([Access Panel on page 166](#)).
- 2. Remove the front bezel ([Front Bezel on page 167](#))..
- 3. To remove a bezel blank, push the two retaining tabs that hold the bezel blank in place towards the outer right edge of the bezel (1) and slide the bezel blank back and to the right to remove it (2).

Figure 8-3 Removing a bezel blank



- 4. Replace the front bezel.

Memory


Description	Spare part number
4-GB, PC3-10600	585157-001
2-GB, PC3-10600	635803-001
1-GB, PC3-10600	635802-001

The computer comes with double data rate 3 synchronous dynamic random access memory (DDR3-SDRAM) dual inline memory modules (DIMMs).

DIMMs

The memory sockets on the system board can be populated with up to four industry-standard DIMMs. These memory sockets are populated with at least one preinstalled DIMM. To achieve the maximum memory support, you can populate the system board with up to 16-GB of memory configured in a high-performing dual channel mode.

DDR3-SDRAM DIMMs

 **CAUTION:** This product DOES NOT support DDR3 Ultra Low Voltage (DDR3U) memory. The processor is not compatible with DDR3U memory and if you plug DDR3U memory into the system board, it can cause the physical damage to the DIMM or invoke system malfunction.

For proper system operation, the DDR3-SDRAM DIMMs must be:


- industry-standard 240-pin
- unbuffered non-ECC PC3-8500 DDR3-1066 MHz-compliant or PC3-10600 DDR3-1333 MHz-compliant
- 1.5 volt DDR3-SDRAM DIMMs

The DDR3-SDRAM DIMMs must also:

- support CAS latency 7 DDR3 1066 MHz (7-7-7 timing) and CAS latency 9 DDR3 1333 MHz (9-9-9 timing)
- contain the mandatory JEDEC SPD information

In addition, the computer supports:

- 512-Mbit, 1-Gbit, and 2-Gbit non-ECC memory technologies
- single-sided and double-sided DIMMs
- DIMMs constructed with x8 and x16 DDR devices; DIMMs constructed with x4 SDRAM are not supported

 **NOTE:** The system will not operate properly if you install unsupported DIMMs.

Populating DIMM Sockets

There are four DIMM sockets on the system board, with two sockets per channel. The sockets are labeled DIMM1, DIMM2, DIMM3, and DIMM4. Sockets DIMM1 and DIMM2 operate in memory channel B. Sockets DIMM3 and DIMM4 operate in memory channel A.


The system will automatically operate in single channel mode, dual channel mode, or flex mode, depending on how the DIMMs are installed.

- The system will operate in single channel mode if the DIMM sockets are populated in one channel only.
- The system will operate in a higher-performing dual channel mode if the total memory capacity of the DIMMs in Channel A is equal to the total memory capacity of the DIMMs in Channel B. The technology and device width can vary between the channels. For example, if Channel A is populated with two 1-GB DIMMs and Channel B is populated with one 2-GB DIMM, the system will operate in dual channel mode.
- The system will operate in flex mode if the total memory capacity of the DIMMs in Channel A is not equal to the total memory capacity of the DIMMs in Channel B. In flex mode, the channel populated with the least amount of memory describes the total amount of memory assigned to dual channel and the remainder is assigned to single channel. For optimal speed, the channels should be balanced so that the largest amount of memory is spread between the two channels. If one channel will have more memory than the other, the larger amount should be assigned to Channel A. For example, if you are populating the sockets with one 2-GB DIMM, and three 1-GB

DIMMs, Channel A should be populated with the 2-GB DIMM and one 1-GB DIMM, and Channel B should be populated with the other two 1-GB DIMMs. With this configuration, 4-GB will run as dual channel and 1-GB will run as single channel.

- In any mode, the maximum operational speed is determined by the slowest DIMM in the system.

Installing DIMMs

 **CAUTION:** You must disconnect the power cord and wait approximately 30 seconds for the power to drain before adding or removing memory modules. Regardless of the power-on state, voltage is always supplied to the memory modules as long as the computer is plugged into an active AC outlet. Adding or removing memory modules while voltage is present may cause irreparable damage to the memory modules or system board.

The memory module sockets have gold-plated metal contacts. When upgrading the memory, it is important to use memory modules with gold-plated metal contacts to prevent corrosion and/or oxidation resulting from having incompatible metals in contact with each other.


Static electricity can damage the electronic components of the computer or optional cards. Before beginning these procedures, ensure that you are discharged of static electricity by briefly touching a grounded metal object. For more information, refer to [Electrostatic Discharge Information on page 60](#).


When handling a memory module, be careful not to touch any of the contacts. Doing so may damage the module.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 165](#)).
2. Remove the access panel ([Access Panel on page 166](#)).
3. Rotate up the internal drive bay housing to access the memory module sockets on the system board.

4. Open both latches of the memory module socket (1), and insert the memory module into the socket (2).

Figure 8-4 Installing a DIMM



 **NOTE:** A memory module can be installed in only one way. Match the notch on the module with the tab on the memory socket.

Populate the black DIMM sockets before the white DIMM sockets.

For maximum performance, populate the sockets so that the memory capacity is spread as equally as possible between Channel A and Channel B. Refer to [Populating DIMM Sockets on page 169](#) for more information.

5. Push the module down into the socket, ensuring that the module is fully inserted and properly seated. Make sure the latches are in the closed position (3).
6. Repeat steps 4 and 5 to install any additional modules.
7. Replace the access panel.
8. If the computer was on a stand, replace the stand.
9. Reconnect the power cord and turn on the computer.
10. Lock any security devices that were disengaged when the access panel was removed.

The computer should automatically recognize the additional memory the next time you turn on the computer.

Expansion Card

Description	Spare part number
Graphics cards	
nVidia Quadro NVS295 PCIe x16 graphics card, 256 MB	641462-001
nVidia Quadro NVS300 PCIe x16 graphics card, 512 MB	632486-001
ATI Radeon HD6350 PCIe x16 graphics card, 512 MB	637995-001
ATI Radeon HD6450 PCIe x16 graphics card, 512 MB	637996-001
AMD FirePro 2270 PCIe x16 graphics card, 512 MB	637213-001
Intel PRO/1000CT NIC, includes bracket	635523-001
HP FireWire / IEEE 1394a PCIe x1 card	637591-001
Ports	
eSATA port assembly, PCI card	645558-001
USB 3.0 port, PCIe x1 card	616610-001
Serial port, PCI card	638815-001
Printer port, PCI card	638817-001
Other boards/cards	
HP WLAN 802.11b/g/n card	538048-001
Intel PRO/1000CT NIC, includes bracket	635523-001

The 8200 Elite computer has one PCI expansion slot, one PCI Express x1 expansion slot, one PCI Express x16 expansion slot, and one PCI Express x16 expansion slot that is downshifted to a x4 slot.

The 6200 Pro computer has one PCI expansion slot, two PCI Express x1 expansion slots, and one PCI Express x16 expansion slot.



NOTE: The PCI and PCI Express slots support only low profile cards.

You can install a PCI Express x1, x4, x8, or x16 expansion card in the PCI Express x16 slot.

For dual graphics card configurations, the first (primary) card must be installed in the PCI Express x16 slot that is NOT downshifted to a x4 slot (8200 Elite models).

To remove, replace, or add an expansion card:

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 165](#)).
2. Remove the access panel ([Access Panel on page 166](#)).
3. Locate the correct vacant expansion socket on the system board and the corresponding expansion slot on the back of the computer chassis.

4. Release the slot cover retention latch that secures the PCI slot covers by lifting the green tab on the latch and rotating the latch to the open position.

Figure 8-5 Opening the expansion slot retainer




5. Before installing an expansion card, remove the expansion slot cover or the existing expansion card.



NOTE: Before removing an installed expansion card, disconnect any cables that may be attached to the expansion card.


- a. If you are installing an expansion card in a vacant socket, remove the appropriate expansion slot cover on the back of the chassis. Pull the slot cover straight up then away from the inside of the chassis.

Figure 8-6 Removing an expansion slot cover




- b. If you are removing a standard PCI card or PCI Express x1 card, hold the card at each end, and carefully rock it back and forth until the connectors pull free from the socket. Pull the expansion card straight up from the socket (1) then away from the inside of the chassis to release it from the chassis frame (2). Be sure not to scrape the card against the other components.

Figure 8-7 Removing a standard PCI expansion card



- c. If you are removing a PCI Express x16 card, pull the retention arm on the back of the expansion socket away from the card and carefully rock the card back and forth until the connectors pull free from the socket. Pull the expansion card straight up from the socket then away from the inside of the chassis to release it from the chassis frame. Be sure not to scrape the card against the other components.

Figure 8-8 Removing a PCI Express x16 expansion card




6. Store the removed card in anti-static packaging.

7. If you are not installing a new expansion card, install an expansion slot cover to close the open slot.

CAUTION: After removing an expansion card, you must replace it with a new card or expansion slot cover for proper cooling of internal components during operation.

8. To install a new expansion card, hold the card just above the expansion socket on the system board then move the card toward the rear of the chassis (1) so that the bracket on the card is aligned with the open slot on the rear of the chassis. Press the card straight down into the expansion socket on the system board (2).


Figure 8-9 Installing an expansion card



NOTE: When installing an expansion card, press firmly on the card so that the whole connector seats properly in the expansion card slot.

9. Rotate the slot cover retention latch back in place to secure the expansion card.

Figure 8-10 Closing the expansion slot retainer



10. Connect external cables to the installed card, if needed. Connect internal cables to the system board, if needed.

11. Replace the computer access panel.
12. If the computer was on a stand, replace the stand.
13. Reconnect the power cord and turn on the computer.
14. Lock any security devices that were disengaged when the access panel was removed.
15. Reconfigure the computer, if necessary.

System Board Connections

Refer to the following illustration and table to identify the system board connectors for your model.

Figure 8-11 8200 Elite Series system board connections





Table 8-1 8200 Elite Series system board connections

No.	System Board Connector	System Board Label	Color	Component
1	DIMM4 (Channel A)	DIMM4	white	Memory Module
2	DIMM3 (Channel A)	DIMM3	black	Memory Module
3	DIMM2 (Channel B)	DIMM2	white	Memory Module
4	DIMM1 (Channel B)	DIMM1	black	Memory Module
5	Power	SATAPWR0	black	SATA Optical Drives
6	Power	SATAPWR1	black	SATA Hard Drives
7	SATA 3.0	SATA0	dark blue	1st Hard Drive
8	SATA 3.0	SATA1	light blue	2nd Hard Drive, or 2nd Optical Drive if an ESATA Adapter Cable exists
9	SATA 2.0	SATA2	white	1st Optical Drive
10	eSATA	ESATA	black	eSATA Adapter Cable, or 2nd Optical Drive
11	Parallel Port	PAR	black	Parallel Port
12	Serial Port	COMB	black	Serial Port

Table 8-1 8200 Elite Series system board connections (continued)

No.	System Board Connector	System Board Label	Color	Component
13	USB	MEDIA	black	USB Device, such as a Media Card Reader
14	Hood Lock	HLCK	black	Hood Lock
15	USB	MEDIA2	black	USB Device, such as a Media Card Reader
16	Hood Sensor	HSENSE	white	Hood Sensor
17	PCI Express x1	X1PCIEXP1	black	Expansion Card
18	PCI Express x16 downshifted to a x4	X4PCIEXP	white	Expansion Card
19	PCI Express x16	X16PCIEXP	black	Expansion Card
20	PCI	PCI	white	Expansion Card

Figure 8-12 6200 Pro Series system board connections**Table 8-2 6200 Pro Series system board connections**

No.	System Board Connector	System Board Label	Color	Component
1	DIMM4 (Channel A)	DIMM4	white	Memory Module
2	DIMM3 (Channel A)	DIMM3	black	Memory Module
3	DIMM2 (Channel B)	DIMM2	white	Memory Module
4	DIMM1 (Channel B)	DIMM1	black	Memory Module
5	Power	SATAPWR0	black	SATA Optical Drives
6	Power	SATAPWR1		SATA Hard Drives
7	SATA 3.0	SATA0	dark blue	1st Hard Drive
8	SATA 2.0	SATA1	white	2nd Hard Drive, or 2nd Optical Drive if an eSATA Adapter Cable exists
9	SATA 2.0	SATA2	white	1st Optical Drive

Table 8-2 6200 Pro Series system board connections (continued)

No.	System Board Connector	System Board Label	Color	Component
10	eSATA	ESATA	black	eSATA Adapter Cable, or 2nd Optical Drive
11	Parallel Port	PAR	black	Parallel Port
12	Serial Port	COMB	black	Serial Port
13	USB	MEDIA	black	USB Device, such as a Media Card Reader
14	Hood Lock	HLCK	black	Hood Lock
15	USB	MEDIA2	black	USB Device, such as a Media Card Reader
16	Hood Sensor	HSENSE	white	Hood Sensor
17	PCI Express x1	X1PCIEXP1	black	Expansion Card
18	PCI Express x1	X4PCIEXP	black	Expansion Card
19	PCI Express x16	X16PCIEXP	black	Expansion Card
20	PCI	PCI	white	Expansion Card

Drives

Description	Spare part number
16X SATA DVD±RW drive with LightScribe	581600-001
16X SATA DVD-ROM drive	581599-001
Blu-ray BD-RW SuperMulti DL Drive with LightScribe	617030-001
1 TB, 7200 rpm SATA hard drive	636930-001
750 GB, 7200 rpm SATA hard drive	632938-001
500 GB, 7200 rpm SATA hard drive	636929-001
320 GB, 7200 rpm SATA hard drive, 2.5-inch	634824-001
300 GB, 10000-RPM SATA3 hard drive	639695-001
300 GB, 10000-RPM SATA2 hard drive	648963-001
250 GB, 7200 rpm SATA hard drive	636927-001
160 GB, 10000-RPM SATA hard drive	639694-001
160 GB, 10000-RPM SATA hard drive, 2.5-inch	508312-001
160 GB Solid State Drive (SSD)	646809-001
80 GB Solid State Drive (SSD)	607817-001

Drive Positions

Figure 8-13 Drive positions




Table 8-3 Drive Positions

1	3.5-inch internal hard drive bay
2	3.5-inch drive bay for optional drives (media card reader shown)
3	5.25-inch drive bay for optional drives (optical drive shown)

NOTE: The drive configuration on your computer may be different than the drive configuration shown above.


To verify the type and size of the storage devices installed in the computer, run Computer Setup.

Installing and Removing Drives

When installing drives, follow these guidelines:


- The primary Serial ATA (SATA) hard drive must be connected to the dark blue primary SATA connector on the system board labeled SATA0. If you are adding a second hard drive, connect it to the light blue connector (8200 Elite models) or the white connector (6200 Pro models) on the system board labeled SATA1.
- Connect a SATA optical drive to the white SATA connector on the system board labeled SATA2.
- Connect an optional eSATA adapter cable to the black SATA connector on the system board labeled ESATA.
- Connect a media card reader USB cable to the USB connector on the system board labeled MEDIA.
- The power cable for the SATA drives is a three-headed cable that is plugged into the system board with the first connector routed to the rear of the hard drive, the second connector routed to the rear of the 3.5" drive, and the third connector routed to the rear of the 5.25" optical drive.
- The system does not support Parallel ATA (PATA) optical drives or PATA hard drives.
- You must install guide screws to ensure the drive will line up correctly in the drive cage and lock in place. HP has provided extra guide screws for the drive bays (five 6-32 standard screws and four M3 metric screws), installed in the front of the chassis, under the front bezel. The 6-32 standard screws are required for a secondary hard drive. All other drives (except the primary hard drive) use M3 metric screws. The HP-supplied metric screws are black and the HP-supplied standard screws are silver. If you are replacing the primary hard drive, you must remove the four silver and blue 6-32 isolation mounting guide screws from the old hard drive and install them in the new hard drive.

Figure 8-14 Extra Guide Screw Locations



No.	Guide Screw	Device
1	Black M3 Metric Screws	All Drives (except primary and secondary hard drives)
2	Silver 6-32 Standard Screws	Secondary Hard Drive

There are at total of five extra silver 6-32 standard screws. Four are used as guide screws for a secondary hard drive. The fifth is used for bezel security.

 **CAUTION:** To prevent loss of work and damage to the computer or drive:

If you are inserting or removing a drive, shut down the operating system properly, turn off the computer, and unplug the power cord. Do not remove a drive while the computer is on or in standby mode.

Before handling a drive, ensure that you are discharged of static electricity. While handling a drive, avoid touching the connector. For more information about preventing electrostatic damage, refer to [Electrostatic Discharge Information on page 60](#).


Handle a drive carefully; do not drop it.

Do not use excessive force when inserting a drive.


Avoid exposing a hard drive to liquids, temperature extremes, or products that have magnetic fields such as monitors or speakers.

If a drive must be mailed, place the drive in a bubble-pack mailer or other protective packaging and label the package "Fragile: Handle With Care."


Removing a 5.25-inch Drive from a Drive Bay

 **CAUTION:** All removable media should be taken out of a drive before removing the drive from the computer.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 165](#)).
2. Remove the access panel ([Access Panel on page 166](#)).
3. Rotate the drive cage to its upright position.
4. If removing an optical drive, disconnect the power cable and data cable from the rear of the optical drive.


 **CAUTION:** When removing the cables, pull the tab or connector instead of the cable itself to avoid damaging the cable.

5. Rotate the drive cage back down to its normal position.

 **CAUTION:** Be careful not to pinch any cables or wires when rotating the drive cage down.


6. Press down on the green drive retainer button located on the left side of the drive to disengage the drive from the drive cage (1). While pressing the drive retainer button, slide the drive back until it stops, then lift it up and out of the drive cage (2).

Figure 8-15 Removing the 5.25-inch Drive



Installing a 5.25-inch Drive into a Drive Bay

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 165](#)).
2. Remove the access panel ([Access Panel on page 166](#)).
3. If you are installing a drive in a bay covered by a bezel blank, remove the front bezel then remove the bezel blank. See [Bezel Blanks on page 168](#) for more information.
4. Install four M3 metric guide screws in the lower holes on each side of the drive. HP has provided four extra M3 metric guide screws on the front of the chassis, under the front bezel. The M3 metric guide screws are black. Refer to [Installing and Removing Drives on page 180](#) for an illustration of the extra M3 metric guide screws location.

 **NOTE:** When replacing the drive, transfer the four M3 metric guide screws from the old drive to the new one.



 **CAUTION:** Use only 5-mm long screws as guide screws. Longer screws can damage the internal components of the drive.

Figure 8-16 Installing Guide Screws in the Optical Drive



5. Position the guide screws on the drive into the J-slots in the drive bay. Then slide the drive toward the front of the computer until it locks into place.

Figure 8-17 Installing the Optical Drive



6. Rotate the drive cage to its upright position.
7. Connect the SATA data cable to the white SATA system board connector labeled SATA2.
8. Route the data cable through the cable guides.

CAUTION: There are two cable guides that keep the data cable from being pinched by the drive cage when raising or lowering it. One is located on the bottom side of the drive cage. The other is located on the chassis frame under the drive cage. Ensure that the data cable is routed through these guides before connecting it to the optical drive.

9. Connect the power cable and data cable to the rear of the optical drive.

NOTE: The power cable for the optical drive is a three-headed cable that is routed from the system board to the hard drive, then to the rear of the optical drive.

10. Rotate the drive cage back down to its normal position.

CAUTION: Be careful not to pinch any cables or wires when rotating the drive cage down.

11. Replace the front bezel (if removed) and access panel.
12. If the computer was on a stand, replace the stand.
13. Reconnect the power cord and turn on the computer.
14. Lock any security devices that were disengaged when the access panel was removed.

Removing a 3.5-inch Drive from a Drive Bay

CAUTION: All removable media should be taken out of a drive before removing the drive from the computer.


The 3.5-inch drive is located underneath the 5.25-inch drive. You must remove the 5.25-inch drive before removing the 3.5-inch drive.

1. Follow the procedure in [Removing a 5.25-inch Drive from a Drive Bay on page 181](#) to remove the 5.25-inch drive and access the 3.5-inch drive.

CAUTION: Ensure that the computer is turned off and that the power cord is disconnected from the electrical outlet before proceeding.


2. Disconnect the drive cables from the rear of the drive, or, if you are removing a media card reader, disconnect the USB cable from the system board as indicated in the following illustration.

Figure 8-18 Disconnecting the Media Card Reader USB Cable




3. Press down on the green drive retainer button located on the left side of the drive to disengage the drive from the drive cage (1). While pressing the drive retainer button, slide the drive back until it stops, then lift it up and out of the drive cage (2).

Figure 8-19 Removing a 3.5-inch Drive (Media Card Reader Shown)




Installing a 3.5-inch Drive into a Drive Bay

The 3.5-inch bay is located underneath the 5.25-inch drive. To install a drive into the 3.5-inch bay:

 **NOTE:** Install guide screws to ensure the drive will line up correctly in the drive cage and lock in place. HP has provided extra guide screws for the drive bays (four 6-32 standard screws and four M3 metric screws), installed in the front of the chassis, under the front bezel. A secondary hard drive uses 6-32 standard screws. All other drives (except the primary hard drive) use M3 metric screws. The HP-supplied M3 metric screws are black and the HP-supplied 6-32 standard screws are silver. Refer to [Installing and Removing Drives on page 180](#) for illustrations of the guide screw locations.

1. Follow the procedure in [Removing a 5.25-inch Drive from a Drive Bay on page 181](#) to remove the 5.25-inch drive and access the 3.5-inch drive bay.

 **CAUTION:** Ensure that the computer is turned off and that the power cord is disconnected from the electrical outlet before proceeding.


2. If you are installing a drive in a bay covered by a bezel blank, remove the front bezel then remove the bezel blank. See [Bezel Blanks on page 168](#) for more information.
3. Install guide screws in the holes on each side of the drive.

Figure 8-20 Installing Guide Screws (Media Card Reader Shown)



4. Position the guide screws on the drive into the J-slots in the drive bay. Then slide the drive toward the front of the computer until it locks into place.


Figure 8-21 Installing a Drive into the 3.5-inch Drive Bay (Media Card Reader Shown)



5. Connect the appropriate drive cables:
 - a. If installing a second hard drive, connect the power cable and data cable to the rear of the drive and connect the other end of the data cable to the light blue connector (8200 Elite models) or the white connector (6200 Pro models) on the system board labeled SATA1.

- b. If installing a media card reader, connect the USB cable from the media card reader to the USB connector on the system board labeled MEDIA.


Figure 8-22 Connecting the Media Card Reader USB Cable



 **NOTE:** Refer to [System Board Connections on page 176](#) for an illustration of the system board drive connectors.

6. Replace the 5.25-inch drive.
7. Replace the front bezel (if removed) and access panel.
8. If the computer was on a stand, replace the stand.
9. Reconnect the power cord and turn on the computer.
10. Lock any security devices that were disengaged when the access panel was removed.

Removing and Replacing the Primary 3.5-inch Internal Hard Drive


 **NOTE:** Before you remove the old hard drive, be sure to back up the data from the old hard drive so that you can transfer the data to the new hard drive.

The preinstalled 3.5-inch hard drive is located under the power supply. To remove and replace the hard drive:

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 165](#)).
2. Remove the access panel ([Access Panel on page 166](#)).
3. Rotate the drive cage for internal drives to its upright position.


4. Rotate the power supply to its upright position. The hard drive is located beneath the power supply.

Figure 8-23 Raising the Power Supply




5. Disconnect the power cable and data cable from the back of the hard drive.
6. Press down on the green release latch next to the hard drive (1). While holding the latch down, slide the drive forward until it stops, then lift the drive up and out of the bay (2).

Figure 8-24 Removing the Hard Drive




7. To install a hard drive, you must transfer the silver and blue isolation mounting guide screws from the old hard drive to the new hard drive.

Figure 8-25 Installing Hard Drive Guide Screws



8. Align the guide screws with the slots on the chassis drive cage, press the hard drive down into the bay, then slide it back until it stops and locks in place.

Figure 8-26 Installing the Hard Drive



9. Connect the power cable and data cable to the back of the hard drive.



NOTE: If the system has only one SATA hard drive, the data cable must be connected to the dark blue connector labeled SATA0 on the system board to avoid any hard drive performance problems.

10. Rotate the drive cage for internal drives and the power supply down to their normal positions.
11. Replace the access panel.
12. If the computer was on a stand, replace the stand.
13. Reconnect the power cord and turn on the computer.
14. Lock any security devices that were disengaged when the access panel was removed.


Fan duct

Description	Spare part number
Fan duct	636921-001

The fan duct sits between the front fan and the heat sink.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 165](#)).
2. Remove the access panel ([Access Panel on page 166](#)).
3. Lift the fan duct straight up out of the chassis.

Figure 8-27 Removing the fan duct



To install the fan duct, reverse the removal procedure.


Front Fan Assembly

Description	Spare part number
Front fan	645327-001

The front fan assembly is attached to the front of the chassis.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 165](#)).
2. Remove the access panel ([Access Panel on page 166](#)).
3. Remove the front bezel ([Front Bezel on page 167](#)).
4. Remove the baffle ([Fan duct on page 189](#)).
5. Disconnect the fan cable from the red/brown system board connector labeled CHFAN1.


Figure 8-28 Disconnecting the front fan cable



6. Press the tabs that secure the fan assembly to the front of the chassis **(1)**.

7. Pull the assembly toward the rear of the unit (2), and then lift it out of the chassis.

Figure 8-29 Removing the front fan



To install the front fan, reverse the removal procedure. Be sure to orient the air flow into the unit.

Hood Sensor

Description	Spare part number
Hood sensor	638816-001

The hood sensor is attached in a slot in the rear of the chassis.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 165](#)).
2. Remove the access panel ([Access Panel on page 166](#)).
3. Unplug the sensor cable from the system board connector labeled HSENSE (1).
4. Slide the hood sensor straight out of the notch in the chassis (2).



 **NOTE:** A flat blade screwdriver can be used to push the hood sensor out of the slot.

Figure 8-30 Removing the hood sensor from the chassis fan



To install the hood sensor, reverse the removal procedure.


Front I/O, Power Switch Assembly

Description	Spare part number
Front I/O and power switch assembly	636926-001

The front I/O and power switch/LEDs is one assembly, attached to the front of the chassis. Push the assembly into the chassis to remove.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 165](#)).
2. Remove the access panel ([Access Panel on page 166](#)).
3. Remove the front bezel ([Front Bezel on page 167](#)).
4. Remove the chassis fan ([Front Fan Assembly on page 190](#)).
5. Rotate the drive cage to its upright position.
6. Disconnect the four cables from the system board as follows:
 - Yellow connector labeled FRONT USB
 - Green connector labeled FRONT USB2
 - Blue connector labeled FRONT AUD
 - Black connector labeled PB/LED


Figure 8-31 Disconnecting the front I/O, power switch/LED assembly cables



7. Remove the screw **(1)** that secures the assembly to the front of the chassis.

8. Route the cables through the slots beneath the drive cage, rotate the assembly into the chassis (2), and then remove the assembly from the computer.

Figure 8-32 Removing the front I/O, power switch/LED assembly screw



To install the front I/O and power switch assembly, reverse the removal procedure.



NOTE: Be sure to correctly route the cables beneath the drive cage when reinstalling the assembly. Proper cable routing prevents damage to the cables and allows the drive cage to close properly.


Speaker

Description	Spare part number
Speaker	636925-001

The speaker is attached to the front of the chassis under the rotating drive cage.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 165](#)).
2. Remove the access panel ([Access Panel on page 166](#)).
3. Remove the front bezel ([Front Bezel on page 167](#)).
4. Rotate the drive cage to its upright position.
5. Disconnect the speaker wire from the system board labeled SPKR (1).
6. Remove the screw that secures the speaker to the chassis (2).
7. Lift the speaker from the inside of the chassis to remove it (3).

Figure 8-33 Removing the speaker



To install the speaker, reverse the removal procedures.

Heat sink


Description	Spare part number
Heat sink	645326-001

The heat sink is secured atop the processor with four captive Torx screws. The heat sink does not include a fan.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 165](#)).
2. Remove the access panel ([Access Panel on page 166](#)).
3. Remove the fan duct ([Fan duct on page 189](#)).
4. Remove the front fan ([Front Fan Assembly on page 190](#)).
5. In the order shown, loosen the four captive screws that secure the heat sink to the system board tray.


CAUTION: Heat sink retaining screws should be removed in diagonally opposite pairs (as in an X) to even the downward forces on the processor. This is especially important as the pins on the socket are very fragile and any damage to them may require replacing the system board.

Figure 8-34 Loosening the heat sink screws



6. After loosening the screws (1), lift the heat sink from atop the processor (2) and set it on its side to keep from contaminating the work area with thermal grease.

Figure 8-35 Removing the heat sink



When reinstalling the heat sink, make sure that its bottom has been cleaned with an alcohol wipe and fresh thermal grease has been applied to the top of the processor.

CAUTION: Heat sink retaining screws should be tightened in diagonally opposite pairs (as in an X) to evenly seat the heat sink on the processor to avoid damage that could require replacing the system board.

Failure to install the fan duct may cause the computer to overheat.

Processor

Description	Spare part number
Intel Core i7 processors	
2600, 3.4 GHz, 8-MB L3 cache, 95W	638632-001
Intel Core i5 processors	
2500, 3.3 GHz, 6-MB L3 cache, 95W	638631-001
2400, 3.1 GHz, 6-MB L3 cache, 95W	638630-001
Intel Core i3 processors	
2120, 3.3 GHz, 3-MB L3 cache, 65W	638629-001
2100, 3.1 GHz, 3-MB L3 cache, 65W	638628-001


1. Prepare the computer for disassembly ([Preparation for Disassembly on page 165](#)).
2. Remove the access panel ([Access Panel on page 166](#)).
3. Remove the fan duct ([Fan duct on page 189](#)).
4. Remove the front fan assembly ([Front Fan Assembly on page 190](#)).
5. Remove the heat sink ([Heat sink on page 196](#)).
6. Rotate the locking lever to its full open position **(1)**.
7. Raise and rotate the microprocessor retainer to its fully open position **(2)**.

8. Carefully lift the processor from the socket (3).

⚠ CAUTION: Do NOT handle the pins in the processor socket. These pins are very fragile and handling them could cause irreparable damage. Once pins are damaged it may be necessary to replace the system board.

The heat sink must be installed within 24 hours of installing the processor to prevent damage to the processor's solder connections.

Figure 8-36 Removing the processor




To install a new processor:

1. Place the processor in its socket and close the retainer. Make sure the slot in the processor fits into the post on the socket.

2. Secure the locking lever. If reusing the existing heat sink, go to step 3. If using a new heat sink, go to step 6.

Figure 8-37 Removing the processor



3. If reusing the existing heat sink, clean the bottom of the heat sink with the alcohol pad provided in the spares kit.

CAUTION: Before reinstalling the heat sink you must clean the top of the processor and the bottom of the heat sink with an alcohol pad supplied in the spares kit. After the alcohol has evaporated, apply thermal grease to the top of the processor from the syringe supplied in the spares kit.


4. Apply the thermal grease provided in the spares kit to the top of the processor and install the heat sink atop the processor.
5. Go to step 7.
6. If using a new heat sink, remove the protective covering from the bottom of the heat sink and place it in position atop the processor.
7. Secure the heat sink to the system board and system board tray.

CAUTION: Heat sink retaining screws should be tightened in diagonally opposite pairs (as in an X) to evenly seat the heat sink on the processor. This is especially important as the pins on the socket are very fragile and any damage to them may require replacing the system board.


NOTE: After installing a new processor onto the system board, always update the system ROM to ensure that the latest version of the BIOS is being used on the computer. The latest system BIOS can be found on the Web at: <http://h18000.www1.hp.com/support/files>.

Power Supply

Description	Spare part number
Power supply, 90% efficient	613762-001
Power supply, standard	613763-001

 **WARNING!** To reduce potential safety issues, only the power supply provided with the computer, a replacement power supply provided by HP, or a power supply purchased as an accessory from HP should be used with the computer.

The rotating power supply is located at the rear of the chassis. It is held in place by a bracket – no screws are used.

 **WARNING!** Voltage is always present on the system board when the computer is plugged into an active AC outlet. To avoid possible personal injury and damage to the equipment the power cord should be disconnected from the computer and/or the AC outlet before opening the computer.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 165](#)).
2. Remove the access panel ([Access Panel on page 166](#)).
3. Rotate the drive cage up and disconnect the power cables from all of the drives.
4. Disconnect all power cables from the system board as follows:
 - white 4-pin PWRCPU
 - white 4-pin PWR
 - white 6-pin PWRCMD
5. Rotate the power supply to its full upright position.
6. Release the power supply cables from the cable retaining clip under the drive cage.

7. Pull the power supply forward until the posts on the power supply move forward in the power supply bracket, and then lift the power supply straight up and out of the chassis.

Figure 8-38 Removing the power supply



To install the power supply, reverse the removal procedure.

CAUTION: When installing the power supply cables, make sure they are properly positioned so they are not cut by the drive cage and are not pinched by the rotating power supply.


System Board

Description	Spare part number
For use in 8200 Elite Series models:	
System board, includes Trusted Platform Module (TPM) (includes thermal material)	611834-001
System board, does not include Trusted Platform Module (TPM)	649741-001
For use in 6200 Pro Series models:	
System board, includes Trusted Platform Module (TPM) (includes thermal material)	615114-001
System board, does not include Trusted Platform Module (TPM)	649515-001

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 165](#)).
2. Remove the access panel ([Access Panel on page 166](#)).
3. When replacing the system board, make sure the following components are removed from the defective system board and installed on the replacement system board:
 - Memory modules ([Memory on page 168](#))
 - Expansion cards ([Expansion Card on page 172](#))
 - Heat sink ([Heat sink on page 196](#))
 - Processor ([Processor on page 198](#))
4. Remove the baffle from the chassis ([Fan duct on page 189](#)).
5. Remove the fan from the chassis ([Front Fan Assembly on page 190](#)).
6. Rotate the drive cage to its upright position.
7. Rotate the power supply to its full upright position.
8. Disconnect all data and power cables from the system board.
9. Disconnect the balance of the cables from the system board.
10. Remove the eight screws (1) that secure the system board to the chassis.

11. Lift up the front of the system board, and then pull the system board forward, up, and out of the chassis (2).

Figure 8-39 Removing the system board



To install the system board, reverse the removal procedure.



NOTE: When replacing the system board, you must also change the chassis serial number in the BIOS.



CAUTION: Before reinstalling the heat sink you must clean the top of the processor and the bottom of the heat sink with an alcohol pad supplied in the spares kit. After the alcohol has evaporated, apply thermal grease to the top of the processor from the syringe supplied in the spares kit.

CAUTION: When reconnecting the cables it is important that they be positioned so they do not interfere with the rotation of the drive cage or power supply.


Using the Small Form Factor Computer in a Tower Orientation

The Small Form Factor computer can be used in a tower orientation. The HP logo plate on the front bezel is adjustable for either desktop or tower orientation.


1. Prepare the computer for disassembly ([Preparation for Disassembly on page 165](#)).
2. Orient the computer so that its right side is facing down and place the computer in the optional stand.

Figure 8-40 Changing from Desktop to Tower Orientation



 **NOTE:** To stabilize the computer in a tower orientation, HP recommends the use of the optional tower stand.

3. Lock any security devices that were disengaged when the access panel was removed.

 **NOTE:** Ensure at least 10.2 centimeters (4 inches) of space on all sides of the computer remains clear and free of obstructions.

9 Removal and Replacement Procedures – Ultra-Slim Desktop (USDT) Chassis

Adherence to the procedures and precautions described in this chapter is essential for proper service. After completing all necessary removal and replacement procedures, run the Diagnostics utility to verify that all components operate properly.



NOTE: Not all features listed in this guide are available on all computers.

Preparation for Disassembly

See [Routine Care, SATA Drive Guidelines, and Disassembly Preparation on page 59](#) for initial safety procedures.

1. Remove/disengage any security devices that prohibit opening the computer.
2. Close any open software applications.
3. Exit the operating system.
4. Remove any compact disc from the computer.
5. Turn off the computer and any peripheral devices that are connected to it.



CAUTION: Turn off the computer before disconnecting any cables.

Regardless of the power-on state, voltage is always present on the system board as long as the system is plugged into an active AC outlet. In some systems the cooling fan is on even when the computer is in the “Standby,” or “Suspend” modes. The power cord should always be disconnected before servicing a unit.

6. Disconnect the power cord from the electrical outlet and then from the computer.
7. Disconnect all peripheral device cables from the computer.



NOTE: During disassembly, label each cable as you remove it, noting its position and routing. Keep all screws with the units removed.



CAUTION: The screws used in the computer are of different thread sizes and lengths; using the wrong screw in an application may damage the unit.

8. If the PC is mounted in the accessory mounting stand, remove it from the stand.


Access Panel

Description	Spare part number
Access panel	646816-001

To access internal components, you must remove the access panel:

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 206](#)).
2. Loosen the thumbscrew on the rear of the computer (1), slide the access panel toward the rear of the computer, then lift it off (2).

Figure 9-1 Removing the access panel




To install the access panel, reverse the removal procedure.

Front Bezel

Description	Spare part number
Front bezel	646817-001

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 206](#)).
2. Remove the computer access panel ([Access Panel on page 207](#)).
3. Lift up the three tabs on the side of the bezel (1), then rotate the bezel off the chassis (2).

Figure 9-2 Removing the front bezel



To install the front bezel, reverse the removal procedure.


Bezel Blank

Description	Spare part number
Bezel blank, jack black	593230-001

On some models, there is a bezel blank covering the external drive bay that needs to be removed before installing a drive. To remove a bezel blank:

1. Remove the computer access panel ([Access Panel on page 207](#)).
2. Remove the front bezel ([Front Bezel on page 208](#)).
3. To remove the bezel blank, push the two retaining tabs that hold the bezel blank in place towards the outer left edge of the bezel (**1**) and pull the bezel blank inwards to remove it (**2**).


Figure 9-3 Removing a bezel blank



System Board Connections

Refer to the following illustration and table to identify the system board connectors.

Figure 9-4 System board connections



No.	System Board Connector	System Board Label	Color	Component
1	SATA 3.0	SATA1	light blue	Optical Drive
2	Power	SATA PWR1	white	Optical Drive
3	Mobile PCI Express Module	MXM	black	Graphics Card
4	Hood Sensor	HSENSE	white	Hood Sensor
5	USB	MEDIA	black	SD Media Card Reader
6	PCI Express x1	X1PCIEXP1	black	Expansion Card

Memory


Description	Spare part number
4-GB, PC3-10600	646801-001
2-GB, PC3-10600	646800-001
1-GB, PC3-10600	646808-001

The computer comes with double data rate 3 synchronous dynamic random access memory (DDR3-SDRAM) small outline dual inline memory modules (SODIMMs).

SODIMMs

The memory sockets on the system board can be populated with up to two industry-standard SODIMMs. These memory sockets are populated with at least one preinstalled SODIMM. To achieve the maximum memory support, you can populate the system board with up to 8-GB of memory.

DDR3-SDRAM SODIMMs

 **CAUTION:** This product DOES NOT support DDR3 Ultra Low Voltage (DDR3U) memory. The processor is not compatible with DDR3U memory and if you plug DDR3U memory into the system board, it can cause the physical damage to the SODIMM or invoke system malfunction.

For proper system operation, the SODIMMs must be:

- industry-standard 204-pin
- unbuffered non-ECC PC3-8500 DDR3-1066 MHz-compliant or PC3-10600 DDR3-1333 MHz-compliant
- 1.5 volt DDR3-SDRAM SODIMMs

The DDR3-SDRAM SODIMMs must also:

- support CAS latency 7 DDR3 1066 MHz (7-7-7 timing) and CAS latency 9 DDR3 1333 MHz (9-9-9 timing)
- contain the mandatory Joint Electronic Device Engineering Council (JEDEC) specification

In addition, the computer supports:

- 512-Mbit, 1-Gbit, and 2-Gbit non-ECC memory technologies
- single-sided and double-sided SODIMMS
- SODIMMs constructed with x8 and x16 devices; SODIMMs constructed with x4 SDRAM are not supported

 **NOTE:** The system will not operate properly if you install unsupported SODIMMs.

Populating SODIMM Sockets

There are two SODIMM sockets on the system board, with one socket per channel. The sockets are labeled XMM1 and XMM3. The XMM1 socket operates in memory channel A. The XMM3 socket operates in memory channel B.

Figure 9-5 SODIMM socket locations




Table 9-1 SODIMM socket locations

Item	Description	System Board Label	Socket Color
1	SODIMM1 socket, Channel B	XMM1	Black
2	SODIMM3 socket, Channel A	XMM3	Black

The system will automatically operate in single channel mode, dual channel mode, or flex mode, depending on how the SODIMMs are installed.

- The system will operate in single channel mode if the SODIMM sockets are populated in one channel only.
- The system will operate in a higher-performing dual channel mode if the memory capacity of the SODIMM in Channel A is equal to the memory capacity of the SODIMM in Channel B.
- The system will operate in flex mode if the memory capacity of the SODIMM in Channel A is not equal to the memory capacity of the SODIMM in Channel B. In flex mode, the channel populated with the least amount of memory describes the total amount of memory assigned to dual channel and the remainder is assigned to single channel. If one channel will have more memory than the other, the larger amount should be assigned to channel A.
- In any mode, the maximum operational speed is determined by the slowest SODIMM in the system.

Installing SODIMMs

⚠ CAUTION: You must disconnect the power cord and wait approximately 30 seconds for the power to drain before adding or removing memory modules. Regardless of the power-on state, voltage is always supplied to the memory modules as long as the computer is plugged into an active AC outlet. Adding or removing memory modules while voltage is present may cause irreparable damage to the memory modules or system board.

The memory module sockets have gold-plated metal contacts. When upgrading the memory, it is important to use memory modules with gold-plated metal contacts to prevent corrosion and/or oxidation resulting from having incompatible metals in contact with each other.

Static electricity can damage the electronic components of the computer or optional cards. Before beginning these procedures, ensure that you are discharged of static electricity by briefly touching a grounded metal object. For more information, refer to [Electrostatic Discharge Information on page 60](#).


When handling a memory module, be careful not to touch any of the contacts. Doing so may damage the module.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 206](#)).
2. Remove the computer access panel ([Access Panel on page 207](#)).
3. Locate the memory module sockets on the system board.

⚠ WARNING! To reduce risk of personal injury from hot surfaces, allow the internal system components to cool before touching.


4. To remove a SODIMM, press outward on the two latches on each side of the SODIMM **(1)** then pull the SODIMM out of the socket **(2)**.


Figure 9-6 Removing a SODIMM



5. Slide the new SODIMM into the socket at approximately a 30° angle (1) then press the SODIMM down (2) so that the latches lock it in place.

Figure 9-7 Installing a SODIMM



 **NOTE:** A memory module can be installed in only one way. Match the notch on the module with the tab on the memory socket.

6. Replace the access panel.
7. If the computer was on a stand, replace the stand.
8. Reconnect the power cord and turn on the computer.
9. Lock any security devices that were disengaged when the computer cover or access panel was removed.

The computer automatically recognizes the additional memory when you turn on the computer.

Front Fan

Description	Spare part number
Front fan	646813-001

The front fan sits against the front on the left side of the chassis.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 206](#)).
2. Remove the computer access panel ([Access Panel on page 207](#)).
3. Disconnect the fan control cable from the red system board connector labeled CHFAN.
4. Lift the fan straight up and out of the chassis.

Figure 9-8 Removing the front fan



To install the front fan, reverse the removal procedure.

Optical Drive

The Ultra-Slim Desktop uses a slimline Serial ATA (SATA) optical drive.

Description	Spare part number
DVD-ROM drive	608394-001
DVD±RW and CD-RW Super Multi Double-Layer Combo Drive with LightScribe (includes drive bracket)	595115-001
Blu-ray BD-RW SuperMulti DL Drive with LightScribe	646810-001


Removing the Optical Drive

CAUTION: All removable media should be taken out of a drive before removing the drive from the computer.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 206](#)).
2. Remove the computer access panel ([Access Panel on page 207](#)).
3. Remove the front bezel ([Front Bezel on page 208](#)).
4. Disconnect the cables on the rear of the optical drive (1), push the green release latch on the right rear side of the drive toward the center of the drive (2), then slide the drive forward and out of the bay through the front bezel (3).

CAUTION: When removing the cables, pull the tab or connector instead of the cable itself to avoid damaging the cable.

Figure 9-9 Removing the optical drive




Preparing the New Optical Drive


Before the new optical drive can be used, the release latch must be attached.

1. Peel the backing off the adhesive on the release latch.
2. Without allowing the release latch to touch the optical drive, carefully align the holes on the release latch with the pins on the side of the optical drive. Make sure the release latch is oriented properly.
3. Insert the pin at the front of the optical drive into the hole at the end of the release latch, and press firmly.
4. Insert the second pin, and press the entire release latch firmly to fasten the latch securely to the optical drive.

Figure 9-10 Aligning the release latch




Installing the New Optical Drive

 **NOTE:** If you are installing an optical drive in a bay that did not previously have a drive in it, you must remove the access panel and the bezel blank covering the opening of the bay before proceeding. Follow the procedures in [Access Panel on page 207](#) and [Bezel Blank on page 209](#).

1. Follow the instructions for removing the optical drive. Refer to [Removing the Optical Drive on page 216](#).
2. Attach the release latch to the new optical drive. Refer to [Preparing the New Optical Drive on page 217](#).
3. With the back of the optical drive facing the computer and the release latch on the inner side of the drive, align the drive with the opening in the front bezel.
4. Slide the optical drive through the front bezel all the way into the bay so that it locks in place **(1)**, then connect the cable to the rear of the drive **(2)**.


Figure 9-11 Installing the optical drive



5. Replace the front bezel and access panel.
6. If the computer was on a stand, replace the stand.
7. Reconnect the power cord and turn on the computer.
8. Lock any security devices that were disengaged when the computer cover or access panel was removed.

Hard Drive

Description	Spare part number
320 GB, 7200 RPM hard drive, Self-Encrypting Drive (SED)	634824-001
320 GB, 7200 RPM hard drive	639135-001
250 GB, 7200 RPM hard drive	608746-001
160 GB, 7200 RPM hard drive	608745-001
160 GB Solid State Drive (SSD)	646809-001
80 GB Solid State Drive (SSD)	607817-001


 **NOTE:** The Ultra-Slim Desktop supports only 2.5-inch Serial ATA (SATA) internal hard drives.

Before you remove the old hard drive, be sure to back up the data from the old hard drive so that you can transfer the data to the new hard drive.

The 2.5-inch hard drive is enclosed in a carrier under the optical drive.


1. Prepare the computer for disassembly ([Preparation for Disassembly on page 206](#)).
2. Remove the computer access panel ([Access Panel on page 207](#)).
3. Remove the optical drive ([Removing the Optical Drive on page 216](#)).
4. Press in the release latch on the left side of the hard drive carrier (**1**) then rotate the carrier handle to the right (**2**).

Figure 9-12 Unlocking the hard drive carrier



5. Lift the hard drive carrier straight up and out of the chassis.

Figure 9-13 Removing the hard drive carrier




6. Remove the four guide screws from the sides of the hard drive carrier.

Figure 9-14 Removing the guide screws



7. Lift the hard drive up to the top of the carrier (1) and slide the drive out of the carrier (2).


Figure 9-15 Removing the hard drive from the carrier



8. Position the hard drive so that the top of the hard drive is up against the top of the carrier (1) so that the circuit board on the bottom of the hard drive does not come in contact with the tabs on the bottom of the carrier, then slide the new hard drive into the carrier (2).


CAUTION: Do not allow the circuit board on the bottom of the hard drive to scrape along the tabs on the bottom of the carrier when sliding the hard drive into the carrier. Doing so can cause irreparable damage to the hard drive.

Figure 9-16 Sliding the hard drive into the carrier




9. Set the hard drive down into the bottom of the carrier (1), then replace the four guide screws on the sides of the carrier to secure the drive in the carrier (2).

Figure 9-17 Lowering the hard drive and replacing the guide screws




10. To place the hard drive carrier back in the chassis, align the guide screws with the slots on the drive bay, drop the carrier straight down into the drive bay (1), and press the handle on the carrier all the way down (2) so that the drive is properly seated and locked in place.

Figure 9-18 Installing the hard drive carrier



11. Replace the optical drive and reconnect the cable on the back of the optical drive.
12. Replace the computer access panel.
13. If the computer was on a stand, replace the stand.
14. Reconnect the power cord and turn on the computer.
15. Lock any security devices that were disengaged when the computer cover or access panel was removed.

 **NOTE:** No configuration of the SATA hard drive is necessary; the computer automatically recognizes it the next time you turn on the computer.


Optical Drive Rail

Description	Spare part number
Optical drive rail and cable kit	594219-001

The optical drive rail sits behind the USB ports on the front of the chassis.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 206](#)).
2. Remove the computer access panel ([Access Panel on page 207](#)).
3. Remove the optical drive ([Removing the Optical Drive on page 216](#)).
4. Remove the hard drive ([Hard Drive on page 219](#)).
5. Remove the two Torx screws that secure the rail to the chassis **(1)**, lift the tab **(2)** on the rail, slide the rail toward the rear of the unit **(3)**, and then pull the rail up and out of the chassis.

Figure 9-19 Removing the optical drive rail



To install the optical drive rail, reverse the removal procedures.

Card Reader

Description	Spare part number
Card reader	593235-001

The card reader is secured to the front right corner of the chassis.


1. Prepare the computer for disassembly ([Preparation for Disassembly on page 206](#)).
2. Remove the computer access panel ([Access Panel on page 207](#)).
3. Remove the front bezel ([Front Bezel on page 208](#)).
4. Remove the optical drive ([Removing the Optical Drive on page 216](#)).
5. Remove the hard drive ([Hard Drive on page 219](#)).
6. Remove the optical drive rail ([Optical Drive Rail on page 223](#)).
7. Disconnect the cable from the system board connector labeled MEDIA.
8. On the outside of the chassis, remove the one Torx screw that secures the card reader to the chassis.

Figure 9-20 Removing the card reader screw



9. Pull the reader away from the front of the chassis while threading the cable through the slot in the front of the chassis.

Figure 9-21 Removing the card reader



To install the card reader, reverse the removal procedure.


Speaker

Description	Spare part number
Speaker	647447-001

The speaker is secured to the front of the chassis between the fan and the I/O ports.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 206](#)).
2. Remove the computer access panel ([Access Panel on page 207](#)).
3. Remove the front bezel ([Front Bezel on page 208](#)).
4. Disconnect the speaker cable from the white system board connector labeled SPKR.
5. On the outside of the chassis, remove the two Torx T8 screws that secure the speaker to the chassis **(1)**, and then from the inside of the chassis, slide the speaker up to remove it **(2)**.

Figure 9-22 Removing the speaker



To install the speaker, reverse the removal procedure.

Heat sink

Description	Spare part number
Heat sink	587456-001

The heat sink is secured by four Torx screws. It does not have an attached fan.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 206](#)).
2. Remove the computer access panel ([Access Panel on page 207](#)).
3. Lift the front fan up and place it on top of the optical drive to access the front bezel release tabs. You do not need to disconnect the fan cable from the system board.
4. Loosen the four Torx screws that secure the heat sink to the system board, and then lift the heat sink from the system board.


Figure 9-23 Loosening the heat sink screws



CAUTION: Heat sink retaining screws should be removed in diagonally opposite pairs (as in an X) to even the downward forces on the processor to avoid damage that could require replacing the system board.

5. Lift the heat sink from the system board.

Figure 9-24 Removing the heat sink



CAUTION: Heat sink retaining screws should be removed in diagonally opposite pairs (as in an X) to even the downward forces on the processor to avoid damage that could require replacing the system board.

6. Lay the heat sink on its top in a safe area to prevent the thermal grease from contaminating the work surface.

If reusing the existing heat sink go to step 1.

If using a new heat sink, go to step 3.

1. If reusing the existing heat sink, clean bottom of the heat sink and apply the thermal grease provided in the spares kit to the top of the processor.
2. Position the heat sink atop the processor.
3. If using a new heat sink, remove the protective covering from the bottom of the heat sink and place it in position atop the processor.
4. Secure the heat sink to the system board and system board tray with the 4 captive screws.

CAUTION: Heat sink retaining screws should be tightened in diagonally opposite pairs (as in an X) to evenly seat the heat sink on the processor. This is especially important as the pins on the socket are very fragile and any damage to them may require replacing the system board.

Processor

Description	Spare part number
Intel Core i7 processors	
2600S, 2.8 GHz, 8-MB L3 cache, 95W	638419-001
Intel Core i5 processors	
2500S, 2.7 GHz, 6-MB L3 cache, 95W	638420-001
2400S, 2.7 GHz, 6-MB L3 cache, 95W	640953-001
Intel Core i3 processors	
2120, 3.3 GHz, 3-MB L3 cache, 65W	638629-001
2100, 3.1 GHz, 3-MB L3 cache, 65W	638628-001


1. Prepare the computer for disassembly ([Preparation for Disassembly on page 206](#)).
2. Remove the computer access panel ([Access Panel on page 207](#)).
3. Remove the heat sink ([Heat sink on page 227](#)).
4. Rotate the processor locking lever to its full open position **(1)**.
5. Raise and rotate the microprocessor retainer to its fully open position **(2)**.

6. Carefully lift the processor from the socket (3).

⚠ CAUTION: Do NOT handle the pins in the processor socket. These pins are very fragile and handling them could cause irreparable damage. Once pins are damaged it may be necessary to replace the system board.

The heat sink must be installed within 24 hours of installing the processor to prevent damage to the processor's solder connections.

Figure 9-25 Removing the processor




To install a new processor:

1. Place the processor in its socket and close the retainer.

2. Secure the locking lever.

Figure 9-26 Replacing the processor



If reusing the existing heat sink, go to step 3.

If using a new heat sink, go to step 5.

3. If reusing the existing heat sink, clean bottom of the heat sink and apply the thermal grease provided in the spares kit to the top of the processor.
4. Position the heat sink atop the processor.
5. If using a new heat sink, remove the protective covering from the bottom of the heat sink and place it in position atop the processor.
6. Secure the heat sink to the system board and system board tray with the 4 captive screws.

CAUTION: Heat sink retaining screws should be tightened in diagonally opposite pairs (as in an X) to evenly seat the heat sink on the processor. This is especially important as the pins on the socket are very fragile and any damage to them may require replacing the system board.

NOTE: After installing a new processor onto the system board, always update the system ROM to ensure that the latest version of the BIOS is being used on the computer. The latest system BIOS can be found on the Web at: <http://h18000.www1.hp.com/support/files>.


TV Tuner or WLAN Module

The procedure to remove and replace the TV tuner module and the WLAN module are similar. The image in this section illustrates a TV tuner module. Use the same basic procedure to remove a WLAN module.

Description	Spare part number
HP TV Tuner Kit (includes hardware)	613990-001
802.11a/b/g/n WLAN module	631954-001

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 206](#)).
2. Remove the computer access panel ([Access Panel on page 207](#)).
3. Remove the optical drive ([Removing the Optical Drive on page 216](#)).
4. Remove the hard drive ([Hard Drive on page 219](#)).
5. Remove the optical drive rail ([Optical Drive Rail on page 223](#)).
6. Remove the heat sink ([Heat sink on page 227](#)).
7. Disconnect the antenna cable from the connector on the module (**1**).
8. Remove the two screws (**2**) that secure the module to the system board.

Figure 9-27 Removing the TV tuner module



9. Lift the module to a 45 degree angle, and then remove the module from the connector by pulling it away at an angle.


To install the TV tuner module or WLAN module, reverse the removal procedure. Make sure the antenna cable is correctly routed.

Hood Sensor

Description	Spare part number
Hood sensor	638816-001

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 206](#)).
2. Remove the computer access panel ([Access Panel on page 207](#)).
3. Remove the optical drive ([Removing the Optical Drive on page 216](#)).
4. Unplug the hood sensor cable from the white system board connector labeled HSENSE **(1)** and remove the cable from the white clip mounted on the inside chassis wall.
5. Slide the hood sensor into the chassis to remove it from its slot **(2)**. Disengaging the hood sensor from the chassis may require use of a screwdriver or similar tool.

Figure 9-28 Removing the hood sensor



To install the hood sensor, reverse the removal procedures.

System Board

Description	Spare part number
System board, includes Trusted Platform Module (TPM)	611836-001
System board, does not include Trusted Platform Module (TPM)	649743-001
Front I/O panel	587458-001

CAUTION: Be very careful when removing or replacing the system board to prevent damaging it.

1. Prepare the computer for disassembly ([Preparation for Disassembly on page 206](#)).
2. Remove the computer access panel ([Access Panel on page 207](#)).
3. Remove the memory modules ([Memory on page 211](#)).
4. Remove the front fan ([Front Fan on page 215](#)).
5. Remove the optical drive ([Removing the Optical Drive on page 216](#)).
6. Remove the hard drive ([Hard Drive on page 219](#)).
7. Remove the optical drive rail ([Optical Drive Rail on page 223](#)).
8. Remove the heat sink ([Heat sink on page 227](#)).
9. Disconnect the rear fan cable from the system board.
10. Disconnect any remaining cables connected to the system board, noting their location for reinstallation.
11. Remove the front I/O panel:
 - a. Remove the screw from the right side of the panel that secures it to the front of the chassis.

Figure 9-29 I/O panel screw




- b. Press the tab on right side of the panel (1), and then swing the right side of the cage away from the chassis to remove it (2).

Figure 9-30 Removing the I/O panel



- 12. Remove the three remaining screws (1) that secure the system board to the chassis.
- 13. Slide system board toward the front of the unit until the rear connectors are clear of their slots in the chassis (2).
- 14. Lift the rear of the system board until it clears the chassis, and then remove the system board from the chassis (3).

Figure 9-31 Removing the system board



To install the system board, reverse the removal procedure.

NOTE: When replacing the system board, you must also change the chassis serial number in the BIOS.

Rear Fan

Description	Spare part number
Rear fan	605155-001

The rear fan is secured to the rear right corner of the chassis. You must remove the system board before you can remove the rear fan.


1. Prepare the computer for disassembly ([Preparation for Disassembly on page 206](#)).
2. Remove the computer access panel ([Access Panel on page 207](#)).
3. Remove the optical drive ([Removing the Optical Drive on page 216](#)).
4. Remove the front fan ([Front Fan on page 215](#)).
5. Remove the hard drive ([Hard Drive on page 219](#)).
6. Remove the optical drive rail ([Optical Drive Rail on page 223](#)).
7. Remove the heat sink ([Heat sink on page 227](#)).
8. Remove the system board ([System Board on page 234](#)).
9. From the outside of the chassis, remove the four Phillips screws that secure the fan to the chassis.

Figure 9-32 Removing the rear fan screws



10. From the inside of the chassis, slide the fan out from underneath the chassis lip, and then remove the fan.

Figure 9-33 Removing the rear fan



To install the rear fan, reverse the removal procedure.

Changing from Desktop to Tower Configuration


1. Prepare the computer for disassembly ([Preparation for Disassembly on page 206](#)).
2. Orient the computer so that its left side is facing down and place the computer firmly down into the stand.

Figure 9-34 Placing the computer on the stand



3. Reconnect the external equipment, plug the power cord into a power outlet, and turn the computer on.
4. Lock any security devices that were disengaged when the computer cover or access panel was removed.

To change from the tower configuration to the desktop configuration, reverse the previous steps.

 **NOTE:** An optional Quick Release mounting bracket is available from HP for mounting the computer to a wall, desk, or swing arm.

Port Cover

Description	Spare part number
Port cover	646818-001


An optional rear port cover is available for the computer.

To install the port cover:

1. Thread the cables through the bottom hole on the port cover **(1)** and connect the cables to the rear ports on the computer.
2. Insert the hooks on the port cover into the slots on the rear of the chassis, then slide the cover to the right to secure it in place **(2)**.


Figure 9-35 Installing a port cover



 **NOTE:** For security purposes, you can install an optional cable lock to the chassis that locks the port cover and secures the computer.

The port cover is secured in place by a retention lever just inside the port cover opening. To remove the port cover, pull the lever back towards the port cover opening **(1)**, then slide the cover to the left and off the computer **(2)**.

Figure 9-36 Removing a port cover




Power Supply, External

The USDT chassis uses an external power supply.

⚠ WARNING! To reduce potential safety issues, only the power supply provided with the computer, a replacement power supply provided by HP, or a power supply purchased as an accessory from HP should be used with the computer.

A Battery Replacement

The battery that comes with the computer provides power to the real-time clock. When replacing the battery, use a battery equivalent to the battery originally installed in the computer. The computer comes with a 3-volt lithium coin cell battery.


 **WARNING!** The computer contains an internal lithium manganese dioxide battery. There is a risk of fire and burns if the battery is not handled properly. To reduce the risk of personal injury:

Do not attempt to recharge the battery.


Do not expose to temperatures higher than 60°C (140°F).

Do not disassemble, crush, puncture, short external contacts, or dispose of in fire or water.

Replace the battery only with the HP spare designated for this product.


 **CAUTION:** Before replacing the battery, it is important to back up the computer CMOS settings. When the battery is removed or replaced, the CMOS settings will be cleared.

Static electricity can damage the electronic components of the computer or optional equipment. Before beginning these procedures, ensure that you are discharged of static electricity by briefly touching a grounded metal object.


 **NOTE:** The lifetime of the lithium battery can be extended by plugging the computer into a live AC wall socket. The lithium battery is only used when the computer is NOT connected to AC power.

HP encourages customers to recycle used electronic hardware, HP original print cartridges, and rechargeable batteries. For more information about recycling programs, go to <http://www.hp.com/recycle>.

1. Remove/disengage any security devices that prohibit opening the computer.
2. Remove all removable media, such as compact discs or USB flash drives, from the computer.
3. Turn off the computer properly through the operating system, then turn off any external devices.
4. Disconnect the power cord from the power outlet and disconnect any external devices.

 **CAUTION:** Regardless of the power-on state, voltage is always present on the system board as long as the system is plugged into an active AC outlet. You must disconnect the power cord to avoid damage to the internal components of the computer.

5. Remove the computer access panel.
6. Locate the battery and battery holder on the system board.


 **NOTE:** On some computer models, it may be necessary to remove an internal component to gain access to the battery.

7. Depending on the type of battery holder on the system board, complete the following instructions to replace the battery.

Type 1

- a. Lift the battery out of its holder.

Figure A-1 Removing a Coin Cell Battery (Type 1)




- b. Slide the replacement battery into position, positive side up. The battery holder automatically secures the battery in the proper position.

Type 2

- a. To release the battery from its holder, squeeze the metal clamp that extends above one edge of the battery. When the battery pops up, lift it out (1).
- b. To insert the new battery, slide one edge of the replacement battery under the holder's lip with the positive side up. Push the other edge down until the clamp snaps over the other edge of the battery (2).

Figure A-2 Removing and Replacing a Coin Cell Battery (Type 2)





Type 3

- a. Pull back on the clip (1) that is holding the battery in place, and remove the battery (2).

- b. Insert the new battery and position the clip back into place.

Figure A-3 Removing a Coin Cell Battery (Type 3)



 **NOTE:** After the battery has been replaced, use the following steps to complete this procedure.

8. Replace the computer access panel.
9. Plug in the computer and turn on power to the computer.
10. Reset the date and time, your passwords, and any special system setups using Computer Setup.
11. Lock any security devices that were disengaged when the computer access panel was removed.

B Power Cord Set Requirements

The power supplies on some computers have external power switches. The voltage select switch feature on the computer permits it to operate from any line voltage between 100-120 or 220-240 volts AC. Power supplies on those computers that do not have external power switches are equipped with internal switches that sense the incoming voltage and automatically switch to the proper voltage.

The power cord set received with the computer meets the requirements for use in the country where you purchased the equipment.


Power cord sets for use in other countries must meet the requirements of the country where you use the computer.

General Requirements

The requirements listed below are applicable to all countries:


1. The power cord must be approved by an acceptable accredited agency responsible for evaluation in the country where the power cord set will be installed.
2. The power cord set must have a minimum current capacity of 10A (7A Japan only) and a nominal voltage rating of 125 or 250 volts AC, as required by each country's power system.
3. The diameter of the wire must be a minimum of 0.75 mm₂ or 18AWG, and the length of the cord must be between 1.8 m (6 feet) and 3.6 m (12 feet).

The power cord should be routed so that it is not likely to be walked on or pinched by items placed upon it or against it. Particular attention should be paid to the plug, electrical outlet, and the point where the cord exits from the product.

 **WARNING!** Do not operate this product with a damaged power cord set. If the power cord set is damaged in any manner, replace it immediately.

Japanese Power Cord Requirements

For use in Japan, use only the power cord received with this product.

 **CAUTION:** Do not use the power cord received with this product on any other products.

Country-Specific Requirements

Additional requirements specific to a country are shown in parentheses and explained below.

Country	Accrediting Agency	Country	Accrediting Agency
Australia (1)	EANSW	Italy (1)	IMQ
Austria (1)	OVE	Japan (3)	METI
Belgium (1)	CEBC	Norway (1)	NEMKO
Canada (2)	CSA	Sweden (1)	SEMKO
Denmark (1)	DEMKO	Switzerland (1)	SEV
Finland (1)	SETI	United Kingdom (1)	BSI
France (1)	UTE	United States (2)	UL
Germany (1)	VDE		

1. The flexible cord must be Type HO5VV-F, 3-conductor, 0.75mm² conductor size. Power cord set fittings (appliance coupler and wall plug) must bear the certification mark of the agency responsible for evaluation in the country where it will be used.
2. The flexible cord must be Type SVT or equivalent, No. 18 AWG, 3-conductor. The wall plug must be a two-pole grounding type with a NEMA 5-15P (15A, 125V) or NEMA 6-15P (15A, 250V) configuration.
3. Appliance coupler, flexible cord, and wall plug must bear a "T" mark and registration number in accordance with the Japanese Dentori Law. Flexible cord must be Type VCT or VCTF, 3-conductor, 0.75 mm² conductor size. Wall plug must be a two-pole grounding type with a Japanese Industrial Standard C8303 (7A, 125V) configuration.

C POST Error Messages

This appendix lists the error codes, error messages, and the various indicator light and audible sequences that you may encounter during Power-On Self-Test (POST) or computer restart, the probable source of the problem, and steps you can take to resolve the error condition.

POST Message Disabled suppresses most system messages during POST, such as memory count and non-error text messages. If a POST error occurs, the screen will display the error message. To manually switch to the POST Messages Enabled mode during POST, press any key (except [F10](#), [F11](#), or [F12](#)). The default mode is POST Message Disabled.

The speed at which the computer loads the operating system and the extent to which it is tested are determined by the POST mode selection.

Quick Boot is a fast startup process that does not run all of the system level tests, such as the memory test. Full Boot runs all of the ROM-based system tests and takes longer to complete.

Full Boot may also be enabled to run every 1 to 30 days on a regularly scheduled basis. To establish the schedule, reconfigure the computer to the Full Boot Every x Days mode, using Computer Setup.



NOTE: For more information on Computer Setup, see [Computer Setup \(F10\) Utility on page 4](#).

POST Numeric Codes and Text Messages

This section covers those POST errors that have numeric codes associated with them. The section also includes some text messages that may be encountered during POST.



NOTE: The computer will beep once after a POST text message is displayed on the screen.

Table C-1 Numeric Codes and Text Messages

Control panel message	Description	Recommended action
101-Option ROM Checksum Error	System ROM or expansion board option ROM checksum.	<ol style="list-style-type: none">1. Verify the correct ROM.2. Flash the ROM if needed.3. If an expansion board was recently added, remove it to see if the problem remains.4. Clear CMOS. (See Appendix B, Password Security and Resetting CMOS on page 302.)5. If the message disappears, there may be a problem with the expansion card.6. Replace the system board.
103-System Board Failure	DMA or timers.	<ol style="list-style-type: none">1. Clear CMOS. (See Appendix B, Password Security and Resetting CMOS on page 302.)2. Remove expansion boards.3. Replace the system board.
110-Out of Memory Space for Option ROMs	Recently added PCI expansion card contains an option ROM too large to download during POST.	<ol style="list-style-type: none">1. If a PCI expansion card was recently added, remove it to see if the problem remains.2. In Computer Setup, set Advanced > Device Options > NIC PXE Option ROM Download to DISABLE to prevent PXE option ROM for the internal NIC from being downloaded during POST to free more memory for an expansion card's option ROM. Internal PXE option ROM is used for booting from the NIC to a PXE server.
162-System Options Not Set	Configuration incorrect. RTC (real-time clock) battery may need to be replaced.	Run Computer Setup and check the configuration in Advanced > Onboard Devices . Reset the date and time under Control Panel . If the problem persists, replace the RTC battery. See the Removal and Replacement section for instructions on installing a new battery, or contact an authorized dealer or reseller for RTC battery replacement.

Table C-1 Numeric Codes and Text Messages (continued)

Control panel message	Description	Recommended action
163-Time & Date Not Set	Invalid time or date in configuration memory. RTC (real-time clock) battery may need to be replaced.	Reset the date and time under Control Panel (Computer Setup can also be used). If the problem persists, replace the RTC battery. See the Removal and Replacement section for instructions on installing a new battery, or contact an authorized dealer or reseller for RTC battery replacement.
163-Time & Date Not Set	CMOS jumper may not be properly installed.	Check for proper placement of the CMOS jumper if applicable.
164-MemorySize Error	Memory amount has changed since the last boot (memory added or removed).	Press the F1 key to save the memory changes.
164-MemorySize Error	Memory configuration incorrect.	<ol style="list-style-type: none"> 1. Run Computer Setup or Windows utilities. 2. Make sure the memory module(s) are installed properly. 3. If third-party memory has been added, test using HP-only memory. 4. Verify proper memory module type.
201-Memory Error	RAM failure.	<ol style="list-style-type: none"> 1. Ensure memory modules are correctly installed. 2. Verify proper memory module type. 3. Remove and replace the identified faulty memory module(s). 4. If the error persists after replacing memory modules, replace the system board.
213-Incompatible Memory Module in Memory Socket(s) X, X, ...	A memory module in memory socket identified in the error message is missing critical SPD information, or is incompatible with the chipset.	<ol style="list-style-type: none"> 1. Verify proper memory module type. 2. Try another memory socket. 3. Replace DIMM with a module conforming to the SPD standard.
214-DIMM Configuration Warning	Populated DIMM Configuration is not optimized.	Rearrange the DIMMs so that each channel has the same amount of memory.
219-ECC Memory Module Detected ECC Modules not supported on this Platform	Recently added memory module(s) support ECC memory error correction.	<ol style="list-style-type: none"> 1. If additional memory was recently added, remove it to see if the problem remains. 2. Check product documentation for memory support information.
301-Keyboard Error	Keyboard failure.	<ol style="list-style-type: none"> 1. Reconnect keyboard with computer turned off. 2. Check connector for bent or missing pins. 3. Ensure that none of the keys are depressed. 4. Replace keyboard.

Table C-1 Numeric Codes and Text Messages (continued)

Control panel message	Description	Recommended action
303-Keyboard Controller Error	I/O board keyboard controller.	<ol style="list-style-type: none"> 1. Reconnect keyboard with computer turned off. 2. Replace the system board.
304-Keyboard or System Unit Error	Keyboard failure.	<ol style="list-style-type: none"> 1. Reconnect the keyboard with computer turned off. 2. Ensure that none of the keys are depressed. 3. Replace the keyboard. 4. Replace the system board.
501-Display Adapter Failure	Graphics display controller.	<ol style="list-style-type: none"> 1. Reseat the graphics card (if applicable). 2. Clear CMOS. (See Appendix B, Password Security and Resetting CMOS on page 302.) 3. Verify monitor is attached and turned on. 4. Replace the graphics card (if possible).
510-Flash Screen Image Corrupted	Flash Screen image has errors.	Reflash the system ROM with the latest BIOS image.
511-CPU, CPUA, or CPUB Fan not Detected	CPU fan is not connected or may have malfunctioned.	<ol style="list-style-type: none"> 1. Reseat CPU fan. 2. Reseat fan cable. 3. Replace CPU fan.
512-Chassis, Rear Chassis, or Front Chassis Fan not Detected	Chassis, rear chassis, or front chassis fan is not connected or may have malfunctioned.	<ol style="list-style-type: none"> 1. Reseat chassis, rear chassis, or front chassis fan. 2. Reseat fan cable. 3. Replace chassis, rear chassis, or front chassis fan.
513-Front Chassis fan not detected	Front chassis fan is not connected or may have malfunctioned.	<ol style="list-style-type: none"> 1. Reseat front chassis fan. 2. Reseat fan cable. 3. Replace front chassis fan.
514-CPU or Chassis Fan not Detected	CPU or chassis fan is not connected or may have malfunctioned.	<ol style="list-style-type: none"> 1. Reseat CPU or chassis fan. 2. Reseat fan cable. 3. Replace CPU or chassis fan.
515-Power Supply fan not detected	Power supply fan is not connected or may have malfunctioned.	<ol style="list-style-type: none"> 1. Reseat power supply fan. 2. Reseat fan cable. 3. Replace power supply fan.

Table C-1 Numeric Codes and Text Messages (continued)

Control panel message	Description	Recommended action
601-Diskette Controller Error	Diskette controller circuitry or floppy drive circuitry incorrect.	<ol style="list-style-type: none"> 1. Check and/or replace cables. 2. Clear CMOS. (See Appendix B, Password Security and Resetting CMOS on page 302.) 3. Replace diskette drive. 4. Replace the system board.
605-Diskette Drive Type Error	Mismatch in drive type.	<ol style="list-style-type: none"> 1. Disconnect any other diskette controller devices (tape drives). 2. Clear CMOS. (See Appendix B, Password Security and Resetting CMOS on page 302.)
660-Display cache is detected unreliable	Integrated graphics controller display cache is not working properly and will be disabled.	Replace system board if minimal graphics degrading is an issue.
912-Computer Cover Has Been Removed Since Last System Startup	Computer cover was removed since last system startup.	No action required.
917-Front Audio Not Connected	Front audio harness has been detached or unseated from motherboard.	Reconnect or replace front audio harness.
918-Front USB Not Connected	Front USB harness has been detached or unseated from motherboard.	Reconnect or replace front USB harness.
921-Device in PCI Express slot failed to initialize	There is an incompatibility/problem with this device and the system or PCI Express Link could not be retrained to an x1.	Try rebooting the system. If the error reoccurs, the device may not work with this system
1151-Serial Port A Address Conflict Detected	Both external and internal serial ports are assigned to COM1.	<ol style="list-style-type: none"> 1. Remove any serial port expansion cards. 2. Clear CMOS. (See Appendix B, Password Security and Resetting CMOS on page 302.) 3. Reconfigure card resources and/or run Computer Setup or Windows utilities.
1152-Serial Port B Address Conflict Detected	Both external and internal serial ports are assigned to COM2.	<ol style="list-style-type: none"> 1. Remove any serial port expansion cards. 2. Clear CMOS. (See Appendix B, Password Security and Resetting CMOS on page 302.) 3. Reconfigure card resources and/or run Computer Setup or Windows utilities.
1155-Serial Port Address Conflict Detected	Both external and internal serial ports are assigned to same IRQ.	<ol style="list-style-type: none"> 1. Remove any serial port expansion cards. 2. Clear CMOS. (See Appendix B, Password Security and Resetting CMOS on page 302.) 3. Reconfigure card resources and/or run Computer Setup or Windows utilities.

Table C-1 Numeric Codes and Text Messages (continued)

Control panel message	Description	Recommended action
1720-SMART Hard Drive Detects Imminent Failure	Hard drive is about to fail. (Some hard drives have a hard drive firmware patch that will fix an erroneous error message.)	<ol style="list-style-type: none"> 1. Determine if hard drive is giving correct error message. Enter Computer Setup and run the Drive Protection System test under Storage > DPS Self-test. 2. Apply hard drive firmware patch if applicable. (Available at http://www.hp.com/support.) 3. Back up contents and replace hard drive.
1796-SATA Cabling Error	One or more SATA devices are improperly attached. For optimal performance, the SATA 0 and SATA 1 connectors must be used before SATA 2 and SATA 3.	Ensure SATA connectors are used in ascending order. For one device, use SATA 0. For two devices, use SATA 0 and SATA 1. For three devices, use SATA 0, SATA 1, and SATA 2.
1797-SATA Drivelock is not supported in RAID mode.	Drivelock is enabled on one or more SATA hard drives, and they cannot be accessed while the system is configured for RAID mode.	Either remove the Drivelocked SATA device or disable the Drivelock feature. To disable the Drivelock feature, enter Computer Setup, change Storage > Storage Options > SATA Emulation to IDE , and select File > Save Changes and Exit . Reenter Computer Setup and select Security > Drivelock Security . For each listed Drivelock-capable SATA device, ensure Drivelock is Disabled . Lastly, change Storage > Storage Options > SATA Emulation back to RAID and select File > Save Changes and Exit .
1801-Microcode Patch Error	Processor is not supported by ROM BIOS.	<ol style="list-style-type: none"> 1. Upgrade BIOS to proper version. 2. Change the processor.
2200-PMM Allocation Error during MEBx Download	Memory error during POST execution of the Management Engine (ME) BIOS Extensions option ROM.	<ol style="list-style-type: none"> 1. Reboot the computer. 2. Unplug the power cord, re-seat the memory modules, and reboot the computer. 3. If the memory configuration was recently changed, unplug the computer, restore the original memory configuration, and reboot the computer. 4. If the error persists, replace the system board.

Table C-1 Numeric Codes and Text Messages (continued)

Control panel message	Description	Recommended action
2201-MEBx Module did not checksum correctly	Memory error during POST execution of the Management Engine (ME) BIOS Extensions option ROM.	<ol style="list-style-type: none">1. Reboot the computer.2. Unplug the power cord, re-seat the memory modules, and reboot the computer.3. If the memory configuration was recently changed, unplug the power cord, restore the original memory configuration, and reboot the computer.4. If the error persists, replace the system board.
2202-PMM Deallocation Error during MEBx cleanup	Memory error during POST execution of the Management Engine (ME) BIOS Extensions option ROM.	<ol style="list-style-type: none">1. Reboot the computer.2. Unplug the power cord, re-seat the memory modules, and reboot the computer.3. If the memory configuration was recently changed, unplug the power cord, restore the original memory configuration, and reboot the computer.4. If the error persists, replace the system board.
2203-Setup error during MEBx execution	MEBx selection or exit resulted in a setup failure.	<ol style="list-style-type: none">1. Reboot the computer.2. Unplug the power cord, re-seat the memory modules, and reboot the computer.3. If the memory configuration was recently changed, unplug the power cord, restore the original memory configuration, and reboot the computer.4. If the error persists, replace the system board.
2204-Inventory error during MEBx execution	BIOS information passed to the MEBx resulted in a failure.	<ol style="list-style-type: none">1. Reboot the computer.2. If the error persists, update to the latest BIOS version.3. If the error still persists, replace the system board.
2205-Interface error during MEBx execution	MEBx operation experienced a hardware error during communication with ME.	<ol style="list-style-type: none">1. Reboot the computer.2. If the error persists, update to the latest BIOS version.3. If the error still persists, replace the system board.

Table C-1 Numeric Codes and Text Messages (continued)

Control panel message	Description	Recommended action
2211-Memory not configured correctly for proper MEBx execution.	DIMM1 or XMM1 is not installed.	Make sure there is a memory module in the black DIMM1 socket and that it is properly seated.
2212-USB Key Provisioning failure writing to device	USB device used for USB key provisioning will not allow BIOS to update provision file properly.	<ol style="list-style-type: none">1. Try a different USB key device for provisioning.2. If the error persists, update to the latest BIOS version and ME firmware version.3. If the error still persists, replace the system board.
2217-ME Firmware Version request failure	ME firmware is not properly responding to BIOS query for version information.	<ol style="list-style-type: none">1. Reboot the computer.2. If the error persists, update to the latest BIOS version and ME firmware version.3. If the error still persists, replace the system board.
2218-ME Firmware Version should be updated	ME firmware must be updated to match current functionality contained in the system BIOS.	<ol style="list-style-type: none">1. Update to the latest ME firmware version.2. If the error persists and system BIOS has been recently updated, restore previous system BIOS version.3. If the error still persists, replace the system board.
2219-USB Key Provisioning file has invalid header identifier	Provisioning file contained on the USB key has been corrupted or is not a valid version for the current ME firmware.	<ol style="list-style-type: none">1. Recreate the provisioning file using third party management console software.2. If the error persists and system BIOS has been recently updated, restore previous system BIOS version. Otherwise, update the ME firmware version.3. If the error still persists, replace the system board.
2220-USB Key Provisioning file has mismatch version	Provisioning file contained on the USB key is not a valid version for the current ME firmware.	<ol style="list-style-type: none">1. Reboot the computer.2. If the error persists and system BIOS has been recently updated, restore previous system BIOS version. Otherwise, update the ME firmware version.3. If the error still persists, replace the system board.

Table C-1 Numeric Codes and Text Messages (continued)


Control panel message	Description	Recommended action
2230-General error during MEBx execution	Error occurred during MEBx execution which fails into the "General" grouping. Status information displayed along with the error provides further clarity into the failure. MEBx handles transference of information between the system BIOS and ME firmware.	<ol style="list-style-type: none">1. Reboot the computer.2. If the error persists, update to the latest BIOS version and ME firmware version.3. If the error still persists, replace the system board.
2231-ME error during MEBx execution	Error occurred during MEBx execution which fails into "ME" grouping.	<ol style="list-style-type: none">1. Reboot the computer.2. If the error persists, update to the latest BIOS version and ME firmware version.3. If the error still persists, replace the system board.
2232-AMT error during MEBx execution	Error occurred during MEBx execution which fails into "AMT" grouping.	<ol style="list-style-type: none">1. Reboot the computer.2. If the error persists, update to the latest BIOS version and ME firmware version.3. If the error still persists, replace the system board.
2233-HECI error during MEBx execution	Error occurred during MEBx execution which fails into "MEI or HECI" grouping.	<ol style="list-style-type: none">1. Reboot the computer.2. If the error persists, update to the latest BIOS version and ME firmware version.3. If the error still persists, replace the system board.
2239-ME image lock failure	Special system configurations with reduced ME firmware image require BIOS control of ME firmware upgrading. A failure has occurred after the ME firmware update process in which the BIOS could not relock the ME firmware region.	<ol style="list-style-type: none">1. Reboot the computer.2. If the error persists, update to the latest BIOS version and ME firmware version.3. If the error still persists, replace the system board.
2240-ME image unlock failure	Special system configurations with reduced ME firmware image require BIOS control of ME firmware upgrading. A failure has occurred prior to the ME firmware update process in which the BIOS could not unlock the ME firmware region.	<ol style="list-style-type: none">1. Reboot the computer.2. If the error persists, update to the latest BIOS version and ME firmware version.3. If the error still persists, replace the system board.
Invalid Electronic Serial Number	Electronic serial number is missing.	Enter the correct serial number in Computer Setup.


Table C-1 Numeric Codes and Text Messages (continued)

Control panel message	Description	Recommended action
Network Server Mode Active and No Keyboard Attached	Keyboard failure while Network Server Mode enabled.	<ol style="list-style-type: none">1. Reconnect keyboard with computer turned off.2. Check connector for bent or missing pins.3. Ensure that none of the keys are depressed.4. Replace keyboard.
Parity Check 2	Parity RAM failure.	Run Computer Setup and Diagnostic utilities.

Interpreting POST Diagnostic Front Panel LEDs and Audible Codes

This section covers the front panel LED codes as well as the audible codes that may occur before or during POST that do not necessarily have an error code or text message associated with them.

 **WARNING!** When the computer is plugged into an AC power source, voltage is always applied to the system board. To reduce the risk of personal injury from electrical shock and/or hot surfaces, be sure to disconnect the power cord from the wall outlet and allow the internal system components to cool before touching.

 **NOTE:** If you see flashing LEDs on a PS/2 keyboard, look for flashing LEDs on the front panel of the computer and refer to the following table to determine the front panel LED codes.

Recommended actions in the following table are listed in the order in which they should be performed.

Not all diagnostic lights and audible codes are available on all models.

Table C-2 Diagnostic Front Panel LEDs and Audible Codes

Activity	Beeps	Possible Cause	Recommended Action
Green Power LED On.	None	Computer on.	None
Green Power LED flashes every two seconds.	None	Computer in Suspend to RAM mode (some models only) or normal Suspend mode.	None required. Press any key or move the mouse to wake the computer.

Table C-2 Diagnostic Front Panel LEDs and Audible Codes (continued)

Activity	Beeps	Possible Cause	Recommended Action
Red Power LED flashes two times, once every second, followed by a two second pause. Beeps stop after fifth iteration but LEDs continue until problem is solved.	2	Processor thermal protection activated: A fan may be blocked or not turning. OR The heat sink/fan assembly is not properly attached to the processor.	<ol style="list-style-type: none"> 1. Ensure that the computer air vents are not blocked and the processor cooling fan is running. 2. Open hood, press power button, and see if the processor fan spins. If the processor fan is not spinning, make sure the fan's cable is plugged onto the system board header. 3. If fan is plugged in, but is not spinning, then replace heat sink/fan assembly. 4. Contact an authorized reseller or service provider.
Red Power LED flashes three times, once every second, followed by a two second pause. Beeps stop after fifth iteration but LEDs continue until problem is solved.	3	Processor not installed (not an indicator of bad processor).	<ol style="list-style-type: none"> 1. Check to see that the processor is present. 2. Reseat the processor.
Red Power LED flashes four times, once every second, followed by a two second pause. Beeps stop after fifth iteration but LEDs continue until problem is solved.	4	Power failure (power supply is overloaded). OR The incorrect external power supply adapter is being used on the USDT.	<ol style="list-style-type: none"> 1. Open the hood and ensure the 4 or 6-wire power supply cable is seated into the connector on the system board. 2. Check if a device is causing the problem by removing ALL attached devices (such as hard, diskette, or optical drives, and expansion cards). Power on the system. If the system enters the POST, then power off and replace one device at a time and repeat this procedure until failure occurs. Replace the device that is causing the failure. Continue adding devices one at a time to ensure all devices are functioning properly. 3. Replace the power supply. 4. Replace the system board. <p>OR</p> <p>The USDT power supply adapter must be at 135W and use the Smart ID technology before the system will power up. Replace the power supply adapter with the HP-supplied USDT power supply adapter.</p>

Table C-2 Diagnostic Front Panel LEDs and Audible Codes (continued)

Activity	Beeps	Possible Cause	Recommended Action
Red Power LED flashes five times, once every second, followed by a two second pause. Beeps stop after fifth iteration but LEDs continue until problem is solved.	5	Pre-video memory error.	<p>CAUTION: To avoid damage to the DIMMs or the system board, you must unplug the computer power cord before attempting to reseat, install, or remove a DIMM module.</p> <ol style="list-style-type: none"> 1. Reseat DIMMs. 2. Replace DIMMs one at a time to isolate the faulty module. 3. Replace third-party memory with HP memory. 4. Replace the system board.
Red Power LED flashes six times, once every second, followed by a two second pause. Beeps stop after fifth iteration but LEDs continue until problem is solved.	6	Pre-video graphics error.	<p>For systems with a graphics card:</p> <ol style="list-style-type: none"> 1. Reseat the graphics card. 2. Replace the graphics card. 3. Replace the system board. <p>For systems with integrated graphics, replace the system board.</p>
Red Power LED flashes seven times, once every second, followed by a two second pause. Beeps stop after fifth iteration but LEDs continue until problem is solved.	7	System board failure (ROM detected failure prior to video).	Replace the system board.
Red Power LED flashes eight times, once every second, followed by a two second pause. Beeps stop after fifth iteration but LEDs continue until problem is solved.	8	Invalid ROM based on bad checksum.	<ol style="list-style-type: none"> 1. Reflash the system ROM with the latest BIOS image. See the “Boot Block Emergency Recovery Mode” section of the <i>Desktop Management Guide</i> for more information. 2. Replace the system board.
Red Power LED flashes nine times, once every second, followed by a two second pause. Beeps stop after fifth iteration but LEDs continue until problem is solved.	9	System powers on but is unable to boot.	<ol style="list-style-type: none"> 1. Check that the voltage selector, located on the rear of the power supply (some models), is set to the appropriate voltage. Proper voltage setting depends on your region. 2. Unplug the AC power cord from the computer, wait 30 seconds, then plug the power cord back in to the computer. 3. Replace the system board. 4. Replace the processor.

Table C-2 Diagnostic Front Panel LEDs and Audible Codes (continued)

Activity	Beeps	Possible Cause	Recommended Action
Red Power LED flashes ten times, once every second, followed by a two second pause. Beeps stop after fifth iteration but LEDs continue until problem is solved.	10	Bad option card.	<ol style="list-style-type: none">1. Check each option card by removing the card (one at a time if multiple cards), then power on the system to see if fault goes away.2. Once a bad card is identified, remove and replace the bad option card.3. Replace the system board.
Red Power LED flashes eleven times, once every second, followed by a two second pause. Beeps stop after fifth iteration but LEDs continue until problem is solved.	11	The current processor does not support a feature previously enabled on this system.	<ol style="list-style-type: none">1. Install a TXT capable processor.2. Disable TXT in the Computer Setup (F10) utility.3. Reinstall the original processor.
System does not power on and LEDs are not flashing.	None	System unable to power on.	<p>Press and hold the power button for less than 4 seconds. If the hard drive LED turns green, the power button is working correctly. Try the following:</p> <ol style="list-style-type: none">1. Check that the voltage selector (some models), located on the rear of the power supply, is set to the appropriate voltage. Proper voltage setting depends on your region.2. Replace the system board. <p>OR</p> <p>Press and hold the power button for less than 4 seconds. If the hard drive LED does not turn on green then:</p> <ol style="list-style-type: none">1. Check that the unit is plugged into a working AC outlet.2. Open hood and check that the power button harness is properly connected to the system board.3. Check that both power supply cables are properly connected to the system board.4. Check to see if the 5V_aux light on the system board is turned on. If it is turned on, then replace the power button harness. If the problem persists, replace the system board.5. If the 5V_aux light on the system board is not turned on, remove the expansion cards one at a time until the 5V_aux light on the system board turns on. If the problem persists, replace the power supply.

D Troubleshooting Without Diagnostics

This chapter provides information on how to identify and correct minor problems, such as diskette drive, hard drive, optical drive, graphics, audio, memory, and software problems. If you encounter problems with the computer, refer to the tables in this chapter for probable causes and recommended solutions.



NOTE: For information on specific error messages that may appear on the screen during Power-On Self-Test (POST) at startup, refer to Appendix A, [POST Error Messages on page 246](#).

Safety and Comfort



WARNING! Misuse of the computer or failure to establish a safe and comfortable work environment may result in discomfort or serious injury. Refer to the *Safety & Comfort Guide* at <http://www.hp.com/ergo> for more information on choosing a workspace and creating a safe and comfortable work environment. For more information, refer to the *Safety & Regulatory Information* guide.

Before You Call for Technical Support

If you are having problems with the computer, try the appropriate solutions below to try to isolate the exact problem before calling for technical support.

- Run the HP diagnostic tool.
- Run the hard drive self-test in Computer Setup. Refer to [Computer Setup \(F10\) Utility on page 4](#) for more information.
- Check the Power LED on the front of the computer to see if it is flashing red. The flashing lights are error codes that will help you diagnose the problem. Refer to Appendix A, [POST Error Messages on page 246](#) for more information.
- If the screen is blank, plug the monitor into a different video port on the computer if one is available. Or, replace the monitor with a monitor that you know is functioning properly.
- If you are working on a network, plug another computer with a different cable into the network connection. There may be a problem with the network plug or cable.
- If you recently added new hardware, remove the hardware and see if the computer functions properly.
- If you recently installed new software, uninstall the software and see if the computer functions properly.
- Boot the computer to the Safe Mode to see if it will boot without all of the drivers loaded. When booting the operating system, use “Last Known Configuration.”


- Refer to the comprehensive online technical support at <http://www.hp.com/support>.
- Refer to [Helpful Hints on page 260](#) in this guide.


To assist you in resolving problems online, HP Instant Support Professional Edition provides you with self-solve diagnostics. If you need to contact HP support, use HP Instant Support Professional Edition's online chat feature. Access HP Instant Support Professional Edition at: <http://www.hp.com/go/ispe>.

Access the Business Support Center (BSC) at <http://www.hp.com/go/bizsupport> for the latest online support information, software and drivers, proactive notification, and worldwide community of peers and HP experts.

If it becomes necessary to call for technical assistance, be prepared to do the following to ensure that your service call is handled properly:

- Be in front of your computer when you call.
- Write down the computer serial number, product ID number, and monitor serial number before calling.
- Spend time troubleshooting the problem with the service technician.
- Remove any hardware that was recently added to your system.
- Remove any software that was recently installed.
- Restore the system from the Recovery Disc Set that you created or restore the system to its original factory condition in HP Backup and Recovery Manager.

 **CAUTION:** Restoring the system will erase all data on the hard drive. Be sure to back up all data files before running the restore process.


 **NOTE:** For sales information and warranty upgrades (Care Packs), call your local authorized service provider or dealer.

Helpful Hints

If you encounter problems with the computer, monitor, or software, see the following list of general suggestions before taking further action:

- Check that the computer and monitor are plugged into a working electrical outlet.
- Check that the voltage select switch (some models) is set to the appropriate voltage for your region (115V or 230V).
- Check that the computer is turned on and the green power light is on.
- Check that the monitor is turned on and the green monitor light is on.
- Check the Power LED on the front of the computer to see if it is flashing red. The flashing lights are error codes that will help you diagnose the problem. Refer to Appendix A, [POST Error Messages on page 246](#) for more information.
- Turn up the brightness and contrast controls of the monitor if the monitor is dim.
- Press and hold any key. If the system beeps, then the keyboard should be operating correctly.
- Check all cable connections for loose connections or incorrect connections.

- Wake the computer by pressing any key on the keyboard or pressing the power button. If the system remains in suspend mode, shut down the computer by pressing and holding the power button for at least four seconds then press the power button again to restart the computer. If the system will not shut down, unplug the power cord, wait a few seconds, then plug it in again. The computer will restart if it is set to power on automatically as soon as power is restored in Computer Setup. If it does not restart, press the power button to start the computer.
- Reconfigure the computer after installing a non-plug and play expansion board or other option. See [Solving Hardware Installation Problems on page 286](#) for instructions.
- Be sure that all the needed device drivers have been installed. For example, if you are using a printer, you need a driver for that model printer.
- Remove all bootable media (diskette, CD, or USB device) from the system before turning it on.
- If you have installed an operating system other than the factory-installed operating system, check to be sure that it is supported on the system.
- If the system has multiple video sources (embedded, PCI, or PCI-Express adapters) installed (embedded video on some models only) and a single monitor, the monitor must be plugged into the monitor connector on the source selected as the primary VGA adapter. During boot, the other monitor connectors are disabled and if the monitor is connected into these ports, the monitor will not function. You can select which source will be the default VGA source in Computer Setup.

 **CAUTION:** When the computer is plugged into an AC power source, there is always voltage applied to the system board. You must disconnect the power cord from the power source before opening the computer to prevent system board or component damage.

Solving General Problems

You may be able to easily resolve the general problems described in this section. If a problem persists and you are unable to resolve it yourself or if you feel uncomfortable about performing the operation, contact an authorized dealer or reseller.

⚠ WARNING! When the computer is plugged into an AC power source, voltage is always applied to the system board. To reduce the risk of personal injury from electrical shock and/or hot surfaces, be sure to disconnect the power cord from the wall outlet and allow the internal system components to cool before touching.

Table D-1 Solving General Problems

Computer appears locked up and will not turn off when the power button is pressed.

Cause	Solution
Software control of the power switch is not functional.	<ol style="list-style-type: none">1. Press and hold the power button for at least four seconds until the computer turns off.2. Disconnect the power cord from the electrical outlet.

Computer will not respond to USB keyboard or mouse.

Cause	Solution
Computer is in standby mode.	To resume from standby mode, press the power button or press any key. CAUTION: When attempting to resume from standby mode, do not hold down the power button for more than four seconds. Otherwise, the computer will shut down and you will lose any unsaved data.
System has locked up.	Restart computer.

Computer date and time display is incorrect.

Cause	Solution
RTC (real-time clock) battery may need to be replaced. NOTE: Connecting the computer to a live AC outlet prolongs the life of the RTC battery.	First, reset the date and time under Control Panel (Computer Setup can also be used to update the RTC date and time). If the problem persists, replace the RTC battery. See the Removal and Replacement section for instructions on installing a new battery, or contact an authorized dealer or reseller for RTC battery replacement.

Cursor will not move using the [arrow](#) keys on the keypad.

Cause	Solution
The Num Lock key may be on.	Press the Num Lock key. The Num Lock light should not be on if you want to use the arrow keys. The Num Lock key can be disabled (or enabled) in Computer Setup.

There is no sound or sound volume is too low.

Cause	Solution
System volume may be set low or muted.	<ol style="list-style-type: none">1. Check the F10 BIOS settings to make sure the internal system speaker is not muted (this setting does not affect the external speakers).2. Make sure the external speakers are properly connected and powered on and that the speakers' volume control is set correctly.3. Use the system volume control available in the operating system to make sure the speakers are not muted or to increase the volume.

Cannot remove computer cover or access panel.

Cause	Solution
Smart Cover Lock, featured on some computers, is locked.	<p>Unlock the Smart Cover Lock using Computer Setup.</p> <p>The Smart Cover FailSafe Key, a device for manually disabling the Smart Cover Lock, is available from HP. You will need the FailSafe Key in case of forgotten password, power loss, or computer malfunction. Order PN 166527-001 for the wrench-style key or PN 166527-002 for the screwdriver bit key.</p>

Poor performance is experienced.

Cause	Solution
Processor is hot.	<ol style="list-style-type: none">1. Make sure airflow to the computer is not blocked. Leave a 10.2-cm (4-inch) clearance on all vented sides of the computer and above the monitor to permit the required airflow.2. Make sure fans are connected and working properly (some fans only operate when needed).3. Make sure the processor heat sink is installed properly.
Hard drive is full.	Transfer data from the hard drive to create more space on the hard drive.
Low on memory.	Add more memory.
Hard drive fragmented.	Defragment hard drive.
Program previously accessed did not release reserved memory back to the system.	Restart the computer.
Virus resident on the hard drive.	Run virus protection program.

Table D-1 Solving General Problems (continued)**Poor performance is experienced.**

Cause	Solution
Too many applications running.	<ol style="list-style-type: none"> 1. Close unnecessary applications to free up memory. 2. Add more memory. Some applications run in the background and can be closed by right-clicking on their corresponding icons in the task tray. To prevent these applications from launching at startup, go to Start > Run (Windows XP) or Start > All Programs > Accessories > Run (Windows Vista and Windows 7) and type <code>msconfig</code>. On the Startup tab of the System Configuration Utility, clear applications that you do not want to launch automatically.
Some software applications, especially games, are stressful on the graphics subsystem	<ol style="list-style-type: none"> 1. Lower the display resolution for the current application or consult the documentation that came with the application for suggestions on how to improve performance by adjusting parameters in the application. 2. Add more memory. 3. Upgrade the graphics solution.
Cause unknown.	Restart the computer.

Computer powered off automatically and the Power LED flashes Red two times, once every second, followed by a two second pause, and the computer beeps two times. (Beeps stop after fifth iteration but LEDs continue flashing).

Cause	Solution
Processor thermal protection activated: A fan may be blocked or not turning. OR The heat sink is not properly attached to the processor.	<ol style="list-style-type: none"> 1. Ensure that the computer air vents are not blocked and the processor cooling fan is running. 2. Open hood, press power button, and see if the processor fan spins. If the processor fan is not spinning, make sure the fan's cable is plugged onto the system board header. 3. If fan is plugged in, but is not spinning, then replace the heat sink/fan assembly. 4. Contact an authorized reseller or service provider.

System does not power on and the LEDs on the front of the computer are not flashing.

Cause	Solution
System unable to power on.	<p>Press and hold the power button for less than 4 seconds. If the hard drive LED turns green, then:</p> <ol style="list-style-type: none">1. Check that the voltage selector, located on the rear of the power supply on some models, is set to the appropriate voltage. Proper voltage setting depends on your region.2. Remove the expansion cards one at a time until the 5V_aux light on the system board turns on.3. Replace the system board. <p>OR</p> <p>Press and hold the power button for less than 4 seconds. If the hard drive LED does not turn on green then:</p> <ol style="list-style-type: none">1. Check that the unit is plugged into a working AC outlet.2. Open hood and check that the power button harness is properly connected to the system board.3. Check that both power supply cables are properly connected to the system board.4. Check to see if the 5V_aux light on the system board is turned on. If it is turned on, then replace the power button harness.5. If the 5V_aux light on the system board is off, then replace the power supply.6. Replace the system board.

Solving Power Problems

Common causes and solutions for power problems are listed in the following table.

Table D-2 Solving Power Problems

Power supply shuts down intermittently.

Cause	Solution
Voltage selector switch on rear of computer chassis (some models) not switched to correct line voltage (115V or 230V).	Select the proper AC voltage using the selector switch.
Power supply will not turn on because of internal power supply fault.	Contact an authorized service provider to replace the power supply.

Computer powered off automatically and the Power LED flashes Red two times, once every second, followed by a two second pause, and the computer beeps two times. (Beeps stop after fifth iteration but LEDs continue flashing.)

Cause	Solution
Processor thermal protection activated: A fan may be blocked or not turning. OR The heat sink is not properly attached to the processor.	<ol style="list-style-type: none">1. Ensure that the computer air vents are not blocked and the processor cooling fan is running.2. Open hood, press power button, and see if the processor fan spins. If the processor fan is not spinning, make sure the fan's cable is plugged onto the system board header.3. If fan is plugged in, but is not spinning, then replace the heat sink/fan assembly.4. Contact an authorized reseller or service provider.

Power LED flashes Red four times, once every second, followed by a two second pause, and the computer beeps four times. (Beeps stop after fifth iteration but LEDs continue flashing.)

Cause	Solution
Power failure (power supply is overloaded).	<ol style="list-style-type: none">1. Check that the voltage selector, located on the rear of the power supply (some models), is set to the appropriate voltage. Proper voltage setting depends on your region.2. Open the hood and ensure the 4- or 6-wire power supply cable is seated into the connector on the system board.3. Check if a device is causing the problem by removing ALL attached devices (such as hard, diskette, or optical drives, and expansion cards). Power on the system. If the system enters the POST, then power off and replace one device at a time and repeat this procedure until failure occurs. Replace the device that is causing the failure. Continue adding devices one at a time to ensure all devices are functioning properly.4. Replace the power supply.5. Replace the system board.
The incorrect external power supply adapter is being used on the USDT.	The USDT power supply adapter must be at 135W and use the Smart ID technology before the system will power up. Replace the power supply adapter with the HP-supplied USDT power supply adapter.

Solving Diskette Problems

Common causes and solutions for diskette problems are listed in the following table.



NOTE: The computer does not support internal diskette drives. Only USB diskette drives are supported.



NOTE: You may need to reconfigure the computer when you add or remove hardware, such as an additional diskette drive. See [Solving Hardware Installation Problems on page 286](#) for instructions.

Table D-3 Solving Diskette Problems

Diskette drive light stays on.

Cause	Solution
Diskette is damaged.	In Microsoft Windows XP, right-click Start , click Explore , and select a drive. Select File > Properties > Tools . Under Error-checking click Check Now . In Microsoft Windows Vista and Windows 7, right-click Start , click Explore , and right-click on a drive. Select Properties then select the Tools tab. Under Error-checking click Check Now .
Diskette is incorrectly inserted.	Remove diskette and reinsert.
Drive cable is not properly connected.	Reconnect drive cable. Ensure that all four pins on the diskette power cable are connected to the drive.

Drive not found.

Cause	Solution
Cable is loose.	Reseat diskette drive data and power cable.
Removable drive is not seated properly.	Reseat the drive.
The device has been hidden in Computer Setup.	Run the Computer Setup utility and ensure Device Available is selected for the Legacy Diskette in Security > Device Security .

Diskette drive cannot write to a diskette.

Cause	Solution
Diskette is not formatted.	Format the diskette. <ol style="list-style-type: none">1. From Windows Explorer select the disk (A) drive.2. Right-click the drive letter and select Format.3. Select the desired options, and click Start to begin formatting the diskette.
Diskette is write-protected.	Use another diskette or remove the write protection.
Writing to the wrong drive.	Check the drive letter in the path statement.

Table D-3 Solving Diskette Problems (continued)

Diskette drive cannot write to a diskette.	
Cause	Solution
Not enough space is left on the diskette.	<ol style="list-style-type: none">1. Use another diskette.2. Delete unneeded files from diskette.
Diskette is damaged.	Replace the damaged disk.
Cannot format diskette.	
Cause	Solution
Invalid media reported.	When formatting a disk in MS-DOS, you may need to specify diskette capacity. For example, to format a 1.44-MB diskette, type the following command at the MS-DOS prompt: FORMAT A: /F:1440
Disk may be write-protected.	Open the locking device on the diskette.
Legacy diskette writes are disabled in Computer Setup.	Enter Computer Setup and enable Legacy Diskette Write in Storage > Storage Options .
A problem has occurred with a disk transaction.	
Cause	Solution
The directory structure is bad, or there is a problem with a file.	In Microsoft Windows XP, right-click Start , click Explore , and select a drive. Select File > Properties > Tools . Under Error-checking , click Check Now . In Microsoft Windows Vista or Windows 7, right-click Start , click Explore , and right-click on a drive. Select Properties then select the Tools tab. Under Error-checking click Check Now .
Diskette drive cannot read a diskette.	
Cause	Solution
You are using the wrong diskette type for the drive type.	Check the type of drive that you are using and use the correct diskette type.
You are reading the wrong drive.	Check the drive letter in the path statement.
Diskette is damaged.	Replace the diskette with a new one.

“Invalid system disk” message is displayed.

Cause	Solution
A diskette that does not contain the system files needed to start the computer has been inserted in the drive.	When drive activity stops, remove the diskette and press the Spacebar . The computer should start up.
Diskette error has occurred.	Restart the computer by pressing the power button.

Cannot Boot to Diskette.

Cause	Solution
Diskette is not bootable.	Replace with a bootable diskette.
Diskette boot has been disabled in Computer Setup.	<ol style="list-style-type: none">1. Run Computer Setup and enable USB device in Storage > Boot Order.2. Run Computer Setup and enable USB device in Storage > Storage Options > Removable Media Boot. <p>NOTE: Both steps should be used as the Removable Media Boot function in Computer Setup overrides the Boot Order enable command.</p>
Network server mode is enabled in Computer Setup.	Run Computer Setup and disable Network Server Mode in Security > Password Options .

Solving Hard Drive Problems

Table D-4 Solving Hard Drive Problems

Hard drive error occurs.	
Cause	Solution
Hard disk has bad sectors or has failed.	<ol style="list-style-type: none">1. In Microsoft Windows XP, right-click Start, click Explore, and select a drive. Select File > Properties > Tools. Under Error-checking, click Check Now. In Microsoft Windows Vista or Windows 7, right-click Start, click Explore, and right-click on a drive. Select Properties then select the Tools tab. Under Error-checking click Check Now.2. Use a utility to locate and block usage of bad sectors. If necessary, reformat the hard disk.
Disk transaction problem.	
Cause	Solution
Either the directory structure is bad or there is a problem with a file.	<p>In Microsoft Windows XP, right-click Start, click Explore, and select a drive. Select File > Properties > Tools. Under Error-checking, click Check Now.</p> <p>In Microsoft Windows Vista or Windows 7, right-click Start, click Explore, and right-click on a drive. Select Properties then select the Tools tab. Under Error-checking click Check Now.</p>
Drive not found (identified).	
Cause	Solution
Cable could be loose.	Check cable connections.
The system may not have automatically recognized a newly installed device.	<p>See reconfiguration directions in the Solving Hardware Installation Problems on page 286 section. If the system still does not recognize the new device, check to see if the device is listed within Computer Setup. If it is listed, the probable cause is a driver problem. If it is not listed, the probable cause is a hardware problem.</p> <p>If this is a newly installed drive, run the Computer Setup utility and try adding a POST delay under Advanced > Power-On.</p>
The device is attached to a SATA port that has been hidden in Computer Setup.	Run the Computer Setup utility and ensure Device Available is selected for the device's SATA port in Security > Device Security .
Drive responds slowly immediately after power-up.	Run Computer Setup and increase the POST Delay in Advanced > Power-On Options .

Nonsystem disk/NTLDR missing message.

Cause	Solution
The system is trying to start from a diskette that is not bootable.	Remove the diskette from the diskette drive.
The system is trying to start from the hard drive but the hard drive may have been damaged.	<ol style="list-style-type: none">1. Insert a bootable diskette into the diskette drive and restart the computer.2. Check the hard drive format using fdisk: If NTFS formatting, use a third party reader to evaluate the drive. If FAT32 formatting, the hard drive cannot be accessed.
System files missing or not properly installed.	<ol style="list-style-type: none">1. Insert a bootable diskette into the diskette drive and restart the computer.2. Check the hard drive format using Fdisk: If NTFS formatting, use a third party reader to evaluate the drive. If FAT32 formatting, the hard drive cannot be accessed.3. Install system files for the appropriate operating system.
Hard drive boot has been disabled in Computer Setup.	Run the Computer Setup utility and enable the hard drive entry in the Storage > Boot Order list.
Bootable hard drive is not attached as first in a multi-hard drive configuration.	If attempting to boot from a hard drive, ensure it is attached to the system board dark blue SATA connector.
Bootable hard drive's controller is not listed first in the Boot Order.	Run the Computer Setup utility and select Storage > Boot Order and ensure the bootable hard drive's controller is listed immediately under the Hard Drive entry.

Computer will not boot from hard drive.

Cause	Solution
The device is attached to a SATA port that has been hidden in Computer Setup.	Run the Computer Setup utility and ensure Device Available is selected for the device's SATA port in Security > Device Security .
Boot order is not correct.	Run the Computer Setup utility and change boot sequence in Storage > Boot Order .
Hard Drive's "Emulation Type" is set to "None."	Run the Computer Setup utility and change the "Emulation Type" to "Hard Disk" in the device's details under Storage > Device Configuration .
Hard drive is damaged.	<p>Observe if the front panel Power LED is blinking RED and if any beeps are heard. See Appendix A, POST Error Messages on page 246 to determine possible causes for the blinking red and beep codes.</p> <p>See the Worldwide Limited Warranty for terms and conditions.</p>

Computer seems to be locked up.

Cause	Solution
Program in use has stopped responding to commands.	Attempt the normal Windows "Shut Down" procedure. If this fails, press the power button for four or more seconds to turn off the power. To restart the computer, press the power button again.

The removable hard drive has no power to the hard drive enclosure.

Cause	Solution
The lock on the enclosure is not turned to the "ON" position.	Insert the key and turn the lock clockwise 90 degrees. The green LED on the front of the enclosure should be on.
Power cable from the computer power supply to the enclosure frame is not properly connected.	Check the power supply to make sure it is properly connected to the rear of the enclosure frame.

The removable hard drive is not recognized by the computer.

Cause	Solution
The removable hard drive carrier is not fully seated in the enclosure frame or the hard drive is not fully seated in the carrier.	Push the carrier into the enclosure frame so that the connector on the rear of the frame is properly seated. If this does not solve the problem, turn off the computer, remove the carrier, and check to see if the connector on the hard drive is properly seated in the carrier.

The removable hard drive enclosure is beeping and the green LED is flashing.

Cause	Solution
Fan failure alarm on the removable hard drive enclosure has been activated.	Shut down the computer and contact HP for a replacement enclosure.

Solving Media Card Reader Problems

Table D-5 Solving Media Card Reader Problems

Media card will not work in a digital camera after formatting it in Microsoft Windows XP or Microsoft Windows Vista.

Cause	Solution
By default, Windows will format any media card with a capacity greater than 32MB with the FAT32 format. Most digital cameras use the FAT (FAT16 & FAT12) format and can not operate with a FAT32 formatted card.	Either format the media card in the digital camera or select FAT file system to format the media card in a computer with Windows.

A write-protected or locked error occurs when attempting to write to the media card.

Cause	Solution
Media card is locked. Locking the media card is a safety feature that prevents writing to and deleting from an SD/ Memory Stick/PRO card.	If using an SD card, make sure that the lock tab located on the right of the SD card is not in the locked position. If using a Memory Stick/PRO card, make sure that the lock tab located on the bottom of the Memory Stick/PRO card is not in the locked position.

Can not write to the media card.

Cause	Solution
The media card is a read-only memory (ROM) card.	Check the manufacturer's documentation included with your card to see if it is writable. Refer to the previous section for a list of compatible cards.
Media card is locked. Locking the media card is a safety feature that prevents writing to and deleting from an SD/ Memory Stick/PRO card.	If using an SD card, make sure that the lock tab located on the right of the SD card is not in the locked position. If using a Memory Stick/PRO card, make sure that the lock tab located on the bottom of the Memory Stick/PRO card is not in the locked position.

Unable to access data on the media card after inserting it into a slot.

Cause	Solution
The media card is not inserted properly, is inserted in the wrong slot, or is not supported.	Ensure that the card is inserted properly with the gold contact on the correct side. The green LED will light if inserted properly.

Do not know how to remove a media card correctly.

Cause	Solution
The computer's software is used to safely eject the card.	Open My Computer (Windows XP) or Computer (Windows Vista/Windows 7), right-click on the corresponding drive icon, and select Eject . Then pull the card out of the slot. NOTE: Never remove the card when the green LED is flashing

After installing the media card reader and booting to Windows, the reader and the inserted cards are not recognized by the computer.

Cause	Solution
The operating system needs time to recognize the device if the reader was just installed into the computer and you are turning the PC on for the first time.	Wait a few seconds so that the operating system can recognize the reader and the available ports, and then recognize whatever media is inserted in the reader.

After inserting a media card in the reader, the computer attempts to boot from the media card.

Cause	Solution
The inserted media card has boot capability.	If you do not want to boot from the media card, remove it during boot or do not select the option to boot from the inserted media card during the boot process.

Solving Display Problems

If you encounter display problems, see the documentation that came with the monitor and to the common causes and solutions listed in the following table.

Table D-6 Solving Display Problems

Blank screen (no video).

Cause	Solution
Monitor is not turned on and the monitor light is not on.	Turn on the monitor and check that the monitor light is on.
Bad monitor.	Try a different monitor.
The cable connections are not correct.	Check the cable connection from the monitor to the computer and to the electrical outlet.
You may have a screen blanking utility installed or energy saver features are enabled.	Press any key or click the mouse button and, if set, type your password.
System ROM is corrupted; system is running in Boot Block Emergency Recovery Mode (indicated by eight beeps).	Reflash the system ROM with the latest BIOS image.
You are using a fixed-sync monitor and it will not sync at the resolution chosen.	Be sure that the monitor can accept the same horizontal scan rate as the resolution chosen.
Computer is in standby mode.	Press the power button to resume from standby mode. CAUTION: When attempting to resume from standby mode, do not hold down the power button for more than four seconds. Otherwise, the computer will shut down and you will lose any unsaved data.
Monitor cable is plugged into the wrong connector.	Systems may have a monitor connection on both the motherboard or an add-in card. Try moving the monitor connection to a different connector on the back of the computer
Monitor settings in the computer are not compatible with the monitor.	<ol style="list-style-type: none">1. In Windows XP Control Panel, double-click the Display icon and select the Settings tab. In Windows Vista or Windows 7 Control Panel, under Appearance and Personalization, select Adjust screen resolution.2. Use the sliding control to reset the resolution.
Monitor is configured to use an input that is not active.	Use the monitor's on-screen menu controls to select the input that is being driven by the system. Refer to the monitor's user documentation for more information on the on-screen controls and settings.

Blank screen and the power LED flashes Red five times, once every second, followed by a two second pause, and the computer beeps five times. (Beeps stop after fifth iteration but LEDs continue flashing.)

Cause	Solution
Pre-video memory error.	<ol style="list-style-type: none">1. Reseat DIMMs. Power on the system.2. Replace DIMMs one at a time to isolate the faulty module.3. Replace third-party memory with HP memory.4. Replace the system board.

Blank screen and the power LED flashes Red six times, once every second, followed by a two second pause, and the computer beeps six times. (Beeps stop after fifth iteration but LEDs continue flashing.)

Cause	Solution
Pre-video graphics error.	<p>For systems with a graphics card:</p> <ol style="list-style-type: none">1. Reseat the graphics card. Power on the system.2. Replace the graphics card.3. Replace the system board. <p>For systems with integrated graphics, replace the system board.</p>

Blank screen and the power LED flashes Red seven times, once every second, followed by a two second pause, and the computer beeps seven times. (Beeps stop after fifth iteration but LEDs continue flashing.)

Cause	Solution
System board failure (ROM detected failure prior to video).	Replace the system board.

Monitor does not function properly when used with energy saver features.

Cause	Solution
Monitor without energy saver capabilities is being used with energy saver features enabled.	Disable monitor energy saver feature.

Dim characters.

Cause	Solution
The brightness and contrast controls are not set properly.	Adjust the monitor brightness and contrast controls.
Cables are not properly connected.	Check that the graphics cable is securely connected to the graphics card and the monitor.

Blurry video or requested resolution cannot be set.

Cause	Solution
If the graphics controller was upgraded, the correct graphics drivers may not be loaded.	Install the video drivers included in the upgrade kit.
Monitor is not capable of displaying requested resolution.	Change requested resolution.
Graphics card is bad.	Replace the graphics card.

The picture is broken up, rolls, jitters, or flashes.

Cause	Solution
The monitor connections may be incomplete or the monitor may be incorrectly adjusted.	<ol style="list-style-type: none">1. Be sure the monitor cable is securely connected to the computer.2. In a two-monitor system or if another monitor is in close proximity, be sure the monitors are not interfering with each other's electromagnetic field by moving them apart.3. Fluorescent lights or fans may be too close to the monitor.
Monitor needs to be degaussed.	Degauss the monitor. Refer to the documentation that came with the monitor for instructions.

Image is not centered.

Cause	Solution
Position may need adjustment.	Press the monitor's Menu button to access the OSD menu. Select ImageControl/ Horizontal Position or Vertical Position to adjust the horizontal or vertical position of the image.

"No Connection, Check Signal Cable" displays on screen.

Cause	Solution
Monitor video cable is disconnected.	Connect the video cable between the monitor and computer. CAUTION: Ensure that the computer power is off while connecting the video cable.

"Out of Range" displays on screen.

Cause	Solution
Video resolution and refresh rate are set higher than what the monitor supports.	Restart the computer and enter Safe Mode. Change the settings to a supported setting then restart the computer so that the new settings take effect.

Vibrating or rattling noise coming from inside a CRT monitor when powered on.

Cause	Solution
Monitor degaussing coil has been activated.	None. It is normal for the degaussing coil to be activated when the monitor is powered on.

Clicking noise coming from inside a CRT monitor.

Cause	Solution
Electronic relays have been activated inside the monitor.	None. It is normal for some monitors to make a clicking noise when turned on and off, when going in and out of standby mode, and when changing resolutions.

High pitched noise coming from inside a flat panel monitor.

Cause	Solution
Brightness and/or contrast settings are too high.	Lower brightness and/or contrast settings.

Fuzzy focus; streaking, ghosting, or shadowing effects; horizontal scrolling lines; faint vertical bars; or unable to center the picture on the screen (flat panel monitors using an analog VGA input connection only).

Cause	Solution
Flat panel monitor's internal digital conversion circuits may be unable to correctly interpret the output synchronization of the graphics card.	<ol style="list-style-type: none">1. Select the monitor's Auto-Adjustment option in the monitor's on-screen display menu.2. Manually synchronize the Clock and Clock Phase on-screen display functions. To download a SoftPaq that will assist you with the synchronization, go to the following Web site, select the appropriate monitor, and download either SP32347 or SP32202: http://www.hp.com/support
Graphics card is not seated properly or is bad.	<ol style="list-style-type: none">1. Reseat the graphics card.2. Replace the graphics card.

Certain typed symbols do not appear correct.

Cause	Solution
The font you are using does not support that particular symbol.	Use the Character Map to locate and select the appropriate symbol. Click Start > All Programs > Accessories > System Tools > Character Map . You can copy the symbol from the Character Map into a document.

Solving Audio Problems

If the computer has audio features and you encounter audio problems, see the common causes and solutions listed in the following table.

Table D-7 Solving Audio Problems

Sound cuts in and out.

Cause	Solution
Processor resources are being used by other open applications.	Shut down all open processor-intensive applications.
Direct sound latency, common in many media player applications.	<p>In Windows XP only:</p> <ol style="list-style-type: none">1. From the Control Panel, select Sounds and Audio Devices.2. On the Audio tab, select a device from the Sound Playback list.3. Click the Advanced button and select the Performance tab.4. Set the Hardware acceleration slider to None and the Sample rate conversion quality slider to Good and retest the audio.5. Set the Hardware acceleration slider to Full and the Sample rate conversion quality slider to Best and retest the audio.

Sound does not come out of the speaker or headphones.

Cause	Solution
Software volume control is turned down or muted.	Double-click the Speaker icon on the taskbar, then make sure that Mute is not selected and use the volume slider to adjust the volume.
Audio is hidden in Computer Setup.	Enable the audio in Computer Setup: Security > Device Security > System Audio .
The external speakers are not turned on.	Turn on the external speakers.
The audio device may be connected to the wrong jack.	Ensure that the device is connected to the correct jack on the computer. The speakers should be plugged into the rear line-out jack and the headphones should be plugged into the front headphone jack.
External speakers plugged into the wrong audio jack on a recently installed sound card.	See the sound card documentation for proper speaker connection.
Digital CD audio is not enabled.	Enable digital CD audio. In the Device Manager, right-click on the CD/DVD device and select Properties . Make sure Enable digital CD audio for this CD-ROM device is checked.
Headphones or devices connected to the line-out connector mute the internal speaker.	Turn on and use headphones or external speakers, if connected, or disconnect headphones or external speakers.

Table D-7 Solving Audio Problems (continued)**Sound does not come out of the speaker or headphones.**

Cause	Solution
Computer is in standby mode.	Press the power button to resume from standby mode. CAUTION: When attempting to resume from standby mode, do not hold down the power button for more than four seconds. Otherwise, the computer will shut down and you will lose any unsaved data.
Internal speaker is disabled in Computer Setup.	Enable the internal speaker in Computer Setup. Select Advanced > Device Options > Internal Speaker .
The application is set to use a different audio device than speakers.	Some graphics cards support audio over the DisplayPort connection, so multiple audio devices may be listed in Device Manager. Make sure the correct device is being used.
Some applications can select which audio output device is used.	Make sure the application has selected the correct audio device.
The operating system controls may be set to use a different audio device as the default output device than what is expected.	Set the operating system to use the correct audio device.

Sound from headphones is not clear or muffled.

Cause	Solution
Headphones are plugged into the rear audio output connector. The rear audio output connector is for powered audio devices and is not designed for headphone use.	Plug the headphones into the headphone connector on the front of the computer.

Computer appears to be locked up while recording audio.

Cause	Solution
The hard disk may be full.	Before recording, make sure there is enough free space on the hard disk. You can also try recording the audio file in a compressed format.

Line-in jack is not functioning properly.

Cause	Solution
Jack has been reconfigured in the audio driver or application software.	In the audio driver or application software, reconfigure the jack or set the jack to its default value.

There is no sound or sound volume is too low.

Cause	Solution
The application is set to use a different audio device than speakers.	Some graphics cards support audio over the DisplayPort connection, so multiple audio devices may be listed in Device Manager. Make sure the correct device is being used.
Some applications can select which audio output device is used.	Make sure the application has selected the correct audio device.
The operating system controls may be set to use a different audio device as the default output device than what is expected.	Set the operating system to use the correct audio device.

Solving Printer Problems

If you encounter printer problems, see the documentation that came with the printer and to the common causes and solutions listed in the following table.

Table D-8 Solving Printer Problems

Printer will not print.

Cause	Solution
Printer is not turned on and online.	Turn the printer on and make sure it is online.
The correct printer drivers for the application are not installed.	<ol style="list-style-type: none">1. Install the correct printer driver for the application.2. Try printing using the MS-DOS command: <code>DIR C:\ > [printer port]</code> where [printer port] is the address of the printer being used. If the printer works, reload the printer driver.
If you are on a network, you may not have made the connection to the printer.	Make the proper network connections to the printer.
Printer may have failed.	Run printer self-test.

Printer will not turn on.

Cause	Solution
The cables may not be connected properly.	Reconnect all cables and check the power cord and electrical outlet.

Printer prints garbled information.

Cause	Solution
The correct printer driver for the application is not installed.	Install the correct printer driver for the application.

Table D-8 Solving Printer Problems (continued)

Printer prints garbled information.

Cause	Solution
The cables may not be connected properly.	Reconnect all cables.
Printer memory may be overloaded.	Reset the printer by turning it off for one minute, then turn it back on.

Printer is offline.

Cause	Solution
The printer may be out of paper.	Check the paper tray and refill it if it is empty. Select online.

Solving Keyboard and Mouse Problems

If you encounter keyboard or mouse problems, see the documentation that came with the equipment and to the common causes and solutions listed in the following table.

Table D-9 Solving Keyboard Problems

Keyboard commands and typing are not recognized by the computer.

Cause	Solution
Keyboard connector is not properly connected.	<ol style="list-style-type: none">1. On the Windows XP Desktop, click Start > Shut Down. On the Windows Vista or Windows 7 Desktop, click Start, click the arrow on the lower right corner of the Start menu, then select Shut Down.2. After the shutdown is complete, reconnect the keyboard to the back of the computer and restart the computer.
Program in use has stopped responding to commands.	Shut down your computer using the mouse and then restart the computer.
Keyboard needs repairs.	See the Worldwide Limited Warranty for terms and conditions.
Computer is in standby mode.	Press the power button to resume from standby mode. CAUTION: When attempting to resume from standby mode, do not hold down the power button for more than four seconds. Otherwise, the computer will shut down and you will lose any unsaved data.

Cursor will not move using the [arrow](#) keys on the keypad.

Cause	Solution
The Num Lock key may be on.	Press the Num Lock key. The Num Lock light should not be on if you want to use the arrow keys. The Num Lock key can be disabled (or enabled) in Computer Setup.

Table D-10 Solving Mouse Problems

Mouse does not respond to movement or is too slow.

Cause	Solution
Mouse connector is not properly plugged into the back of the computer.	Shut down the computer using the keyboard. <ol style="list-style-type: none">1. Press the Ctrl and Esc keys at the same time (or press the Windows logo key) to display the Start menu.2. Use the arrow keys to select Shut Down and then press the Enter key.3. After the shutdown is complete, plug the mouse connector into the back of the computer (or the keyboard) and restart.

Table D-10 Solving Mouse Problems (continued)

Mouse does not respond to movement or is too slow.

Cause	Solution
Program in use has stopped responding to commands.	Shut down the computer using the keyboard then restart the computer.
Mouse may need cleaning.	Remove the roller ball cover on the mouse and clean the internal components.
Mouse may need repair.	See the Worldwide Limited Warranty for terms and conditions.
Computer is in standby mode.	Press the power button to resume from standby mode. CAUTION: When attempting to resume from standby mode, do not hold down the power button for more than four seconds. Otherwise, the computer will shut down and you will lose any unsaved data.

Mouse will only move vertically, horizontally, or movement is jerky.

Cause	Solution
Mouse roller ball or the rotating encoder shafts that make contact with the ball are dirty.	Remove roller ball cover from the bottom of the mouse and clean the internal components with a mouse cleaning kit available from most computer stores.

Solving Hardware Installation Problems

You may need to reconfigure the computer when you add or remove hardware, such as an additional drive or expansion card. If you install a plug and play device, Windows automatically recognizes the device and configures the computer. If you install a non-plug and play device, you must reconfigure the computer after completing installation of the new hardware. In Windows, use the **Add Hardware Wizard** and follow the instructions that appear on the screen.

⚠ WARNING! When the computer is plugged into an AC power source, voltage is always applied to the system board. To reduce the risk of personal injury from electrical shock and/or hot surfaces, be sure to disconnect the power cord from the wall outlet and allow the internal system components to cool before touching.

Table D-11 Solving Hardware Installation Problems

A new device is not recognized as part of the system.

Cause	Solution
Device is not seated or connected properly.	Ensure that the device is properly and securely connected and that pins in the connector are not bent down.
Cable(s) of new external device are loose or power cables are unplugged.	Ensure that all cables are properly and securely connected and that pins in the cable or connector are not bent down.
Power switch of new external device is not turned on.	Turn off the computer, turn on the external device, then turn on the computer to integrate the device with the computer system.
When the system advised you of changes to the configuration, you did not accept them.	Reboot the computer and follow the instructions for accepting the changes.
A plug and play board may not automatically configure when added if the default configuration conflicts with other devices.	Use Windows Device Manager to deselect the automatic settings for the board and choose a basic configuration that does not cause a resource conflict. You can also use Computer Setup to reconfigure or disable devices to resolve the resource conflict.
USB ports on the computer are disabled in Computer Setup.	Run the Computer Setup utility and ensure that Device available is selected for appropriate USB ports under Security > USB Security .

Computer will not start.

Cause	Solution
Wrong memory modules were used in the upgrade or memory modules were installed in the wrong location.	<ol style="list-style-type: none">1. Review the documentation that came with the system to determine if you are using the correct memory modules and to verify the proper installation. NOTE: DIMM1 or XMM1 must always be installed. On all computers expect the USDt, DIMM1 must be installed before DIMM2, and DIMM3 must be installed before DIMM4.2. Observe the beeps and LED lights on the front of the computer. Beeps and flashing LEDs are codes for specific problems.3. If you still cannot resolve the issue, contact Customer Support.

Power LED flashes Red five times, once every second, followed by a two second pause, and the computer beeps five times. (Beeps stop after fifth iteration but LEDs continue flashing.)

Cause	Solution
Memory is installed incorrectly or is bad.	<p>CAUTION: To avoid damage to the DIMMs or the system board, you must unplug the computer power cord before attempting to reseat, install, or remove a DIMM module.</p> <ol style="list-style-type: none">1. Reseat DIMMs. Power on the system.2. Replace DIMMs one at a time to isolate the faulty module. <p>NOTE: DIMM1 or XMM1 must always be installed. On all computers expect the USDT, DIMM1 must be installed before DIMM2, and DIMM3 must be installed before DIMM4</p> <ol style="list-style-type: none">3. Replace third-party memory with HP memory.4. Replace the system board.

Power LED flashes Red six times, once every second, followed by a two second pause, and the computer beeps six times. (Beeps stop after fifth iteration but LEDs continue flashing.)

Cause	Solution
Graphics card is not seated properly or is bad, or system board is bad.	<p>For systems with a graphics card:</p> <ol style="list-style-type: none">1. Reseat the graphics card. Power on the system.2. Replace the graphics card.3. Replace the system board. <p>For systems with integrated graphics, replace the system board.</p>

Power LED flashes Red ten times, once every second, followed by a two second pause, and the computer beeps ten times. (Beeps stop after fifth iteration but LEDs continue flashing.)

Cause	Solution
Bad option card.	<ol style="list-style-type: none">1. Check each option card by removing the cards one at time (if multiple cards), then power on the system to see if fault goes away.2. Once bad card is identified, remove and replace bad option card.3. Replace the system board.

Solving Network Problems

Some common causes and solutions for network problems are listed in the following table. These guidelines do not discuss the process of debugging the network cabling.

Table D-12 Solving Network Problems**Wake-on-LAN feature is not functioning.**

Cause	Solution
S5 Maximum Power Saving feature is enabled.	Disable the S5 Maximum Power Saving option in Computer Setup. Select Power > Hardware Power Management > S5 Maximum Power Saving .
S5 Wake on LAN is disabled.	: Enable the S5 Wake on LAN option in Computer Setup. Select Advanced > Device Options > S5 Wake on LAN .
Wake-on-LAN is not enabled.	<p>To enable Wake-on-LAN in Windows XP:</p> <ol style="list-style-type: none"> 1. Select Start > Control Panel. 2. Double-click Network Connections. 3. Double-click Local Area Connection. 4. Click Properties. 5. Click Configure. 6. Click the Power Management tab, then select the check box to Allow this device to bring the computer out of standby. <p>To enable Wake-on-LAN in Windows Vista:</p> <ol style="list-style-type: none"> 1. Select Start > Control Panel. 2. Under Network and Internet, select View network status and tasks. 3. In the Tasks list, select Manage network connections. 4. Double-click Local Area Connection. 5. Click the Properties button. 6. Click the Configure button. 7. Click the Power Management tab, then select the check box to Allow this device to wake the computer. <p>To enable Wake-on-LAN in Windows 7:</p> <ol style="list-style-type: none"> 1. Select Start > Control Panel. 2. Under Network and Internet, select View network status and tasks. 3. Click Local Area Connection. 4. Click the Properties button. 5. Click the Configure button. 6. Click the Power Management tab, then select the check box to Allow this device to wake the computer.

Network driver does not detect network controller.

Cause	Solution
Network controller is disabled.	<ol style="list-style-type: none">1. Run Computer Setup and enable network controller.2. Enable the network controller in the operating system via Device Manager.
Incorrect network driver.	Check the network controller documentation for the correct driver or obtain the latest driver from the manufacturer's Web site.

Network status link light never flashes.

NOTE: The network status light is supposed to flash when there is network activity.

Cause	Solution
No active network is detected.	Check cabling and network equipment for proper connection.
Network controller is not set up properly.	Check for the device status within Windows, such as Device Manager for driver load and the Network Connections applet within Windows for link status.
Network controller is disabled.	<ol style="list-style-type: none">1. Run Computer Setup and enable network controller.2. Enable the network controller in the operating system via Device Manager.
Network driver is not properly loaded.	Reinstall network drivers.
System cannot autosense the network.	Disable auto-sensing capabilities and force the system into the correct operating mode.

Diagnostics reports a failure.

Cause	Solution
The cable is not securely connected.	Ensure that the cable is securely attached to the network connector and that the other end of the cable is securely attached to the correct device.
The cable is attached to the incorrect connector.	Ensure that the cable is attached to the correct connector.
There is a problem with the cable or a device at the other end of the cable.	Ensure that the cable and device at the other end are operating correctly.
Network controller interrupt is shared with an expansion board.	Under the Computer Setup Advanced menu, change the resource settings for the board.
The network controller is defective.	Contact an authorized service provider.

Diagnostics passes, but the computer does not communicate with the network.

Cause	Solution
Network drivers are not loaded, or driver parameters do not match current configuration.	Make sure the network drivers are loaded and that the driver parameters match the configuration of the network controller. Make sure the correct network client and protocol is installed.
The network controller is not configured for this computer.	Select the Network icon in the Control Panel and configure the network controller.

Network controller stopped working when an expansion board was added to the computer.

Cause	Solution
Network controller interrupt is shared with an expansion board.	Under the Computer Setup Advanced menu, change the resource settings for the board.
The network controller requires drivers.	Verify that the drivers were not accidentally deleted when the drivers for a new expansion board were installed.
The expansion board installed is a network card (NIC) and conflicts with the embedded NIC.	Under the Computer Setup Advanced menu, change the resource settings for the board.

Network controller stops working without apparent cause.

Cause	Solution
The files containing the network drivers are corrupted.	Reinstall the network drivers, using the Recovery Disc Set created from the hard drive's Recovery Partition.
The cable is not securely connected.	Ensure that the cable is securely attached to the network connector and that the other end of the cable is securely attached to the correct device.
The network controller is defective.	Contact an authorized service provider.

New network card will not boot.

Cause	Solution
New network card may be defective or may not meet industry-standard specifications.	Install a working, industry-standard NIC, or change the boot sequence to boot from another source.

Cannot connect to network server when attempting Remote System Installation.


Cause	Solution
The network controller is not configured properly.	Verify Network Connectivity, that a DHCP Server is present, and that the Remote System Installation Server contains the NIC drivers for your NIC.

System setup utility reports unprogrammed EEPROM.

Cause	Solution
Unprogrammed EEPROM.	Contact an authorized service provider.

Solving Memory Problems

If you encounter memory problems, some common causes and solutions are listed in the following table.

 **CAUTION:** Power may still be supplied to the DIMMs when the computer is turned off (depending on the Management Engine (ME) settings). To avoid damage to the DIMMs or the system board, you must unplug the computer power cord before attempting to reseat, install, or remove a DIMM module.

For those systems that support ECC memory, HP does not support mixing ECC and non-ECC memory. Otherwise, the computer will not boot the operating system.


 **NOTE:** The memory count will be affected by configurations with the Management Engine (ME) enabled. The ME uses 8MB of system memory in single channel mode or 16MB of memory in dual-channel mode to download, decompress, and execute the ME firmware for Out-of-Band (OOB), third-party data storage, and other management functions.

Table D-13 Solving Memory Problems

System will not boot or does not function properly after installing additional memory modules.

Cause	Solution
A memory module is not installed in the DIMM1 or XMM1 socket.	Ensure that a memory module is installed in the DIMM1 or XMM1 socket on the system board. This socket must be populated with a memory module.
Memory module is not the correct type or speed grade for the system or the new memory module is not seated properly.	Replace module with the correct industry-standard device for the computer. On some models, ECC and non-ECC memory modules cannot be mixed.

Out of memory error.

Cause	Solution
Memory configuration may not be set up correctly.	Use the Device Manager to check memory configuration.
You have run out of memory to run the application.	Check the application documentation to determine the memory requirements.

Memory count during POST is wrong.

Cause	Solution
The memory modules may not be installed correctly.	Check that the memory modules have been installed correctly and that proper modules are used.
Integrated graphics may use system memory.	No action required.

Insufficient memory error during operation.

Cause	Solution
Too many Terminate and Stay Resident programs (TSRs) are installed.	Delete any TSRs that you do not need.
You have run out of memory for the application.	Check the memory requirements for the application or add more memory to the computer.

Power LED flashes Red five times, once every second, followed by a two second pause, and the computer beeps five times. (Beeps stop after fifth iteration but LEDs continue flashing.)

Cause	Solution
Memory is installed incorrectly or is bad.	<ol style="list-style-type: none">1. Reseat DIMMs. Power on the system.2. Replace DIMMs one at a time to isolate the faulty module.3. Replace third-party memory with HP memory.4. Replace the system board.

Solving Processor Problems

If you encounter processor problems, common causes and solutions are listed in the following table.

Table D-14 Solving Processor Problems

Poor performance is experienced.

Cause	Solution
Processor is hot.	<ol style="list-style-type: none">1. Make sure the airflow to the computer is not blocked.2. Make sure the fans are connected and working properly (some fans only operate when needed).3. Make sure the processor heat sink is installed properly.

Power LED flashes Red three times, once every second, followed by a two second pause.

Cause	Solution
Processor is not seated properly or not installed.	<ol style="list-style-type: none">1. Check to see that the processor is present.2. Reseat the processor.

Power LED flashes Red eleven times, once every second, followed by a two second pause.

Cause	Solution
The current processor does not support a feature previously enabled on this system.	<ol style="list-style-type: none">1. Install a TXT capable processor.2. Disable TXT in the Computer Setup (F10) utility.3. Reinstall the original processor.

Solving CD-ROM and DVD Problems

If you encounter CD-ROM or DVD problems, see the common causes and solutions listed in the following table or to the documentation that came with the optional device.

Table D-15 Solving CD-ROM and DVD Problems

System will not boot from CD-ROM or DVD drive.

Cause	Solution
The device is attached to a SATA port that has been hidden in the Computer Setup utility.	Run the Computer Setup utility and ensure Device Available is selected for the device's SATA port in Security > Device Security .
Removable Media Boot is disabled in the Computer Setup utility.	Run the Computer Setup utility and enable booting to removable media in Storage > Storage Options . Ensure CD-ROM is enabled in Storage > Boot Order .
Network Server Mode is enabled in Computer Setup.	Run the Computer Setup utility and disable Network Server Mode in Security > Password Options .
Non-bootable CD in drive.	Try a bootable CD in the drive.
Boot order not correct.	Run the Computer Setup utility and change boot sequence in Storage > Boot Order .

Drive not found (identified).

Cause	Solution
Cable could be loose.	Check cable connections.
The system may not have automatically recognized a newly installed device.	<p>See reconfiguration directions in the Solving Hardware Installation Problems on page 286 section. If the system still does not recognize the new device, check to see if the device is listed within Computer Setup. If it is listed, the probable cause is a driver problem. If it is not listed, the probable cause is a hardware problem.</p> <p>If this is a newly installed drive, run the Computer Setup utility and try adding a POST delay under Advanced > Power-On Options.</p>
The device is attached to a SATA port that has been hidden in Computer Setup.	Run the Computer Setup utility and ensure Device Available is selected for the device's SATA port in Security > Device Security .
Drive responds slowly immediately after power-up.	Run Computer Setup and increase the POST Delay in Advanced > Power-On Options .

CD-ROM or DVD devices are not detected or driver is not loaded.

Cause	Solution
Drive is not connected properly or not properly configured.	See the documentation that came with the optional device.

Movie will not play in the DVD drive.

Cause	Solution
Movie may be regionalized for a different country.	See the documentation that came with the DVD drive.
Decoder software is not installed.	Install decoder software.
Damaged media.	Replace media.
Movie rating locked out by parental lock.	Use DVD software to remove parental lock.
Media installed upside down.	Reinstall media.

Cannot eject compact disc (tray-load unit).

Cause	Solution
Disc not properly seated in the drive.	Turn off the computer and insert a thin metal rod into the emergency eject hole and push firmly. Slowly pull the tray out from the drive until the tray is fully extended, then remove the disc.

CD-ROM, CD-RW, DVD-ROM, or DVD-R/RW drive cannot read a disc or takes too long to start.

Cause	Solution
Media has been inserted upside down.	Re-insert the media with the label facing up.
The DVD-ROM drive takes longer to start because it has to determine the type of media played, such as audio or video.	Wait at least 30 seconds to let the DVD-ROM drive determine the type of media being played. If the disc still does not start, read the other solutions listed for this topic.
CD or DVD disc is dirty.	Clean CD or DVD with a CD cleaning kit, available from most computer stores.
Windows does not detect the CD-ROM or DVD-ROM drive.	<ol style="list-style-type: none">1. Use Device Manager to remove or uninstall the device.2. Restart the computer and let Windows detect the CD or DVD driver.

Recording or copying CDs is difficult or impossible.

Cause	Solution
Wrong or poor quality media type.	<ol style="list-style-type: none">1. Try using a slower speed when recording.2. Verify that you are using the correct media for the drive.3. Try a different brand of media. Quality varies widely between manufacturers.

USDT computer boots too slow after removing a CD-ROM or DVD drive.

Cause	Solution
The system is searching for the drive during boot because the drive cable is still attached to the system board.	Disconnect the drive cable from the system board.

Solving USB Flash Drive Problems

If you encounter USB flash drive problems, common causes and solutions are listed in the following table.

Table D-16 Solving USB Flash Drive Problems

USB flash drive is not seen as a drive letter in Windows.

Cause	Solution
The drive letter after the last physical drive is not available.	Change the default drive letter for the flash drive in Windows.

USB flash drive not found (identified).

Cause	Solution
The device is attached to a USB port that has been hidden in Computer Setup.	Run the Computer Setup utility and ensure that "Device available" is selected for "Front USB Ports" and "Rear USB Ports" under Security > Device Security .
The device was not properly seated before power-up.	Ensure the device is fully inserted into the USB port before applying power to the system

System will not boot from USB flash drive.

Cause	Solution
Boot order is not correct.	Run the Computer Setup utility and change boot sequence in Storage > Boot Order .
Removable Media Boot is disabled in the Computer Setup utility.	Run the Computer Setup utility and enable booting to removable media in Storage > Storage Options . Ensure USB is enabled in Storage > Boot Order .

The computer boots to DOS after making a bootable flash drive.

Cause	Solution
Flash drive is bootable.	Install the flash drive only after the operating system boots.

Solving Front Panel Component Problems

If you encounter problems with devices connected to the front panel, refer to the common causes and solutions listed in the following table.

Table D-17 Solving Front Panel Component Problems

A USB device, headphone, or microphone is not recognized by the computer.

Cause	Solution
Device is not properly connected.	<ol style="list-style-type: none">1. Turn off the computer.2. Reconnect the device to the front of the computer and restart the computer.
The device does not have power.	If the USB device requires AC power, be sure one end is connected to the device and one end is connected to a live outlet.
The correct device driver is not installed.	<ol style="list-style-type: none">1. Install the correct driver for the device.2. You might need to reboot the computer.
The cable from the device to the computer does not work.	<ol style="list-style-type: none">1. If possible, replace the cable.2. Restart the computer.
The device is not working.	<ol style="list-style-type: none">1. Replace the device.2. Restart the computer.
USB ports on the computer are disabled in Computer Setup.	Run the Computer Setup utility and ensure that Device available is selected for appropriate USB ports under Security > USB Security .

Solving Internet Access Problems

If you encounter Internet access problems, consult your Internet Service Provider (ISP) or refer to the common causes and solutions listed in the following table.

Table D-18 Solving Internet Access Problems

Unable to connect to the Internet.

Cause	Solution
Internet Service Provider (ISP) account is not set up properly.	Verify Internet settings or contact your ISP for assistance.
Modem is not set up properly.	Reconnect the modem. Verify the connections are correct using the quick setup documentation.
Web browser is not set up properly.	Verify that the Web browser is installed and set up to work with your ISP.
Cable/DSL modem is not plugged in.	Plug in cable/DSL modem. You should see a "power" LED light on the front of the cable/DSL modem.

Table D-18 Solving Internet Access Problems (continued)**Unable to connect to the Internet.**

Cause	Solution
Cable/DSL service is not available or has been interrupted due to bad weather.	Try connecting to the Internet at a later time or contact your ISP. (If the cable/DSL service is connected, the “cable” LED light on the front of the cable/DSL modem will be on.)
The CAT5 UTP cable is disconnected.	Connect the CAT5 UTP cable between the cable modem and the computer’s RJ-45 connector. (If the connection is good, the “PC” LED light on the front of the cable/DSL modem will be on.)
IP address is not configured properly.	Contact your ISP for the correct IP address.
Cookies are corrupted. (A “cookie” is a small piece of information that a Web server can store temporarily with the Web browser. This is useful for having the browser remember some specific information that the Web server can later retrieve.)	<p>Windows 7</p> <ol style="list-style-type: none"> 1. Select Start > Control Panel. 2. Click Network and Internet. 3. Click Internet Options. 4. In the Browsing history section on the General tab, click the Delete button. 5. Select the Cookies check box and click the Delete button. <p>Windows Vista</p> <ol style="list-style-type: none"> 1. Select Start > Control Panel. 2. Click Network and Internet. 3. Click Internet Options. 4. In the Browsing history section on the General tab, click the Delete button. 5. Click the Delete cookies button. <p>Windows XP</p> <ol style="list-style-type: none"> 1. Select Start > Control Panel. 2. Double-click Internet Options. 3. On the General tab, click the Delete Cookies button.

Cannot automatically launch Internet programs.

Cause	Solution
You must log on to your ISP before some programs will start.	Log on to your ISP and launch the desired program.

Internet takes too long to download Web sites.

Cause	Solution
Modem is not set up properly.	<p>Verify that the modem is connected and communicating properly.</p> <p>Windows 7</p> <ol style="list-style-type: none">1. Select Start > Control Panel.2. Click on Hardware and Sound.3. Click on Device Manager.4. Double-click Modems.5. Double-click Agere Systems PCI-SV92PP Soft Modem.6. On the General tab, click Diagnostics.7. Click Query Modem. A "Success" response indicates the modem is connected and working properly. <p>Windows XP</p> <ol style="list-style-type: none">1. Select Start > Control Panel.2. Double-click System.3. Click the Hardware tab.4. In the Device Manager area, click the Device Manager button.5. Double-click Modems.6. Double-click Agere Systems PCI-SV92PP Soft Modem.7. On the General tab, click Diagnostics.8. Click Query Modem. A "Success" response indicates the modem is connected and working properly. <p>Windows Vista</p> <ol style="list-style-type: none">1. Select Start > Control Panel.2. Click on System and Maintenance.3. Click on System.4. In the Tasks list, select Device Manager.5. Double-click Modems.6. Double-click Agere Systems PCI-SV92PP Soft Modem.7. On the General tab, click Diagnostics.8. Click Query Modem. A "Success" response indicates the modem is connected and working properly.

Solving Software Problems

Most software problems occur as a result of the following:

- The application was not installed or configured correctly.
- There is insufficient memory available to run the application.
- There is a conflict between applications.
- Be sure that all the needed device drivers have been installed.
- If you have installed an operating system other than the factory-installed operating system, check to be sure it is supported on the system.

If you encounter software problems, see the applicable solutions listed in the following table.

Table D-19 Solving Software Problems

Computer will not continue and no HP logo screen has appeared.

Cause	Solution
POST error has occurred.	Observe the beeps and LED lights on the front of the computer. See Appendix A, POST Error Messages on page 246 to determine possible causes. See the Restore Kit or the Worldwide Limited Warranty for terms and conditions.

Computer will not continue after HP logo screen has appeared.

Cause	Solution
System files may be damaged.	Use recovery diskette to scan hard drive for errors.

“Illegal Operation has Occurred” error message is displayed.

Cause	Solution
Software being used is not Microsoft-certified for your version of Windows.	Verify that the software is certified by Microsoft for your version of Windows (see program packaging for this information).
Configuration files are corrupt.	If possible, save all data, close all programs, and restart the computer.

Contacting Customer Support

For help and service, contact an authorized reseller or dealer. To locate a reseller or dealer near you, visit <http://www.hp.com>.



NOTE: If you take the computer to an authorized reseller, dealer, or service provider for service, remember to provide the setup and power-on passwords if they are set.

Refer to the number listed in the warranty or in the *Support Telephone Numbers* guide for technical assistance.


E Password Security and Resetting CMOS

This computer supports security password features, which can be established through the Computer Setup Utilities menu.

This computer supports two security password features that are established through the Computer Setup Utilities menu: setup password and power-on password. When you establish only a setup password, any user can access all the information on the computer except Computer Setup. When you establish only a power-on password, the power-on password is required to access Computer Setup and any other information on the computer. When you establish both passwords, only the setup password will give you access to Computer Setup.

When both passwords are set, the setup password can also be used in place of the power-on password as an override to log in to the computer. This is a useful feature for a network administrator.


If you forget the password for the computer, you can clear that password so you can gain access to the information on the computer by resetting the password jumper.


 **CAUTION:** Pushing the CMOS button will reset CMOS values to factory defaults. It is important to back up the computer CMOS settings before resetting them in case they are needed later. Back up is easily done through Computer Setup. See [Computer Setup \(F10\) Utility on page 4](#) for information on backing up the CMOS settings.

Resetting the Password Jumper

To disable the power-on or setup password features, or to clear the power-on or setup passwords, complete the following steps:


1. Shut down the operating system properly, then turn off the computer and any external devices, and disconnect the power cord from the power outlet.
2. With the power cord disconnected, press the power button again to drain the system of any residual power.

 **WARNING!** To reduce the risk of personal injury from electrical shock and/or hot surfaces, be sure to disconnect the power cord from the wall outlet, and allow the internal system components to cool before touching.

 **CAUTION:** When the computer is plugged in, the power supply always has voltage applied to the system board even when the unit is turned off. Failure to disconnect the power cord can result in damage to the system.

Static electricity can damage the electronic components of the computer or optional equipment. Before beginning these procedures, ensure that you are discharged of static electricity by briefly touching a grounded metal object. See the *Safety & Regulatory Information* guide for more information.

3. Remove the computer cover or access panel.
4. Locate the header and jumper.

 **NOTE:** The password jumper is green so that it can be easily identified. For assistance locating the password jumper and other system board components, see the Illustrated Parts & Service Map (IPSM). The IPSM can be downloaded from <http://www.hp.com/support>.

5. Remove the jumper from pins 1 and 2. Place the jumper on either pin 1 or 2, but not both, so that it does not get lost.
6. Replace the computer cover or access panel.
7. Reconnect the external equipment.
8. Plug in the computer and turn on power. Allow the operating system to start. This clears the current passwords and disables the password features.
9. To establish new passwords, repeat steps 1 through 4, replace the password jumper on pins 1 and 2, then repeat steps 6 through 8. Establish the new passwords in Computer Setup.


Clearing and Resetting the CMOS


The computer's configuration memory (CMOS) stores information about the computer's configuration.

The CMOS button resets CMOS but does not clear the power-on and setup passwords.

Clearing CMOS will clear the Active Management Technology (AMT) settings in the Management Engine BIOS Extension (MEBx), including the password. The password will default to "admin" and will need to be reset. The AMT settings will also need to be reset. To access the MEBx, press **Ctrl+P** during POST.


1. Turn off the computer and any external devices, and disconnect the power cord from the power outlet.
2. Disconnect the keyboard, monitor, and any other external equipment connected to the computer.

 **WARNING!** To reduce the risk of personal injury from electrical shock and/or hot surfaces, be sure to disconnect the power cord from the wall outlet, and allow the internal system components to cool before touching.

 **CAUTION:** When the computer is plugged in, the power supply always has voltage applied to the system board even when the unit is turned off. Failure to disconnect the power cord can result in damage to the system.

Static electricity can damage the electronic components of the computer or optional equipment. Before beginning these procedures, ensure that you are discharged of static electricity by briefly touching a grounded metal object. See the *Safety & Regulatory Information* guide for more information.

3. Remove the computer cover or access panel.

 **CAUTION:** Pushing the CMOS button will reset CMOS values to factory defaults. It is important to back up the computer CMOS settings before resetting them in case they are needed later. Back up is easily done through Computer Setup. See [Computer Setup \(F10\) Utility on page 4](#) for information on backing up the CMOS settings.

4. Locate, press, and hold the CMOS button in for five seconds.




 **NOTE:** Make sure you have disconnected the AC power cord from the wall outlet. The CMOS button will not clear CMOS if the power cord is connected.

Figure E-1 CMOS button



 **NOTE:** For assistance locating the CMOS button and other system board components, see the Illustrated Parts & Service Map (IPSM).

5. Replace the computer cover or access panel.
6. Reconnect the external devices.
7. Plug in the computer and turn on power.

 **NOTE:** You will receive POST error messages after clearing CMOS and rebooting advising you that configuration changes have occurred. Use Computer Setup to reset any special system setups along with the date and time.

For instructions on Computer Setup, see [Computer Setup \(F10\) Utility on page 4](#).

F Drive Protection System (DPS)

The Drive Protection System (DPS) is a diagnostic tool built into the hard drives installed in some computers. DPS is designed to help diagnose problems that might result in unwarranted hard drive replacement.

When these systems are built, each installed hard drive is tested using DPS, and a permanent record of key information is written onto the drive. Each time DPS is run, test results are written to the hard drive. Your service provider can use this information to help diagnose conditions that caused you to run the DPS software.

Running DPS will not affect any programs or data stored on the hard drive. The test resides in the hard drive firmware and can be executed even if the computer will not boot to an operating system. The time required to execute the test depends on the manufacturer and size of the hard drive; in most cases, the test will take approximately two minutes per gigabyte.

Use DPS when you suspect a hard drive problem. If the computer reports a SMART Hard Drive Detect Imminent Failure message, there is no need to run DPS; instead, back up the information on the hard drive and contact a service provider for a replacement hard drive.

Accessing DPS Through Computer Setup

When the computer does not power on properly you should use Computer Setup to access the DPS program. To access DPS, perform the following steps:

1. Turn on or restart the computer.
2. When the F10 Setup message appears in the lower-right corner of the screen, press the **F10** key.



NOTE: If you do not press the **F10** key while the message is displayed, you must turn the computer off, then on again, to access the utility.

A choice of five headings appears in the Computer Setup Utilities menu: **File**, **Storage**, **Security**, **Power**, and **Advanced**.

3. Select **Storage > DPS Self-Test**.

The screen will display the list of DPS-capable hard drives that are installed on the computer.



NOTE: If no DPS-capable hard drives are installed, the **DPS Self-Test** option will not appear on the screen.

4. Select the hard drive to be tested and follow the screen prompts to complete the testing process.


When the test has been completed, one of three messages will be displayed:

- Test Succeeded. Completion Code 0.
- Test Aborted. Completion Code 1 or 2.
- Test Failed. Drive Replacement Recommended. Completion Code 3 through 14.

If the test failed, the completion code should be recorded and reported to your service provider for help in diagnosing the computer problem.

G Computer Diagnostic Features

Hewlett-Packard Vision Diagnostics


 **NOTE:** HP Vision Diagnostics is included on CD with some computer models only.

The Hewlett-Packard Vision Diagnostics utility allows you to view information about the hardware configuration of the computer and perform hardware diagnostic tests on the subsystems of the computer. The utility simplifies the process of effectively identifying, diagnosing, and isolating hardware issues.

The Survey tab is displayed when you invoke HP Vision Diagnostics. This tab shows the current configuration of the computer. From the Survey tab, there is access to several categories of information about the computer. Other tabs provide additional information, including diagnostic test options and test results. The information in each screen of the utility can be saved as an html file and stored on a USB flash drive.


Use HP Vision Diagnostics to determine if all the devices installed on the computer are recognized by the system and functioning properly. Running tests is optional but recommended after installing or connecting a new device.

You should run tests, save the test results, and print them so that you have printed reports available before placing a call to the Customer Support Center.

 **NOTE:** Third party devices may not be detected by HP Vision Diagnostics.

Accessing HP Vision Diagnostics


To access HP Vision Diagnostics, you must create a Recovery Disc Set then boot to the CD containing the utility. It can also be downloaded from <http://www.hp.com> and either burned to CD or installed to a USB flash drive. See [Downloading the Latest Version of HP Vision Diagnostics on page 312](#) for more information.

 **NOTE:** HP Vision Diagnostics is included as part of the Recovery Disk Set with some computer models only.


If you have already downloaded HP Vision Diagnostics to either CD or USB Flash drive, then begin the following procedure at step 2.

1. In Windows Explorer, go to **C:\SWSetup\ISOs** and burn the file **Vision Diagnostics.ISO** to a CD or copy it to a USB flash drive.
2. While the computer is on, insert the CD in the Optical Drive or USB flash drive in a USB port on the computer.

3. Shut down the operating system and turn off the computer.
4. Turn on the computer. The system will boot into HP Vision Diagnostics.

 **NOTE:** If the system does not boot to the CD in the optical drive or to the USB flash drive, you may need to change the boot order in the Computer Setup (F10) utility. Refer to the *Computer Setup (F10) Utility Guide* for more information.

5. At the boot menu, select either the **HP Vision Diagnostics** utility to test the various hardware components in the computer or the **HP Memory Test** utility to test memory only.

 **NOTE:** The HP Memory Test is a comprehensive memory diagnostic utility that is run as a stand-alone application, outside of HP Vision Diagnostics.

6. If running **HP Vision Diagnostics**, select the appropriate language and click **Continue**.
7. In the End User License Agreement page, select **Agree** if you agree with the terms. The HP Vision Diagnostics utility launches with the Survey tab displayed.

Survey Tab

The Survey tab displays important system configuration information.

In the **View level** field, you can select the **Summary** view to see limited configuration data or select the **Advanced** view to see all the data in the selected category. By default, the View Level is set to **Overview** which displays general information about all of the component categories.

In the **Category** field, you can select the following categories of information to display:

All—Gives a listing of all categories of information about the computer.

Architecture—Provides system BIOS and PCI device information.

Asset Control—Shows product name, system serial number, asset tag and universal unique ID information.

Audio—Displays information about the audio controllers present in the system, including PCI audio cards.

Communication—Shows information about the computer parallel (LPT) and serial (COM) port settings, plus USB and network controller information.

Graphics—Shows information about the graphics controller of the computer.

Input Devices—Shows information about the keyboard, mouse, and other input devices connected to the computer.

Memory—Shows information about all memory in the computer. This includes memory slots on the system board and any memory modules installed.

Processors—Shows information about the processor(s) installed in the computer, including clock speeds and cache sizes.

Storage—Shows information about storage media connected to the computer. This list includes all hard drives and optical drives.

System—Shows information about the computer model, internal fans, chassis, and BIOS.

Test Tab

The Test tab allows you to choose various parts of the system to test. You can also choose the type of test and testing mode.

There are three types of tests to choose from:

- **Quick Test**—Provides a predetermined script where a sample of each hardware component is exercised. You may further modify which of the Quick tests are executed by selecting or deselecting individual tests in the hardware component check list.
- **Complete Test**—Provides a predetermined script where each hardware component is fully tested. You may further modify which of the Complete tests are executed by selecting or deselecting individual tests in the hardware component check list.
- **Custom Test**—Provides the most flexibility in controlling the testing of a system. The Custom Test mode allows you to specifically select which devices, tests, and test parameters are run.

By default, the three test modes do not display prompts and require no interaction. If errors are found, they are displayed when testing is complete.

However, for each test type, you may also optionally add interactive tests by clicking the **Include interactive tests** box under **Test mode**. Selecting interactive tests provides the maximum control over the testing process. The diagnostic software will prompt you for input during tests.



NOTE: Memory can not be tested from within the HP Vision Diagnostics application. To test the memory in your computer, you must exit HP Vision Diagnostics, boot to either the CD or USB flash drive and select **HP Memory Test** from the boot menu.

To begin testing:

1. Select the Test tab.
2. Select the type of tests you want to run: **Quick**, **Complete**, or **Custom**.
3. Include optional interactive tests by selecting **Include interactive tests**.
4. Choose how you want the test to be executed, either **Number of Loops** or **Total Test Time**. When choosing to run the test over a specified number of loops, enter the number of loops to perform. If you want the diagnostic test for a specified time period, enter the amount of time in minutes.
5. Click the **Start Test** button to start the testing. The Status tab, which allows you to monitor the progress of the tests, is automatically displayed during the testing process. When the tests are complete, the Status tab shows whether the devices passed or failed.
6. If errors are found, go to the Errors tab to display detailed information and recommended actions.

Status Tab

The Status tab displays the status of the selected tests. The main progress bar displays the percent complete of the current set of tests. While testing is in progress, a **Cancel Testing** button is displayed for use if you want to cancel the test.

The Status tab also shows:

- The devices being tested
- The test status (running, waiting, passed, or failed) of each device being tested
- The overall test progress of all devices being tested
- The test progress for each device being tested
- The elapsed test times for each device being tested

History Tab

The History tab contains information on past test executions.

The History Log displays all tests that have been executed, the number of times of execution, the number of times failed, the date each test was executed, and the time it took to complete each test. The **Clear History** button will clear the contents of the History Log.

The contents of the History Log may be saved as a HTML file to USB flash drive by clicking the **Save** button.

Errors Tab

The Errors tab displays detailed information about any errors found, as well as any recommended actions.

The Error Log displays the tests for devices that have failed during the diagnostic testing and includes the following columns of information.

- The **Device** section displays the device tested.
- The **Test** section displays the type of test run.
- The **Times Failed** is the number of times the device has failed a test.
- The **Defect Code** provides a numerical code for the failure. The error codes are defined in the Help tab.
- The **Description** section describes the error that the diagnostic test found.
- The **Reason** section describes the likely cause of the error.
- The **Recommended Repair** will give a recommended action that should be performed to resolve the failed hardware.
- The **Warranty ID** is a unique error code associated with the specific error on your computer. When contacting the HP Support Center for assistance with a hardware failure, please be prepared to provide the Warranty ID.

The **Clear Errors** button will clear the contents of the Error Log.

The contents of the Error Log may be saved as a HTML file to USB flash drive by clicking the **Save** button.

Help Tab

The Help tab contains a **Vision Help** section, and a **Test Components** section. This tab includes search and index features. You may also review the HP End User License Agreement (EULA), as well as the HP Vision Diagnostic application version information on this tab.

The **Vision Help** section contains information on the major functions of Hewlett-Packard Vision Diagnostics.

The **Test Components** section provides a description of each test, as well as the parameters that may be adjusted when running in Custom test mode.

The **Defect codes** section contains information on the numerical error code that may appear in the Errors tab.

The **Memory test tab** section provides information on the **HP Memory Test** application that may be launched from the boot menu.

The **HP Support** section provides information on obtaining technical support from HP.

Saving and Printing Information in HP Vision Diagnostics

You can save the information displayed in the HP Vision Diagnostics **Survey**, **History** and **Errors** tabs to a USB flash drive. You can not save to the hard drive. The system will automatically create an html file that has the same appearance as the information displayed on the screen.

1. Insert a USB flash drive if running HP Vision Diagnostics from CD.
2. Click **Save** in the bottom on any of the **Survey**, **History** or **Errors** tabs. All three log files will be saved regardless of from which tab the Save button was clicked.
3. Select the drive onto which you will save the log files and click the **Save** button. Three html files will be saved to the inserted USB flash drive.



NOTE: Do not remove the USB flash drive until you see a message indicating that the html files have been written to the media.

4. Print the desired information from the storage device used to save it.



NOTE: To exit HP Vision Diagnostics, click the **Exit Diagnostics** button at the bottom of the screen. Be sure to remove the USB flash drive or CD from the optical drive.

Downloading the Latest Version of HP Vision Diagnostics

1. Go to <http://www.hp.com>.
2. Click the **Software & Drivers** link.
3. Select **Download drivers and software (and firmware)**.
4. Enter your product name in the text box and press the **Enter** key.
5. Select your specific computer model.
6. Select your OS.
7. Click the **Diagnostic** link.

8. Click the **Hewlett-Packard Vision Diagnostics** link.
9. Click the **Download** button.



NOTE: The download includes instructions on how to create the bootable CD or the bootable USB flash drive.

Protecting the Software

To protect software from loss or damage, you should keep a backup copy of all system software, applications, and related files stored on the hard drive. See the operating system or backup utility documentation for instructions on making backup copies of data files.

H Backup and Recovery

Windows 7 – Backup and Recovery

To protect your information, use Windows® Backup and Restore to back up individual files and folders, back up your entire hard drive (select models only), create system repair discs (select models only), or create system restore points. In case of system failure, you can use the backup files to restore the contents of your computer.

Windows Backup and Restore provides the following options:

- Creating a system repair disc (select models only)
- Backing up individual files and folders
- Creating a system image (select models only)
- Scheduling automatic backups (select models only)
- Creating system restore points
- Recovering individual files
- Restoring the computer to a previous state
- Recovering information using recovery tools



NOTE: For detailed instructions, perform a search for these topics in Help and Support.



NOTE: In case of system instability, HP recommends that you print the recovery procedures and save them for later use.

Backing up your information

Recovery after a system failure is as complete as your most current backup. You should create system repair discs (select models only) and your initial backup immediately after software setup. As you add new software and data files, you should continue to back up your system on a regular basis to maintain a reasonably current backup. The system repair discs (select models only) are used to start up (boot) the computer and repair the operating system in case of system instability or failure. Your initial and subsequent backups allow you to restore your data and settings if a failure occurs.

You can back up your information to an optional external hard drive, a network drive, or discs.

Note the following when backing up:

- Store personal files in the Documents library, and back it up regularly.
- Back up templates that are stored in their associated programs.
- Save customized settings that appear in a window, toolbar, or menu bar by taking a screen shot of your settings. The screen shot can be a time-saver if you have to reset your preferences.

To create a screen shot:

1. Display the screen you want to save.
2. Copy the screen image:

To copy only the active window, press **alt+fn+prt sc**.

To copy the entire screen, press **fn+prt sc**.

3. Open a word-processing document, and then select **Edit > Paste**.

The screen image is added to the document.

4. Save the document.

- When backing up to discs, use any of the following types of discs (purchased separately): CD-R, CD-RW, DVD+R, DVD+R DL, DVD-R, DVD-R DL, or DVD±RW. The discs you use will depend on the type of optical drive installed in your computer.



NOTE: DVDs and DVDs with double-layer (DL) support store more information than CDs, so using them for backup reduces the number of recovery discs required.

- When backing up to discs, number each disc before inserting it into the optical drive of the computer.

To create a backup using Backup and Restore, follow these steps:



NOTE: Be sure that the computer is connected to AC power before you start the backup process.



NOTE: The backup process may take over an hour, depending on file size and the speed of the computer.

1. Select **Start > All Programs > Maintenance > Backup and Restore**.
2. Follow the on-screen instructions to set up your backup, create a system image (select models only), or create a system repair disc (select models only).



NOTE: Windows® includes the User Account Control feature to improve the security of your computer. You may be prompted for your permission or password for tasks such as installing software, running utilities, or changing Windows settings. Refer to Help and Support for more information.

Performing a recovery

In case of system failure or instability, the computer provides the following tools to recover your files:

- Windows recovery tools: You can use Windows Backup and Restore to recover information you have previously backed up. You can also use Windows Startup Repair to fix problems that might prevent Windows from starting correctly.
- F11 recovery tools: You can use the F11 recovery tools to recover your original hard drive image. The image includes the Windows operating system and software programs installed at the factory.



NOTE: If you are unable to boot (start up) your computer and you cannot use the system repair discs you previously created (select models only), you must purchase a Windows 7 operating system DVD to reboot the computer and repair the operating system. For additional information, refer to the “Using a Windows 7 operating system DVD (purchased separately)” section in this guide.

Using the Windows recovery tools

To recover information you previously backed up, follow these steps:

1. Select **Start > All Programs > Maintenance > Backup and Restore**.
2. Follow the on-screen instructions to recover your system settings, your computer (select models only), or your files.



NOTE: Windows includes the User Account Control feature to improve the security of your computer. You may be prompted for your permission or password for tasks such as installing software, running utilities, or changing Windows settings. Refer to Help and Support for more information.

To recover your information using Startup Repair, follow these steps:



CAUTION: All files you have created and any software installed on the computer are permanently removed. When reformatting is complete, the recovery process restores the operating system, as well as the drivers, software, and utilities from the backup used for recovery.

1. If possible, back up all personal files.
2. If possible, check for the presence of the Windows partition and the HP Recovery partition.

To check for the Windows partition, select **Start > Computer**.


To check for the HP Recovery partition, select **Start**, right-click **Computer**, click **Manage**, and then click **Disk Management**.




NOTE: If the Windows partition and the HP Recovery partition are not listed, you must recover your operating system and programs using the System Recovery discs that you can obtain from HP Support.

3. If the Windows partition and the HP Recovery partition are listed, restart the computer, and then press F8 before the Windows operating system loads.
4. Select **Repair Your Computer**. The following options display: Startup Repair, System Restore, System Image Recovery, Windows Memory Diagnostics, Command Prompt, Recovery Manager.

5. Select one of the first three listed tools to repair your computer.
6. Follow the on-screen instructions.


 **NOTE:** For additional information on recovering information using the Windows tools, perform a search for these topics in Help and Support.

Using F11

 **CAUTION:** Using **F11** completely erases hard drive contents and reformats the hard drive. All files you have created and any software installed on the computer are permanently removed. The **F11** recovery tool reinstalls the operating system and HP programs and drivers that were installed at the factory. Software not installed at the factory must be reinstalled.

If Windows 7 is not responding, but the computer is working, follow these steps to perform a System Recovery.


1. If possible, back up all personal files.
2. If possible, check for the presence of the HP Recovery partition: select **Start**, right-click **Computer**, click **Manage**, and then click **Disk Management**.

 **NOTE:** If the Windows partition and the HP Recovery partition are not listed, you must recover your operating system and programs using the System Recovery discs that you can obtain from HP Support.

3. Press the Power button to turn on the computer.
4. As soon as you see the initial company logo screen appear, repeatedly press the **F11** key on your keyboard until the `Windows is Loading Files...` message appears on the screen.
5. Under **I need help immediately**, tap **System Recovery**.
6. If you are prompted to back up your files, and you have not done so, tap **Back up your files first (recommended)**, and then tap **Next**. Otherwise, tap **Recover without backing up your files**, and then tap **Next**.
7. System Recovery begins. After System Recovery is complete, tap **Finish** to restart the computer.

Using a Windows 7 operating system DVD (purchased separately)

If you are unable to boot (start up) your computer and you cannot use the system repair discs you previously created (select models only), you must use System Recovery discs that you can obtain from HP Support to reboot the computer and repair the operating system. Make sure that your most recent backup (stored on discs or on an external drive) is easily accessible.

 **CAUTION:** All files you have created and any software installed on the computer are permanently removed. When reformatting is complete, the recovery process helps you restore the operating system, as well as drivers, software, and utilities.

To initiate recovery using a Windows 7 operating system DVD, follow these steps:



NOTE: This process takes several minutes.

1. If possible, back up all personal files.
2. Restart the computer, and then insert the Windows 7 operating system DVD into the optical drive before the Windows operating system loads.
3. When prompted, press any keyboard key.
4. Follow the on-screen instructions.
5. Click **Next**.
6. Select **Repair your computer**.
7. Follow the on-screen instructions.

Windows Vista – Backup and Recovery

To protect your information, use the Backup and Restore Center to back up individual files and folders, back up your entire hard drive (select models only), or create system restore points. In case of system failure, you can use the backup files to restore the contents of your computer.

The Backup and Restore Center provides the following options:

- Backing up individual files and folders
- Backing up the entire hard drive (select models only)
- Scheduling automatic backups (select models only)
- Creating system restore points
- Recovering individual files
- Restoring the computer to a previous state
- Recovering information using recovery tools



NOTE: For detailed instructions, perform a search for these topics in Help and Support.



NOTE: In case of system instability, HP recommends that you print the recovery procedures and save them for later use.

Backing up your information

Recovery after a system failure is as complete as your most current backup. You should create your initial backup immediately after software setup. As you add new software and data files, you should continue to back up your system on a regular basis to maintain a reasonably current backup.

You can back up your information to an optional external hard drive, a network drive, or discs.

Note the following when backing up:

- Store personal files in the Documents folder, and back it up regularly.
- Back up templates that are stored in their associated programs.

- Save customized settings that appear in a window, toolbar, or menu bar by taking a screen shot of your settings. The screen shot can be a time-saver if you have to reset your preferences.

To create a screen shot:

1. Display the screen you want to save.

2. Copy the screen image:

To copy only the active window, press **alt+fn+prt sc**.


To copy the entire screen, press **fn+prt sc**.

3. Open a word-processing document, and then select **Edit > Paste**.

The screen image is added to the document.


4. Save the document.


- When backing up to discs, use any of the following types of discs (purchased separately): CD-R, CD-RW, DVD+R, DVD+R DL, DVD-R, DVD-R DL, or DVD±RW. The discs you use will depend on the type of optical drive installed in your computer.

 **NOTE:** DVDs and DVDs with double-layer (DL) support store more information than CDs, so using them for backup reduces the number of recovery discs required.


- When backing up to discs, number each disc before inserting it into the optical drive of the computer.

To create a backup using Backup and Restore Center, follow these steps:

 **NOTE:** Be sure that the computer is connected to AC power before you start the backup process.

 **NOTE:** The backup process may take over an hour, depending on file size and the speed of the computer.


1. Select **Start > All Programs > Maintenance > Backup and Restore Center**.
2. Follow the on-screen instructions to back up your entire computer (select models only) or your files.

 **NOTE:** Windows® includes the User Account Control feature to improve the security of your computer. You may be prompted for your permission or password for tasks such as installing software, running utilities, or changing Windows settings. Refer to Help and Support for more information.

Performing a recovery

In case of system failure or instability, the computer provides the following tools to recover your files:


- Windows recovery tools: You can use the Backup and Restore Center to recover information you have previously backed up. You can also use Windows Startup Repair to fix problems that might prevent Windows from starting correctly.
- F11 recovery tools: You can use the **F11** recovery tools to recover your original hard drive image. The image includes the Windows operating system and software programs installed at the factory.

 **NOTE:** If you are unable to boot (start up) your computer, you must use System Recovery discs that you can obtain from HP Support to reboot the computer and repair the operating system. For additional information, refer to the “Using a Windows Vista operating system DVD (purchased separately)” section in this guide.


Using the Windows recovery tools

To recover information you previously backed up, follow these steps:


1. Click **Start > All Programs > Maintenance > Backup and Restore Center**.
2. Follow the on-screen instructions to recover your entire computer (select models only) or your files.

 **NOTE:** Windows includes the User Account Control feature to improve the security of your computer. You may be prompted for your permission or password for tasks such as installing software, running utilities, or changing Windows settings. Refer to Help and Support for more information.


To recover your information using Startup Repair, follow these steps:

 **CAUTION:** All files you have created and any software installed on the computer are permanently removed. When reformatting is complete, the recovery process restores the operating system, as well as the drivers, software, and utilities from the backup used for recovery.


1. If possible, back up all personal files.
2. If possible, check for the presence of the Windows partition and the HP Recovery partition. To find the partitions, select **Start > Computer**.

 **NOTE:** If the Windows partition and the HP Recovery partition have been deleted, you must recover your operating system and programs using System Recovery discs that you can obtain from HP Support. For additional information, refer to the “Using a Windows Vista operating system DVD (purchased separately)” section in this guide.

3. Restart the computer, and then press **F8** before the Windows operating system loads.
4. Select **Repair Your Computer**. The following options display: Startup Repair, System Restore, System Image Recovery, Windows Memory Diagnostics, Command Prompt, Recovery Manager.
5. Select one of the first three listed tools to repair your computer.
6. Follow the on-screen instructions.

 **NOTE:** For additional information on recovering information using the Windows tools, perform a search for these topics in Help and Support.

Using F11

 **CAUTION:** Using **F11** completely erases hard drive contents and reformats the hard drive. All files you have created and any software installed on the computer are permanently removed. The **F11** recovery tool reinstalls the operating system and HP programs and drivers that were installed at the factory. Software not installed at the factory must be reinstalled.

To recover the original hard drive image using **F11**, follow these steps:

1. If possible, back up all personal files.
2. If possible, check for the presence of the HP Recovery partition. To find the partition, select **Start > Computer**.



NOTE: If the HP Recovery partition has been deleted, you must recover your operating system and programs using System Recovery discs that you can obtain from HP Support. For additional information, refer to the “Using a Windows Vista operating system DVD (purchased separately)” section in this guide.

3. Press the Power button to turn on the computer.
4. As soon as you see the initial company logo screen appear, repeatedly press the **F11** key on your keyboard until the **Windows is Loading Files...** message appears on the screen.
5. Under **I need help immediately**, tap **System Recovery**.
6. If you are prompted to back up your files, and you have not done so, tap **Back up your files first (recommended)**, and then tap **Next**. Otherwise, tap **Recover without backing up your files**, and then tap **Next**.
7. System Recovery begins. After System Recovery is complete, tap **Finish** to restart the computer.

Using a Windows Vista operating system DVD (purchased separately)

If you are unable to boot (start up) your computer, you must use System Recovery discs that you can obtain from HP Support to reboot the computer and repair the operating system. Make sure that your most recent backup (stored on discs or on an external drive) is easily accessible.



CAUTION: All files you have created and any software installed on the computer are permanently removed. When reformatting is complete, the recovery process helps you restore the operating system, as well as drivers, software, and utilities.

To initiate recovery using a Windows Vista operating system DVD, follow these steps:



NOTE: This process takes several minutes.

1. If possible, back up all personal files.
2. Restart the computer, and then insert the Windows Vista operating system DVD into the optical drive before the Windows operating system loads.
3. When prompted, press any keyboard key.
4. Follow the on-screen instructions.
5. Click **Next**.
6. Select **Repair your computer**.
7. Follow the on-screen instructions.

I Specifications

CMT Specifications

Table I-1 Specifications

Chassis		
Height	17.6 in	44.8 cm
Width	7.0 in	17.8 cm
Depth	18.0 in	44.5 cm
Approximate Weight	24.5 lb	11.2 kg
Weight Supported (maximum distributed load in desktop position)	77 lb	35 kg
Temperature Range		
Operating	50° to 95°F	10° to 35°C
Nonoperating	-22° to 140°F	-30° to 60°C
NOTE: Operating temperature is derated 1.0° C per 300 m (1000 ft) to 3000 m (10,000 ft) above sea level; no direct sustained sunlight. Maximum rate of change is 10° C/Hr. The upper limit may be limited by the type and number of options installed.		
Relative Humidity (noncondensing)		
Operating	10-90%	10-90%
Nonoperating (38.7°C max wet bulb)	5-95%	5-95%
Maximum Altitude (unpressurized)		
Operating	10,000 ft	3048 m
Nonoperating	30,000 ft	9144 m
Power Supply		
Operating Voltage Range	90-264 VAC	
Rated Voltage Range ¹	100-240 VAC	
Rated Line Frequency	50-60 Hz	
Operating Line Frequency	47-63 Hz	

Table I-1 Specifications (continued)

Standard Efficiency	320W
High Efficiency	320W active PFC; 87/90/87% efficient at 20/50/100% load
Rated Input Current	5.5A

¹ This system utilizes an active power factor corrected power supply. This allows the system to pass the CE mark requirements for use in the countries of the European Union. The active power factor corrected power supply also has the added benefit of not requiring an input voltage range select switch.

MT Specifications

Table I-2 Specifications

Chassis		
Height	14.9 in	37.7 cm
Width	7.0 in	17.7 cm
Depth	17.0 in	43.1 cm
Approximate Weight	20.5 lb	9.3 kg
Weight Supported (maximum distributed load in desktop position)	77 lb	35 kg
Temperature Range		
Operating	50° to 95°F	10° to 35°C
Nonoperating	-22° to 140°F	-30° to 60°C
NOTE: Operating temperature is derated 1.0° C per 300 m (1000 ft) to 3000 m (10,000 ft) above sea level; no direct sustained sunlight. Maximum rate of change is 10° C/Hr. The upper limit may be limited by the type and number of options installed.		
Relative Humidity (noncondensing)		
Operating	10-90%	10-90%
Nonoperating (38.7°C max wet bulb)	5-95%	5-95%
Maximum Altitude (unpressurized)		
Operating	10,000 ft	3048 m
Nonoperating	30,000 ft	9144 m
Power Supply		
Operating Voltage Range	90-264 VAC	
Rated Voltage Range ¹	100-240 VAC	
Rated Line Frequency	50-60 Hz	
Operating Line Frequency	47-63 Hz	
Standard Efficiency	320W	
High Efficiency	320W active PFC; 87/90/87% efficient at 20/50/100% load	

Table I-2 Specifications (continued)

Rated Input Current	5.5A
---------------------	------

¹ This system utilizes an active power factor corrected power supply. This allows the system to pass the CE mark requirements for use in the countries of the European Union. The active power factor corrected power supply also has the added benefit of not requiring an input voltage range select switch.

SFF Specifications

Table I-3 Specifications

Chassis (in the desktop position)		
Height	4.0 in	10.0 cm
Width	13.3 in	33.8 cm
Depth	14.9 in	37.9 cm
Approximate Weight	16.7 lb	7.6 kg
Weight Supported (maximum distributed load in desktop position)	77 lb	35 kg
Temperature Range		
Operating	50° to 95°F	10° to 35°C
Nonoperating	-22° to 140°F	-30° to 60°C
NOTE: Operating temperature is derated 1.0° C per 300 m (1000 ft) to 3000 m (10,000 ft) above sea level; no direct sustained sunlight. Maximum rate of change is 10° C/Hr. The upper limit may be limited by the type and number of options installed.		
Relative Humidity (noncondensing)		
Operating	10-90%	10-90%
Nonoperating (38.7°C max wet bulb)	5-95%	5-95%
Maximum Altitude (unpressurized)		
Operating	10,000 ft	3048 m
Nonoperating	30,000 ft	9144 m
Power Supply		
Operating Voltage Range	90-264 VAC	
Rated Voltage Range ¹	100-240 VAC	
Rated Line Frequency	50-60 Hz	
Operating Line Frequency	47-63 Hz	
Standard Efficiency	240W active PFC	
High Efficiency	240W active PFC; 87/90/87% efficient at 20/50/100% load	
Rated Input Current	4A	

¹ This system utilizes an active power factor corrected power supply. This allows the system to pass the CE mark requirements for use in the countries of the European Union. The active power factor corrected power supply also has the added benefit of not requiring an input voltage range select switch.

USDT Specifications

Table I-4 Specifications

Chassis		
Height	2.60 in	6.6 cm
Width	9.90 in	25.1 cm
Depth	10.00 in	25.4 cm
(depth will increase if the computer is equipped with a port security bracket)		
Approximate Weight	6.8 lb	3.1 kg
Weight Supported (maximum distributed load in desktop position)	77 lb	35 kg
Temperature Range (values subject to change with increasing altitude above sea level)		
Operating	50° to 95° F	10° to 35° C
Nonoperating	-22° to 140° F	-30° to 60° C
NOTE: Operating temperature is derated 1.0° C per 300 m (1,000 ft) to 3,000 m (10,000 ft) above sea level, no direct sustained sunlight. Maximum rate of change is 10° C (50° F)/Hr. The upper limit may be limited by the type and number of options installed.		
Relative Humidity (noncondensing)		
Operating (28° C (82.4° F) max wet bulb)	10-90%	10-90%
Nonoperating (38.7° C (101.66° F) max wet bulb)	5-95%	5-95%
Maximum Altitude (unpressurized)		
Operating	10,000 ft	3,048 m
Nonoperating	30,000 ft	9,144 m
Power Supply		
Operating Voltage Range	90-264 VAC	
Rated Voltage Range ¹	100-240 VAC	
Rated Line Frequency	50-60 Hz	
Operating Line Frequency	47-63 Hz	
Rated Input Current	N/A	

¹ This system utilizes an active power factor corrected external power supply. This allows the system to pass the CE mark requirements for use in the countries of the European Union. The active power factor corrected power supply also has the added benefit of not requiring an input voltage range select switch.

Index

A

AC adapter, USDT
 spare part number 38, 45
access panel
 CMT removal and replacement 74
 CMT spare part number 74
 MT removal 126
 MT spare part number 126
 SFF removal and replacement 166
 SFF spare part number 166
 USDT removal and replacement 207
 USDT spare part number 207
access panel, CMT
 spare part number 17
access panel, locked 263
access panel, MT
 spare part number 27, 37
access panel, SFF
 spare part number 48, 58
access panel, USDT
 spare part number 38, 47
adapter, DisplayPort to DVI
 spare part number 21, 32, 42, 53
adapter, DisplayPort to DVI (not illustrated)
 spare part number 19, 29, 39, 49
adapter, DisplayPort to HDMI
 spare part number 24, 35, 45, 56
adapter, DisplayPort to HDMI (not illustrated)
 spare part number 19, 29, 39, 49

adapter, DisplayPort to VGA
 spare part number 24, 35, 44, 55
adapter, DisplayPort to VGA (not illustrated)
 spare part number 19, 29, 39, 49
antenna, spare part number 19
audible codes 255
audio problems 280

B

backing up files 314, 318
Backup and Restore 314, 315
Backup and Restore Center 318, 319
battery
 disposal 66
battery replacement 241
beep codes 255
bezel blank
 spare part number 128
bezel blank, 3.5-inch
 spare part number 31, 34
bezel blank, 5.25-inch
 spare part number 31, 34
bezel blank, USDT
 spare part number 44
boot problems 295
booting options
 Full Boot 246
 Quick Boot 246

C

cable management 67
cable pinouts
 SATA data 67

card reader
 spare part number 30, 36, 50, 57
 USDT removal and replacement 224
 USDT spare part number 224
card reader, USDT
 spare part number 40, 44
cautions
 AC power 59
 cables 65
 cooling fan 64
 electrostatic discharge 60
 keyboard cleaning 64
 keyboard keys 64
CD-ROM or DVD problems 293
chassis types, illustrated 59
chassis fan, CMT
 spare part number 19, 26
clamp lock, spare part number 19, 21, 30, 32, 41, 42, 50, 53
cleaning
 computer 63
 mouse 64
 safety precautions 63
CMOS
 backing up 302
 clearing and resetting 304
CMT
 access panel removal and replacement 74
 access panel, spare part number 17
 chassis fan, spare part number 19, 26
 disassembly preparation 73
 fan shroud removal and replacement 106
 fan, spare part number 19, 26

- front bezel removal and replacement 75
- front bezel, spare part number 17
- front I/O assembly, spare part number 18
- front I/O device removal and replacement 107
- heat sink removal and replacement 112
- heat sink, spare part number 19, 26
- power supply removal and replacement 117
- power supply, spare part number 17
- power switch removal and replacement 109
- power switch/LED assembly, spare part number 18
- preparation for disassembly 73
- processor removal and replacement 114
- rear chassis fan removal and replacement 111
- SATA hard drive cable, spare part number 18
- SATA optical drive cable, spare part number 18
- speaker removal and replacement 110
- speaker, spare part number 19, 26
- system board removal and replacement 118
- system board, spare part number 17
- computer
 - changing from desktop to tower 238
 - specifications 325, 326
- computer cleaning 63
- connecting drive cables 87
- country power cord set requirements 245
- creating a backup 314, 318
- Customer Support 259, 301

D

- desktop conversion
 - CMT 120
- diagnostics utility 308
- DIMMs. *See* memory
- disassembly preparation
 - CMT 73
 - MT 125
 - SFF 165
 - USDT 206
- diskette problems 268
- DisplayPort cable
 - spare part number 21, 32, 42, 53
- DisplayPort cable (not illustrated)
 - spare part number 19, 29, 39, 49
- DMS-59 to dual VGA cable
 - spare part number 21, 32, 53
- DMS-59 to dual VGA cable (not illustrated)
 - spare part number 19, 29, 49
- Drive Protection System (DPS) 306
- drives
 - CMT cable connections 92
 - CMT installation 92
 - CMT locations 88
 - connecting cables 87
 - installing 87
 - MT cable connections 139
 - MT installation 139
 - MT locations 138
 - SFF cable connections 180
 - SFF installation 180
 - SFF locations 179

E

- electrostatic discharge (ESD) 60
 - preventing damage 60
- error
 - codes 246, 255
 - messages 247
- eSATA port (expansion), spare part number 21, 26, 32, 37, 52, 58, 172
- expansion card
 - CMT installation 83
 - CMT removal 83
 - MT installation 134

- MT removal 134
- SFF installation 172
- SFF removal 172
- expansion slot cover
 - CMT removal 84
 - MT removal 135
 - SFF removal 173

F

- F11 recovery 317, 320
- fan
 - CMT spare part number 111
 - MT spare part number 159
- fan (front), USDT
 - spare part number 41, 47
- fan (rear), USDT
 - spare part number 40
- fan duct
 - SFF removal and replacement 189
 - SFF spare part number 189
 - spare part number 37, 57
- fan duct, MT
 - spare part number 30
- fan duct, SFF
 - spare part number 50
- fan sink
 - CMT removal and replacement 112
 - CMT spare part number 112
- fan with guard, MT
 - spare part number 30, 34
- fan with guard, USDT
 - spare part number 44
- fan, CMT
 - spare part number 19, 26
- fan, MT
 - spare part number 30, 37
- fan, power supply 64
- fan, SFF
 - spare part number 50, 58
- fan/baffle assembly
 - MT removal and replacement 149
- FireWire card, spare part number 21, 26, 32, 37, 52, 57, 172
- flash drive problems 295
- flashing LEDs 255

- front bezel
 - CMT removal and replacement 75
 - CMT security 76
 - CMT spare part number 75
 - MT blank removal 128
 - MT removal 127
 - MT spare part number 127
 - removing blanks 77, 168, 209
 - SFF removal and replacement 167
 - SFF spare part number 167
 - USDT removal and replacement 208
 - USDT spare part number 208
- front bezel, CMT
 - spare part number 17
- front bezel, MT
 - spare part number 27, 37
- front bezel, SFF
 - spare part number 48, 58
- front bezel, USDT
 - spare part number 39, 47
- front fan
 - SFF removal and replacement 190
 - SFF spare part number 190
 - USDT removal and replacement 215
 - USDT spare part number 215
- front fan assembly
 - MT spare part number 149
- front I/O and power switch assembly
 - SFF spare part number 193
- front I/O and USB assembly
 - CMT spare part number 107
- front I/O assembly
 - MT spare part number 151
- front I/O assembly, CMT
 - spare part number 18
- front I/O assembly, MT
 - spare part number 27, 29, 37
- front I/O assembly, SFF
 - spare part number 49, 57
- front I/O device
 - CMT removal and replacement 107
- front I/O panel, USDT
 - spare part number 40, 44
- front I/O, power switch assembly
 - SFF removal and replacement 193
- front panel problems 297
- front USB panel
 - MT removal and replacement 151
- G**
 - general problems 262
 - graphics card, spare part number 21, 26, 31, 37, 52, 58, 172
 - grounding methods 61
 - guide screws 87
 - CMT location 92
 - MT location 140
 - SFF location 180
- H**
 - hard drive
 - CMT installation 95
 - CMT removal 89
 - installing 100
 - MT installation 145
 - MT removal 144
 - proper handling 65
 - SATA characteristics 67
 - SFF installation 186
 - SFF removal 186
 - spare part number 26, 36, 46, 57
 - spare part numbers 20, 26, 27, 31, 37, 38, 41, 51, 57, 58
 - USDT installation 219
 - USDT removal 219
 - hard drive conversion bracket, spare part number 19, 21, 30, 32
 - hard drive problems 271
 - hard drive recovery 317, 320
 - hard drive, USDT
 - spare part number 219
 - hardware installation problems 286
 - heat sink
 - MT removal and replacement 153
 - MT spare part number 153
 - SFF removal and replacement 196
 - SFF spare part number 196
 - USDT removal and replacement 227
 - USDT spare part number 227
- heat sink, CMT
 - spare part number 19, 26
- heat sink, MT
 - spare part number 30, 37
- heat sink, SFF
 - spare part number 50, 58
- heat sink, USDT
 - spare part number 40, 44
- helpful hints 260
- hood sensor
 - CMT removal and replacement 106
 - SFF removal and replacement 192
 - SFF spare part number 192
 - spare part number 19, 26, 30, 37, 41, 46, 50, 58, 106
 - USDT removal and replacement 233
 - USDT spare part number 233
- I**
 - installing
 - battery 241
 - CMT drive cables 92
 - CMT expansion card 83
 - CMT hard drive 95
 - CMT media card reader 93
 - CMT memory 79
 - CMT optical drive 93
 - drive cables 87
 - guide screws 87
 - hard drive 100
 - MT drive cables 139
 - MT expansion card 134
 - MT hard drive 145
 - MT media card reader 142
 - MT memory 131
 - MT optical drive 142
 - removable hard drive 101
 - SFF drive cables 180
 - SFF expansion card 172
 - SFF hard drive 186
 - SFF media card reader 184

- SFF memory 168
- SFF optical drive 182
- USDT hard drive 219
- USDT memory 211
- USDT optical drive 218
- Internet access problems 297

K

- keyboard
 - cleaning 63
 - spare part numbers 20, 21, 22, 23, 24, 25, 30, 32, 33, 34, 35, 36, 41, 42, 43, 44, 45, 50, 53, 54, 55, 56
- keyboard problems 284

L

- LEDs
 - blinking power 255
 - blinking PS/2 keyboard 255
- locks
 - CMT front bezel 76

M

- media card reader
 - CMT installation 93
 - CMT removal 89
 - MT installation 142
 - MT removal 141
 - SFF installation 184
 - SFF removal 183
- Media Card Reader problems 274
- memory
 - CMT installation 79
 - CMT socket population 80
 - CMT specifications 79
 - MT installation 131
 - MT socket population 132
 - MT specifications 131
 - SFF installation 168
 - SFF socket population 169
 - SFF specifications 169
 - USDT installation 211
 - USDT socket population 212
 - USDT specifications 211
- memory module
 - spare part number 79, 131, 168
- memory module, USDT
 - spare part number 211

- memory modules
 - spare part number 18, 24, 26, 28, 34, 36, 39, 48, 55, 57
- memory modules, USDT
 - spare part number 47
- memory problems 291
- monitor problems 276
- mouse
 - cleaning 64
 - spare part numbers 20, 30, 41, 51
- mouse problems 284
- MT
 - access panel, spare part number 27, 37
 - disassembly preparation 125
 - fan duct, spare part number 30
 - fan with guard, spare part number 30, 34
 - fan, spare part number 30, 37
 - fan/baffle assembly removal and replacement 149
 - front bezel, spare part number 27, 37
 - front I/O assembly, spare part number 27, 29, 37
 - front USB panel removal and replacement 151
 - heat sink removal and replacement 153
 - heat sink, spare part number 30, 37
 - optical drive cable/connector, spare part number 44
 - power supply removal and replacement 161
 - power supply, spare part number 17, 24, 28, 35
 - power switch/LED assembly removal and replacement 152
 - power switch/LED assembly, spare part number 27, 29, 38
 - preparation for disassembly 125
 - processor removal and replacement 155

- rear chassis fan removal and replacement 159
- SATA cable, spare part number 26, 29, 37
- SATA hard drive cable, spare part number 27, 29, 38
- SATA optical drive cable, spare part number 27, 29, 38
- speaker removal and replacement 158
- speaker, spare part number 19, 26, 30, 37
- system board removal and replacement 163
- system board, spare part number 24, 27, 28, 35, 38

N

- network problems 287
- NIC, spare part number 21, 26, 36, 57, 172
- numeric error codes 247

O

- operating guidelines 62
- optical drive
 - CMT installation 93
 - CMT removal 89
 - MT installation 142
 - MT removal 141
 - SFF installation 182
 - SFF removal 181
 - spare part numbers 20, 24, 31, 34, 35, 41, 44, 47, 51, 55, 56
 - USDT installation 218
 - USDT release latch attachment 217
 - USDT removal 216
- optical drive cable/connector, USDT
 - spare part number 39, 44
- optical drive problems 293
- optical drive rail
 - USDT removal and replacement 223
- optical drive rail and cable kit, USDT
 - spare part number 44

- optical drive rail kit
 - USDT spare part number 223
- optical drive rail, USDT
 - spare part number 41
- optical drive, USDT
 - spare part number 216
- overheating, prevention 62

P

- password
 - clearing 302
 - power-on 302
 - setup 302
- port cover
 - USDT spare part number 239
- POST error messages 246
- power cord set requirements
 - country specific 245
- power problems 266
- power supply
 - CMT removal and replacement 117
 - CMT spare part number 117
 - fan 64
 - MT removal and replacement 161
 - MT spare part number 161
 - operating voltage range 322, 323, 325, 326
 - SFF removal and replacement 201
- power supply, MT
 - spare part number 24, 28, 35
- power supply, MT, CMT
 - spare part number 17
- power supply, SFF
 - spare part number 48, 56
- power switch
 - CMT removal and replacement 109
- power switch/LED assembly
 - CMT spare part number 109
 - MT removal and replacement 152
 - MT spare part number 152
- power switch/LED assembly, CMT
 - spare part number 18
- power switch/LED assembly, MT
 - spare part number 27, 29, 38
- power-on password 302

- printer port (expansion), spare part number 21, 26, 32, 37, 52, 58, 172
- printer problems 282
- problems
 - audio 280
 - CD-ROM or DVD 293
 - diskette 268
 - flash drive 295
 - front panel 297
 - general 262
 - hard drive 271
 - hardware installation 286
 - Internet access 297
 - keyboard 284
 - Media Card Reader 274
 - memory 291
 - monitor 276
 - mouse 284
 - network 287
 - power 266
 - printer 282
 - processor 292
 - software 300
- processor
 - CMT removal and replacement 114
 - MT removal and replacement 155
 - SFF removal and replacement 198
 - spare part number 18, 26, 28, 37, 39, 46, 48, 57
 - USDT removal and replacement 229
- processor problems 292
- product ID locations 71

R

- rear chassis fan
 - CMT removal and replacement 111
 - CMT spare part number 111
 - MT removal and replacement 159
 - MT spare part number 159
- rear fan
 - USDT removal and replacement 236
 - USDT spare part number 236

- rear port cover, USDT
 - spare part number 41, 47
- recovering information 316, 319
- recovery partition 317, 320
- removable hard drive
 - replacing 101
- removal and replacement
 - CMT access panel 74
 - CMT fan sink 112
 - CMT front bezel 75
 - CMT front I/O device 107
 - CMT hood sensor 106
 - CMT power supply 117
 - CMT power switch 109
 - CMT processor 114
 - CMT rear chassis fan 111
 - CMT speaker 110
 - CMT system board 118
 - MT fan/baffle assembly 149
 - MT front USB panel 151
 - MT heat sink 153
 - MT power supply 161
 - MT power switch/LED assembly 152
 - MT processor 155
 - MT rear chassis fan 159
 - MT speaker 158
 - MT system board 163
 - SFF fan duct 189
 - SFF front bezel 166, 167
 - SFF front fan 190
 - SFF front I/O, power switch assembly 193
 - SFF heat sink 196
 - SFF hood sensor 192
 - SFF power supply 201
 - SFF processor 198
 - SFF speaker 195
 - SFF system board 203
 - USDT access panel 207
 - USDT card reader 224
 - USDT front bezel 208
 - USDT front fan 215
 - USDT heat sink 227
 - USDT hood sensor 233
 - USDT optical drive rail 223
 - USDT processor 229
 - USDT rear fan 236
 - USDT speaker 226
 - USDT system board 234

- USDT TV tuner module 232
- USDT WLAN tuner module 232
- removing
 - battery 241
 - bezel blanks 168, 209
 - CMT bezel blanks 77
 - CMT drives 89
 - CMT expansion card 83
 - CMT expansion slot cover 84
 - CMT media card reader 89
 - MT bezel blanks 128
 - MT computer access panel 126
 - MT expansion card 134
 - MT expansion slot cover 135
 - MT front bezel 127
 - MT hard drive 144
 - MT media card reader 141
 - MT optical drive 141
 - SFF expansion card 172
 - SFF expansion slot cover 173
 - SFF hard drive 186
 - SFF media card reader 183
 - SFF optical drive 181
 - USDT hard drive 219
 - USDT optical drive 216
- resetting
 - CMOS 302
 - password jumper 302
- restoring the hard drive 317, 320

S

- safety and comfort 259
- safety precautions
 - cleaning 63
- SATA
 - connectors on system board 67
 - data cable pinouts 67
 - hard drive characteristics 67
- SATA cable
 - spare part number 19
- SATA cable, MT
 - spare part number 26, 29, 37
- SATA cable, SFF
 - spare part number 49, 58
- SATA drive cable, SFF
 - spare part number 49, 57

- SATA hard drive cable, CMT
 - spare part number 18
- SATA hard drive cable, MT
 - spare part number 27, 29, 38
- SATA optical drive cable, CMT
 - spare part number 18
- SATA optical drive cable, MT
 - spare part number 27, 29, 38
- screws, correct size 65
- security
 - CMT front bezel 76
- serial number locations 71
- serial port (expansion), spare part number 21, 26, 32, 37, 52, 58, 172
- service considerations 64
- setup password 302
- SFF
 - access panel, spare part number 48, 58
 - disassembly preparation 165
 - fan duct removal and replacement 189
 - fan duct, spare part number 50
 - fan, spare part number 50, 58
 - front bezel removal and replacement 166, 167
 - front bezel, spare part number 48, 58
 - front fan removal and replacement 190
 - front I/O assembly, spare part number 49, 57
 - front I/O, power switch assembly removal and replacement 193
 - heat sink removal and replacement 196
 - heat sink, spare part number 50, 58
 - hood sensor removal and replacement 192
 - power supply removal and replacement 201
 - power supply, spare part number 48, 56
 - preparation for disassembly 165

- processor removal and replacement 198
- SATA cable, spare part number 49, 58
- SATA drive cable, spare part number 49, 57
- speaker removal and replacement 195
- speaker, spare part number 50, 57
- system board removal and replacement 203
- system board, spare part number 45, 48, 55, 56, 58
- software
 - backing up 313
 - problems 300
 - servicing computer 65
- solenoid lock
 - spare part number 19, 26, 30, 37, 50, 58
- solid-state drive, spare part number 20, 24, 26, 31, 35, 37, 41, 44, 47, 51, 55, 58
- spare part number
 - tamper-resistant wrench 65
 - Torx T-15 screwdriver 65
- speaker
 - CMT removal and replacement 110
 - CMT spare part number 110
 - MT removal and replacement 158
 - MT spare part number 158
 - SFF removal and replacement 195
 - SFF spare part number 195
 - USDT removal and replacement 226
 - USDT spare part number 226
- speaker, CMT, MT
 - spare part number 19, 26
- speaker, MT
 - spare part number 30, 37
- speaker, SFF
 - spare part number 50, 57
- speaker, USDT
 - spare part number 40, 47
- specifications
 - CMT memory 79

- computer 322, 325, 326
- MT memory 131
- SFF memory 169
- USDT memory 211
- stand, USDT
 - spare part number 45
- static electricity 60
- system board
 - CMT removal and replacement 118
 - CMT spare part number 118
 - MT removal and replacement 163
 - MT spare part number 163, 203
 - SATA connectors 67
 - SFF removal and replacement 203
 - SFF spare part number 203
 - USDT removal and replacement 234
 - USDT spare part number 234
- system board connections
 - MT 128
 - SFF 176
 - USDT 210
- system board, CMT
 - spare part number 17
- system board, MT
 - spare part number 24, 27, 28, 35, 38
- system board, SFF
 - spare part number 45, 48, 55, 56, 58
- system board, USDT
 - spare part number 38, 47

T

- tamper-proof screws
 - tool 65
- temperature control 62
- tools, servicing 65
- Torx T15 screwdriver 65
- tower configuration 238
- tower conversion
 - CMT 122
- tower orientation 205
- TV tuner module
 - USDT removal and replacement 232

- TV tuner, spare part number 42, 45

U

- USB 3.0 port (expansion), spare part number 21, 24, 32, 35, 52, 56, 172
- USB powered speakers, spare part number 19, 26, 30, 37, 41, 46, 50, 57
- USDT
 - AC adapter, spare part number 38, 45
 - access panel removal and replacement 207
 - access panel, spare part number 38, 47
 - card reader removal and replacement 224
 - card reader, spare part number 40, 44
 - disassembly preparation 206
 - fan (front), spare part number 41, 47
 - fan (rear), spare part number 40
 - fan with guard, spare part number 44
 - front bezel removal and replacement 208
 - front bezel, spare part number 39, 47
 - front fan removal and replacement 215
 - front I/O panel, spare part number 40, 44
 - heat sink removal and replacement 227
 - heat sink, spare part number 40, 44
 - hood sensor removal and replacement 233
 - optical drive cable/connector, spare part number 39
 - optical drive rail and cable kit, spare part number 44
 - optical drive rail removal and replacement 223
 - optical drive rail, spare part number 41

- preparation for disassembly 206
- processor removal and replacement 229
- rear fan removal and replacement 236
- rear port cover, spare part number 41, 47
- speaker removal and replacement 226
- speaker, spare part number 40, 47
- stand, spare part number 45
- system board removal and replacement 234
- system board, spare part number 38, 47
- TV tuner module removal and replacement 232
- WLAN module removal and replacement 232

V

- ventilation, proper 62
- Vision Diagnostics 308

W

- Wake-on-LAN feature 288
- Windows 7 operating system
 - DVD 317
- Windows Vista operating system
 - DVD 321
- WLAN module
 - USDT removal and replacement 232
 - USDT spare part number 232