REGULATED DC POWER SUPPLY MODELS 6259B, 6260B, 6261B, 6268B, 6269B

* OPERATING AND SERVICE MANUAL FOR MODEL 6259B, SERIALS 1535A-00651 AND ABOVE MODEL 6260B, SERIALS 1545A-01026 AND ABOVE MODEL 6261B, SERIALS 1543A-00551 AND ABOVE MODEL 6268B, SERIALS 1539A-01481 AND ABOVE MODEL 6269B, SERIALS 1535A-01631 AND ABOVE

> For instruments with serial numbers above those listed, a change page may be included.

HP Part No. 5950-1766

Printed: March, 1976

MANUAL CHANGES Models 6259B, 6260B, 6261B, 6268B, 6269B Manual HP Part No. 5950-1766

Make all corrections in the manual according to errata below, then check the following table for your power supply serial number and enter any listed change(s) in the manual.

		SERIAL	MAKE	MODEL	SERIAL		MAKE
MODEL	Prefix .	Number	CHANGES	MODEL	Prefix	Number	CHANGES
6259B	1717A	00771-00875	2,3		2037A	01981-02120	1-3,5-9,
02000	1839A	00876-01055	2,3,5				11,12
	1937A	01056-01195	2,3,5,6		2302A	02121-02140	1-3,5-9,
	2035A	01196-01215	2,3,5,6,8			00000	11-13,15
	2039A	01216-01385	2,3,5,6,8,		2309A	02141 -02200	1-3,5-9,
			Þ				11-13,154
	2039A	01386-01465	2,3,5,6,8,		000501	02201-110	1-2 5-0
			9,11		2325A	02201-up	1-3,5-9
	2039A	01466-01625	2,3,5,6,8,				11-15,15-
			9,11,12				11
,	2301A	01626 -01735	2,3,5,6,8,				
			p,11-13,15	6268B	1713A	02081-02120	2
	23252	01736-110	2.3.5.6.8		1721A	02121-02670	2,3
	ZJZJA	orige ap	9.11-13.		1332A	02671-03250	2,3,5
			15, 17		1930A	03251-03990	2,3,5,6
			1	•	2034A	03991-04150	2,3,5,6,8
					2043A	04151-C4900	2,3,5,6,8,
	17175	01076 01200	2.2				Ð
6260B	1713A	01276-01300	2,3		2043A	04901-05150	2,3,5,6,8,
	1/13A	01301-01665	2-4				P,11
	1838A	01666-02095	2-5		2043A	05151-05675	2,3,5,6,8,
	1933A	02096-02445	2-6.8				9,11,12
	2031A	02446-02495	2-6,8 9		2249A	05676 - 05850	2,3,5;6,8,
	2035A	02756-02005	0-6 8 9 11				2,11,12,14
	2035A	02756-02505	2-6.8.9.			05051 06050	13 5 6 6
	20354	02500-05170	11.12		2309A	03831-06030	9 11, 12, 13
	22492	03171-3195 .	2-6.8.9.				15.16
	22430	05171 5155	11-14		2324A ·	06051-up	2,3,5,6,0,
	2251A	03196 -03570	2-6.8.9.				9,11,12,13
		00100 000.01	11-15				15,16,17
	2326A	03571-up	2-6.8.9	6269B	1715A	02351-03230	2,3
		obbit up (11-15.17		1830A	03231-04340	2,3,5
					1936A	04341-05670	2,3,5,6
					2033A	05671-05820	2,3,5,6,8
					2038A	05820-07020	2,3,5,0,0-
6261B	1624A	00626-00745			20202	07021-07470	6.3.5.6.8-
	1714A	00746-01015	1-3		2038A	0/021-0/4/0	61
	1833A	01016-01265	1-3,5		20385	07471-08445	6.3.5.6.8-
	1934A	01266-01410	1-3,5,6		20304		12
	2006A	01411-01560	1-3,5-7		2250A	08446 -08975	6.3,5.6,8-
	2034A	01561-01590	1-3,5-8				1315
	2037A	01591-01830	1-3,5-9		2323A	08976-up	2,3,5,6,
	2037A	01831-01980	1-3, 5-9, 12	1			3-13,15,17

. .

•

MANUAL CHANGES/Models 6259B, 6260B, 6261B, 6268B, 6269B Manual HP Part No. 5950-1766 Page -2-

ERRATA:

On page 6-11, change the voltage rating listed for Cl9 in Models 6268B and 6269B to 50 volts.

On page 6-15 under Option 022, the first line in the reference designation column should read: AlR1,21.

Under Chassis-Mechanical on page 6-13, add the part number of the 3/8 inch 1/4-20 screws that connect load wires to the output busbars. The part number is 2940-0197.

Effective January 1, 1977, Option 007(10turn voltage control) and 008(10-turn current control) are no longer available individually, but they are still available combined as Option 009. Likewise, Options 013(10-turn voltage control with decadial) and 014(10-turn current control with decadial) are no longer available individually, is added as shown in Figure 2-1. gle new option designated Option 015. Options 020 and 021 (voltage and current available individually, but they are still available combined as Option 022. Make these changes wherever Option 007, 008, 013, 014, 020, or 021 is mentioned in the manual.

Change the part number of pilot light DS1 to 1450-0566.

In Figure 3-9, voltage source E_S is drawn with incorrect polarity. The positive end of the voltage source should be connected to the +S terminal.

In Table 1-1, change the output impedence specification for Model 6261B to 0.1mΩ. Also, add this sentence under Input Power Connections: No line cord is provided. Also add the following note under Drift (Stability): The drift specification for this power supply is realized using a low temperature coefficient programming resistance. If the output is set via the front panel controls, the drift may be ten times the indicated value.

On page 5-7, paragraph 5-42, change Step e to read as follows: Short out load resistor (Ry) by closing switch Sl. (Shorting out Ry activates a short circuit protection circuit within the supply, reducing the output current to near zero for about seven seconds.

In the reference designation column on page 6-11, change the line following B2 to read: 6260B,-61B,-68B.

In Table 6-4 on page 6-10, change the HP Part No. of A5DS2 to 1450-0566.

On page 6-11, under A2 RFI Filter Assy, change PC board mounting standoff to HP Part No. 0380-1197, gty 4. Change cover standoff to HP Part No. 0380-1046, gty 4.

On page 6-12, under A4 Heatsink Assy, reverse the HP part numbers for the left and right end fan mounting brackets.

CHANGE 1:

Make the following changes in the parts list and the schematic table for the 6261B only: Change R77 to 249k, HP Part No. 0757-0270. Change R78 to 160k, HP Part No. 0698-5092.

CHANGE 2:

Make the following changes to the preregulator control circuit of all five models: a) Capacitor C92(elect. 15uF, 50V, 0180-1634) but they are available combined into a sin- b) C93(polyester, 0.0luF, 200V, 0160-0161) is added to the base circuit of Q72; see Fig. 2-1. c) Diode CR 75 in the Q72 base circuit has programming adjustments) are also no longer been deleted and is replaced with a 6.2k, 5%, 1/2W resistor (0686-6225) as shown in Fig. 2-1. d) C94 and C95 are added across the secondary of A3T2 as shown in Fig 2-2. Both are C.O5uF, 400V, ceramic, HP Part No. 0150-0052. Make these changes to the parts list and the schematic.



FIG 2-1 (SEE CHANGE 2)

CHANGE 3:

In the parts list on page 6-13, change the part number of the cover, ac input barrier block HF P/N 5000-6249 to 5060-2741.

MANUAL CHANGES/ MOUCES 02000, 02000, 02010, 6268B, 6269B Manual HP Part No. 5950-1766 Page -3-



FIG. 2-2 (SEE CHANGE 2)

CHANGE 4:

In Model 6260B only, change resistor AlR21 in the preregulator control circuit back to a diode (HP Part No. 1901-0033) designated CR75 as before, and connect it as it was connected prior to Change 2. CR75 is installed in the R121 pads on the board with its cathode physically oriented toward C93. See Figure 7-8 in the manual and Figure 2-1 on the change page.

CHANGE 5:

In the parts list, delete cover, ac barrier block, HP P/N 5060-2741, and add assembly strain relief, HP P/N 5060-2744.

CHANGE 6:

In the parts list on page 6-11 under Al clamp, HP Part No. 1400-0321, and add cable sion HP P/N 5020-2648, gty.l. tie, HP Part No. 1400-0493.

CHANGE 7:

On page 6-5, change the HP Part No. of CR40 to 1901-0701. On page 6-6 and on Figure 7-8, change R40 to 1.6k2, HP Part No. 0686-1625 and change R45 to 5102, HP Part No. 0686-5115.

CHANGE 8:

Change resistor AlR66 to 100k, 5%, 1/2W, HP Part No. 0686-1045 on all models.

CHANGE 9:

In the replaceable parts list, page 6-9, change Bl fan to HP Part No. 3160-0369.

CHANGE 10:

In the replaceable parts list, page 6-11, change B2 fan to HP Part No. 3160-0369

CHANGE 11:

In the replaceable parts list, page 6-12. under A4 Heatsink Assy.-Mechanical, delete plastic support rods, qty 4, HP Part No. 0380-0901 and add the following parts: screw-machine, qty 4, HP Part No. 2360-0477 and tube-insulation, qty 4, HP Part No. 0890-1449.

CHANGE 12:

In the replaceable parts list, page 6-12. under A4 Heatsink Assy, change the flat nylon spacing washers to qty 4 and add Insulator, HP Part No. 5000-3190, qty 1. The insulator replaces the nylon washers.

CHANGE 13:

In the parts list on page 6-10 under A5 Front Panel Assy, delete capacitors Cl10-112. On page 6-11 under Chassis-Electrical, add capacitors Cll0-112, .OluF, 250Vac, HP Part No. 0360-0270.

CHANGE 14:

In the replaceable parts list, on page 6-11, under Chassis - Electrical, change B2 HP P/N 3160-0209 to HP P/N 3160-0273.

CHANGE 15:

On page 1-1, paragraph 1-6, change the last sentence to read... "the supply's output may be floated at up to 120 volts above ground.

On page 3-3, paragraph 3-19 change the last sentence to read the following: "This supply can be operated up to 120 volts above ground if neither output terminal is grounded.

Add to the replaceable parts list on page Main PC Board-Mechanical, delete capacitor 6-13 under Chassis-Mechanical, guard extru-

ERRATA:

The drift specfication for this power supply is oriented towards the systems designer and therefore based on remote programming. The specification is realizing a low temperatur coefficient (<10ppm/°C) programming resistance. If the output is set via the front panel controls, the drift may be ten times indicated value.

CHANGE 16:

This change pertains only to models 6268B and 6261B. In the replace:ble parts list, page 6-11, change Fan B2 to HP P/N 3160-0273.

6268B, 6269B Manual HP P/N 5950-1766 Page 4

1

CHANGE 17:

Add Bushing (rubber) HP P/N 1251-6532 Qty. 1. to the Strain Relief Assembly HP P/N 5060-2744 added in change 5.

On the Strain Relief Installation Instructions (provided with each power supply) Bushing (rubber) should be listed as Item #10. Also, change step #2 to read as follows: Route the cable lugs through the rubber bushing then up to the lower connection screws and connect them.

ERRATA:

In the replaceable parts list, page 6-11, under Al Main PC Board-Mechanical, change barrier strip, 13 terminal to HP Part No. 0360-2175.

9/12/83

TABLE OF CONTENTS

Section		Page
1	GE	NERAL INFORMATION 1-1
	1-1	DESCRIPTION 1-1
	1-8	SPECIFICATIONS 1-1
	1-10	OPTIONS 1-2
	1.12	INSTRUMENT/MANUAL
		IDENTIFICATION 1-2
	1-15	ORDERING ADDITIONAL
		MANUALS
н	INS	TALLATION 2.1
	2.1	INITIAL INSPECTION
	2.3	Mechanical Check 2-1
	2.5	Electrical Check 2-1
	2.7	INSTALLATION DATA 2.1
	2.9	Location and Cooling 2-1
	2.11	Outline Diagram 2-1
	2.13	Back Mounting 2-1
	2-15	INPUT POWER
		REQUIREMENTS 2.1
	2.17	INPUT LINE VOLTAGE OR
		FREQUENCY CONVERSION 2-2
	2.20	Converting a Standard Instrument
		to 208-Volt Operation (Models
		6259B, 6261B, and 6268B), 2-2
	2.22	Converting a Standard Instrument
		to 208-Volt Operation (Models
		6260B and 6269B)
	2.24	Converting a Standard Instrument
		to 115-Volt Operation (Models
		6259B, 6261B, and 6268B), 2.2
	2.26	Converting a Standard Instrument
		to 115-Volt Operation (Model
		6260B) 2-3
	2.28	Converting a Standard Instrument
		to 50Hz Operation
	2.30	INPUT POWER CONNECTIONS . 2-3
	2.32	REPACKAGING FOR
		SHIPMENT
ш	OPE	BATING INSTRUCTIONS 3.1
	3.1	TUBN-ON CHECKOUT
		PROCEDURE 3.1
	3.3	OPERATING MODES 3.2
	3-6	NORMAL OPERATING MODE 3.2
	3-8	Constant Voltage Operation 3.2
	3.10	Constant Current Operation 2.2
	3-12	Overvoltage Trip Point
		Adjustment

Section		Page
111	3-15	Connecting The Load
(con't.)	3.20	Operation With No Load 3-3
	3.22	Operation Beyond Rated
		Output
	3-24	OPTIONAL OPERATING
		MODES
	3-27	Remote Voltage Sensing 3-3
	3-34	Remote Programming 3-5
	3-51	Auto-Parallel Operation 3-8
	3-57	Auto-Series Operation
	3-67	Auto-Tracking Operation 3-10
	3-76	SPECIAL OPERATING
		CONSIDERATIONS 3.12
	3-77	Pulse Loading
	3-79	Output Capacitance
	3-82	Reverse Voltage Protection 3-12
	3-85	Reverse Current Loading 3-12
	3-87	Battery Charging
	3-91	Battery Discharging
IV	PRIN	NCIPLES OF OPERATION 4-1
	4-1	OVERALL BLOCK
		DIAGRAM DISCUSSION 4-1
	4-16	DETAILED CIRCUIT
		ANALYSIS
	4-17	Preregulator Control Circuit 4-3
	4.27	Overvoltage Limit Circuit 4-4
	4-29	Series Regulator and Driver 4-4
	4-31	Short-Circuit Protection 4-4
	4-33	Constant-Voltage Comparator 4-4
	4-40	Constant-Current Comparator 4-5
	4-45	Voltage Clamp Circuit 4-6
	4-48	Mixer and Error Amplifiers 4-6
	4-52	Overvoltage Protection Crowbar 4-6
	4-58	Turn-On Control Circuit 4-7
	4-61	Reference Regulator 4-7
	4-66	Meter Circuit
	4-70	Additional Protection Features 4-7
v		
v		
	5-1	
	5.3	
	5-5	PERFORMANCE LEST
	5-/	CONSTANT OUDDENT TECTO
	5-38	TROUBLESHOOTING
	5-49	INOURLESHOOTING 5-8

TABLE OF CONTENTS (Continued)

	Page
5-54	OVERALL TROUBLE-
	SHOOTING PROCEDURES 5-8
5-60	Disassembly Procedures 5-15
5-69	REPAIR AND REPLACEMENT . 5-16
5.71	ADJUSTMENT AND
	CALIBRATION
5-73	Meter Zero Adjustment 5-16
5-75	Voltmeter Calibration 5-16
5.77	Ammeter Calibration
5-79	Constant-Voltage Programming
	Calibration 5-17
5-89	Constant-Current Programming
	Calibration
5-98	Load Transient Recovery Time
	Adjustment
	5-54 5-60 5-69 5-71 5-73 5-75 5-77 5-79 5-89 5-98

Section				Page
v	5-100	Ripple Balance Adjustment .		5-19
(con't.)	5-102	Preregulator Tracking Adjustment		5-20
	5-104	Crowbar Trip Voltage		5 20 4
	5-106	Maximum Crowbar Trip	•••	5-20 7
		Voltage Adjustment	••	5-20
	5-108	Disabling the Crowbar	••	5-20
VI	REPL	ACEABLE PARTS	••	6-1
VII	CIRC	UIT DIAGRAM AND		
	CO	MPONENT LOCATION		
	DI	AGRAMS		7-1

SECTION I GENERAL INFORMATION

1-1 DESCRIPTION

1-2 The five constant-voltage/constant current power supply models included in this manual use a transistor series-regulator combined with a triac preregulator for high efficiency, excellent regulation, and low ripple and noise. These supplies are packaged in 7-inch high full-rack-width cabinets that are suitable for either bench or relay rack operation.

1.3 The outputs of these supplies can be varied from zero to full rated voltage or current by setting coarse and fine voltage and current controls on the front panel or they can be programmed remotely by resistance or voltage inputs to rear panel terminals. When the voltage controls are used to establish a constant output voltage, the current controls establish a current limit that can protect the load from overcurrent. When the current controls are used to establish a constant output current, the voltage controls establish a voltage limit that can protect the load from excessive voltage. The crossover from constant-voltage to constantcurrent operation, or vice versa, occurs automatically when the load current reaches the value established by the current controls or the voltage reaches the value established by the voltage controls. The output voltage and current can both be monitored continuously on front panel meters.

1-4 Output loads are further protected by a built-in fast-acting overvoltage protection crowbar circuit that automatically shorts the supply's output terminals if a preset voltage limit is exceeded. A front panel control sets the voltage at which the crowbar trips and can be adjusted from approximately 10% to 110% of the supply's maximum rated voltage. When several supplies are installed in the same system, whether in series, parallel, or independently, their crowbar circuits can be interconnected so that all will trip simultaneously whenever any one of them does.

1-5 These power supplies are forced air cooled.

1-6 The ac input connections to these supplies are made at rear panel terminals. All dc output, remote sensing, and remote programming connections are also made at rear panel terminals. Either the positive or negative output terminal of a supply may be grounded or the supply's output may be floated at up to 300 volts above ground.

1-7 Remote programming, remote sensing, and several

methods of operating supplies in combination of two or three are made possible by rear panel terminals that allow access to control points within the regulator circuits. These capabilities are described below.

a. <u>Remote Programming</u>. The power supply's output voltage or current (or both) can be controlled from a remote location by varying a resistance or a voltage input signal to the supply's voltage or current regulator circuit.

b. <u>Remote Sensing</u>. Connecting the voltage regulator's feedback circuit to the load terminals rather than to the supply's output terminals prevents the voltage drop in the load leads from impairing voltage regulation at the load when operating in the constant voltage mode. A separate pair of sensing leads which carry no load current extend the feedback loop to the load terminals.

c. <u>Auto-Parallel Operation</u>. Two or three similar supplies connected in parallel can be made to share loads equally and can be controlled by the voltage and current controls (or remote programming terminals) of one of the supplies designated the master if they are connected for auto-parallel operation. Normally, only supplies having the same model number are connected in auto-parallel, but auto-parallel operation can be used with any of the supplies covered by this manual that have equal current capabilities.

d. <u>Auto-Series Operation</u>. Two or three supplies can be connected in series and have their outputs simultaneously controlled by the voltage and current controls (or remote programming terminals) of one of the supplies designated the master. The voltage contributed by each slave is maintained in a constant ratio to that of the master. These ratios can be set as desired. Auto-series operation provides higher output voltages in constant voltage operation and greater voltage compliance in constant current operation. Any HP supply that offers auto-series operation can serve as a slave supply; the master supply does not have to be an auto-series model.

e. <u>Auto-Tracking Operation</u>. Auto-tracking is similar to auto-series operation except that two or three supplies share a common negative output bus and are interconnected so that the output voltage of each slave supply is maintained at some constant fraction of that of the master supply. All of the supplies are controlled through the master supply, and each supply feeds a separate load.

1-8 SPECIFICATIONS

1-9 Detailed specifications for these power supplies are given in Table 1-1.

1-10 OPTIONS

1-11 Options are customer-requested factory modifications of a standard instrument. The following options are available for the instruments covered by this manual. Where necessary, detailed coverage of the options is included throughout the manual.

Option No.

Description

- 005 <u>Realignment for 50Hz Operation</u>: Standard instruments are designed for 57 to 63Hz operation. For 50Hz operation, a resistor in the preregulator control circuit is changed and the preregulator is realigned.
- 007 <u>Ten-Turn Output Voltage Control</u>: A tenturn control replaces the coarse voltage control for improved resolution in setting the output voltage.
- 008 <u>Ten-Turn Output Current Control</u>: A tenturn control replaces the coarse current control for improved resolution in setting the output current.
- 009 <u>Ten-Turn Output Voltage and Current</u> <u>Controls:</u> This option includes Options 007 and 008 in the same instrument.
- 010 <u>Chassis Slides</u>: Factory installed slides permit convenient access to the interior of a rack mounted supply for maintenance.
- 013 <u>Three-Digit Graduated Decadial Voltage</u> <u>Control:</u> To improve mechanical stability and permit accurate resetting of the output voltage, Option 013 replaces the coarse voltage control with a ten-turn control equipped with a 3-digit turns-counting dial.
- 014 <u>Three-Digit Graduated Decadial Current</u> <u>Control</u>: To improve mechanical stability and permit accurate resetting of the output current, Option 014 replaces the coarse current control with a ten-turn control equipped with a 3-digit turns-counting dial.
- 016 Rewiring for 115Vac ±10% Single-Phase Input (Model 6260B only): This factory modification replaces the circuit breaker and power transformer, adds a resistor to the A2 assembly, and reconnects the bias transformer, preregulator choke, and fans for 115Vac operation.

Option No.

Description

- 020 Adjustable Voltage Programming: Two screwdriver-adjustable controls accessible through holes in the rear panel allow the voltage programming coefficient and zero output voltage to be adjusted conveniently to an accuracy of 0.1%.
- 021 Adjustable Current Programming: Two screwdriver-adjustable controls accessible through holes in the rear panel allow the current programming coefficient and zero output current to be adjusted conveniently to an accuracy of 0.1%.
- 022 Adjustable Voltage and Current Programming: This option includes Options 020 and 021 in the same instrument.
- 026 Rewiring for 115Vac ±10% Single-Phase Input (Models 6259B, 6261B, and 6268B only): This factory modification replaces the circuit breaker (except in the Model 6259B), adds a resistor to the A2 assembly, and reconnects the power transformer, bias transformer, preregulator choke, and fans for 115Vac operation.
- 027 Rewiring for 208Vac ±10% Single-Phase Input: This factory modification reconnects the power and bias transformers for 208Vac operation.
- 040 Interfacing for Multiprogrammer Operation: This factory modification prepares standard power supplies for resistance programming by the 6940B Multiprogrammer or the 6941B Multiprogrammer Extender. Operation with either of these instruments requires that the power supply be subjected to a special calibration and a protection checkout. The special calibration insures that the power supply can be accurately set to zero and to the maximum rated output voltage or current when programmed by the multiprogrammer. The protection checkout insures that the power supply will not be damaged by the rapid repetitive programming possible with the multiprogrammer. This option includes Option 022.

1-12 INSTRUMENT/MANUAL IDENTIFICATION

1-13 Hewlett-Packard power supplies are identified by a

two-part serial number. The first part is the serial number prefix, a number-letter combination that denotes the date of a significant design change and the country of manufacture. The first two digits indicate the year (10 = 1970, 11 = 1971, etc.), the second two digits indicate the week, and the letter "A" designates the U. S. A. as the country of manufacture. The second part is the power supply serial number. A different sequential number is assigned to each power supply, starting with 00101.

1-14 If the serial number on your instrument does not agree with those on the title page of the manual, Change

Sheets supplied with the manual define the differences between your instrument and the instrument described by this manual.

1-15 ORDERING ADDITIONAL MANUALS

1-16 One manual is shipped with each power supply. Additional manuals may be purchased from your local Hewlett-Packard field office (see list at rear of this manual for addresses). Specify the model number, serial number prefix, and HP part number shown on the title page.

4

INPUT:	PARD (F	RIPPLE AND NOISE):		
230Vac ±10%, single phase, 57-63Hz for the standard		ured within 20Hz to 20MH	Iz bandwidth)	
models. (For other input voltages or 50Hz operation, see	Model	Constant Voltage	Constant Current	
the option listings in paragraph 1-10. Input power require-				
ments are listed in paragraph 2-15.	6259B	500µVrms/5mV p-p	25mA rms	
	6260B	500µVrms/5mV p-p	50mA rms	
OUTPUT:	6261B	500µVrms/5mV p-p	25m A rms	
Model 6259B 0-10 volts at 0-50 amps	6268B	1mVrms/5mV p-p	20m A rms	
6260B 0-10 volts at 0-100 amps	6269B	1mVrms/5mV p-p	25m A rms	
6261B 0-20 volts at 0-50 amps				
6268B 0-40 volts at 0-30 amps				
6269B 0-40 volts at 0-50 amps	TEMPER	ATURE COEFFICIENT:		
	Const	ant Voltage - Less than 0.	01% plus 200µV change	
LOAD EFFECT (LOAD REGULATION):	in output	t per degree Celsius change	in ambient following	
<u>Constant Voltage</u> – Less than 0.01% of output plus 200μ V	a 30-min	ute warmup.		
for a load change equal to the current rating of the supply.	Consta	ant Current -		
Constant Current –	Mo	dels 6259B, 6261B, and 62	269B – Less than 0.01%	
Models 6259B and 6261B – Less than 0.02% of output	plus 4mA	A change in output per degr	ree Celsius change in	
plus 1mA for a load change equal to the voltage rating of	ambient	ambient following a 30-minute warmup.		
the supply.	Model 6260B – Less than 0.01% plus 8mA change			
Models 6260B, 6268B, and 6269B — Less than 0.02%	in output	per degree Celsius change	in ambient following	
of output plus 2mA for a load change equal to the voltage	a 30-min	ute warmup.		
rating of the supply.	Mo	del 6268B – Less than 0.0	1% plus 2mA change	
	in output	per degree Celsius change	in ambient following	
SOURCE EFFECT (LINE REGULATION):	a 30-min	ute warmup.		
Constant Voltage - Less than 0.01% of output plus				
$200\mu V$ for a change in line voltage between 208 and 254Vac				
(or 104 and 127Vac) at any output voltage and current				
within rating.	DRIFT (S	STABILITY):		
Constant Current -	(Chang	ge in output (dc to 20Hz) o	over an 8-hour interval	
Models 6259B and 6261B - Less than 0.02% of output	under constant line, load, and ambient temperature follow-			
plus 1mA for a change in line voltage between 208 and 254 Vac	ing a 30-r	ninute warmup.)		
(or 104 and 127Vac) at any output voltage and current	Consta	ant Voltage - Less than 0.0	3% of output plus 2mV.	
within rating.	Consta	ant Current -		
Models 6260B, 6268B, and 6269B - Less than 0.02%	Mo	dels 6259B, 6261B, and 62	269B - Less than 0.03%	
of output plus 2mA for a change in line voltage between	of output	plus 10mA.		
208 and 254 Vac (or 104 and 127 Vac) at any output voltage	Mo	del 6260B - Less than 0.0	3% of output plus 20mA.	
and current within rating.	Mo	del 6268B - Less than 0.0	3% of output plus 5mA.	
6.0				

Table 1-1 Specifications: Models 6259B, 6260B, 6261B, 6268B, 6269B

Table 1-1 Specifications: Models 6259B, 6260B, 6261B, 6268B, 6269B (Continued)

LOAD TRANSIENT RECOVERY TIME:

Less than 50µsec is required for output voltage recovery (in constant voltage operation) to within 10mV of the nominal output following a change in output current equal to the current rating of the supply or 5 amps, whichever is smaller.

REMOTE PROGRAMMING COEFFICIENTS:

Output Voltage Programming -Voltage Resistance Control (±1%) Control (±1%) Model 200Q/V 1V/V All Models Output Current Programming -Voltage Resistance Control (±10%) Control (±10%) Model 10mV/A 6259B 4Ω/A $2\Omega/A$ 5mV/A 6260B 10mV/A 4Ω/A 6261B 6Ω/A 16.7mV/A 6268B 10mV/A 6269B 4Ω/A

REMOTE PROGRAMMING SPEED:

(Typical time required to nonrepetitively change from zero to within 99.9% of the maximum rated output voltage, or from the maximum rated output voltage to within 0.1% of that voltage above zero.)

01 1101 101		
Model	Up, Full Load	Down, Full Load
6259B	70ms	10ms
6260B	70ms	5ms
6261 B	150ms	25ms
6268B	300ms	30ms
6269B	350ms	20ms
Model	Up, No Load	Down, No Load
6259B	70ms	200ms
6260B	70ms	200ms
6261 B	150ms	250ms
6268B	300ms	1sec
6269B	350ms	1 sec

PANEL METERS:

The accuracy of the front panel voltmeter and ammeter is ±2% of full scale. The ranges of these meters are:

Model		Model		
6259B	12V, 60A	6268B	50V, 35A	
6260B	12V, 120A	6269B	50V, 60A	
6261B	24V, 60A			

TEMPERATURE RATINGS:

Storage -40 to +75°C Operating 0 to 55°C

COOLING:

These power supplies are forced air cooled. The Model 6259B is cooled by a single fan; the other models are cooled by two fans.

RESOLUTION:

be obtaine	d using the front panel c	ontrols.)
Model	Constant Voltage	Constant Current
6259B	1mV	60mA
6260B	. 1mV	100mA
6261B	2mV	50m A
6268B	5mV	30m A
6269B	5mV	50m A
02000		1

A there in

OUTPUT IMPEDANCE (TYPICAL):

Approximated by a resistance in series with an inductance as follows:

Model	Model
6259B 0.05mΩ, 1µH	6268B 0.2mΩ, 1µH
6260B 0.02mΩ, 1µH	6269B 0.1mΩ, 1µH
6261B 0.01mΩ, 1µH	

OVERVOLTAGE PROTECTION CROWBAR:

To avoid false tripping, the recommended trip margin above the output voltage is 5% of the output voltage plus 2 volts for Models 6259B, 6260B, and 6261B, and 5% of the output voltage plus 1 volt for Models 6268B and 6269B. The approximate crowbar trip voltage ranges are: Model

6259B	2V-12V	6268B	4V-45V
6260B	2V-12V	6269B	4V-45V
6261B	2V-23V		

OPTIONS AVAILABLE: (See paragraph 1-10 for descriptions) All Models - Options 005, 007, 008, 009, 010, 013, 014, 020, 021, 022, 027, 040. Model 6260B only - Option 016. Model 6259B, 6261B, and 6268B only - Option 026.

INPUT POWER CONNECTIONS:

Input power is connected by way of a 3-terminal barrier strip on the rear panel.

DIMENSIONS:

Model

(See Figure 2-1 outline diagrams.)

VEIGHT:		1 and 16 with the second
Model	Net	Shipping
6259B	69 lbs. (31.3 kg)	78 lbs. (35.3 kg)
6260B	97 lbs. (43.9 kg)	106 lbs. (48.0 kg)
6261B	78 lbs. (35.3 kg)	87 lbs. (39.4 kg)
6268B	76 lbs. (34.4 kg)	84 lbs. (38.1 kg)
6269B	89 lbs. (40.3 kg)	98 lbs. (44.0 kg)

SECTION II

2-1 INITIAL INSPECTION

2-2 Before shipment, this instrument was inspected and found to be free of mechanical and electrical defects. As soon as the instrument is unpacked, inspect for any damage that may have occurred in transit. Save all packing materials until the inspection is completed. If damage is found, file a claim with the carrier immediately. The Hewlett-Packard Sales and Service office should be notified as soon as possible.

2-3 Mechanical Check

2-4 This check should confirm that there are no broken knobs or connectors, that the cabinet and panel surfaces are free of dents and scratches, and that the meters are not scratched or cracked.

2-5 Electrical Check

2-6 The instrument should be checked against its electrical specifications. Section V includes an "in-cabinet" performance check to verify proper instrument operation.

2-7 INSTALLATION DATA

2-8 The instrument is shipped ready for permanent rack installation or bench operation. It is necessary only to connect the instrument to a source of power and it is ready for use.

2-9 Location and Cooling

2-10 These instruments are fan-cooled and must be installed with sufficient space for cooling air to reach their sides. These power supplies should be used in an area where the ambient temperature does not exceed 55°C.

2-11 Outline Diagram

2-12 Figure 2-1 shows the outline shape and dimensions of these supplies.

2-13 Rack Mounting

2-14 This instrument is full rack size and can be easily rack mounted in a conventional 19-inch rack panel using standard mounting screws.



Figure 2-1. Outline Diagrams (Models 6259B, 6260B, 6261B, 6268B, and 6269B)

2-15 INPUT POWER REQUIREMENTS

2.16 The standard instrument is wired for a nominal input of 230Vac 57-63Hz when it is shipped from the factory. The supplies covered by this manual are also available equipped for a 208-volt input (Option 027), and except for the Model 6269B, are also available equipped for a 115-volt input (Option 026 for Models 6259B, 6261B, and 6268B, or Option 016 for the Model 6260B). In addition, all five models are available in a 50Hz version. The input voltage and frequency required is marked on the rear panel of the supply. Except for the Model 6269B, which cannot be converted to 115-volt operation, a standard instrument can be converted by the user to 208 or 115-volt and to 50Hz operation by following the instructions given in the following paragraphs. The standard instrument requires the input current and power listed below when operated at full load from a 230-volt source. When the supply is operated from a 115-volt source, the input current is approximately twice the amount listed.

Model	Input Current	Input Power
6259B	6A	850W
6260B	12A	1600W
6261B	12A	1500W
6268B	12A	1600W
6269B	18A	2500W

2-17 INPUT LINE VOLTAGE OR FREQUENCY CONVERSION

2-18 Converting a 230-volt instrument to 208-volt operation is simply a matter of changing some taps or jumper connections on main power transformer T1 and bias transformer A3T2. Converting to 115-volt operation is more involved. The Models 6259B, 6260B, 6261B, and 6268B require an added resistor and some jumper changes in the A2 RFI assembly and a changed A3T2 transformer tap. In addition, the 6260B, 6261B, and 6268B need a replacement circuit breaker, and the 6260B needs a replacement T1 power transformer. Complete line voltage conversion instructions are given in paragraphs 2-20 through 2-27.

2-19 Converting a 60Hz instrument to 50Hz operation requires that one resistor be replaced and some adjustments be made. Line frequency conversion instructions are given in paragraph 2-28.

2-20 Converting a Standard Instrument to 208-Volt Operation (Models 6259B, 6261B and 6268B).

2-21 To convert these 230-volt instruments to 208-volt operation, proceed as follows:

a. Disconnect instrument from power source and remove top and bottom covers.

b. Remove A2 RFI assembly as described in steps (a) through (c) of paragraph 5-65. This provides access to bias transformer A3T2 (see Fig. 7-2).

c. Locate the wire that connects circuit breaker CB1 to the A3T2 bias transformer terminal marked "230V", disconnect it from the transformer, and reconnect it to the terminal marked "208V". Leave the wire from fan B2 (not used in the 6259B) connected to the terminal marked "230V" (see Fig. 2-2B).

d. Re-install the RFI assembly by reversing the procedure of step (b) above.

e. Unsolder the wire connected to terminal 5 of power transformer T1 and solder it instead to terminal 4 (see Figure 2-3B).

2-22 Converting a Standard Instrument to 208-Volt Operation (Models 6260B and 6269B).

2-23 To convert these 230-volt instruments to 208volt operation, proceed as follows:

a. Perform steps (a) through (d) of paragraph 2-21.

b. Unsolder the wire connected to the terminal marked "230V" on power transformer T1 and solder it instead to the terminal marked "208V" (see Fig. 2-4B).

2-24 Converting a Standard Instrument to 115-Volt Operation (Models 6259B, 6261B and 6268B).



Figure 2-2. Bias Transformer Primary Connections for 208Vac Operation (Model 6259B, 6260B, 6261B, 6268B, and 6269B) and 115Vac Operation (except Model 6269B). 2-25 To convert these 230-volt instruments to 115-volt operation, proceed as follows:

a. (Omit this step for the Model 6259B.) Obtain and install a new circuit breaker CB1. Refer to Option 026 in the Table 6-4 parts list for its current rating and HP Part Number. Connections to the replacement are the same as those to the original breaker.

 b. Remove and partially disassemble the A2 RFI assembly as described in steps (a) through (d) of paragraph 5-65.

c. Unsolder jumper J3 from the A2 circuit board (see Fig. 7-1) and install jumpers J1 and J2. Also install resistor A2R3 on the circuit board. Refer to Option 026 in the Table 6-4 parts list for its description and HP Part Number. Replace cover on RFI assembly.

d. Locate the wire that connects circuit breaker CB1 to the A3T2 bias transformer terminal marked "230V", disconnect it from the transformer, and reconnect it to the terminal marked "115V." Also disconnect the wire from fan B2 (not used in the 6259B) from the terminal marked "230V" and reconnect it to the terminal marked "0V" (see Fig. 2-2C).

e. Re-install the RFI assembly by reversing the procedure of step (b).

f. Unsolder the jumper connecting terminals 2 and 3 of power transformer T1 (see Fig. 2-3C) and solder jumpers between terminals 1 and 3, and 2 and 5.

2-26 Converting a Standard Instrument to 115-Volt Operation (Model 6260B)

2-27 To convert the standard Model 6260B to 115-volt operation, proceed as follows:

a. Obtain and install a new power transformer (T1) and a new circuit breaker (CB1). Refer to Option 016 in the Table 6-4 parts list for their description and HP Part Number. The new transformer has two primary terminals. Transfer the wire from the "OV" terminal on the old transformer to the "OV" on the new one, and from the "230V" terminal on the old one to the "115V" terminal on the new one. The connections to the replacement circuit breaker are the same as to the old one.

b. Perform steps (b) through (e) of paragraph 2-25.

2-28 Converting a Standard Instrument to 50Hz Operation

2-29 To convert a 60Hz instrument to 50Hz operation, proceed as follows:

a. Replace A1 R82 with a 240 ohm 5% 1/2-watt resistor. Refer to the Table 6-4 parts list under Option 005 for the HP Part Number of a suitable replacement.

b. After replacing A1 R82, perform the preregulator tracking adjustment given in paragraph 5-102.

c. Check the ripple balance adjustment by the procedure given in paragraph 5-100.



Figure 2-3. Power Transformer Primary Connections for 208Vac and 115Vac Operation (Model 6259B, 6261B, and 6268B)

2-30 INPUT POWER CONNECTIONS

2-31 No input power cable is supplied with the instruments covered by this manual. Input power connections are made to a 3-terminal barrier block on the rear panel. Its center terminal is grounded to the instrument chassis. To protect operating personnel, the National Electrical Manufacturers Association (NEMA) recommends that the instrument panel and cabinet be grounded. The usersupplied power cable should have three conductors (with the third conductor grounded) and should be of adequate wire size to handle the input current drawn by the supply (see paragraph 2-15). Note that when the supply is operated from a 115-volt source, the input current is approximately twice that shown in paragraph 2-15.

2-32 REPACKAGING FOR SHIPMENT

2-33 To insure safe shipment of the instrument, it is recommended that the package designed for the instrument be used. The original packaging material is reusable. If it is not available, contact your local Hewlett-Packard field office to obtain the materials. This office will also furnish the address of the nearest service office to which the instrument can be shipped and provide the Authorized Return label necessary to expedite the handling of your instrument return. Be sure to attach a tag to the instrument which specifies the owner, model number, full serial number, and service required, or a brief description of the trouble.



Figure 2-4. Power Transformer T1 Primary Connections for 208Vac Operation (Model 6260B and 6269B)

SAFETY SUMMARY

The following general safety precautions must be observed during all phases of operation, service, and repair of this instrument. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended use of the instrument. Hewlett-Packard Company assumes no liability for the customer's failure to comply with these requirements.

BEFORE APPLYING POWER.

Verify that the product is set to match the available line voltage and the correct fuse is installed.

GROUND THE INSTRUMENT.

This product is a Safety Class 1 instrument (provided with a protective earth terminal). To minimize shock hazard, the instrument chassis and cabinet must be connected to an electrical ground. The instrument must be connected to the ac power supply mains through a three-conductor power cable, with the third wire firmly connected to an electrical ground (safety ground) at the power outlet. For instruments designed to be hard-wired to the ac power lines (supply mains), connect the protective earth terminal to a protective conductor before any other connection is made. Any interruption of the protective (grounding) conductor or disconnection of the protective earth terminal will cause a potential shock hazard that could result in personal injury. If the instrument is to be energized via an external autotransformer for voltage reduction, be certain that the autotransformer common terminal is connected to the neutral (earthed pole) of the ac power lines (supply mains).

INPUT POWER MUST BE SWITCH CONNECTED.

For instruments without a built-in line switch, the input power lines must contain a switch or another adequate means for disconnecting the instrument from the ac power lines (supply mains).

DO NOT OPERATE IN AN EXPLOSIVE ATMOSPHERE.

Do not operate the instrument in the presence of flammable gases or fumes.

KEEP AWAY FROM LIVE CIRCUITS.

Operating personnel must not remove instrument covers. Component replacement and internal adjustments must be made by qualified service personnel. Do not replace components with power cable connected. Under certain conditions, dangerous voltages may exist even with the power cable removed. To avoid injuries, always disconnect power, discharge circuits and remove external voltage sources before touching components.

DO NOT SERVICE OR ADJUST ALONE.

Do not attempt internal service or adjustment unless another person, capable of rendering first aid and resuscitation, is present.

DO NOT EXCEED INPUT RATINGS.

This instrument may be equipped with a line filter to reduce electromagnetic interference and must be connected to a properly grounded receptacle to minimize electric shock hazard. Operation at line voltages or frequencies in excess of those stated on the data plate may cause leakage currents in excess of 5.0 mA peak.

SAFETY SYMBOLS.



Instruction manual symbol: the product will be marked with this symbol when it is necessary for the user to refer to the instruction manual (refer to Table of Contents).



Indicate earth (ground) terminal.

Indicates hazardous voltages.

WARNING

The WARNING sign denotes a hazard. It calls attention to a procedure, practice, or the like, which, if not correctly performed or adhered to, could result in personal injury. Do not proceed beyond a WARNING sign until the indicated conditions are fully understood and met.



The CAUTION sign denotes a hazard. It calls attention to an operating procedure, or the like, which, if not correctly performed or adhered to, could result in damage to or destruction of part or all of the product. Do not proceed beyond a CAUTION sign until the indicated conditions are fully understood and met.

DO NOT SUBSTITUTE PARTS OR MODIFY INSTRUMENT.

Because of the danger of introducing additional hazards, do not install substitute parts or perform any unauthorized modification to the instrument. Return the instrument to a Hewlett-Packard Sales and Service Office for service and repair to ensure that safety features are maintained.

Instruments which appear damaged or defective should be made inoperative and secured against unintended operation und they can be repaired by qualified service personnel.

SECTION III OPERATING INSTRUCTIONS



Figure 3-1. Front Panel Controls and Indicators

3-1 TURN-ON CHECKOUT PROCEDURE

3-2 The following steps describe the use of the front panel controls and indicators illustrated in Figure 3-1 and serve as a brief check that the supply is operational. This checkout procedure or the more detailed performance test of paragraph 5-5 should be followed when the instrument is received and before it is connected to any load equipment. Proceed to the more detailed test and troubleshooting procedures in Section V if any difficulties are encountered.

a. Turn CURRENT controls (7) and OVERVOLTAGE ADJUST potentiometer (5) fully clockwise and check that rear panel straps are connected as shown in Figure 3-2, but do not connect load R_1 .

b. Connect ac power of the appropriate voltage and frequency to the rear panel ac and acc terminals. The supply's input rating is identified on its rear panel.

Do not interchange the ac and acc input lines; connect the ac input terminal to the hot side and the acc input terminal to the grounded

CAUTION-

side of the ac line. Do not fail to connect the input ground terminal ($\frac{1}{2}$) securely to an external earth ground.

c. Set LINE switch or circuit breaker (1) ON and observe that pilot lamp (2) lights.

d. Adjust COARSE and FINE VOLTAGE controls ③ for desired indication on voltmeter ④

e. Ensure that overvoltage crowbar circuit is operational by slowly turning OVERVOLTAGE ADJUST control (5) counterclockwise with a screwdriver until OVERVOLTAGE lamp (6) lights and voltmeter indication drops to zero volts. f. Reset crowbar by returning OVERVOLTAGE ADJUST control to its maximum clockwise position and turning off the supply. On turning the supply back on, the voltage should be the same value as was set in step (d).

g. To check the constant current circuit, first turn off the supply, connect a short across the output bus bars (see Figure 3-2), and turn it back on.

h. Adjust COARSE and FINE CURRENT controls (7) until ammeter (8) indicates desired output current or current limit. (The VOLTAGE controls must be set for a greater-than-zero output to obtain the output current programmed.)

i. Turn off the supply, remove the short from its output, and read the remainder of these operating instructions before connecting the supply to an actual load.

3-3 OPERATING MODES

3-4 This power supply is designed so that its mode of operation can be selected by making strapping connections between terminals on its rear panel. The following paragraphs first describe normal operation using the normal strapping pattern as it is connected at the factory. Later paragraphs cover some optional operating modes including remote voltage sensing, remote programming, and some methods of operating these power supplies in combinations of two or three.

3-5 The DC Power Supply Handbook, Application Note 90A, is a useful source of additional information on using regulated power supplies effectively. This 138-page handbook includes chapters on operating principles, ac and load connections, optional operating modes, and performance measurements and is available at no charge from your local HP sales office. The address of your local sales office can be found in the back of this manual.

3-6 NORMAL OPERATING MODE

3.7 This power supply was shipped with the proper rear panel strapping connections made for constant-voltage/ constant-current operation with local sensing and local programming. This strapping pattern is illustrated in Figure 3-2. By means of the front panel voltage and current controls, the operator selects either a constant-voltage or a constant-current output. Whether the supply functions in the constant-voltage or the constant-current mode depends on the settings of the voltage and current controls and on the resistance of the output load. For values of load resistance greater than a critical crossover value equal to the voltage setting divided by the current setting, the supply operates in the constant-voltage mode. With a load resistance smaller than this critical value, it operates in the constant-current mode. The transition occurs automatically; no switches need to be operated or connections changed.



Figure 3-2. Normal Strapping Pattern

3-8 Constant Voltage Operation

3.9 To adjust the supply for constant voltage operation:
a. Turn on supply and, with output terminals open,
adjust the VOLTAGE controls for the desired output
voltage. Then turn power off.

b. Connect a short across the rear panel output terminals, restore power, and adjust the CURRENT controls for the desired maximum output current. Then remove the short. If a load change causes this current limit to be exceeded, the supply automatically crosses over to constant current operation at this preset current limit and the output voltage drops proportionately. In setting the current limit, make an adequate allowance for high peak currents that could cause unwanted crossover. (Refer to paragraph 3-77.)

3-10 Constant Current Operation

3-11 To adjust the supply for constant current operation: a. Connect a short across the rear output terminals, turn the power on, and adjust the CURRENT controls for the desired output current.

b. Open the output terminals and adjust the VOLTAGE controls for the desired maximum output voltage. If a load change causes this voltage limit to be exceeded, the supply automatically crosses over to constant voltage operation at this preset voltage limit and the output current drops proportionately. In setting the voltage limit, make an adequate allowance for high peak voltages that could cause unwanted crossover. (Refer to paragraph 3-77.)

3-12 Overvoltage Trip Point Adjustment

3-13 The crowbar trip voltage is adjusted by using the screwdriver control on the front panel. The approximate trip voltage ranges are listed in Table 1-1. When the crowbar trips, an SCR shorts the output and the amber OVER-VOLTAGE indicator on the front panel lights. Rotating the control clockwise sets the trip voltage higher. (It is set to maximum at the factory.) Paragraph 5-108 contains instructions for completely disabling the crowbar, if this is desired.

3-15 Connecting The Load

3-16 To satisfy the requirements of safety, the wires to the load should be at least heavy enough not to overheat while carrying the power supply current that would flow if the load were shorted. Generally, heavier wire than this is required to obtain good regulation at the load. If the load regulation is critical, use remote voltage sensing. (Refer to paragraph 3-27.)

3-17 If multiple loads are connected to one supply, each load should be connected to the supply's output terminals using separate pairs of connecting wires. This minimizes mutual coupling effects between loads and takes full advantage of the supply's low output impedance. Each pair of connecting wires should be as short as possible and twisted or shielded to reduce noise pickup.

3-18 If load considerations require the use of output distribution terminals that are located remotely from the supply, then the power supply output terminals should be connected to the remote distribution terminals by a pair of twisted or shielded wires and each load should be separately connected to the remote distribution terminals. Remote voltage sensing would be required under these circumstances. (Refer to paragraph 3-27.)

3-19 Either positive or negative voltages can be obtained from this supply by grounding one of the output terminals or one end of the load. Always use two wires to connect the load to the supply regardless of where or how the system is grounded. Never ground the system at more than one point. This supply can be operated up to 300 volts above ground if neither output terminal is grounded.

3-20 Operation With No Load

3-21 When the supply is operated without a load, its down-programming speed is considerably slower than when its output is loaded. This slower programming speed is evident whether the VOLTAGE controls are turned fully counterclockwise or an external voltage programming input

signal is decreased. When the crowbar is activated during no-load operation, the supply's output falls rapidly to about two volts and then decreases more slowly towards zero. The actual time required for the output to fall from two volts to zero varies from several seconds to several minutes, depending on the output rating of the supply.

3-22 Operation Beyond Rated Output

3-23 The supply may be able to provide voltage? and currents greater than its rated maximum outputs. Operation can extend into the shaded areas on the meter face without damage to the supply, but performance cannot be guaranteed to meet all specifications.

3-24 OPTIONAL OPERATING MODES

3-25 The optional operating modes discussed in the following paragraphs include:

- a. Remote voltage sensing
- b. Remote programming
- c. Auto-Parallel operation
- d. Auto-Series operation
- e. Auto-Tracking operation

Special operating instructions for instruments equipped with Option 040 to permit their interfacing with a Model 6940B Multiprogrammer or a 6941B Multiprogrammer Extender are not included but can be found in the manual covering the programmable resistance cards that are necessary to complete the interface. Special calibration instructions for power supplies equipped with Option 040 are included in Section V of this manual.

3-26 By changing its rear panel strapping pattern according to the instructions which follow, any of the supplies covered by this manual can be operated in any of the modes listed above.

----- CAUTION ------

Disconnect input ac power before changing any rear panel connections and make certain all wires and straps are properly connected and terminal strip screws are securely tightened before reapplying power.

3-27 Remote Voltage Sensing

3-28 Because of the unavoidable voltage drop developed in the load leads, the normal strapping pattern shown in Figure 3-2 will not provide the best possible voltage regulation at the load. If, for example, one were to use 4-gauge wire to connect a load that is located only 5 feet from a Model 6259B 10V 50A supply, the full-load regulation measured at the load would be about 120 millivolts as compared to the 1.2 millivolt regulation that could be measured at the supply's output terminals. Thus even relatively short load leads can cause a considerable degradation of the supply's performance. The remote sensing connections shown in Figure 3-3 improve the voltage regulation at the load by monitoring the voltage there instead of at the supply's output terminals. (The advantages of remote sensing apply only during constant voltage operation.)

3-29 As can be seen in Figure 3-3, remote sensing involves removing the +S and -S jumpers from the output terminals, connecting the load leads normally, and using a separate pair of wires to connect the +S and -S sensing terminals to the load. The following paragraphs discuss some precautions that should be observed when making a remote sensing installation.

NOTE

The +S jumper is the one that links the +S terminal to the +OUT terminal when the supply's terminals are strapped for normal operation as shown in Figure 3-2. The -S jumper is the one that links the -S terminal to the -OUT terminal.

3-30 The load leads should be of the heaviest practicable wire gauge, at least heavy enough to limit the voltage drop in each lead to 0.5 volt. This limitation is dictated by the adverse effect that a greater load lead voltage drop has on bias voltages within the supply when remote sensing is used. Twisting the load leads may help to minimize noise pick-up. While there are practical limitations on the distance that can separate a power supply from its load when using remote sensing, it isn't possible to define these limits precisely due to a variety of factors that are unique to each particular installation.



Figure 3-3. Remote Sensing

3-31 Since the sensing leads carry only a few milliamps, the wires used for sensing can be much lighter than the load leads (22 AWG is generally adequate), but they should be a shielded, twisted pair to minimize the pickup of external noise. Any noise picked up on the sensing leads will appear at the supply's output. The shield should be grounded at one end only and should not be used as one of the sensing conductors. The sensing leads should be connected as close to the load as possible.

3-32 The sensing leads are part of the supply's programming circuit, so they should be connected in such a way as to make it unlikely that they might inadvertently become open circuited. If the sensing leads were to open during operation, the output voltage would tend to rise. Although the increase would be limited by protective resistors R108 and R109, damage to the supply or to the load might occur if the loss of sensing were accompanied by a load transient. For this reason no switch, relay, or connector contacts should be included in the remote sensing path.

When using remote voltage sensing, it is possible to damage the supply by disconnecting a load lead while the sensing lead is still connected and the supply is energized. If a load lead becomes disconnected, current flows through internal protection resistors R108 and R109, the sensing leads, and the load and may burn out the resistors. Additional factors could compound the damage caused by an opened load lead. If the output of the supply is connected to an inductive load or a battery *, or is connected in parallel with another supply, then opening a load lead would allow current from the external source to flow through the sensing leads and damage the supply's input circuits. If the crowbar fires, the damage could even be greater.

For these reasons, if there is any risk of an opened load circuit while remote sensing is used, 1/16-amp fuses should be installed in both sensing leads. Fuses in the sensing leads will not affect the performance of the supply and should protect against costly damage.

* Remote sensing is not recommended when charging or discharging a battery. See paragraphs 3-87 and 3-91.

3-33 Another factor to be considered when making a remote sensing installation is the inductance of the long load leads. Although dc and low frequency performance are improved by remote sensing, the higher inductance of longer leads does impair transient response and could affect



the stability of the feedback loop seriously enough to cause oscillation. If remote sensing disturbs the supply's stability, try these two corrective measures:

a. Adjust the equalization control R47 until the oscillation stops. To achieve the best possible transient response for a given remote sensing installation, measure the transient response using the procedure given in paragraph 5-27 and adjust R47 while observing the transient response waveforms.

b. If adjusting R47 does not eliminate the instability, it may be beneficial to disconnect output capacitor A3C3 from the circuit and connect a similar capacitor directly across the load. To gain access to capacitor A3C3, the A2 RFI Assembly must first be removed. Follow steps (a) through (c) of paragraph 5-65 to remove the A2 assembly. Then unsolder the heavy wire from the A3 circuit board that connects the positive terminal of A3C3 to the positive output bus bar. (This heavy red-insulated wire is identified in Figure 7-2.)

NOTE

Do not unsolder the capacitor's negative lead. The negative lead to A3C3 carries collector current for transistor A4Q101 and would disable the power supply if disconnected.

Tape the free end of the disconnected wire, replace the A2 assembly, and replace the bottom cover of the supply. The substitute capacitor should have approximately the same capacitance, an equal or greater voltage rating, and good high frequency characteristics. Connect it directly across the load using the shortest possible leads. Readjust equalization control R47 as in step (a) above after installing the substitute output capacitor.

3-34 Remote Programming

3-35 The output voltage or current of these power supplies can be remotely controlled by connecting an external resistor or applying an external voltage to rear panel terminals. If resistance programming is used, a variable resistor can control the output over its entire range. Or, a variable resistor connected in series with a fixed resistor can have its control restricted to a limited portion of the output range. Alternately, a switch can be used to select fixed values of programming resistance to obtain a set of discrete voltages or currents. (The switch must have make-before-break contacts to avoid producing the output voltage transients that momentarily opening the programming terminals would cause.) To maintain the temperature and stability specifications of the supply, programming resistors must be stable, low noise resistors with a temperature coefficient of less than 30ppm per °C and a power rating at least 30 times what they will actually dissipate.

3-36 Both voltage and current outputs can also be controlled through a voltage input. When voltage programming the output voltage, the choice can be made between using a connection that produces a unity gain relationship between input and output (paragraph 3-41) or another connection that produces variable voltage gains (paragraph 3-42). Similarly, the output current can be programmed using a connection that produces a fixed gain (paragraph 3-47) or a variable gain (paragraph 3-48).

3-37 Connecting a supply for remote voltage or current programming disables the corresponding front panel controls.

3-38 The following paragraphs discuss in greater detail the methods of remotely programming the output voltage or current using either a resistance or a voltage input. Whichever method is used, the wires connecting the programming terminals of the supply to the remote programming device must be shielded to reduce noise pickup. The outer shield of the cable should not be used as a conductor but should be connected to ground at one end only.

3-39 Constant Voltage Output, Resistance Input. The rear panel connections shown in Figure 3-4 allow the output voltage to be varied by using an external resistor to program the supply. The supply's constant voltage programming current determines its programming coefficient. In the supplies covered by this manual, this programming current is factory adjusted to within 1% of 5mA, resulting in a programming accuracy is required, it can be obtained either by changing resistor R3 as discussed in paragraph 5-86 or, if the instrument is equipped with Options 020 or 022, by adjusting potentiometer R112 as discussed in paragraph 5-87.

3-40 With the programming terminals shorted (terminals A2 to -S), the no-load output voltage of the supply should be $-15mV \pm 5mV$. If a minimum output voltage is required that is closer to zero than this, it can be obtained either



Figure 3-4. Resistance Programming of Output Voltage

2 .

by installing and adjusting R110 as discussed in paragraph 5-81 or, if the instrument is equipped with Option 020 or 022, by adjusting potentiometer R113 as discussed in paragraph 5-83.

- CAUTION------

Do not allow programming terminals A2 or -S to become open circuited while resistance programming the output voltage. If they do become open circuited, the supply's output voltage tends to rise beyond its rated maximum. If the supply's current controls and overvoltage crowbar trip point are properly adjusted, however, no damage to the power supply or load should result.

3-41 Constant Voltage Output, Voltage Input (Unity Gain). The rear panel connections shown in Figure 3-5 allow the output voltage to be varied by using an external voltage source to program the supply. In this mode, the output voltage varies in a 1 to 1 ratio with the programming voltage. The load on the programming voltage source is less than 20 microamperes. Impedance matching resistor R_X is required to maintain the temperature coefficient and stability specifications of the supply. To adjust the output voltage to exactly zero with a zero programming voltage, follow the same instructions as are referred to in paragraph 3-40.

3-42 Constant Voltage Output, Voltage Input (Variable Gain). In the remote programming arrangement shown in Figure 3-6, the series combination of external voltage source E_S and reference resistor R_R replaces the supply's internal voltage programming current source. As a result, the voltage this external current source develops across gain control R_P becomes the output voltage of the supply, and the gain relationship between E_S and the output voltage quals the resistance ratio R_P/R_R .



Figure 3-5. Voltage Programming of Output Voltage (Unity Gain)

3-43 When using this programming technique, select a value for R_R that is less than 10k ohms and that would conduct at least 5 milliamps if connected across the programming voltage source with its voltage at the maximum value of input voltage to be used. Once the value for R_R is selected, multiply R_R by the maximum voltage gain desired to find R_P . (If desired, the power supply's front panel voltage controls can be used in place of external gain control R_P by deleting the external gain control from the circuit and strapping together terminals A1 and A2.)

3-44 The output voltage of the supply can be adjusted to exactly zero with a zero programming voltage input⁴⁴ either by installing and adjusting R111 as discussed in paragraph 5-82 or, if the instrument is equipped with Option Q20 or 022, by adjusting potentiometer R112 as discussed in paragraph 5-83.

3-45 Constant Current Output, Resistance Input. The rear panel connections shown in Figure 3-7 allow the output current to be varied by using an external resistor to program the supply. The supply's constant current programming current, which is factory adjusted to 2.5mA ±10%, determines the exact value of its programming coefficient. The programming coefficients for the supplies included in this manual are as follows:

Models	6259B	4 ohms/ampere
	6260B	2 ohms/ampere
	6261B	4 ohms/ampere
	6268B	6 ohms/ampere
	6269B	4 ohms/ampere

If the $\pm 10\%$ accuracy of these coefficients is not adequate, they may be adjusted either by changing resistor R30 as discussed in paragraph 5-96 or, if the instrument is equipped with Option 021 or 022, by adjusting potentiometer R116 as discussed in paragraph 5-97.



Figure 3-6. Voltage Programming of Output Voltage (Variable Gain)

3-46 With zero ohms connected across the programming terminals, the output current of the supply may be set to exactly zero either by installing and adjusting R117 as described in paragraph 5-91 or, if the instrument is equipped with Option 021 or 022, by adjusting potentiometer R119 as discussed in paragraph 5-93.

- CAUTION-

Do not allow programming terminals A4 or A6 to become open-circuited while resistance programming the output current. If they do open, the supply's output current rises to a value that may damage the supply or the load. If in the particular programming configuration used there is a chance that the terminals might open, we suggest that a 200 ohm resistor be connected across the programming terminals. Of course, when this resistor is used, the resistance value actually programming the supply is the parallel combination of the remote programming resistance and the resistor across the programming terminals. Like the programming resistor, this resistor should be a low noise, low temperature coefficient type.

3-47 Constant Current Output, Voltage Input (Fixed Gain). The rear panel connections shown in Figure 3-8 allow the output current to be varied by using an external voltage source to program the supply. The constant-current programming coefficients for the supplies included in this manual are as follows (±10%):

Model	6259B	10.0mV/ampere
	6260B	5.0mV/ampere
	6261B	10.0mV/ampere
	6268B	16.7mV/ampere
	6269B	10.0mV/ampere



Figure 3-7. Resistance Programming of Output Current

The load on the programming voltage source is less than 20 microamperes. The programming voltage required to obtain maximum rated current from these supplies is about 500 millivolts. An input greater than 600mV may damage the instrument through excessive power dissipation. Impedance matching resistor R_X is required to maintain the temperature coefficient and stability specifications of the supply. To adjust the output current to exactly zero with a zero programming voltage, follow the same instructions as are referred to in paragraph 3-46.

3-48 Constant Current Output, Voltage Input (Variable Gain). In the remote programming arrangement shown in Figure 3-9, the series combination of external voltage source E_S and reference resistor R_R replaces the supply's internal current programming source. As a result, the voltage this external current source develops across gain control R_P becomes the reference against which the voltage drop across the output current sampling resistor is compared by the constant-current comparator. The relationship between E_S and the supply's output current depends on the resistance ratio R_P/R_R and on the constant-current programming coefficient (K_P) of the supply. (These coefficients are given in paragraph 3-47.) The relationship between input voltage and output current is

 $I_{OUT} = (E_S \times R_P)/(K_P \times R_R).$

3-49 When using this programming technique, select a value for R_R that is less than 10k ohms and that would conduct at least 2.5 milliamps if connected across the programming voltage source with its voltage at the maximum value of input voltage to be used. Once the value for R_R is selected, multiply it by $K_P \times I_{OUT}$ (max)/ E_S (max) to find R_P . (If desired, the power supply's front panel current controls can be used in place of external gain control R_P by deleting the external gain control from the circuit and strapping together terminals A5 and A6.)



Figure 3-8. Voltage Programming of Output Current (Fixed Gain)

3-50 The output current of the supply can be adjusted to exactly zero with a zero programming voltage input either by installing and adjusting R115 as discussed in paragraph 5-92 or, if the instrument is equipped with Option 021 or 022, by adjusting potentiometer R116 as discussed in paragraph 5-94

3-51 Auto-Parallel Operation

3-52 Use the rear panel interconnections shown in Figure 3-10 or 3-11 to auto-parallel two or three supplies. This mode of operation provides a greater current capacity than can be obtained from a single supply while maintaining nearly equal load sharing among the paralleled supplies under all load conditions. Supplies having the same model number make the most practical auto-parallel combinations, but any of the supplies included in this manual that have equal current ratings may be used.

NOTE

Use wires of equal length and gauge to connect each auto-paralleled supply to the load. Load sharing accuracy is affected unless the positive leads connecting each supply to the load are all equal in resistance.

3-53 Setting the Voltage and Current Controls. The auto-parallel combination of two or three supplies behaves as if it were a single constant-voltage/constant-current supply controlled by the voltage and current controls of the master supply. The voltage controls of the slave(s) are disabled, but their current controls remain operative and must be set to maximum to prevent a slave supply from independently reverting to constant current operation as would occur if the output current setting of the master supply exceeded that of a slave.





3-54 Overvoltage Protection in Auto-Parallel. The sinterconnections shown in Figures 3-10 and 3-11 between the external crowbar trigger terminals on the master and on the slave(s) must be made to permit the overvoltage crowbar in the master to fire the SCRs in the master and the slave(s) if an overvoltage condition occurs. Be sure to connect them with correct polarity, plus to plus and minus to minus. Set the slave supply overvoltage potentiometer(s) to maximum (clockwise) to disable them, and adjust the overvoltage trip point at the master supply.

3-55 Auto-Parallel With Remote Sensing. To combine auto-parallel operation with remote sensing, connect the supplies as described above but remove the +S and -S jumpers from the master supply and connect the +S and -S terminals directly to the (+) and (-) ends of the load. Observe the precautions outlined under paragraph 3-27.

3-56 Auto-Parallel With Remote Programming. When two or three supplies are connected in auto-parallel, their combined output voltage, current, or both can also be remotely programmed. Refer to the appropriate sections of paragraph 3-34 for the additional rear panel connections required and make these connections to the master supply only. Observe all precautions outlined in the paragraphs on remote programming. The simultaneous use of remote sensing and remote programming is also possible during auto-parallel operation.

3-57 Auto-Series Operation



Figure 3-10. Auto-Parallel Operation of Two Units

3-58 Figures 3-12 and 3-13 show the rear panel and circuit board interconnections required to operate two or three supplies in the auto-series mode. This mode of operation allows two or three series-connected supplies to be simultaneously programmed by the voltage and current controls of a master supply. The master supply must always be the one at the positive end of the series combination. The output voltage of each slave supply varies in direct proportion to that of the master and the ratio of each slave's output voltage to the master's is established by the settings of the slave supplies' voltage controls. The resulting combination of two or three supplies behaves as if it were a single constant-voltage/constant-current supply. The supply with the lowest current rating limits the maximum output current of the combination. Any of the supplies included in this manual can be used as an auto-series slave, and any well-regulated variable output supply can be used as the master.

3-59 In applications where coordinated positive and negative voltages are required, grounding the center tap of an auto-series combination of supplies allows simultaneous proportional control of both supply voltages.

Determining the Value for R_X . Each slave supply 3-60 has an external resistor RX associated with it that supplies its voltage programming current. If the temperature coefficient and stability specifications of the supplies are to be maintained, these must be stable, low noise resistors with a temperature coefficient of less than 30ppm per °C and a power rating at least 30 times what they will actually dissipate. The proper value for R_X (when using two units in auto-series) or for RX1 (for the first slave when using three units) is calculated by first finding the voltage programming current of the slave supply. This is calculated by referring to Table 1-1 for the remote voltage programming resistance control coefficient and taking its reciprocal. For example, the voltage programming current in the Model 6259B is $1/(200\Omega/V)$ or 5mA. Next, divide this current into the maximum voltage rating of the master supply to determine R_X for the first slave. If our master supply were a zero-to-25-volt unit, for example, R_X or R_{X1} would be 25V/5mA = 5000 ohms.

3-61 When operating three supplies in auto-series, find R_{X2} by dividing the voltage programming current of the second slave, calculated as in paragraph 3-60, into the maximum voltage expected from the first slave.

3-62 Setting the Voltage Controls. The voltage each slave supply contributes is determined by its voltage control setting. The output voltage of the first slave supply tracks the voltage of the master, and the voltage of the second slave (if used) tracks the voltage of the first slave. For this reason, the voltage of the master must be adjusted to

maximum, and then each slave, in turn, must be set to the corresponding voltage desired during initial setup of the auto-series combination. Once this has been done, the total voltage of the combination can be controlled by the voltage controls of the master supply or it can be remotely programmed through the master supply.

3-63 Setting the Current Controls. Auto-series operation leaves the current controls of all supplies operative, but the supply whose current control has the lowest setting determines the point at which automatic crossover to constant current operation begins to lower its output voltage and thus that of the series combination. The constant current circuit of a supply has no effect on the outputs of the supplies connected in a more positive position in the series combination, but it does affect its own output and the outputs of the supplies connected in a more negative position. If the current controls of one of the slave supplies are set the lowest, then an overload or short circuit at the output will cause the master supply (or the master and the first slave) to force current through the reverse voltage protection diodes at the outputs of the downstream slaves. Because this current could be excessive either for the diodes



Figure 3-11. Auto-Parallel Operation of Three Units

or the load, the current controls of the slave supplies should be set to maximum and the master supply's current controls used to establish the output current or current limit.

3-64 Overvoltage Protection in Auto-Series. The interconnections shown in Figures 3-12 and 3-13 between the external crowbar trigger terminals on the master and on the slave(s) must be made to permit the overvoltage crowbar in any one of the interconnected supplies to fire the SCRs in all of them if an overvoltage condition occurs. Be sure to connect them with correct polarity, plus to plus and minus to minus. Set the overvoltage potentiometer in each supply so that it trips at a point slightly above the voltage that supply will contribute.

3-65 Auto-Series With Remote Sensing. To combine auto-series operation with remote sensing, connect the supplies as described above but remove the +S jumper from the master supply and the -S jumper from the last slave supply and connect the +S and -S terminals directly to the (+) and (-) ends of the load. Observe the precautions outlined under paragraph 3-27.

3-66 Auto-Series With Remote Programming. When two or three supplies are connected in auto-series, their combined output voltage, current, or both can also be remotely programmed. Refer to the appropriate sections of paragraph 3-34 for the additional rear panel connections required and make these connections to the master supply only. Observe all precautions outlined in the paragraphs on



Figure 3-12. Auto-Series Operation of Two Units

remote programming. The simultaneous use of remote sensing and remote programming is also possible during auto-series operation.

3-67 Auto-Tracking Operation

3-68 Figures 3-14 and 3-15 show the rear panel interconnections required to operate two or three supplies in the auto-tracking mode. This mode of operation allows two or three supplies that share a common negative output bus to power separate loads and have their outputs simultaneously programmed by the voltage and current controls of a master supply. Unless their outputs are to be equal, the supply that is to have the greatest output voltage must be selected as the master. The output voltage of each slave supply remains a constant percentage of the master's with the percentage for each slave established by that slave's voltage control settings and the choice of its external programming resistor R_X. Any of the supplies included in this manual can be used as an auto-tracking slave, and any well-regulated variable output supply can be used as the master.



Figure 3-13. Auto-Series Operation of Three Units

3-69 Determining the Value for R_X . Each slave supply has an external resistor R_X associated with it that supplies its voltage programming current. If the temperature coefficient and stability specifications of the supplies are to be maintained, these must be stable, low noise resistors with a temperature coefficient of less than 30ppm per °C and a power rating at least 30 times what they will actually dissipate. To calculate the proper value for R_X for each slave, the following information is required:

a. E_M, the rated maximum voltage of the master supply

b. Es, the corresponding maximum voltage desired of

the slave supply with its voltage control set to maximum. c. Rp, the resistance of the slave supply's coarse

voltage control.

The Rp values for the supplies included in this manual are as follows:

Model	6259B, 6260B	$2.5k\Omega$
	6261B	5kΩ
	6268B, 6269B	$10k\Omega$
To find R,	use the formula:	

$$R_X = (E_M R_P/E_S) - R_P$$

For example, if the slave supply is a Model 6259B and we want its output to vary from zero to 10 volts as the master supply varies from zero to 40 volts, the solution for R_X is:

$$R_{X} = (40V \times 2.5k\Omega/10V) - 5k\Omega$$
$$R_{X} = 5k\Omega$$

3-70 It is also possible to make an auto-tracking slave's voltage equal the output of the master supply. To do this, make a direct connection from the +S terminal of the master to the A2 terminal of the slave instead of using a programming resistor, and remove the slave's A1 to A2 jumper.

3-71 Setting the Voltage and Current Controls. The voltage control of each slave must be set fully clockwise to obtain the voltage ratios established by the formula for R_X given in paragraph 3-69. By lowering the settings of the slave's voltage controls, the voltage of the slave can be made a smaller percentage of the master supply's voltage. The current controls of all supplies in an auto-tracking combination are independently operative and can be used to set current limits for each individual load. If the master supply goes into constant current mode, the output voltages of the slaves continue to track that of the master. If a slave supply goes into constant current mode, however, no other supply is affected.

3-72 Overvoltage Protection in Auto-Tracking. Paralleling the crowbar circuits, as is required for the auto-parallel and auto-series modes, is optional in the auto-tracking mode. If the external trigger windings of transformer T90 in the master and in the slave supplies are not paralleled, the overvoltage protection circuit in each supply independently monitors the voltage across its own load. Then if the master supply crowbars, the output voltage of the slave(s) also decreases, but if one of the slaves crowbars, no other supply is affected.

3-73 In order to have all supplies in an auto-tracking combination crowbar simultaneously if any of them has an overvoltage condition, parallel their crowbar circuits as shown in Figure 3-14 or 3-15. Set the overvoltage potentiometer in each supply so that it trips at a point slightly above the voltage that supply will provide.

3-74 Auto-Tracking With Remote Sensing. To combine auto-tracking operation with remote sensing, connect the supplies as described above but remove the +S and -S jumpers from each supply and connect the +S and -S terminals directly to the (+) and (-) ends of its load. Observe the precautions outlined under paragraph 3-27.

3-75 Auto-Tracking With Remote Programming. When two or three supplies are connected for auto-tracking operation, their output voltages can be remotely programmed but their currents cannot. Refer to the appropriate sections of paragraph 3-34 for the additional rear panel connections required and make these connections to the master supply only. Observe all precautions outlined in the paragraphs on remote programming. The simultaneous use of remote sensing and remote programming is also possible during auto-tracking operation.



Figure 3-14. Auto-Tracking Operation of Two Units

3-76 SPECIAL OPERATING CONSIDERATIONS

3-77 Pulse Loading

3-78 The power supply automatically crosses over from constant-voltage to constant-current operation, or the reverse, in response to an increase beyond the preset voltage or current limit. Although the preset limit may be set higher than the average output current or voltage, high peak currents or voltages may exceed the preset limit and cause crossover to occur. If this current or voltage limiting is not desired, set the current or voltage requirement.

3-79 Output Capacitance

3-80 An internal capacitor (A3C3) connected across the output terminals of the supply helps to supply highcurrent pulses of short duration during constant voltage operation. Adding capacitance externally would improve the pulse current capability of the supply but would decrease the load protection provided by the constantcurrent circuit. A high-current output pulse could damage load components before the average output current is large enough to cause the constant-current circuit to operate. Another drawback to adding additional capacitance is the possibility of causing the supply to become unstable and oscillate.

3-81 During constant-current operation, additional capacitance connected across the output of the supply would have the following disadvantages:

 a. With additional capacitance connected, the output impedance of the supply decreases with increasing frequency.

b. With additional capacitance connected, the output current takes longer to recover from the effects of a change in the load resistance.

c. With additional capacitance connected, a rapid reduction in load resistance can produce a larger than normal surge current that could cause a high power dissipation in the load.

3-82 Reverse Voltage Protection

3-83 One or two internal diodes (A4CR106, or A4CR106 and A4CR107) connected with reverse polarity across the output terminals of the supply protect the output electrolytic capacitors and series transistors from the effects of a reverse voltage applied across the supply's output. Such a reverse voltage might inadvertently be applied when operating supplies in series if one of them were to be turned on or off before the other. The current rating of the output diodes is equal to the rated output current of the supply.

3-84 The series regulator transistors are also protected against reverse voltage by diode A4CR105. This diode shunts the series regulators if the supply is connected in parallel with another supply but is deenergized.

1. IF.

3-85 Reverse Current Loading

3-86 An active load connected to the power supply may actually deliver a reverse current to the supply during a portion of its operating cycle. If an external source is allowed to pump current into the supply, it will cause a loss of regulation and might possibly damage the output capacitor. To avoid these effects, it is necessary to preload the supply with a dummy load resistor so that it delivers current through the entire operating cycle of the load device.

3-87 Battery Charging

3-88 The automatic crossover between constant-voltage and constant-current exhibited by these supplies makes them ideal for battery charging applications. Using this



Figure 3-15. Auto-Tracking Operation of Three Units

feature, a battery may be charged at a constant-current until the maximum charge voltage is reached, at which point the supply reverts to constant-voltage operation and continues to supply a trickle charge current sufficient to maintain full charge. Thus, the charging operation can be unattended after properly setting the charging rate and maximum charge voltage and connecting the battery to the output terminals of the supply.

-----CAUTION ------

Any time these supplies are used to charge a battery, be sure to install a protective diode CR_p in series with the battery as shown in Figure 3-16 to prevent the battery from discharging into the supply if the supply is turned off. Extensive damage to the supply could result if this diode were omitted.

The use of remote voltage sensing provides no advantages when performing a constant-current battery charge as discussed in paragraph 3-89 or a taper charge as discussed in paragraph 3-90. Because of a serious risk of damage to the supply, the use of remote voltage sensing should not be attempted when charging (or discharging) a battery. Also see the CAUTION following paragraph 3-32.

NOTE

A large battery, connected as a load, presents a large capacitance to the output terminals. This capacitance could cause the supply to oscillate. If the supply appears unstable, it may be beneficial to readjust equalization control R47 located on the main circuit board.

3-89 Constant-Current Charge. To perform a constantcurrent battery charge, set the charging rate and full charge voltage as follows:

a. Turn both the VOLTAGE and CURRENT controls fully counterclockwise (CCW).

 b. Connect a short circuit across the output terminals and rotate the VOLTAGE control fully clockwise (CW).

c. Adjust the CURRENT control for the desired charging rate as read on the front panel ammeter.

d. Rotate VOLTAGE control fully CCW and remove the short circuit.

e. Adjust the VOLTAGE control for an output voltage 0.7 volts greater than the desired full charge voltage. (The added 0.7 volts compensates for the drop across CR_p .) The supply may then be connected to the battery terminals, positive to positive and negative to negative as shown in Figure 3-16 (omit R_T).

3-90 Taper Charge. When charging lead-acid cells, many manufacturers recommend that the charging current be reduced as the charge nears completion. This can be accomplished by inserting a small resistance (R_T) in series with one of the load leads from the supply to the battery. (See Figure 3-16.) This resistor alters the normally rectangular charging plot in such a manner as to provide a taper charge for the last portion of the charge. The proper value for this resistor is the difference between the full charge voltage and the voltage at which the tapering is to start, divided by the initial charging current. Set the initial charging rate and full charge voltage as instructed in paragraph 3-89.

3-91 Battery Discharging

3-92 These power supplies are also useful when batteries must be discharged at a constant current in order to test them. Connecting a supply as shown in Figure 3-17 and following the instructions below makes an unattended constant-current discharge possible by automatically shutting off the output of the supply when the battery voltage reaches zero.

3-93 The supply operates in the constant-current mode, delivering the current set by the current control. This constant current flowing through dropping resistor R_X produces a constant voltage across the resistor. Initially, the battery voltage is high and the supply's output voltage is low, but as the battery voltage decreases during discharge, the supply voltage increases. When the battery voltage reaches zero,



Figure 3-16. Battery Charging

1 .

the supply senses this through the connection to its A2 terminal and reduces the output current to zero. (If this automatic shutoff feature is not required, the 10k ohm resistor may be omitted.) As shown in Figure 3-17, R_X must be selected so that its IR drop is less than the maximum rated output voltage of the supply, but greater than the initial battery voltage.

3-94 To give a battery a constant-current discharge, proceed as follows:

a. Turn off the power supply and disconnect the jumpers from terminal A1 to A2 and from A2 to A3. (This step disables the supply's VOLTAGE controls.)

b. Connect terminal A3 to +S and leaves all other jumpers connected as for normal operation as shown in Figure 3-17.

c. Connect the positive terminal of the battery to A2 through a $10k\Omega$ resistor.

d. Connect the positive terminal of the supply to the negative terminal of the battery.

e. Connect R_X between the negative terminal of the supply and the positive terminal of the battery, rotate the supply's current control fully counterclockwise (CCW), energize the supply, and set the current control for the desired discharge current as indicated on the front panel meter.





4-25 When the negative threshold voltage is reached, transistor Q72 is turned off and Q73 is turned on. The conduction of Q73 allows capacitor C71 to discharge rapidly through pulse transformer T70, generating a firing pulse across the secondary of T70. Diode CR88 blocks any positive overshoot.

4-26 The control circuit is reset once every 8.33 milliseconds when the rectified ac voltage at the junction of CR77, CR78, and CR79 (TP82) forward biases diode CR78. Summing capacitor C70 is then allowed to discharge through CR78. Diodes CR74 and CR75 become reverse biased at reset, allowing Q72 to turn on. Consequently, Q73 is turned off and capacitor C71 charges up through R79 at a comparatively slow rate until the collector voltage of Q73 reaches approximately +11 volts.

4-27 Overvoltage Limit Circuit

4-28 Under normal circumstances, Q70 in the overvoltage limit circuit is biased off by the equal voltages on its base and emitter. Diodes CR70 and CR71 are forward biased by a small current through R71 to develop Q70's base voltage. R72, connected between Q70's base and the supply's negative output, shunts an amount of current away from the diodes that is proportional to the supply's output voltage. When the output voltage reaches approximately 120% of its rated maximum, the diode current falls to zero, biasing Q70 on. When Q70 conducts, it disables the preregulator by holding CR74 and CR75 reverse biased to prevent Q72 and Q73 from generating triac firing pulses.

4-29 Series Regulator and Driver

4.30 Depending on the model, the series regulator is composed of four, six, or eight transistors connected in parallel. These transistors serve as the series element that provides precise and rapid control of the output. The series transistors are controlled by driver A4Q102. Thermal switch A4TS101 turns off the series regulator transistors by opening if the heatsink temperature exceeds approximately 230°F. This feature protects critical components from the excessive temperatures that could occur if cooling fan A4B1 failed. Diode CR50 provides a discharge path for the output capacitors when the supply is rapidly downprogrammed. Resistor R57 limits the discharge current through the diode and through error amplifier A4Q101. Diode A4CR105 is connected across the regulator circuit to protect the series elements from reverse voltages that could develop if one supply is turned on or off before the other during parallel operation.

4-31 Short-Circuit Protection

4-32 The short-circuit protection circuit protects the

series regulator against damage due to a simultaneous fullvoltage full-current condition as might occur if the output were shorted while the controls were set to deliver a high output voltage and current. If this occurs, the increased voltage across the series regulator turns Q20 on and shuts off the preregulator. The conduction of Q20 puts R26 in parallel with the current controls to limit the output current to less than 10% of the supply's rating. The preregulator shuts off within 10 milliseconds after the short circuit is imposed. Then the input capacitor begins to discharge through the series regulator and the voltage across the regulator decreases until Q20 turns off. The discharge time (typically 1/2 to 4 seconds) depends on the voltage and " current ratings of the supply, the size of the main filter capacitor, and the control settings. Once this recovery time has elapsed, the output current returns to the level set by the current controls, and the preregulator returns the voltage across the series regulator to its normal 3.5-volt level.

4-33 Constant-Voltage Comparator

4-34 The constant-voltage comparator consists of programming resistors A5R121 and A5R122, differential amplifier Z1, and associated components. An integrated circuit is used for the differential amplifier to minimize



Figure 4-4. Preregulator Control Circuit Waveforms

voltage differentials due to mismatched transistors or temperature differences.

4-35 The constant-voltage comparator compares the voltage drop across the VOLTAGE controls with the supply's output voltage. If a difference exists, it produces an error voltage proportional to this difference. This error signal alters the conduction of the series regulator, which changes the output voltage until it is equal to the voltage drop across the VOLTAGE controls. Hence, through feed-back action, the difference between the two inputs to Z1 is held at zero volts.

4-36 One input of the differential amplifier (pin 10) is connected to the output voltage sensing terminal of the supply (+S) through impedance equalizing resistor R23. Resistors R1 and optional resistor R110 zero bias the input. If the supply is equipped with Option 020 or 040, resistor R114 and potentiometer R113 provide a variable input bias that allows the output voltage to be easily adjusted to exactly zero volts when the supply is programmed for zero output. The other input of the differential amplifier (pin 1) is connected to the summing point (terminal A2) at the junction of the programming resistors and current pullout resistors R3, R4, and R5. Instantaneous changes in the output voltage or changes in the voltage at the summing point due to changes in the VOLTAGE control setting produce a difference voltage between the two inputs of the differential amplifier. This difference voltage is amplified and appears at the output of the differential amplifier (pin 12) as an error voltage which ultimately varies the conduction of the series regulator.

4.37 Resistor R6, in series with the summing point input to the differential amplifier, limits the current flowing into the differential amplifier during rapid voltage turndown. Diode CR7 prevents excessive current drain from the +6.2 volt reference supply during rapid down-programming. Diodes CR5 and CR6 prevent excessive voltage excursions from overdriving the differential amplifier.

4-38 During constant-voltage operation, the programming current flowing through the programming resistors (VOLTAGE controls) is constant because the summing point is held constant at zero volts by feedback action and virtually all of the reference supply current flowing through pull-out resistors R3, R4, and R5 flows through VOLTAGE controls A5R121 and A5R122. Linear constantvoltage programming is thus assured. Resistor R3 serves as a trimming adjustment for the programming current flowing through A5R121 and A5R122. If the supply is equipped with Option 020 or 040, resistor R111 and potentiometer R112 allow the programming current to be adjusted over a narrow range around its nominal value. In practice, this adjustment sets the power supply output to exactly the maximum rated voltage when programmed to that level.

4-39 Main output capacitor A3C3, connected across the output terminals of the supply, stabilizes the series regulator feedback loop and helps supply high-current pulses of short duration during constant-voltage operation. An additional output capacitor (C19) is connected directly across the output bus bars to maintain a low ac output impedance by compensating for the inductive reactance of the main output capacitor at high frequencies. C19 also helps to minimize output spikes.

4-40 Constant-Current Comparator

•4-41 The constant-current comparator is similar in appearance and operation to the constant voltage comparator. It consists of programming resistors A5R123 and A5R124, differential amplifier Z1, and associated components.

4.42 The constant-current comparator circuit compares the voltage drop across the CURRENT controls with the voltage drop across current sampling resistor A4R123. If a difference exists, the differential amplifier produces an error signal proportional to this difference. The remaining components in the feedback loop (amplifiers and the series regulator) maintain the drop across the current sampling resistor, and hence the output current, at a constant value.

4-43 One input of the differential amplifier (pin 7) is connected to the output bus through impedance equalizing resistor R20 and is zero-biased by R21 and optional resistor R117. Its other input (pin 4) is connected to the summing point (terminal A6) at the junction of programming resistors A5R123 and A5R124 and current pullout resistors R30 and R31. Instantaneous changes in the output current due to load changes or changes in the voltage at the summing point due to changes in the CURRENT control setting produce a difference voltage between the two inputs of the differential amplifier. This difference voltage is amplified and appears at the output of the differential amplifier (pin 6) as an error voltage which ultimately varies the conduction of the series regulator.

4-44 Resistor R30 serves as a trimming adjustment for the programming current flowing through A5R123 and A5R124. If the supply is equipped with Option 021 or 040, resistor R115 and potentiometer R116 allow the programming current to be adjusted over a narrow range around its nominal value, and resistor R118 and potentiometer R119 provide a variable input bias to allow the output current to be easily adjusted to exactly zero when the supply is programmed for zero output. Diode CR21 limits excessive voltage excursions at the summing-point input to the differential amplifier.

4-45 Voltage Clamp Circuit

4-46 The voltage clamp circuit keeps the constantvoltage programming current relatively constant when the power supply is operating in the constant-current mode. This is accomplished by clamping terminal A2, the voltage summing point, to a fixed bias voltage. During constantcurrent operation the constant-voltage programming resistors are a shunt load across the output terminals of the supply. When the output voltage changes, the current through these resistors also tends to change. Since this programming current flows through the current sampling resistor, it is erroneously interpreted as a load change by the current comparator circuit. The voltage clamp eliminates this undesirable effect by maintaining the programming current at a constant level.

110222

4-47 The voltage divider consisting of Z2A, Z2B, and VR1 back biases CR2 and Q1 during constant-voltage operation. When the power supply goes into constant-current operation, CR2 becomes forward biased by the voltage at pin 12 of Z1. This results in the conduction of Q1 and the clamping of the summing point at a potential only slightly more negative than the normal constant-voltage potential. Clamping this voltage at approximately the same potential that exists in constant-voltage operation results in a constant voltage across, and consequently a constant current through, current pullout resistors R3, R4, and R5.

4-48 Mixer and Error Amplifiers

4-49 The mixer and error amplifiers amplify the error signal received from the constant-voltage or constantcurrent input circuit to a level sufficient to drive the series regulator transistors. Mixer amplifier Q41 receives the error voltage input from either the constant-voltage or constantcurrent comparator via the OR-gate diode (CR1 or CR20) that is conducting at the time. Diode CR1 is forward biased and CR20 reverse biased during constant-voltage operation. The reverse is true during constant-current operation.

4-50 Transistor Q40 provides a constant current to the collector of Q41 and also generates a negative-going turn-off signal for the series regulator when the unit is first turned off. Feedback network C41, R47, and R53 shapes the high frequency rolloff in the loop gain response in order to stabilize the series regulator feedback loop.

4-51 Error amplifiers Q42 and A4Q101 serve as the predriver elements for the series regulator. A4Q101 also provides a discharge path for the output capacitors in order to allow faster down-programming and conducts a bleed current for the series regulator to keep it in its active region when the supply is set for zero output current. Diode CR44 prevents A4Q101's base from going more negative than -3 volts in order to limit the bleed current through R57 and protect A4Q101 from damage if a voltage higher than the programmed output voltage is applied across the output terminals.

4-52 Overvoltage Protection Crowbar

4-53 The overvoltage protection crowbar circuit protects sensitive loads against the application of an excessively high voltage, as might result from a series regulator transistor failure. It accomplishes this by immediately shorting the output of the supply as soon as a preset threshold voltage is exceeded. Until silicon controlled rectifier A4CR119 has been triggered, it acts as an open circuit and has no effect on the output voltage. Transistors Q91 and Q92 detect an overvoltage condition and trigger the SCR to fire. When the SCR fires, it shorts the supply's output.

During normal operation, Q92 is biased on by 4-54 current through R99, Q91 is kept turned off by Q92, and CR91 is reverse biased by the voltage divider formed by resistors R90, R95, and A5R125. Zener diode VR90 provides a stable reference voltage with which the -S potential is compared. Potentiometer A5R125 (OVER-VOLTAGE ADJUST) establishes the output voltage at which CR91 becomes forward biased and turns Q92 off. When Q92 turns off, Q91 begins to conduct, sending a positive-going trigger pulse to A4CR110 and causing it to create a near short circuit across the output. When A4CR110 fires, overvoltage lamp A5DS2 turns on, completing a path for a +11V unregulated holding current through A5DS2. (R92 supplies the holding current if the lamp should open.) This current holds A4CR110 on even after the output voltage has fallen. A4CR110 remains in conduction until the supply is turned off. A4R106 protects A4CR108 and A4CR110 from the large surge current that occurs when A4CR110 is first fired. CR93 damps out negative overshoot in the trigger pulse.

4-55 The firing of A4CR110 biases Q90 into conduction. This places approximately +11 volts on the cathode of CR74 in the preregulator control circuit to reverse bias CR74 and CR75. By preventing transistor Q72 from turning off, this prevents the generation of any trigger pulses and turns off the preregulator.

4-56 The crowbar circuit creates an extra current path during normal operation of the supply, thus changing the current that flows through the sampling resistor. Diode CR92 keeps this extra current at a fixed level for which compensation can then be made in the constant-current comparator circuit.

4.57 A slaving arrangement for the crowbar circuits in more than one supply is made possible by an extra

secondary winding (terminals 5 and 6) on T90. This winding is connected to terminals on the rear barrier strip marked \pm EXT. CROWBAR TRIGGER. When two or three units have these windings connected in parallel, all of their crowbars are activated when any one of the crowbars is tripped. To reset the crowbars in this arrangement, all of the units must be turned off and then on. Polarity must be observed when connecting units in this fashion.

4-58 Turn-On Control Circuit

4-59 The turn-on control circuit is a long-time-constant network which protects the triac and the series regulator from possible damage during turn-on. When the supply is first turned on, C35 applies a positive voltage to the anodes of CR35 and CR36. Diode CR35 couples this voltage to the cathode of CR74 in the preregulator control circuit to ensure that it is initially reverse biased. After C35 becomes sufficiently charged, CR35 becomes reverse biased and the preregulator control circuit is permitted to fire the triac.

4-60 Diode CR36 performs a similar function for the series regulator. This diode initially couples a positive voltage to Q41, which inverts it and applies it to the series regulator. This negative voltage keeps the regulator cut off until C35 charges up. Diode CR37 provides a discharge path for C35 when the supply is turned off.

4-61 Reference Regulator

4-62 The reference circuit is a feedback power supply similar to the main supply. It provides stable reference voltages used throughout the unit. All the regulated reference voltages are derived from dc obtained from fullwave rectifier CR61 and CR62 and filter capacitor C61. Zener diodes VR60 and VR61 establish well regulated potentials of +6.2V and -6.2V with respect to common point +S, while the regulator circuit establishes a well regulated potential of +12.4 volts. Resistor R63 establishes an optimum bias current through the zener diodes.

4.63 The regulating circuit consists of series regulating transistor Q60, driver Q61, and differential amplifier Q62 and Q63. The voltage across zener diodes VR60 and VR61 is compared to the voltage across resistor Z2J, and any difference is amplified by Q62 and Q63. The error voltage thus appearing at the collector of Q62 is amplified by driver stage Q61 and applied to series regulator Q60 in the correct phase and amplitude to maintain the +12.4 volt output at a constant level.

4-64 Diode CR60, connected from voltage divider R66 and R67 to the base of Q61, serves as a turn-on circuit for series regulator transistor Q60. When the supply is first turned on, CR60 biases driver Q61 on, thus turning on the series regulator. When the reference supply reaches normal output, the base voltage of Q61 is sufficient to reverse bias CR60, thus effectively removing it from the circuit. Capacitor C60, connected across the output of the reference supply, removes spikes and stabilizes the reference regulator loop.

4-65 A separate winding on transformer A3T2, diodes CR53 and CR54, and filter capacitor C44 provide an unregulated +11V output. Additional lightly regulated reference voltages of -2.4 volts and -4 volts are provided by diodes CR45 through CR49. Resistor R41 biases the diodes. Diode CR43 prevents reverse current flow from damaging the main supply series regulator transistor(s). Diode CR27, shown on the schematic near current pullout resistors R3, R4, and R5, protects the zener diodes in the reference circuit by providing a path for surge currents that occur during rapid down-programming.

4-66 Meter Circuit

4-67 The front panel voltmeter and ammeter provide continuous indications of output voltage and current. Both meter movements can withstand an overload of several times the maximum rated output without damage.

4-68 The ammeter, together with its series resistors R101 and R105, is connected across current sampling resistor A4R123. As mentioned previously, the voltage drop across A4R123 varies in proportion to the output current. Potentiometer R101 permits calibration of the ammeter.

4-69 The voltmeter, in series with R103 and R104 and shunted by R102 and R106, is connected directly across the output terminals of the supply. Potentiometer R106 permits calibration of the voltmeter.

4-70 Additional Protection Features

4-71 The supply contains several special purpose components that protect it in the event of unusual circumstances. One of these components is diode A4CR106 (and A4CR107). Connected across the output terminals of the supply, it prevents internal damage from reverse voltages that might be applied across the supply. This could occur, for example, during Auto-Series operation if one supply were turned on or off before the other.

4-72 Resistors R108 and R109 limit the output of the supply if the jumpers between the output buses and the sensing terminals (+S and -S) are inadvertently removed.

4-73 Diode A4CR105, previously mentioned in the series regulator description, protects the regulating transistor from reverse voltages.

SECTION V MAINTENANCE

5-1 INTRODUCTION

5-2 Upon receipt of the power supply, the performance test (paragraph 5-5) should be made. This test is suitable for incoming inspection. If a fault is detected in the power supply while making the performance test or during normal operation, proceed to the troubleshooting procedures (paragraph 5-49). After troubleshooting and repair (paragraph 5-69) perform any necessary adjustments and calibrations (paragraph 5-71). Before returning the power supply to normal operation, repeat the applicable portions of the performance test to ensure that the fault has been properly corrected and that no other faults exist. Before performing any maintenance checks, turn on the power supply and allow a half-hour warm-up.

ТУРЕ	REQUIRED CHARACTERISTICS	USE	RECOMMENDED MODEL
Digital Voltmeter	Sensitivity: $100\mu V$ full scale (min.) Input Impedance: $10M\Omega$ (min.)	Measure dc voltages; calibration procedures.	HP 3450B .
Oscilloscope	Sensitivity and bandwidth: 100µV/cm and 400kHz for all measurements except noise spike; 5mV sensitivity and 20MHz bandwidth for noise spike measurement.	Measure ripple; display transient recovery waveform; measure noise spikes.	HP 180C with 1821A time base and 1806A vertical plug-in; 1803A plug-in for spike measurement.
Variable Voltage Transformer	Range: 208-254 volts. Output current: 200% (min.) of supply input current listed in para. 2-16.	Vary ac input for line regulation measurement.	
Digital or Analog Multimeter		Measure ac and dc voltages, resistance.	HP 3490A or HP 427A
Repetitive Load Switch	Switching rate: 60-400Hz. Rise time: 2µsec.	Measure transient recovery time.	See Figure 5-4.
Resistive Load	Values: see Figures 5-1, 5-4, and 5-7.	Power supply load resistor.	
Current Sampling Resistor	Value: See Figure 5-7.	Measure output current; calibrate ammeter.	
Terminating Resistors	Value: 50 ohms, 1/2 watt, ±5% non-inductive. (Four required.)	Noise spike measurement.	
Blocking Capacitors	Value: 0.01µF, 100Vdc. (Two required.)	Noise spike measurement.	

Table 5-1. Test Equipment Required

5-3 TEST EQUIPMENT REQUIRED

5-4 Table 5-1 lists the test equipment required to perform the procedures described in this section.

5-5 PERFORMANCE TEST

5-6 The following test can be used as an incoming inspection check. Appropriate portions of the test can be repeated either to check the operation of the instrument after repairs or for periodic maintenance tests. The tests are performed using a 230Vac 60Hz single-phase input power source. If the correct result is not obtained for a particular check, do not adjust any internal controls; instead proceed to troubleshooting (paragraph 5-49).

5-7 CONSTANT-VOLTAGE TESTS

5.8 Connect all of the measuring devices used in the constant voltage performance tests directly to the power supply sensing terminals (±S). For best accuracy, the sensing terminals must be used rather than the output terminals, since the measuring instruments must be connected to the same pair of terminals to which the feedback amplifier within the power supply is connected. This is particularly important when measuring the regulation, transient response, or ripple of the power supply. Note that the measuring instruments should not be connected across the load. A measurement made across the load includes the impedance of the leads to the load and such lead lengths can easily have an impedance several orders of magnitude greater than the supply impedance (typically less than 1 milliohm at dc), thus invalidating the measurement.

5-9 To avoid mutual coupling effects, connect each monitoring device to the sensing terminals by a separate pair of leads. Use twisted pairs or shielded two-wire cables to avoid pickup on the measuring leads. Connect the load resistor across the output terminals as close to the supply as possible. When measuring the constant-voltage performance specifications set the current controls well above (at least 10% above) the maximum output current the supply will draw, since the onset of constant-current operation will cause a drop in output voltage, increased ripple, and other performance changes not properly ascribed to the constant-voltage operation of the supply.

5-10 Voltage Output and Voltmeter Accuracy. To check that the supply will furnish its rated output voltage, proceed as follows:

a. Connect load resistor (R_L) indicated in Figure 5-1 across output terminals of supply.

b. Connect digital voltmeter across +S and -S terminals of supply, observing correct polarity.

c. Turn CURRENT controls fully clockwise.

d. Turn on supply and adjust VOLTAGE controls until front panel meter indicates exactly maximum rated output voltage.

e. Digital voltmeter should indicate:

6259B, 6260B	10 ±0.2Vdc
6261B	20 ±0.4 Vdc
6268B, 6269B	40 ±0.8Vdc

5-11 Load Effect (Load Regulation).

Definition: The change ΔE_{OUT} in the static value of dc output voltage resulting from a change in load resistance from open circuit to a value which yields maximum rated output current, or vice versa.

5-12 To check the constant-voltage load effect, proceed as follows:

a. Connect test setup shown in Figure 5-1.

b. Turn CURRENT controls fully clockwise.

c. Turn on supply and adjust VOLTAGE controls until front panel meter indicates exactly maximum rated output current.

d. Read and record voltage indicated on digital voltmeter.

e. Disconnect load resistor.

f. Reading on digital voltmeter should not differ from reading recorded in step (d) by more than:

6259B, 6260B	1.2mV	
6261B	2.2mV	
6268B, 6269B	4.2mV	



Figure 5-1. Constant-Voltage Load Regulation Test Setup
Definition: The change ΔE_{OUT} in the static value of dc output voltage resulting from a change in ac input voltage over the specified range from low line to high line, or from high line to low line.

5-14 To check the source effect, proceed as follows: a. Connect test setup shown in Figure 5-1.

b. Connect variable autotransformer between input power source and power supply ac input.

c. Adjust autotransformer for 208Vac input.

d. Turn CURRENT controls fully clockwise.

e. Turn on supply and adjust VOLTAGE controls until front panel meter indicates exactly maximum rated output voltage.

f. Read and record voltage indicated on digital voltmeter.

g. Adjust variable autotransformer for 254 Vac input.

h. Digital voltmeter reading should not differ from reading recorded in step (f) by more than:

6259B, 6260B	1.2mV
6261B	2.2mV
6268B, 6269B	4.2mV

5-15 PARD (Ripple and Noise).

Definition: The residual ac voltage superimposed on the dc output of a regulated power supply. Ripple and noise measurements may be made at any input ac line voltage combined with any dc output voltage and load current within the supply's rating.

5-16 The amount of ripple and noise present on the power supply output is measured either in terms of its rms or (preferably) peak-to-peak value. The peak-to-peak measurement is particularly important for applications where noise spikes could be detrimental to sensitive loads such as logic circuitry. The rms measurement is not an ideal representation of the noise since fairly high output noise spikes of short duration can be present in the ripple without appreciably increasing the rms value.

5-17 Ripple Measurement Techniques. Figure 5-2A shows an incorrect method of measuring peak-to-peak ripple. Note that a continuous ground loop exists from the third wire of the input power cord of the supply to the third wire of the input power cord of the oscilloscope via the grounded power supply case, the internal jumper connecting the power supply negative output and sensing terminals, the wire between the negative sensing terminal of the power supply and the vertical input of the scope, and the grounded scope case. Any ground current circulating in this loop as a result of the difference in potential E_G between the two ground points causes an IR drop which is in series with the scope input. This IR drop, normally having a 60Hz line frequency fundamental,

plus any pickup on the unshielded leads interconnecting the power supply and scope, appears on the face of the CRT. The magnitude of this resulting noise signal can easily be much greater than the true ripple developed between the plus and minus sensing terminals of the power supply and can completely invalidate the measurement.

5-18 The same ground current and pickup problems can exist if an rms voltmeter is substituted for the oscilloscope in Figure 5-2A. However, the oscilloscope display, unlike the true-rms meter reading, tells the observer immediately whether the fundamental period of the signal displayed is 8.3 milliseconds (1/120Hz) or 16.7 = milliseconds (1/60Hz). Since the fundamental ripple frequency present on the output of an HP supply is 120Hz (due to full-wave rectification), an oscilloscope display showing a 120Hz fundamental component indicates a "clean" measurement setup, while the presence of a 60Hz fundamental usually means that an improved setup will result in a more accurate (and lower) value of measured ripple.



Figure 5-2. Ripple Test Setup

5-19 Although the method shown in Figure 5-2A is not recommended for ripple measurements, it may prove satisfactory in some instances provided certain precautions are taken. One method of minimizing the effects of ground current flow (I_G) is to ensure that both the supply and the test instrument are plugged into the same ac power bus.

5-20 To minimize pickup, a twisted pair or (preferably) a shielded two-wire cable should be used to connect the sensing terminals of the power supply to the vertical input terminals of the scope. When using a twisted pair, take care that the same wire is connected both to the grounded terminal of the power supply and the grounded input terminal of the oscilloscope. When using shielded twowire cable, it is essential for the shield to be connected to ground at only one end to prevent any ground current flowing through this shield from inducing a signal in the shielded leads.

5-21 To verify that the oscilloscope is not displaying ripple that is induced in the leads or picked up from the grounds, short the (+) scope lead to the (-) scope lead at the power supply terminals. The ripple value obtained when the leads are shorted should be subtracted from the indicated ripple measurement.

5-22 If the foregoing measures are used, the singleended scope of Figure 5-2A might be adequate to eliminate extraneous ripple components so that a satisfactory measurement can be obtained. However, in stubborn cases or in measurement situations where it is essential that both the power supply case and the oscilloscope case be connected to ground (if both are rack-mounted, for example), it may be necessary to use a differential scope with floating input as shown in Figure 5-2B. If desired, two single-conductor shielded cables may be substituted in place of the shielded two-wire cable with equal success. Because of its common mode rejection, a differential oscilloscope displays only the difference in signal between its two vertical input terminals, thus ignoring the effects of any common mode signal produced by the difference in the ac potential between the power supply case and scope case. Before using a differential input scope, however, it is imperative that the common mode rejection capability of the scope be verified by shorting together its two input leads at the power supply and observing the trace on the CRT. If this trace is a straight line, then the scope is properly ignoring any common mode signal present. If this trace is not a straight line, then the scope is not rejecting the ground signal and must be realigned in accordance with the manufacturer's instructions so that proper common mode rejection is attained.

5-23 Ripple Measurement Procedure. To check the ripple output, proceed as follows:

a. Connect oscilloscope or rms voltmeter as shown in Figures 5-2A or 5-2B.

b. Turn CURRENT controls fully clockwise.

 c. Turn on supply and adjust VOLTAGE controls until front panel meter indicates maximum rated output voltage.
 d. The observed ripple should be less than:

••	The Observed rippic should	
	6259B, 6260B, 6261B	500μV rms, 5mV p-p
	6268B, 6269B	1mV rms, 5mV p-p

5-24 Noise Spike Measurements. An instrument of sufficient bandwidth must be used when making a high frequency spike measurement. An oscilloscope with a bandwidth of 20MHz or more is adequate. Measuring noffse with an instrument that has insufficient bandwidth may conceal high frequency spikes that could be detrimental to the load.

5-25 The test setup illustrated in Figure 5-2A is generally not adequate for measuring spikes; a differential oscilloscope is necessary. Furthermore, the measurement technique of Figure 5-2B must be modified as follows if accurate spike measurement is to be achieved:

 As shown in Figure 5-3, two coax cables must be substituted for the shielded two-wire cable.

2. Impedance matching resistors must be included to eliminate standing waves and cable ringing, and capacitors must be connected to block dc current.

3. The length of the test leads outside the coax is critical and must be kept as short as possible. The blocking capacitor and impedance matching resistor should be connected directly from the inner conductor of the cable to the power supply sensing terminal.

4. Notice that the shields at the power supply end of the two coax cables are not connected to the power supply ground since such a connection would give rise to a ground current path through the coax shield and result in an erroneous measurement.



Figure 5-3. Noise Spike Measurement Test Setup

5. Since the impedance matching resistors constitute a 2-to-1 attenuator, the noise spikes observed on the oscilloscope should be less than 2.5mV p-p instead of 5mV p-p.

5-26 The circuit of Figure 5-3 can also be used for the normal measurement of low frequency ripple. Simply remove the four terminating resistors and the blocking capacitors and substitute a higher gain vertical plug-in for the wide-band plug-in required for spike measurements. Notice that with these changes, Figure 5-3 becomes a two-cable version of Figure 5-2B.

5-27 Load Transient Recovery Time.

Definition: The time "X" for output voltage recovery to within "Y" millivolts of the nominal output voltage following a "Z" amp step change in load current, where: "Y" is specified as 10mV; the nominal output voltage is defined as the dc level halfway between the static output voltage before and after the imposed load change; and "Z" is the specified load current change of 5 amps or the fullload current rating of the supply, whichever is less. Load transient recovery time may be measured at any input line voltage combined with any output voltage and load current within rating.

5-28 Measurement Techniques. Care must be taken in switching the load resistance on and off. A hand-operated switch in series with the load is not adequate since the resulting one-shot displays are difficult to observe on most oscilloscopes and the arc energy occurring during switching completely masks the display with a noise burst. Transistor load switching devices are expensive if reasonably rapid load current changes are to be achieved.

5-29 We suggest that a mercury-wetted relay connected in the load switching circuit shown in Figure 5-4 be used for loading and unloading the supply. When this load switch is connected to a 60Hz ac input, the mercury-wetted relay opens and closes 60 times per second. The 25k control adjusts the duty cycle of the load current switching to reduce jitter in the oscilloscope display. This relay may also be used with a 50Hz ac input. The load resistance shown in Figure 5-4 is the minimum resistance that can be used without damaging the mercury-wetted relay contacts.

5-30 Measurement Procedure. To check the load transient recovery time, proceed as follows:

- a. Connect test setup shown in Figure 5-4.
- b. Turn CURRENT controls fully clockwise.

c. Turn on supply and adjust VOLTAGE controls until front panel ammeter indicates either 5 amps or the full-load current rating of the supply, whichever is less.

d. Close line switch on repetitive load switch setup.

e. Set oscilloscope for internal sync and lock on either the positive or negative load transient spike. f. Set vertical input of oscilloscope for ac coupling so that small dc level changes in power supply output voltage will not cause display to shift.

g. Adjust the vertical centering on the scope so that the tail ends of the no-load and full-load waveforms are symmetrically displaced about the horizontal centerline of the oscilloscope. This centerline now represents the nominal output voltage defined in the specification.

h. Adjust the horizontal positioning control so that the trace starts at a major graticule division. This point then represents time zero.

i. Increase the sweep rate so that a single transient spike can be examined in detail.

j. Adjust the sync controls separately for the positive and negative-going transients so that not only the recovery waveshape but also as much as possible of the rise time of the transient is displayed.

k. Starting from the major graticule division representing time zero, count to the right 50µsec and vertically 10mV. Recovery should be within these tolerances as illustrated in Figure 5-5.



Figure 5-4. Load Transient Recovery Time Test Setup



Figure 5-5. Load Transient Recovery Time Waveforms

5-31 Temperature Coefficient.

Definition: The change in output voltage per degree Celsius change in the ambient temperature measured while ac line voltage, output voltage setting, and load resistance are all held constant.

5-32 The temperature coefficient of a power supply is measured by placing the power supply in an oven and varying it over any temperature span within its rating. (Most HP power supplies are rated for operation from 0 °C to 55°C.) The power supply temperature must be allowed to stabilize for a sufficient time at each measurement temperature.

5-33 The temperature coefficient given in the specifications is the maximum temperature-dependent output voltage change which will result over any one-degree interval. The digital voltmeter used to measure the supply's output voltage change should be placed outside the oven and should have a long-term stability adequate to insure that its drift will not affect the overall measurement accuracy.

5-34 To check the temperature coefficient, proceed as follows:

a. Connect load resistance and digital voltmeter as illustrated in Figure 5-1.

b. Turn CURRENT controls fully clockwise.

c. Turn on supply and adjust front panel VOLTAGE controls until front panel voltmeter indicates maximum rated output voltage.

d. Place power supply in temperature-controlled oven

(digital voltmeter remains outside overi) : Set temperature to 30° C and allow 30-minute: warm-upolit in a low low to a set ex:Becord digital voltmeter reading); and a low low to a set

f. Raise temperature to 40°C and allow 30-minute warm-up,
 g. Observe digital voltmeter reading. Difference in voltage reading between steps (e) and (g) should be less than:

۶	144	\$74.	and the second	11- 11- 1 V	
•	1	6259B,	6260B	· 12mV	19. 21
	1	6261B	taket and	22mV	Sec.
		6268B,	6269B	42mV-	\$.h) \$

5-35 Drift (Stability): a subset of subset of

1. A. 197

Definition: The change in output voltage for the first eight hours following a 30-minute warm-up period. During the interval of measurement, input line voltage, load resistance, and ambient temperature, are all held constant.

5-36 This measurement is made by monitoring the output of the power supply on a digital voltmeter over the stated measurement interval. A strip chart recorder can be used to provide a permanent record. Place a thermometer near the supply to verify that the ambient temperature remains constant during the period of measurement. The supply should be located away from any source of stray air currents. If possible, place the supply in an oven and hold it at a constant temperature. Take care that the measuring instrument has an eight-hour stability at least an order of magnitude better than the stability specification of the power supply being tested. Typically, a supply will drift less over the eight-hour measurement interval than during the half-hour warm-up.

5-37 To check the output stability, proceed as follows:
a. Connect load resistance and digital voltmeter as illustrated in Figure 5-1.

b. Turn CURRENT controls fully clockwise.

c. Turn on supply and adjust front panel VOLTAGE controls until digital voltmeter indicates maximum rated output voltage.

d. Allow 30-minute warm-up, then record digital voltmeter reading.

e. After 8 hours, digital voltmeter reading should not differ from the step (d) reading by more than:

6259B, 6260B	5mV
6261B, 6268B	8mV
6269B	14mV

5-38 CONSTANT-CURRENT TESTS

5-39 The instruments, methods, and precautions for the proper measurement of constant-current power supply characteristics are for the most part identical to those already described for the measurement of constant-voltage characteristics. There are, however, two main differences: First, the power supply performance will be checked between <u>short circuit</u> and full load rather than <u>open circuit</u> and full load. Second, a current monitoring resistor is inserted between the output of the power supply and the load.

5-40 For all output current measurements, the current sampling resistor must be connected as a four-terminal device in the same manner as a meter shunt would be. The load current is fed to the extremes of the wire leading to the resistor while the sampling terminals are located as close as possible to the resistance element itself (see Figure 5-6). A current sampling resistor should have low noise, low temperature coefficient (less than 30ppm/°C) and should be used at no more than 5% of its rated power so that its temperature rise will be minimized.

NOTE

In case of difficulty obtaining a low resistance, high current resistor suitable for current sampling, a duplicate of the sampling resistor used in this unit (A4R123, or A4R123A and A4R123B) may be obtained from the factory.

5-41 Current Output and Ammeter Accuracy. To check that the supply will furnish its rated output current, proceed as follows:

a. Connect test setup shown in Figure 5-7.

b. Turn VOLTAGE controls fully clockwise.

c. Turn on supply and adjust CURRENT controls until front panel ammeter indicates maximum rated output current.

d. Digital voltmeter should read 0.5 ±0.01 Vdc.

5-42 Load Effect (Load Regulation).

Definition: The change ΔI_{OUT} in the static value of the dc output current resulting from a change in load resistance from short circuit to a value which yields maximum rated output voltage, or vice versa.





5-43 To check the constant-current load effect proceed

"e. Connect test setup shown in Figure 5-7.

b. Turn VOLTAGE controls fully clockwise.

C. Turn on supply and adjust CURRENT controls until front panel emmeter indicates exactly maximum rated output current.

d. Read and record voltage indicated on digital voltmeter.

e. Short circuit load resistor (R1).

f. Digital voltmeter reading should not differ from reading recorded in step (d) by more than:

3259B	110µV	
3260B	110µV	į
6261B	110µV	
5268B	134µV	1
6269B	120µV	

5-44 Source Effect (Line Regulation).

Definition: The change ΔI_{OUT} in the static value of dc output current resulting from a change in ac input voltage over the specified range from low line to high line or from high line to low line.

5-45 To check source effect, proceed as follows:

a. Connect test setup shown in Figure 5-7.

b. Connect variable autotransformer between input

power source and power supply ac input.

c. Adjust autotransformer for 208Vac input.

d. Turn VOLTAGE controls fully clockwise.

e. Turn on supply and adjust CURRENT controls until front panel ammeter reads exactly maximum rated output current.

f. Read and record voltage indicated on digital voltmeter.

g. Adjust autotransformer for 254 Vac input.

h. Digital voltmeter reading should not differ from reading recorded in step (f) by more than:

6259B	110µV
6260B	110µV
6261B	110µV
6268B	134µV
6269B	120µV

5-46 PARD (Ripple and Noise).

Definition: The residual ac current superimposed on the dc output of a regulated power supply. Ripple and noise measurements may be made at any input ac line. voltage combined with any dc output voltage and load current within the supply's rating.

5-47 Most of the instructions pertaining to the ground loop and pickup problems associated with constant-voltage ripple and noise measurement also apply to the measurement of constant-current ripple and noise. Figure 5-8 illustrates the most important precautions to be observed when measuring the ripple and noise of a constant-current

And with the of several 1. in tio 1. P. 1 -A. 144 POWER SUPPLY erg. Set m mail in thematic a UNDER TEST 17 te. and strately ... RL 900 ~~ LOAD DIGITAL RESISTOR OLTMETER CURRENT 0 RESISTOR 5 --Rs TC ALLOY MODEL RL (15%) 1 20 ppm 62598 0.190 500W 0.010 0.095 Q 1000W 6260B 0.0050 6261B 0.39Q 1000W 0.010 62688 1.310 1200M 0.01670 6269B 0.79 £ 2000W 0.010

Figure 5-7. Constant-Current Load Regulation Test Setup



Figure 5-8. Constant-Current Ripple and Noise Test Setup

supply. The presence of a 120Hz waveform on the oscilloscope normally indicates a correct measurement method. A waveshape having 60Hz as its fundamental component usually indicates an incorrect measurement setup.

5-48 To check the ripple and noise, proceed as follows: a. Connect oscilloscope or rms voltmeter as shown in Figure 5-8A or 5-8B.

b. Rotate VOLTAGE controls fully clockwise.

c. Turn on supply and adjust CURRENT controls until front panel ammeter reads exactly maximum rated output current.

d. The observed ripple and noise should be less than: "

6259B	250µV rms
6260B	250µV rms
6261B	250µV rms
6268B	334µV rms
6269B	250µV rms

5-49 TROUBLESHOOTING

5.17.

5-50 Before attempting to troubleshoot this instrument, ensure that the fault is with the instrument and not with an associated circuit. The performance test (paragraphs 5-5 through 5-48) enables this to be determined without removing the instrument from the cabinet.

5-51 A good understanding of the principles of operation is a helpful aid in troubleshooting, and it is recommended that the reader review Section IV of the manual before attempting to troubleshoot the unit in detail. Once the principles of operation are understood, refer to the overall troubleshooting procedures in paragraph 5-54 to locate the symptom and probable cause.

5-52 The schematic diagram contains normal voltage readings adjacent to some test points. (Test points are identified by circled numbers.) The measurement conditions are listed in the Schematic Notes. Consult the component location diagrams in Section VII to determine the locations of components and test points.

5-53 If a component is found to be defective, replace it and re-conduct the performance test. When a component is replaced, refer to the repair and replacement (paragraph 5-69) and adjustment and calibration (paragraph 5-71) sections of this manual.

5-54 OVERALL TROUBLESHOOTING PROCEDURES

5-55 To locate the cause of trouble, follow steps 1, 2, and 3 in sequence:

(1) Check for obvious troubles such as a defective power cord, an input power failure, or a defective meter.

Next, remove the top and bottom covers and inspect for open connections, charred components, or any other visible defects. If the trouble source cannot be detected by visual inspection, proceed to step (2).

(2) In almost all cases, the trouble can be caused by incorrect dc bias or reference voltages; thus, it is a good practice to check the voltages in Table 5-2 before proceeding with step (3).

(3) Disconnect the load and examine Table 5-3 for your symptom and its probable cause.

5-56 Table 5-3 contains symptoms and probable causes of many possible troubles. If either high or low output voltage is a symptom, Table 5-4 contains the steps necessary to isolate the trouble to one of the feedback loops and instructions directing the tester to the proper table for further isolation. Because of the interactions between loops, it is necessary to refer to Table 5-4 before proceeding to Tables 5-5, 5-6, or 5-7.

5-57 Tables 5-5, 5-6, and 5-7 contain troubleshooting procedures for the series regulator and preregulator feed-

back loops once the fault has been isolated to one of them. Tables 5-5 and 5-6 contain instructions for driving each stage into conduction or cut-off. By following the steps in these tables, the fault can be isolated to a circuit or a component.

5-58 Table 5-7 contains troubleshooting procedures for the preregulator feedback loop. Troubleshooting is accomplished by comparing waveform illustrations with the waveforms found at various test points and then checking the components most likely to be at fault.

5-59 After troubleshooting the unit, it may be necessary to perform one or more of the calibration procedures given in this section.

WARNING

Some circuits in this power supply are connected directly to the input ac power line. The redpainted case and heatsink of the A2 RFI Assembly are also at ac line potential. Exercise extreme caution when working on energized circuits.

STEP	METER COMMON	METER POSITIVE	NORMAL VDC	NORMAL RIPPLE (P-P)	PROBABLE CAUSE
1		TP63	12.4 ±7%	2.0mV	CR61, CR62, Q60, Q61, Q62, Q63
2	(+S)	TP64	6.2 ±5%	0.5mV	VR60, VR61, R63
3	TP65	+5	6.2 ±5%	2.0mV	VR60, VR61, R63
4	+5	TP66	11 ±15%	2.0V	CR53, CR54, C44
5	TP67	ŦS	4.0 ±12.5%	0.8V	CR53, CR54, C44, CR45-49
6	TP68	FS	2.4 ±12.5%	0.4V	CR53, CR54, C44, CR45-49

Table 5-2. Reference and Bias Voltages
 (Refer to schematic and component location diagrams in Section VII for test point locations)

Table 5-3. Overall Troubleshooting

SYMPTOM	PROBABLE CAUSE		
Low or no output voltage (OVERVOLTAGE lamp may be on or off).	a. Front panel meter defective. b. Crowbar not reset or defective. Refer to Table 5-4. c. Series regulator or preregulator feedback loop defective. Refer to Table 5-4.		
High output voltage	 a. Front panel meter defective. b. Series regulator or preregulator loop defective. If crowbar does not trip, it too is faulty. Refer to Table 5-4. c. Open circuit between sensing terminals (±S) and output terminals (±OUT). Refer to Table 5-4. 		

29

SYMPTOM	PROBABLE CAUSE
High ripple	 a. Ground loops in operating setup. Refer to paragraph 5-17. b. Incorrect reference or bias voltages. Refer to Table 5-2. c. Supply crossing over to constant-current operation under loaded conditions. Check current limit setting or constant-current comparator circuit (Z1 and associated components).
Poor line regulation	a. Improper measurement technique. Refer to paragraph 5-13. b. Incorrect reference or bias voltages. Refer to Table 5-2.
Poor load regulation (Constant-voltage)	 a. Improper measurement technique. Refer to paragraph 5-11. b. Incorrect reference or bias voltages. Refer to Table 5-2. c. Supply current limiting. Check constant-current comparator circuit (Z1 and associated components).
Poor load regulation (Constant-current)	 a. Incorrect reference or bias voltages. Refer to Table 5-2. b. Supply voltage limiting. Check constant-voltage comparator circuit (Z1 and associated components) and voltage clamp circuit Q1. c. Leaky C19, A3C3. d. CR92 defective.
Oscillates (Constant-current or constant-voltage)	 a. Adjustment of R47. Refer to paragraph 5-98. b. Faulty C40, C41, C19, A3C3, R50. c. Open sensing lead (+S).
Instability (Constant-current/ constant-voltage)	 a. Incorrect reference or bias voltages; CR92 defective. Refer to Table 5-2. b. Noisy voltage or current controls (A5R121, A5R122, or A5R123, A5R124); noisy VR60 or VR61. c. Integrated circuit Z1 defective. d. CR4, CR5, CR6, or CR21 leaky. e. R3, R4, R5, R6, R22, R30, R31, C2 noisy or drifting.
Cannot reach maximum output	Q20 shorted. One or more series regulator transistors (A4Q103 thru A4Q110) open.

· · · · · · · · · ·

Table 5-4. Feedback Loop Isolation

STEP	ACTION	RESPONSE	PROBABLE CAUSE
	NOTE: After each s	tep, reset crowbar by turning sup	oply off then on.
1	Inspect LINE circuit breaker.	a. Breaker tripped.	a. Check rectifier, filter, and triac for short. Proceed to step 3.
		 Breaker OK; output voltage high. 	b. Proceed to step 2.
		c. Breaker OK; output voltage low.	c. Proceed to step 2.

3

STEP	ACTION	RESPONSE	PROBABLE CAUSE
3	Inspect OVERVOLTAGE lamp on front panel.	a. On. b. Off; output voltage high. c. Off; output voltage low.	 a. Check setting of OVERVOLTAGE ADJUST (A5R125). Check A4CR110 for short. Proceed to step 3. b. Check OVERVOLTAGE ADJUST (A5R125). Check A4CR110 for open. Also check Q91 and Q92. Proceed to step 3. c. Check OVERVOLTAGE ADJUST (A5R125). Check A4CR110 for open. Also check Q20, Q91, and Q92. Proceed to step 3.
3	Isolate fault to series regulator or preregulator by proceeding as follows: (1) Open the gate lead of triac A2CR1 by disconnecting one end of R88 (TP87 or TP88). (2) Observing correct polarity, connect a small dc power supply across input capacitor (C101). A 0-10V, 2A supply is sufficient. (3) Set external supply to ten volts. (4) Vary front panel voltage controls.	 a. Output voltage normal (variable from 0 volts to about 9 volts). b. Output voltage high. Varying controls has little or no effect. c. Output voltage low. Varying controls has little or no effect. 	 a. Check each series regulator transistor (A4Q103 through A4Q106, A4Q108, or A4Q110) for open. Then check preregulator by disconnecting external source and proceed- ing to Table 5-7. b. High voltage condition in series regulator. Proceed to Table 5-5. Leave external source connected. c. Low voltage condition in series regulator. loop. Proceed to Table 5-6. Leave external source connected.

35 - 1

dback Loop Isolation (Continued)

Table 5-5. Series Regulator Troubleshooting, High Output Voltage

STEP	ACTION	RESPONSE	PROBABLE CAUSE	
	Make these tests with external source connected as described in step 3 of Table 5-4. Leave the coarse voltage control set to the center of its range while making these tests.			
1	Check turn-off of series regulator transistors A4Q103 through A4Q106, A4Q108, or A4Q110 by momentarily shorting base (TP101) to emitter	 a. Output voltage remains high. b. Output voltage 	 a. One or more of A4Q103 through A4Q106, A4Q108, or A4Q110 shorted or A4CR105 shorted. Check A4R150-A4R165 (as applicable). b. Proceed to step 2. 	
	(TP103).	decreases.		
2	Check turn-off of driver A4Q102 by momentarily	 a. Output voltage remains high. 	a. A4Q102 shorted.	
	shorting base (TP100) to emitter (TP101).	b. Output voltage decreases.	b. Proceed to step 3.	
3	Check turn-on of error amplifier A4Q101 by momentarily shorting Q42	a. Output voltage high.	a. A4Q101 open.	
	emitter (TP46) to collector (TP68).	decreases.		

STEP	ACTION	RESPONSE	PROBABLE CAUSE
4	Check turn-on of error amplifier Q42 by momentarily shorting	a. Output voltage remains high.	a. Q42 open.
	base (TP44) to collector (TP68).	b. Output voltage decreases.	b. Proceed to step 5.
5	Check turn-off of mixer amplifier Q41 by momentarily shorting	a. Output voltage remains high.	a. Q41 shorted.
	base (TP40) to emitter (TP47).	b. Output voltage decreases.	b. Proceed to step 6.
6	Measure the voltage at pin 1 of constant-voltage comparator Z1	a. TP11 voltage is about +0.7 volts.	a. Open sensing lead, open strap between A1 and A2, A5R121 or A5R122 open.
	(between TP11 and the +S sensing terminal).	 D. TP11 voltage is about 0.7 volts. 	b. CR1 open, Z1 or Z2 defective.

Table 5-5. Series Regulator Troubleshooting. High Output Voltage (Continued)

Table 5-6. Series Regulator Troubleshooting, Low Output Vol

STEP	ACTION	RESPONSE	PROBABLE CAUSE
	Make these tests with external sou control se	I arce connected as described in state to the center of its range while	tep 3 of Table 5-4. Leave the coarse voltage e making these tests.
1	Check turn-off of error amplifier A4Q101 by momentarily short- ing base (TP45) to emitter (TP100).	 a. Output voltage remains low. b. Output voltage rises. 	 a. A4Q101 shorted; A4Q102 open, thermal switch A4TS101 open; A4Q103 through A4Q106, A4Q108, or A4Q110 open; A4R150 through A4R165 (as applicable) open; A4CR106 (or A4CR107) shorted. b. Proceed to step 2.
2	Check turn-off of error amplifier Q42 by momentarily shorting base (TP44) to emitter (TP46).	a. Output voltage remains low.b. Output voltage rises.	a. Q42 shorted, CR44 shorted.b. Proceed to step 3.
3	Isolate fault to constant-voltage comparator or constant-current comparator by opening the cathode of CR20.	a. Output voltage rises.b. Output voltage remains low.	 a. Z1 defective, open strap between A6 and A7, or shorted A5R123 or A5R124. b. Reconnect CR20 and proceed to step 4.
4	Check turn-on of mixer amplifier Q41 by momentarily shorting base (TP40) to collector (TP41).	a. Output voltage remains low.b. Output voltage rises.	a. Q41, CR40, or CR41 open; Q40 shorted.b. Proceed to step 5.
5	Measure the voltage at pin 1 of constant-voltage comparator Z1 (between TP11 and the +S sensing terminal).	 a. TP11 voltage is about -0.7 volts. b. TP11 voltage is about +0.7 volts. 	 a. Open strap between A2 and A3; CR3, CR7, or Q1 shorted; VR1, R3, R4, or R5 open. b. CR1, CR4, Z1 or Z2 defective.

; .

Table 5-7. Preregulator Troubleshooting (See Figure 4-4 for Waveforms)

1

STEP	ACTION	RESPONSE	PROBABLE CAUSE
1	Connect oscilloscope between TP85 (+) and TP103 ().	a. Normal waveform. b. Little or no voltage.	 a. Proceed to step 2. b. Defective Q72, Q73, CR76, or C71. Proceed to step 3.
2	Connect oscilloscope between TP89 (+) and TP86 ().	a. Normal waveform b. Little or no voltage.	 a. Defective A2CR1, A2L1, T1, A2C1, A2C3. b. Defective T70, CR88, R88, Proceed to step 3.
	To avoid a p oscilloscope	otentially lethal shock hazard, a must be used in making this mea	differential surement.
3	Connect oscilloscope between TP80 (+) and TP103 (-).	a. Amplitude incorrect.b. Period incorrect.	 a. Defective Q71, C70, C72, CR74, CR75, R75, R78, or R82. b. CR78 defective. Proceed to step 4.
4	Connect oscilloscope between TP82 (+) and TP103 (-).	Amplitude, dc reference, or period incorrect.	Defective CR77, CR78, CR79, CR80, CR82, CR84. Check R87.
5	Connect oscilloscope between TP81 (+) and TP103 ().	Amplitude, dc reference, or period incorrect.	Defective CR81, CR83, R83, R86, C73.

Table 5-8. Checks and Adjustments Required After Semiconductor Replacement

REFERENCE	FUNCTION OR CIRCUIT	CHECK	ADJUST
Z1	Constant voltage and constant current differential amplifiers.	Constant voltage (CV) line and load regu- lation. Zero volt output. Constant current (CC) line and load regu- lation. Zero current output.	R110, or R113 (Option 020 or 040); R117, or R119 (Option 021 or 040). See para. 5-81 thru 5-85 or 5-91 thru 5-95 as applicable).
Q1	Voltage clamp circuit.	CC load regulation	
Q20 .	Short circuit protection.	Output current.	
Q40, Q41	Mixer amplifier.	CV/CC load regulation. CV transient response.	R47 (See para. 5-98).
Q42, A4Q101, A4Q102	Driver and error amplifiers.	CV/CC load regulation.	
Q60, Q61, Q62, Q63	Reference regulator.	+12.4V, +6.2V, and -6.2V reference voltages and reference circuit line regulation.	
Q70	Overvoltage limit.	Limiting action and level.	

Table 5-8. Checks and Adjustments Required After Semiconductor Replacement (Continued)

4.5

. .

ŝ.,

REFERENCE	FUNCTION OR CIRCUIT	CHECK	ADJUST
Q71, Q72 Q73	Preregulator control circuit.	Output voltage, ripple imbalance, and preregulator waveforms.	R70, R82 (See para. 5-100 and 5-102).
Q90, Q91 Q92	Crowbar.	Crowbar action, trip voltage, voltage across series regulator when tripped.	A5R125 (See para. 5-104).
A4Q103 thru A4Q106, A4Q108, or A4Q110 (as applicable)	Series regulator.	CV/CC load regulation.	
A2CR1	Preregulator.	Output voltage.	R70 (See para. 5-102).
CR1, CR20	CV/CC OR gate.	CV/CC crossover operation.	
CR2, CR3	Voltage clamp circuit.	CC load regulation.	
CR4, CR40, CR41	Temperature stabilizing diodes.	Temperature coefficient.	· "·
CR5, CR6, CR21	Limiting diodes.	CV/CC load regulation.	
CR7, CR60, CR61, CR62.	Reference regulator.	+12.4V, +6.2V, and -6.2V reference voltages.	
CR35, CR36, CR37.	Turn-on circuit.	Preregulator and series regulator turn-on delay.	
CR43, CR45 thru CR49, CR53, CR54	Bias supply.	+11V, —4V, and —2.4V bias voltages.	
CR44, CR50	Driver and error amplifier.	Down-programming speed, CV/CC load regulation.	
CR70, CR71	Overvoltage limit circuit.	Limiting action and level.	
CR72 thru CR84, CR88	Preregulator control.	Output voltage, ripple imbalance, and preregulator waveforms.	R70, R82 (See para. 5-100 and 5-102).
CR90 thru CR93, A4CR108, A4CR110	Crowbar.	Trip voltage, voltage across series regulator when crowbar is tripped, supply stability.	R95, A5R125 (See para. 5-104 and 5-106).
A4CR101 and A4CR102, or A4CR101 thru A4CR104.	Main rectifier diodes.	Voltage across main filter capacitors.	

5-14

Table 5-8. Checks and Adjustments Required After Semiconductor Replacement (Continued)

REFERENCE	FUNCTION OR CIRCUIT	The CHECK Sectors of the	ADJUST Surroute de
A4CR105	Reverse voltage protection.	Output voltage.	
VR1	Voltage clamp circuit.	CC load regulation.	.
VR40	Mixer amplifier stabilization diode.	CV transient response.	R47 (See para. 5-98).
VR60,,VR61	Reference regulator.	+6.2V and -6.2V reference voltages.	2
VR90	Crowbar.	Trip voltage.	R95, A5R125 (See para. 5-104 and 5-106).

5-60 Disassembly Procedures

5-61 The following seven paragraphs describe the procedures for removing and disassembling the five subassemblies in this supply. These procedures are referred to throughout the manual where necessary.

5-62 A1 Main Circuit Board Removal. To remove the main printed circuit board, proceed as follows:

a. Disconnect input power and remove top cover from supply.

b. Remove six hold-down screws visible on component side of main circuit board.

c. Unplug board from receptacle mounted on interconnection circuit board by gently pulling on finger hole in opposite end of circuit board. Only finger hole should be used to remove board; do not pull on board-mounted components to aid removal. Take care that rear barrier strip clears opening in rear panel.

5-63 A5 Front Panel Removal. To remove the front panel, proceed as follows:

a. Disconnect input power, turn supply upside down, and remove four screws holding handles to front panel.

b. The front panel may now be swung outward, hinging on wires to circuit breaker. Access is provided to all panelmounted components.

5-64 Main Filter Capacitor Bank Removal. To remove the main filter capacitors (C101 through C103, C104, or C105 depending on the power supply model), proceed as follows:

a. Disconnect input power and remove top and bottom covers from the supply.

b. Remove the long flat-head screws and V-shaped clamps that hold the main filter capacitors in place.

Sufficient lead length is provided to allow capacitors to be lifted partially out of instrument.

5-65 A2 RFI Filter Assembly Removal. To remove the RFI assembly, proceed as follows:

a. Disconnect input power, turn supply upside down, and remove bottom cover.

 Remove four screws holding RFI heat sink to mounting brackets.

c. Lift out RFI assembly and turn over.

 d. Remove four screws holding cover to heat sink.
 This allows access to the internal components and 115V/ 230V jumpers.

5-66 A4 Heat Sink Removal. In order to gain access to the following components, it is necessary to remove the heat sink assembly: Transistors A4Q101 through A4Q110; diodes A4CR101 through A4CR108, and A4CR110; resistors A4R106, A4R123, and A4R150 through A4R165; capacitors A4C1 through A4C5; cooling fan A4B1; and thermal switch A4TS101. For the location of these components, see Figures 7-5 and 7-6. To remove the heat sink assembly, proceed as follows:

a. Disconnect input power from the supply, stand it on its left side, and remove top and bottom cover.

b. Remove main printed circuit board as described in paragraph 5-62.

c. Remove two screws holding upper edge of heat sink to upper chassis flange (marked "A" in Figure 7-4).

d. Disengage two pins holding lower section of heat sink assembly to main circuit board support tray by sliding heat sink down about 1/2 inch and slightly away from chassis. Before fully removing heat sink assembly, observe lead dress so assembly may be returned easily to correct position.

e. Maneuver heat sink assembly downwards and away

from chassis until it is resting on table (sufficient lead 🖘 3 😓 tray) can be angled up enough to allow access length is provided). Gentle leverage with a thin screwdriver may be necessary to allow heat sink assembly to clear upper chassis flange. Access is now provided to all components mounted on heat sink except resistors A4R150 through A4R165, and A4R123.

5-67 A4 Heat Sink Disassembly. To gain access to resistors A4R123 and A4R150 through A4R165, it is necessary to disassemble the heat sink assembly as follows:

a. Remove heat sink assembly as described in paragraph 5-66 above.

b. Turn supply upside down and place heat sink assembly partially into chassis so fan (A4B1) is protruding above chassis.

c. Remove four screws and four shoulder washers attaching fan mounting plate to heat sink. Do not remove fan from mounting plate. When reassembling heat sink, do not overtighten these screws. Too much tension will damage the insulating rods.

d. Remove two screws holding current sampling resistor A4R123 to heat sink. If necessary, the resistor may be unsoldered at this point.

e. Remove mounting nuts from A4CR106 (and A4CR107) on left side of heat sink, and from A4CR108 on right side of heat sink. Remove mounting nuts, bolts and shoulder washers from transistor A4Q102 on right side of heat sink (see Figure 7-5).

f. Slide this section of heat sink forward and off insulating rods.

g. Remove four screws holding emitter resistor circuit board to adjoining heat sink section. Access is now provided to series regulator emitter resistors A4R150 through A4R165 (see Figure 7-9).

h. To remove emitter resistor circuit board completely, unsolder connections to board, marking wires to permit proper replacement.

5-68 A3 Interconnection Circuit Board Removal, To replace capacitor A3C3 or transformer A3T2, (shown in Figure 7-2), it is necessary to remove the interconnection circuit board by following the following procedure:

a. Remove main circuit board, RFI assembly, and heat sink assembly as described in paragraphs 5-62, 5-65, and 5-66.

b. Remove six screws holding back panel to chassis frame.

c. Stand supply on left side, and remove two screws holding main circuit board support tray to back panel. Move panel away from frame.

d. Remove two screws holding main circuit board support tray to internal chassis divider.

e. Working from top rear of supply, interconnection circuit board (still attached to main circuit board support

. f. If necessary to completely remove interconnection circuit board, remove two screws holding board to support tray, one screw holding A3C3 capacitor clamp to support tray, and two screws holding bias transformer A3T2 to support tray. Unsolder connections to board, marking wires

to enable correct replacement, and remove board. REPAIR AND REPLACEMENT 5-69

5.70 Section VI of this manual contains a list of replaceable parts. If the part to be replaced does not have a standard manufacturers' part number, it is a special part and must be obtained directly from Hewlett-Packard. After replacing a semiconductor device, refer to Table 5-8 for checks and adjustments that may be necessary. All components listed in Table 5-8 without A-designators are on the A1 main printed circuit board.

ADJUSTMENT AND CALIBRATION 5-71

5-72 Adjustment and calibration may be required after performance testing, troubleshooting, or repair and replacement. Perform only those adjustments that affect the operation of the faulty circuit.

5-73 Meter Zero Adjustment

5-74 The meter pointer must rest on the zero calibration mark on the meter scale when the instrument is at normal operating temperature, resting in its normal operating position, and turned off. To zero the meter proceed as follows:

 Connect load resistor of value shown in Figure 5-1, turn on instrument, and allow it to come up to normal operating temperature (about 30 minutes).

b. Turn instrument off and wait two minutes for power supply capacitors to discharge completely.

c. Insert pointed object (pen point or awl) into small indentation near top of round black plastic disc located directly below meter face.

d. Rotate plastic disc clockwise until meter reads zero, then rotate counterclockwise slightly in order to free adjustment screw from meter suspension. Pointer should not move during latter part of adjustment.

5-75 Voltmeter Calibration

To calibrate the voltmeter, proceed as follows: 5-76 a. Connect digital voltmeter across plus and minus

output terminals of supply, observing correct polarity. b. Turn on supply and adjust VOLTAGE controls until digital voltmeter reads exactly the maximum rated output voltage.

c. Adjust R106 until front panel voltmeter also

indicates exactly the maximum rated output voltage

5-77 Ammeter Calibration

5-78 To calibrate the ammeter, proceed as follows:

a. Connect test setup shown in Figure 5-7.

b. Turn VOLTAGE controls fully clockwise.

c. Turn on supply and adjust CURRENT controls until digital voltmeter reads 500mV.

d. Adjust R101 until front panel ammeter indicates exactly maximum rated output current.

5-79 Constant-Voltage Programming Calibration

5-80 To calibrate the zero voltage programming accuracy, proceed as directed in paragraph 5-81, 5-82, 5-83, 5-84, or 5-85, whichever applies to your particular instrument. To calibrate the constant voltage programming accuracy, proceed as directed in paragraph 5-86, 5-87 or 5-88.

5-81 Zero Output Voltage, Standard Instrument With Resistance or Unity-Gain Voltage Programming. For instruments using either local programming or the remote programming setup shown in Figure 3-4 or 3-5, zero the output voltage as follows:

a. Connect digital voltmeter between +OUT and -OUT bus bars.

b. If unit is to be used in local programming mode, turn VOLTAGE controls fully counterclockwise. If unit is to be used in remote programming mode, connect remote programming setup and adjust remote resistance or voltage to zero.

c. Connect decade resistance box between pads in zero adjust section of A1 main circuit board that are marked "A" and "B" in Figure 5-9. (These pads are for R110).

d. Rotate CURRENT controls fully clockwise and turn on supply.

e. Adjust decade resistance box until digital voltmeter reads exactly zero volts.

f. Replace decade resistance box with fixed, metal film,
1%, 1/4 or 1/8 watt resistor of same value.

5-82 Zero Output Voltage, Standard Instrument With Variable Gain Voltage Programming. For instruments using the programming setup shown in Figure 3-6, zero the output voltage as follows:

a. Perform steps (a) and (b) of paragraph 5-81.

b. Solder a jumper between pads in zero adjust section of A1 main circuit board that are marked "C" and "D" in Figure 5-9.

c. Connect decade resistance box between pads marked "E" and "F" in Figure 5-9. (These pads are for resistor R111).

d. Perform steps (d) through (f) of paragraph 5-81.

5-83 Zero Output Voltage, Option 020 Instrument With Resistance or Unity-Gain Voltage Programming. For Option 020 instruments using either local programming or the remote programming setup shown in Figure 3-4 or 3-5, zero the output voltage as follows:

a. Perform steps (a) and (b) of paragraph 5-81.

b. Rotate CURRENT controls fully clockwise and turn on supply.

c. If reading on digital voltmeter is not exactly zero volts, adjust potentiometer R113 (labeled "VOLTAGE ZERO" and accessible through hole in rear panel) until a reading is exactly zero.

5-84 Zero Output Voltage, Option 020 Instrument With Variable Gain Voltage Programming. For Option 020 instruments using the programming setup shown in Figure 3-6, zero the output voltage as follows:

a. Perform steps (a) and (b) of paragraph 5-81.

b. Rotate CURRENT controls fully clockwise and turn on supply.

c. If reading on digital voltmeter is not exactly zero volts, adjust potentiometer R112 (labeled "VOLTAGE PROG" and accessible through hole in rear panel) until reading is exactly zero.

5-85 Zero Output Voltage, Option 040 Instrument. Zero the output voltage of Option 040 instruments as follows:

a. Connect digital voltmeter between +OUT and -OUT bus bars.

b. Connect a $10\Omega \pm 1\%$ programming resistor as shown in Figure 3-4.

c. Rotate CURRENT controls fully clockwise and turn on supply.

d. Adjust potentiometer R113 (labeled "VOLTAGE ZERO" and accessible through hole in rear panel) until reading is zero volts ±1mV.



Figure 5-9. Zero Adjust Section of Main Circuit Board

5-17

The internal temperature rise of the power supply has an effect on the accuracy of the programming coefficient. For example, an internal temperature rise of 15°C (typical of the temperature difference between no-load and full-load operation) causes the supply output to change by 0.15%. Since the factory calibration procedure for instruments equipped with Option 020 or 040 sets the voltage programming coefficient to within 0.1%, the resulting accuracy specification including the effect of the 15°C temperature rise would be 0.25%.

5-86 Constant-Voltage Programming Accuracy, Standard Instrument. To calibrate the constant-voltage programming current of a standard instrument, proceed as follows:

a. Connect 0.1%, 1/8 watt resistor of value shown below between terminals -S and A2 on rear barrier strip.

Model	Value
6259B	2000Ω
6260B	2000Ω
6261B	4000Ω
6268B	20008
6269B	Ω0008

b. Disconnect strap between terminals A1 and A2 on rear barrier strip.

 c. Connect digital voltmeter between +OUT and -OUT bus bars.

 d. Connect decade resistance box in place of R3 (mounted on standoffs on main circuit board; see Figure 7-7).

e. Rotate CURRENT controls fully clockwise and turn on supply.

 Adjust decade resistance box until digital voltmeter indicates exactly maximum rated output voltage.

g. Replace decade resistance box with fixed, composition, 5%, 1/2 watt resistor of same value.

5-87 Constant-Voltage Programming Accuracy, Option 020 Instrument. To calibrate the constant-voltage programming current of an Option 020 instrument, proceed as follows:

a. Perform steps (a) through (c) of paragraph 5-86.

b. Rotate CURRENT controls fully clockwise and turn on supply.

c. Adjust potentiometer R112 (labeled "VOLTAGE PROG" and accessible through hole in rear panel) until digital voltmeter indicates exactly maximum rated output voltage. 5-88 Constant-Voltage Programming Accuracy, Option 040 Instrument. To calibrate the constant-voltage programming current of an Option 040 Instrument, proceed as follows: ALL NAMES

としてのない 日本語のないであるい

 a. Connect 0.1%, 1/8 watt resistor of value shown below between terminals -S and A2 on rear barrier strip.

Model	Value
6259B	20100
5260B	2010Ω
6261B	4010Ω
6268B	8010Ω
6269B	8010Ω

b. Disconnect strap between terminals A1 and A2 on rear barrier strip.

c. Connect digital voltmeter between +OUT and -OUT bus bars.

d. Rotate CURRENT controls fully clockwise and turn on supply.

e. Adjust potentiometer R112 (labeled "VOLTAGE PROG" and accessible through hole in rear panel) until digital voltmeter indicates full rated output voltage ±0.1%.

5-89 Constant-Current Programming Calibration

5-90 To calibrate the zero current programming accuracy, proceed as directed in paragraph 5-91, 5-92, 5-93, 5-94, or 5-95 whichever applies to your particular instrument. To calibrate the constant current programming accuracy, proceed as directed in paragraph 5-96 or 5-97.

5-91 Zero Output Current, Standard Instrument With Resistance or Fixed Gain Voltage Programming. For instruments using either local programming or the remote programming setup shown in Figure 3-7 or 3-8, zero the output current as follows:

a. Connect test setup shown in Figure 5-7.

b. If unit is to be used in local programming mode, turn CURRENT controls fully counterclockwise. If unit is to be used in remote programming mode, connect remote programming setup and adjust remote resistance or voltage to zero.

c. Connect decade resistance box between pads in zero adjust section of A1 main circuit board that are marked "G" and "H" in Figure 5-9. (These pads are for R117.)

d. Rotate VOLTAGE controls fully clockwise and turn on supply.

e. Adjust decade resistance box until digital voltmeter reads exactly zero volts.

f. Replace decade resistance box with fixed, metal film, 1%, 1/4 or 1/8 watt resistor of same value.

5-92 Zero Output Current, Standard Instrument With Variable Gain Voltage Programming. For instruments using the remote programming setup shown in Figure 3-9, zero the output current as follows:

a. Perform steps (a) and (b) of paragraph 5-91.

b. Solder a jumper between pads in zero adjust section of A1 main circuit board that are marked "I" and "J" in Figure 5-9.

c. Connect decade resistance box between pads marked "K" and "L" in Figure 5-9. (These pads are for R115.)

d. Perform steps (d) through (f) of paragraph 5-91.

5-93 Zero Output Current, Option 021 Instrument With Resistance or Fixed Gain Voltage Programming. For Option 021 instruments using either local programming or the remote programming setup shown in Figure 3-7 or 3-8, zero the output current as follows:

a. Perform steps (a) and (b) of paragraph 5-91.

b. Rotate VOLTAGE controls fully clockwise and turn on supply.

c. If reading on digital voltmeter is not exactly zero volts, adjust potentiometer R119 (labeled "CURRENT ZERO" and accessible through hole in rear panel) until reading is exactly zero.

5-94 Zero Output Current, Option 021 Instrument With Variable Gain Voltage Programming. For Option 021 instruments using the programming setup shown in Figure 3-9, zero the output current as follows:

a. Perform steps (a) and (b) of paragraph 5-91.

b. Rotate VOLTAGE controls fully clockwise and turn on supply.

c. If reading on digital voltmeter is not exactly zero volts, adjust potentiometer R116 (labeled "CURRENT PROG" and accessible through hole in rear panel) until reading is exactly zero.

5-95 Zero Output Current, Option 040 Instrument. Zero the output current of Option 040 instruments as follows:

a. Connect test setup shown in Figure 5-7, except omit load resistor R_L and connect just current sampling resistor R_S across the output of the supply.

b. Connect remote programming setup shown in Figure 3-7 and adjust remote resistance to zero.

c. Rotate VOLTAGE controls fully clockwise and turn on supply.

d. If reading on digital voltmeter is not exactly zero volts, adjust potentiometer R119 (labeled "CURRENT ZERO" and accessible through hole in rear panel) until reading is zero volts ±2mV.

5-96 Constant-Current Programming Accuracy, Standard Instrument. To calibrate the constant-current programming current of a standard instrument, proceed as follows: at a case of set are a 2. The St. And a. Connect test setup shown in Figure 5-7.

b. Disconnect strap between terminals A5 and A6 on rear barrier strip.

c. Connect 0.1%, 1/8 watt resistor of value shown below between terminals A4 and A6 on rear barrier strip.

Model	Value
6259B	200Ω
6260B	200Ω
6261B	200Ω
6268B	180Ω
6269B	200 Ω

d. Connect decade resistance box in place of R30 (mounted on standoffs on main circuit board; see Figure 7-7).

e. Rotate VOLTAGE controls fully clockwise and turn on supply.

f. Adjust decade resistance box until digital voltmeter indicates exactly 0.5Vdc.

g. Replace decade resistance box with fixed, composition, 5%, 1/2 watt resistor of same value.

5-97 Constant-Current Programming Accuracy, Option 021 or Option 040 Instrument. To calibrate the constantcurrent programming current of an Option 021 or Option 040 instrument, proceed as follows:

a. Perform steps (a) through (c) of paragraph 5-96.

b. Rotate VOLTAGE controls fully clockwise and turn on supply.

c. Adjust potentiometer R116 (labeled "CURRENT PROG" and accessible through hole in rear panel) until digital voltmeter indicates 0.5Vdc ±10mV.

5-98 Load Transient Recovery Time Adjustment

5-99 To adjust the transient response, proceed as follows:

a. Connect test setup shown in Figure 5-4.

b. Repeat steps (a) through (k) as outlined in paragraph 5-30.

c. Adjust R47 until transient response to within specification as shown in Figure 5-5.

5-100 Ripple Balance Adjustment

5-101 This procedure ensures balanced triac operation by ensuring that its conduction time is within 25% of being equal in both directions. To check for imbalance, proceed as follows:

 a. Connect load resistor specified in Figure 5-1 across rear output terminals of supply.

 b. Connect variable autotransformer between input power source and power supply input and adjust it for a 230Vac input to the supply.

 c. Connect ac-coupled oscilloscope across series regulator (between TP102 and TP103). d. Turn CURRENT controls fully clockwise, turn on supply, and adjust VOLTAGE controls for maximum rated output voltage,

e. Adjust oscilloscope to observe 120Hz sawtooth waveform. Peak amplitudes of adjacent sawtooth peaks should be within 25% of each other.

f. If amplitude difference is greater than 25%, turn off supply and replace R82 with decade resistance.

g. Turn on supply and adjust decade resistance to reduce imbalance to within 25%.

h. Vary input line voltage from 208 to 254Vac and insure that excessive imbalance does not exist anywhere within this range. Replace decade box with equivalent resistor.

NOTE

If imbalance cannot be reduced to within 25%, check capacitors C70 and C72, and diodes CR79 through CR84. If these components test satisfactorily, the problem may be due to distortion present on the ac power line.

5-102 Preregulator Tracking Adjustment

5-103 To adjust the voltage drop across the series regulator, proceed as follows:

a. Connect load resistor specified in Figure 5-1 across rear output terminals of supply.

 b. Connect variable autotransformer between input power source and power supply input and adjust it for a 230Vac input to the supply.

c. Connect dc voltmeter across series regulator (between TP102 and TP103).

d. Turn CURRENT controls fully clockwise.

e. To check voltage drop across regulator at low output voltage, short circuit the load resistor and adjust VOLTAGE controls for maximum rated output current on front panel ammeter.

f. Adjust R70 (RAMP ADJ.) until voltmeter reads 3.5 ±0.3Vdc.

g. To check the voltage drop at high output voltage, remove short circuit from across load resistor and adjust VOLTAGE controls for maximum rated output current. Voltmeter reading should again be 3.5 ± 0.3 Vdc.

h. Vary input line voltage from 208 to 254Vac. Voltmeter reading should vary between 3.2 and 3.8Vdc. If reading exceeds this range, proceed to step (i).

i. Replace R77 with decade box. Vary input line voltage between 208 and 254 Vac and adjust decade box until voltmeter reading variation is minimal and within range of 3.2 to 3.8Vdc. Replace decade box with equivalent resistor.

5-104 Crowbar Trip Voltage Adjustment

5-105 To adjust the voltage at which the crowbar fires, proceed as follows:

a. Turn front panel OVERVOLTAGE ADJUST potentiometer A5R125 fully clockwise.

b. Turn on supply.

c. Set output voltage to desired trip voltage.

d. Turn A5R125 slowly counterclockwise until the crowbar fires (amber OVERVOLTAGE lamp lights and voltmeter indication falls to zero).

e. Turn off supply and turn down output voltage controls.

f. Turn on supply and set desired output voltage.

NOTE

It is recommended that the crowbar trip voltage be set higher than the normal output voltage by no less than 5% of the output voltage plus 2 volts for the Models 6259B, 6260B, or 6261B, or 5% of the output voltage plus one volt for the Models 6268B or 6269B. If an occasional tripping of the crowbar can be tolerated as a load is being disconnected, the 4 crowbar trip point can be set much closer to the operating voltage of the supply.

5-106 Maximum Crowbar Trip Voltage Adjustment

5-107 To adjust the maximum voltage at which the crowbar fires, proceed as follows:

 a. Rotate A5R125 (OVERVOLTAGE ADJUST) and CURRENT controls fully clockwise.

b. Disconnect one end of R72 (at TP70 or TP71) to temporarily disable the overvoltage limit circuit.

c. Connect decade resistance box in place of R95 (mounted on standoffs on main circuit board).

d. Turn on supply and adjust VOLTAGE controls for output voltage shown below:

Model	Value
6259B	12Vdc
6260B	12Vdc
6261B	23Vdc
6268B	45Vdc
6269B	45Vdc

e. Adjust decade resistance box until crowbar fires.

f. Replace decade resistance with appropriate value resistor in R95 position and reconnect resistor R72. Maximum crowbar trip voltage is now set at voltage given in step (d).

5-108 Disabling the Crowbar

5-109 To disable the crowbar completely, disconnect either end of R98 at TP96 or TP97 on the main circuit board.

the water and the works stand the side the second

MARCH BALL

SECTION VI REPLACEABLE PARTS

6-1 INTRODUCTION

6-2 This section contains information for ordering replacement parts. Table 6-4 lists parts in alpha-numeric order by reference designators and provides the following information:

a. Reference Designators. Refer to Table 6-1.

b. Description. Refer to Table 6-2 for abbreviations.

c. Manufacturer's Part Number or Type.

d. Manufacturer's Federal Supply Code Number. Refer to Table 6-3 for manufacturer's name and address.

e. Hewlett-Packard Part Number.

f. Parts not identified by a reference designator are listed at the end of Table 6-4 under Mechanical and/or Miscellaneous. The former consists of parts belonging to and grouped by individual assemblies; the latter consists of all parts not immediately associated with an assembly.

6-3 ORDERING INFORMATION

6-4 To order a replacement part, address order or inquiry to your local Hewlett-Packard sales office (see lists at rear of this manual for addresses). Specify the following information for each part: Model, complete serial number, and any Option or special modification (J) numbers of the instrument; Hewlett-Packard part number; circuit reference designator; and description. To order a part not listed in Table 6-4, give a complete description of the part, its function, and its location.

Table 6-1. Reference Designators

Α	= assembly	E	= miscellaneous
в	= blower (fan)		electronic part
С	= capacitor	F	= fuse
CB	= circuit breaker	J	= jack, jumper
CR	= diode	к	= relay
DS	= device, signaling	L	= inductor
	(lamp)	M	= meter

Table 6-1. Reference Designators (Continued)

Ge7127 ()

TTTAR

P	= plug	V	= vacuum tube,	
Q	= transistor		neon bulb,	
R	= resistor	1 A.	photocell, etc.	
S	= switch	VR	= zener diode	
т	= transformer	X	= socket	4
TB	= terminal block	Z	= integrated cir-	
TS	= thermal switch		cuit or network	

Table 6-2. Description Abbreviations

Α	= ampere	mod	i. = modular or
ac	= alternating current		modified
assy	. = assembly	mtg	= mounting
bd	= board	n	= nano = 10 ⁻⁹
bkt	= bracket	NC	= normally closed
°C	= degree Centigrade	NO	= normally open
cd	= card	NP	= nickel-plated
coef	= coefficient	Ω	= ohm
com	p = composition	obd	= order by
CRT	= cathode-ray tube		description
СТ	= center-tapped	OD	= outside diameter
dc	= direct current	p	= pico = 10 ⁻¹²
DPD)T= double pole,	P.C.	= printed circuit
	double throw	pot.	= potentiometer
DPS	T = double pole,	р.р	= peak-to-peak
	single throw	ppm	= parts per million
elect	t = electrolytic	pvr	= peak reverse
enca	p = encapsulated		voltage
F	= farad	rect	= rectifier
°F	= degree Farenheit	rms	= root mean square
fxd	= fixed	Si	= silicon
Ge	= germanium	SPD	T= single pole,
н	= Henry		double throw
Hz	= Hertz	SPST	= single pole,
IC	= integrated circuit		single throw
ID	= inside diameter	SS	= small signal
incne	d = incandescent	т	= slow-blow
k	= kilo = 10 ³	tan.	= tantulum
m	= milli = 10 ⁻³	Ti	= titanium
М	= mega = 10 ⁶	v	= volt
μ	= micro = 10 ⁻⁰	var	= variable
met.	= metal	ww	= wirewound
mfr	= manufacturer	W	= Watt

CODE	MANUFACTURER ADDRESS	co	DE	MANUFACTURER . ADDRESS
00620	EBX Sales Co. Inc. Jamaica N.Y.	107	137	Transistor Electronics Corp.
00028	Aerovov Com New Bedford, Mass			Minneapolis, Minn.
00050	Sangamo Electric Co.	07	138	Westinghouse Electric Corp. Elmira, N.Y.
00005	S Carolina Div Pickens, S.C.	07	263	Fairchild Camera and Instrument
01121	Allen Bradley Co. Milwaukee, Wis.	"	~~~	Mountain View, Calif.
01255	Litton Ind. Beverly Hills Calif.	07	387	Birtcher Corp., The Los Angeles, Calif.
01281	TRW Semiconductors, Inc.	07	397	Sylvania Electric Prod. Inc.
01201	Lawndale, Calif.			Mountainview, Calif.
01295	Texas Instruments, Inc. Dallas, Texas	07	716	IRC Div. of TRW Inc. Burlington, Iowa
01686	RCL Electronics, Inc. Manchester, N.H.	07	910	Continental Device Corp.
01930	Amerock Corp. Rockford, III.		1	Hawthorne, Calif.
02107	Sparta Mfg. Co. Dover, Ohio	07	933	Raytheon Co. Components Div.
02114	Ferroxcube Corp. Saugerties, N.Y.			Mountain View, Calif.
02606	Fenwal Laboratories Morton Grove, III.	084	484	Breeze Corporations, Inc. Union, N.J.
02660	Amphenol Corp. Broadview, III.	08	530	Reliance Mica Corp. Brooklyn, N.Y.
02735	Radio Corp. of America, Solid State and	087	717	Sloan Company, The Sun Valley, Calif.
	Receiving Tube Div. Somerville, N.J.	08	730	Vemaline Products Co. Inc.
03508	G.E. Semiconductor Products Dept.		+	Wyckoff, N.J.
	Syracuse, N.Y.	080	806	General Elect. Co. Minature
03797	Eldema Corp. Compton, Calif.			Lamp Dept. Cleveland, Ohio
03877	Transitron Electronic Corp.	088	863	Nylomatic Corp. Norrisville, Pa.
	Wakefield, Mass.	089	919	Alex Same Electronic Components
03888	Pyrofilm Resistor Co., Inc.	090	021	Airco Speer Electronic Components Bradford Pa
140000000000000	Cedar Knolls, N.J.		102	*Hawlett Packard Co. New Jersey Div
04009	Arrow, Hart and Hegeman Electric Co.	09	102	Rockaway N I
	Hartford, Conn.		213	General Elect Co. Semiconductor
04072	ADC Electronics, Inc. Harbor City, Calif.		215	Prod Dept. Buffalo, N.Y.
04213	Caddell & Burns Mig. Co. Inc.	093	214	General Elect. Co. Semiconductor
04404	Mineola, N.T.			Prod. Dept. Auburn, N.Y.
04404	Palo Alto Calif	09:	353	C & K Components Inc. Newton, Mass.
04712	Motorola Semiconductor Prod. Inc.	099	922	Burndy Corp. Norwalk, Conn.
04713	Phoenix Arizona	111	115	Wagner Electric Corp.
05277	Westinghouse Electric Corp.		20020	Tung-Sol Div. Bloomfield, N.J.
03277	Semiconductor Dept. Youngwood, Pa.	11:	236	CTS of Berne, Inc. Berne, Ind.
05347	Ultronix, Inc. Grand Junction, Colo.	11:	237	Chicago Telephone of Cal. Inc.
05820	Wakefield Engr. Inc. Wakefield, Mass.			So. Pasadena, Calif.
06001	General Elect. Co. Electronic	11	502	IRC Div. of TRW Inc. Boone, N.C.
	Capacitor & Battery Dept. Irmo, S.C.	11	711	General Instrument Corp. Newark, N.J.
06004	Bassik Div. Stewart-Warner Corp.	12	136	Philadelphia Handle Co. Camden, N.J.
	Bridgeport, Conn.	12	615	U.S. Terminals, Inc. Cincinnati, Ohio
06486	IRC Div. of TRW Inc.	12	617	Hamlin Inc. Lake Mills, Wisconsin
	Semiconductor Plant Lynn, Mass.	12	697	Clarostat Mfg. Co. Inc. Dover, N.H.
06540	Amatom Electronic Hardware Co. Inc.	13	103	Thermalloy Co. Dallas, Texas
and a second second second	New Rochelle, N.Y.	14	493	Hewlett-Packard Co. Loveland, Colo.
06555	Beede Electrical Instrument Co.	14	655	Cornell-Dubilier Electronics Div.
	Penacook, N.H.			Federal Pacific Electric Co.
06666	General Devices Co. Indianapolis, Ind.			Newark, N.J.
06751	Semoor Div. Components, Inc.		936	General Instrument Corp. Semicon-
00770	Phoenix, Arizona		0.04	Guctor Prod. Group Hicksville, N.Y.
06776	Nobinson Nugent, Inc. New Aldany, N.Y.	15	200	Corping Glass Works Raleigh N.C.
06812	Torrington Mfg. Co. Van Nuys, Calif.	1 16	283	Corning Glass Works Maleight, M.C.

*Use Code 28480 assigned to Hewlett-Packard Co., Palo Alto, California

1.

Table 8-3. Code List of Manufacturers

٠.

1

	A REALIZED FOR THEAD			198
CODE	MANUFACTURER ADDRESS	$x_{0}h$	-CODE	MANUFACTURER ADDRESS
16758	Delco Radio Div. of General Motors		59730	Thomas and Betts Co. Philadelphia, Pa.
1.11.15.4.1	Corp. Kokomo, Ind.	1	61637	Union Carbide Corp. New York, N.Y.
17545	Atlantic Semiconductors, Inc.		63743	Ward Leonard Electric Co.
1963-1963	Asbury Park, N.J.			Mt. Vernon, N.Y.
17803	Fairchild Camera and Instrument Corp.		70563	Amperite Co. Inc. Union City, N.J.
	Mountain View, Calif.		70901	Beemer Engrg Co.
17870	Daven Div. Thomas A. Edison Industries		+ a	Fort Washington, Pa.
1.1.1	McGraw-Edison Co. Orange, N.J.		70903	Belden Corp. Chicago, III.
18324	Signetics Corp. Supryvale, Calif.		71218	Bud Radio, Inc. Willoughby, Ohio
10315	Bendix Corp. The Navigation and		71279	Cambridge Thermionic Corp.
10010	Control Div. Teterboro, N.J.			Cambridge, Mass.
10701	Electra/Midland Corp.		71400	Bussmann Mfg. Div.of McGraw &
10/01	Mineral Wells, Texas			Edison Co. St. Louis, Mo.
21520	Easteel Metallurgical Corp.		71450	CTS Corp. Elkhart, Ind.
21020	No. Chicago, III.		71468	I.T.T. Cannon Electric Inc.
22220	Union Cerbide Corp. Electronics Div.			Los Angeles, Calif.
11119	Mountain View Calif.		71590	Globe-Union Inc.
22752	LUD Electronics Corp Hollywood Ela			Milwaukee, Wis.
22/03	Pampa Texas		71700	General Cable Corp. Cornish
23930	Canada Electric Co. Schenectedy N.Y.		/1/00	Wire Co Div Williamstown Mass
24440	General Electric Co. Schenectady, N.T.		71707	Coto Coil Co Inc Providence B.I.
24400	Seneral Electric Co.		71744	Chicago Miniature Lamp Works
DACEE	Conserved Partie Co. West Conserved Mass		11/44	Chicago III
24055	General Radio Co. West Concord, Mass.		71705	Cinch Mfa Co. and Howard
24001	LTV Electrosystems inc. Menicor/com-		/1/05	R long Div Chicago III
00000	ponents Operations Huntington, Ind.		71004	Dow Corping Corp Midland Mich
20982	Dynacool Mitg. Co. Inc. Saugerties, N. T.		71904	Electro Motive Mfg. Co. Inc.
2/014	National Semiconductor Corp.		12130	Electro Motive Mig. Co. Inc.
00400	Santa Ciara, Calif.		72610	Dislight Corp Brooklyn NY
28480	Hewiett-Packard Co. Palo Alto, Call.		72019	Diangin Corp. Diookiyi, N.T.
28520	Heyman Mig. Co. Kenilworth, N.J.		72699	General Instrument Corp. Newark, N.J.
288/5	IMC Magnetics Corp. Rochester, N.H.		/2/65	Drake Mig. Co. Harwood Heights, III.
31514	SAE Advance Packaging, Inc.		72962	Elastic Stop Nut Div. of
01007	Santa Ana, Calif. Buduia Méa Co		70000	Amerace Esna Corp. Union, N.J.
31827	Budwig Mitg. Co. Ramona, Call.		12982	Erie Technological Products
33173	G.E. Co. Tube Dept. Owensboro, Ky.		72006	Hart Min Co. Hartford Copp
35434	B.B. Mellem & Co. Indianapolia Ind		73090	Backman Instruments
3/942	P.R. Mallory & Co. Indianapolis, Ind.		73130	Eullerton Calif
42190	Muter Co. Chicago, III.		70100	Ecouvel Inc. Ashland Mass
43334	New Departure-Hyatt Bearings Div.		73100	Husher Aircraft Co. Electron
	General Motors Corp.		13283	Dunamice Dive Torrance Calif
	Sandusky, Offio		72445	Amparax Electropic
44655	Ohmite Manufacturing Co. Skokle, III.		73445	Hicksville N Y
46384	Penn Engr. and Mig. Corp.		73506	Bradley Semiconductor Corp
17004	Doylestown, Pa.		10000	New Haven Conn.
47904	Polaroid Corp. Cambridge, Mass.	1	73559	Carling Electric Inc Hartford Conn
49956	Raytheon Co. Lexington, Mass.		73734	Federal Screw Products Inc
55026	Simpson Electric Co. Div. of American	1	10/04	Chicago III
	Gage and Machine Co. Chicago, III.		74103	Heinemann Electric Co. Trenton N.I.
56289	Sprague Electric Co.		74545	Hubbell Harvey Inc. Bridgenort Conn.
	North Adams, Mass.		74868	Amphenol Corp Amphenol RF Div
58474	Superior Electric Co. Bristol, Conn.		74000	Danhury Conn.
68849	Syntron Div. of FMC Corp.		74970	E.E. Johnson Co. Wasaca Minn.
7 H - AN	Homer City, Pa.		14070	

6-3

2.

163

•

a -	Table 6-3. Code	List of Manufactu	rers
CODE	MANUFACTURER ADDRESS	CODE	MANUFACTURER
75042 -	IRC Div. of TRW, Inc. Philadelphia, Pa.	82866	Research Products Corp.
75183	"Howard B. Jones Div. of Cinch	82877	Rotron Inc.
4	Mfg. Corp. New York, N.Y.	82893	Vector Electronic Co.
75376	Kurz and Kasch, Inc. Dayton, Ohio	83058	Carr Fastener Co.
75382	Kilka Electric Corp. Mt. Vernon, N.Y.	83186	Victory Engineering
75915	Littlefuse, Inc. Des Plaines, III.	83298	Bendix Corp.
76381	Minnesota Mining and Mfg. Co.	83330	Herman H. Smith, Inc.
	St. Paul, Minn.	83385	Central Screw Co.
76385	Minor Rubber Co. Inc. Bloomfield, N.J.	83501	Gavitt Wire and Cable
76487	James Millen Mfg. Co. Inc. Malden, Mass.	83508	Grant Pulley and Hardwa
76493	J.W. Miller Co. Compton, Calif.		v
76530	Cinch City of Industry, Calif.	83594	Burroughs Corp.
76854	Oak Mfg. Co. Div. of Oak Electro/	83835	U.S. Radium Corp.
	Netics Corp. Crystal Lake, III.	83877	Yardeny Laboratories
77068	Bendix Corp., Electrodynamics Div.	84171	Arco Electronics, Inc.
	No. Hollywood, Calif.	84411	TRW Capacitor Div.
77122	Palnut Co. Mountainside, N.J.	86684	RCA Corp.
77147	Patton-MacGuyer Co. Providence, R.I.	86838	Rummel Fibre Co.
77221	Phaostron Instrument and Electronic Co.	87034	Marco & Oak Industries
	South Pasadena, Calif.	87216	Philco Corp.
77252	Philadelphia Steel and Wire Corp.	87585	Stockwell Rubber Co.
1	Philadelphia, Pa.	87929	Tower-Olschan Corp. B
77342	American Machine and Foundry Co.	88140	Cutler-Hammer Inc.
	Princeton, Ind.	88245	Litton Precision Products
77630	TRW Electronic Components Div.	00004	Culture Industriat Inc.
	Camden, N.J.	90634	Guiton Industries Inc.
77764	Resistance Products Co. Harrisburg, Pa.	90763	United-Car Inc.
78189	Illinois Tool Works Inc. Elgin, III.	91345	Miller Dial and Nameplate
78452	Everlook Chicago, Inc. Chicago, III.		De l'a Manaisle Ca
78488	Stackpole Carbon Co. St. Marys, Pa.	91418	Radio Materiais Co.
78526	Stanwyck Winding Div. San Fernando	91506	Augat, Inc.
	Electric Mfg. Co. Inc. Newburgh, N.Y.	91637	Elec Corp. W
78553	Tinnerman Products, Inc. Cleveland, Ohio	91002	Heneywell Inc
78584	Stewart Stamping Corp. Yonkers, N.Y.	91929	Whiteo Inc.
79136	Waldes Kohinoor, Inc. L.I.C., N.Y.	92825	Sulvenia Electric Prod
79307	Whitehead Metals Inc. New York, N.Y.	93332	Ease Wire Corp
79727	Continental-Wirt Electronics Corp.	93410	Essex wire corp.
	Philadelphia, Pa.	94144	Haymeon Co.
79963	Zierick Mfg. Co. Mt. Kisco, N.Y.	94154	Southeo Inc.
80031	Mepco Morristown, N.J.	94222	Southeo Inc.
80294	Bourns, Inc. Riverside, Calif.	95203	Leecran Mig. Co. Inc.
81042	Howard Industries Racine, Wisc.	95354	Readin Corp
81073	Grayhill, Inc. La Grange, III.	95/12	Wedverser Co. Inc.
81483	International Rectifier El Segundo, Calif.	95987	Amphanol Corp
81751	Columbus Electronics Yonkers, N.Y.	96/91	Amphenol Corp.
82099	Goodyear Sundries & Mechanical Co. Inc.	9/404	moustrial netaining ring
	New York, N.Y.	07702	IMC Magnetics Corp
82142	Airco Speer Electronic Components	9//02	Sealectro Corp Ma
671-10-10-10-10-10-10-10-10-10-10-10-10-10	Du Bois, Pa.	09410	FTC Inc
82219	Sylvania Electric Products Inc.	08978	International Electronic F
00000	Emporium, Pa.		
82389	Switchcraft, Inc. Chicago, III.	99934	Renbrandt, Inc.
82647	Metals and Controls Inc. Attleboro, Mass.		

gineering Springfield, N.J. Eatontown, N.J. p. Smith, Inc. Brooklyn, N.Y. ew Co. Chicago, III. and Cable Brook field, Mass. y and Hardware Co. West Nyack, N.Y. Plainfield, N.J. Corp. m Corp. Morristown, N.J. New York, N.Y. boratories onics, Inc. Great Neck, N.Y .: Ogallala, Neb. citor Div. Harrison, N.J. bre Co. Newark, N.J. Anaheim, Calif. ak Industries Lansdale, Pa. э. Rubber Co. Philadelphia, Pa. han Corp. Bridgeport, Conn. mer Inc. Lincoln, III. ision Products Inc, USECO Van Nuys, Calif. Metuchen, N.J. ustries Inc. Inc. Chicago, III. and Nameplate Co. El Monte, Calif. Chicago, III. rials Co. Attleboro, Mass. onics, Inc. Columbus, Neb. Willow Grove, Pa. Freeport, III. Inc. Schiller Pk., Ill. ectric Prod. Woburn, Mass.

ADDRESS

Madison, Wisc. Woodstock, N.Y. Glendale, Calif.

Cambridge, Mass.

Boston, Mass.

Corp. Mansfield, Ohio Quincy, Mass. ю. Livingston, N.J. ctric Corp. Lester, Pa. c. L.I.C., N.Y. g. Co. Inc. Rolling Meadows, III. fg. Co. Franklin, Ind. p. Chicago, III. Co. Inc. Janesville, Wis. Corp. Retaining Ring Co. Irvington, N.J. Westbury, N.Y. tics Corp. Mamaroneck, N.Y. orp. Cleveland, Ohio al Electronic Research Corp. Burbank, Calif.

*Use Code 71785 assigned to Cinch Mfg. Co., Chicago, III.

REF. DESIG. (AND MODELS)	DESCRIPTION	MFG. PART NUMBER	MFG. CODE	HP PART NUMBER
	A1 Main PC Board - Electrical		•	
	(See Note 1)			
			50000	
C1	fxd, polyester .01µF 200V	192P10392	56289	0160-0161
C2	fxd, elect. 5µF 50V	30D505G050BB2	56289	0180-0301
C20	fxd, elect. 68µF 15V	150D686X0015R2	56289	0180-1835
C35	fxd, elect. 20µF 50V	30D206G050C02	56289	0180-00494
C40	fxd, polyester .022µF 200V	192P22392	56289	0160-0162
C41			50000	0100 0100
6259B, -60B, -61B	fxd, polyester .022µF 200V	192P22392	56289	0160-0162
6268B, -69B	fxd, polyester .01µF 200V	192P10392	56289	0160-0161 1
C44	fxd, elect. 1400µF 30V		28480	0180-1860
C60	fxd, elect. 4.7µF 35V	150D475X9035B2	56289	0180-0100
C61	fxd, elect. 325µF 35V	D34656-DEE	56289	0180-0332
C70	fxd, elect. 1µF 35V	150D105X9035A2	50289	0180-0291
C71	fxd, polyester 0.22µF 80V	AE22R224K1	06001	0160-2453
C72, 73	fxd, elect. 5µF 50V	30D505G050BB2	56289	0180-0301
C90	fxd, cer. 0.47µF 25V	5C11B7-CML	56289	0160-0174
C91	fxd, polyester 4700pF 200V	292P47292	56289	0160-0157
CR1-7, 20, 21, 35-37	diode, Si. 200mA 180V	1N485		1901-0033
CR40	diode, Si. 3-junction	STB 523	03508	1901-0460
CR41	diode, Si. 200mA 180V	1N485		1901-0033
CR42	(not used)			
CR43, 44	diode, Si. 200mA 180V	1N485		1901-0033
CR45-50, 53, 54	diode, Si. 1A 200V	1N5059		1901-0327
CR60-62, 70-84, 88, 90-93	diode, Si. 200mA 180V	1N485		1901-0033
Q1	SS PNP Si.	TZ 173	56289	1853-0099
Q20, 40	SS NPN Si.	2N3391		1854-0071
Q41, 42	SS PNP Si.	TZ 173	56289	1853-0099
Q60	SS PNP Si.	2N4036		1853-0041
Q61-63	SS NPN Si.	2N3391		1854-0071
Q70, 71	SS PNP Si.	TZ 173	56289	1853-0099
Q72, 73	SS NPN Si.	2N3391		1854-0071
Q90	SS PNP Si.	TZ 173	56289	1853-0099
Q91, 92	SS NPN Si.	2N3391	-	1854-0071
R1	fxd, film 1M 1% 1/4W	CEB T-0	07716	0757-0344
R2				
6259B, -60B	fxd, comp. 39 5% 1/2W	EB-3905	01121	0686-3905
6261B	fxd, comp. 82 5% 1/2W	EB-8205	01121	0686-8205
6268B; -69B	fxd, comp. 160 5% 1/2W	EB-1615	01121	0686-1615
R3	fxd, comp (selected) 5% 1/2W	EB-	01121	
R4	fxd, ww 680 5% 5W	243E6815	56289	0811-2099
R5			5	
6259B, -60B, -61B	fxd, ww 600 5% 5W	243E6015	56289	0811-1860
6268B, -69B	fxd, ww 680 5% 5W	243E6815	56289	0811-2099

Note 1: This assembly is designed for component-level repair. Replacement assemblies cannot be supplied.

STATE STATE STREET

3

Table 6-4. Replaceable Parts

14

SUPPORT.

1.4

1.36

14 20

.

South Constraint in the

A MARTINE POINT

ALL S

· · · · ·

1. 8.00 -

2

REF. DESIG.	A A A A A A A A A A A A A A A A A A A	MFG.	MFG.	A HP
(AND MODELS)	DESCRIPTION IL	PART NUMBER	CODE	PARTNUMBER
R6	1	5 1		
6259B, -60B, -61B	fxd, ww 470 5% 3W	242E4715	66289	0811-1555
6268B, -69B	fxd, ww 1k 5% 3W	RS2B	91637	0813-0001
R20	fxd, film 330 1% 1/8W	CEA T-0	.07716	0698-5663
R21	fxd, film 200k 1% 1/8W	CEA T-0	07716	0757-0472
R22	fxd, film 196 1% 1/8W	CEA T-0	07716	0698-3440
R23	fxd, film 1.21k 1% 1/8W	CEA T-0	07716	0757-0274
62508 -608 -618	fxd, film 7.5k 1% 1/8W	CEA T-0	07716	0757-0440
6268B, -69B	fxd, film 127k 1/4% 1/8W	CEA-993	07716	0698-6659
62500 600 61B	fyd film 5.49k 1% 1/8W	CEA T-0	07716	0698-3382
6259B, -00B, -01D	fxd film 90.9k 1% 1/8W	CEA-993	07716	0757-0464
826	fxd film 21.5 1% 1/8W	CEA T-0	07716	0698-3430
- P27	frd comp 3 9M 5% 1/2W	EB-3955	01121	0686-3955
R20 20	frd comp 3 3 5% 1/2W	EB-0335	01121	0686-0335
N20, 23	fyd comp (selected) 5% 1/2W	EB-	01121	
P21	fxd, www 2 6k 5% 3W	242E2625	56289	0811-1808,
N31	fyd comp 10k 5% 1/2W	EB-1035	01121	0686-1035
N35, 30	fyd comp 180k 5% 1/2W	EB-1845	01121	0686-1845
R37	fxd_comp 1 5k 5% 1/2W	EB-1525	01121	0686-1525
R40	fxd, comp 510 5% 1/2W	EB-5115	01121	0686-5115
R41	fxd, comp 560 1% 1/2W	CEB T-0	07716	0698-5146
R42	fred www.50.5% 5W	242E5005	56289	0811-1854
R43	fud met ov 22.5% 2W/	C42S	16299	0698-3609
R45	1xd, met. 0x. 22 5% 2W	0120		
6259B60B61B	fxd, comp 1k 5% 1/2W	EB-1025	01121	0686-1025
6268B -69B	fxd, comp 820 5% 1/2W	EB-8215	01121	0686-8215
R46	fxd, comp 1k 5% 1/2W	EB-1025	01121	0686-1025
B47	var, ww 5k 20%	110-F4	11236	2100-1824
B48	fxd, comp 5.1k 5% 1/2W	EB-5125	01121	0686-5125
R49	fxd, comp 47 5% 1/2W	EB-4705	01121	0686-4705
R50	fxd, comp 39 5% 1/2W	EB-3905	01121	0686-3905
R51	fxd, comp 1k 5% 1/2W	EB-1025	01121	0686-1025
R52	fxd, film 61.9k 1% 1/8W	CEA T-0	07716	0757-0460
R53	fxd, comp 560 5% 1/2W	EB-5615	01121	0686-5615
R54	fxd, ww 50 5% 5W	243E5005	56289	0811-1854
COEOD COD	frd www 50 5% 5W	243E5005	56289	0811-1854
6259B, -00B	fxd, ww 50 5% 5% 1/2W	EB-7505	01121	0686-7505
R57				
6259B, -60B	fxd, ww 1 5% 2W	BWH	75042	0811-1666
6261 B	fxd, ww 1.8 5% 2W	BWH	75042	0811-1669
6268B, -69B	fxd, ww 3.9 5% 2W	BWH	75042	0811-1673
R58			0.000	
6259B, -60B	fxd, ww 50 5% 10W	10XM	63743	0811-1902
6261B	fxd, ww 135 5% 10W	10XM	63743	0811-1905
6268B, -69B	fxd, ww 400 5% 10W	10XM	63743	0811-0942
R60	fxd, film 600 1% 1/8W	CEA T-0	07716	0757-1100

Table 6-4. Rep

100

.

Table 6-4. Replaceable Parts

14.1

Sector Sector Sector

REF. DESIG. AND MODELS	DESCRIPTION	MFG. PART NUMBER	MFG. CODE	HP PART NUMBER
R61 R62	fxd, film 7.5k 1% 1/8W	CEA T-0	07716	0757-0440
62598 -688 -69B	fxd, met. ox. 180 5% 2W	C42S	16299	0698-3626
6260B61B	fxd, met. ox. 200 5% 2W	FP-42	27167	0698-3627
R63	fxd, met. ox. 499 1% 1/4W	CEB T-0	07716	0698-3207
R64	fxd, film 2k 1% 1/4W	CEB T-0	07716	0757-0739
- R65	fxd, comp 100k 5% 1/2W	EB-1045	01121	0686-1045
B66	fxd, comp 200k 5% 1/2W	EB-2045	01121	0686-2045
B67	fxd, comp 33k 5% 1/2W	EB-3335	01121	0686-3335
R68	fxd, film 5.49k 1% 1/8W	CEA T-0	07716	0698-3382
R69A	fxd, film 7.5k 1% 1/8W	CEA T-0	07716	0757-0440
B69B	fxd, film 3.4k 1% 1/8W	CEA T-0	07716	0698-4440
870	var. ww 5k 20%	110-F4	11236	2100-1824
B71	fxd, film 12k 1% 1/8W	CEA T-0	07716	0698-5088
B72				14 A A A A A A A A A A A A A A A A A A A
259B -60B	fxd, film 12k 1% 1/8W	CEA T-0	07716	0698-5088
6261B	fxd, film 23k 1% 1/8W	CEA T-0	07716	0698-3269
5268B -69B	fxd, film 45k 1% 1/8W	CEA T-0	07716	0698-5091,
B73	fxd. comp 12k 5% 1/2W	EB-1235	01121	0686-1235
B74	fxd_comp 82k 5% 1/2W	EB-8235	01121	0686-8235
875				
2598	fxd_film 2.37k 1% 1/8W	CEA T-0	07716	0698-3150
260B .61B .68B .69B	fxd film 4 75k 1% 1/8W	CEA T-0	07716	0757-0437
R76		01		
~?59B	fxd, film 3.4k 1% 1/8W	CEA T-0	07716	0698-4440
260B, -61B, -68B, -69B 877	fxd, film 4.75k 1% 1/8W	CEA T-0	07716	0757-0437
6259B	fxd, comp 200k 5% 1/2W	EB-2045	01121	0686-2045
260B	fxd, film 68.1k 1% 1/8W	CEA T-0	07716	0757-0461
2618	fxd, film 110k 1% 1/8W	CEA T-0	07716	0757-0466
6268B -69B	fxd, comp 430k 5% 1/2W	EB-4345	01121	0686-4345
R78				
'59B, -60B	fxd, film 60.4k 1% 1/8W	CEA T-0	07716	0698.3572
6261 B	fxd, film 118k 1% 1/8W	CEA T-0	07716	0698-3265
F768B, -69B	fxd, film 249k 1% 1/8W	CEA T-0	07716	0757-0270
R79	fxd, comp 1.8k 5% 1/2W	EB-1825	01121	0686-1825
R80	fxd, film 4.32k 1% 1/8W	CEA T-0	07716	0757-0436
R81	fxd, comp 4.7 5% 1/2W	EB-47G5	01121	0698-0001
R82 R83	fxd, comp 9.1k 5% 1/2W	EB-9125	01121	0686-9125
6259B60B61B	fxd, comp 30 5% 1/2W	EB-3005	01121	0686-3005
C^68B -69B	fxd, comp 27 5% 1/2W	EB-2705	01121	0686-2705
R84	fxd, comp 100k 5% 1/2W	EB-1045	01121	0686-1045
Pos	fxd_comp 9 1k 5% 1/2W	EB-9125	01121	0686-9125
R86				0000 0001
59B,-60B, -61B	fxd, met. ox. 330 5% 2W	C42S	16299	0698-3631
5288, -69B	fxd, met. ox. 270 5% 2W	C42S	16299	0698-3629
R87	fxd, met. ox. 1.5k 5% 2W	C42S	16299	0698-3338
R88	fxd, comp 10 5% 1/2W	EB-1005	01121	0686-1005

6-7

1 .

REF. DESIG.	DESCRIPTION	MFG. PART NUMBER	MFG. CODE	HP PART NUMBER
				0000 0007
R90	fxd, met. ox. 820 5% 2W	C42S	16299	0698-3637
R91	fxd, comp 180 5% 1W	GB-1815	75040	0089-1815
R92	fxd, ww 220 5% 2W	BWH	75042	0811-1763
R93	fxd, comp 3.9k 5% 1/2W	EB-3925	01121	0686-3925
R94	fxd, comp 510 5% 1/2W	EB-5115	01121	0080-5115
R95			07740	0757 1000
6259B, -60B, -61B	fxd, film 3k 1% 1/8W	CEA T-0	07716	0757-1093-
6268B, -69B	fxd, film 1.5k 1% 1/8W	CEA T-0	0//16	0/5/-042/
R96	fxd, comp 200k 5% 1/2W	EB-2045	01121	0686-2045
R97	fxd, comp 4.7 5% 1/2W	EB-47G5	01121	0698-0001
R98	fxd, comp 10 5% 1/2W	EB-1005	01121	0686-1005
R99	fxd, comp 10k 5% 1/2W	EB-1035	11006	0000-1035
R101	var. ww 250 20%	110	11236	2100-0439
R102			07710	0757 0421
6259B,60B	fxd, film 825 1% 1/8W	CEA T-O	07716	0757-0421
6261B	fxd, film 900 1% 1/8W	CEA T-0	07710	0757-1099
6268B, -69B	fxd, film 909 1% 1/8W	CEA T-0	0//16	0/5/-0422
R103		054 70	07716	0757 0274
6259B, -60B, -61B	fxd, film 1.21k 1% 1/8W	CEA T-0	07716	0757-0274
6268B, -69B	fxd, film 1.5k 1% 1/8W	CEA 1-0	0//16	0757-0427
6259B -60B	fxd_film 4.53k 1% 1/8W	CEA T-0	07716	0698-4443
6261 B	fxd film 10k 1% 1/8W	CEA T-0	07716	0757-0442
6268B .60B	fxd film 19 1k 1% 1/8W	CEA T-0	07716	0698-4484
B105	fxd film 422 1% 1/4W	CEB T-0	07716	0698-4590
B106	var ww 250 20%	110	11236	2100-0439
B108 109	fxd_comp 100 5% 1/2W	EB-1015	01121	0686-1015
B110	(not supplied see Fig. 7-8, note 14)			
B117	(not supplied, see Fig. 7-8, note 14)			
B120	fxd, film 4.7k 5% 1/4W	CCA-993	07716	0758-0005
T70.90	pulse transformer	1977 - 27 March 1996 - 1997	28480	5080-7192
VB1 40	diode, zener 4.22V 5%	SZ 10939-74	04713	1902-3070
V860 61	diode, zener 6.2V 5%	1N825		1902-1221
VB90	diode, zener 6.19V 5%	SZ 10939-122	04713	1902-0049
Z1	dual diff. amp IC	CA 3026	02735	1820-0240
Z2	resistor network		28480	1810-0042
2	A2 RFI Filter Ass'y. – Electrical (See Note 1)			
C1 2	fxd_paper 0.1µF 250V		28480	0160-4065
C3	fxd_paper_047µF 250Vac		28480	0160-4323
63	fxd cer 5000pE 1kV	C023B102G502ZS31	56289	0160-0899
CB1	thyristor, Si, (Triac)	T6440M *	02735	1884-0248
.11.2				
6259B, -60B, -61B, -68B	(omit for 230Vac or 208Vac operation)			
J3				
6259B, -60B, -61B, -68B	jumper for 230Vac operation			

* nearest commercial equivalent

1

REF. DESIG. (AND MODELS)	DESCRIPTION	MFG. PART NUMBER	MFG. CODE	HP PART NUMBER
L1A/L1B 6259B, -60B, -61B, 68B L1 6269B	inductor		28480 28480	5080-1781 5080-1782
R1, 2 R3	fxd, met. ox. 1.5k 5% 2W (omit for 230Vac or 208Vac operation)	FP-42	27167	0698-3338
R4 RV1	fxd, met. ox. 220 5% 2W varistor 250Vac	FP-42 V250LA40B	27167 03508	0698-3628 4 0837-0117
	A3 Interconnection Board – Electrical (See Note 1)			ł
C3 6259B, -60B, -61B 6268B, -69B	fxd, elect. 8600μF 25V fxd, elect. 5000μF 45V	(32D)D46882-DQB (36D)D38008-DQB	56289 56289	0180-1882 0180-1919
J1 R120 T2	connector, PC board edge fxd, comp 51k 5% 1/2W bias transformer	64-718-22 EB 5135	01121 28480	0686-5135 9100-2607
	A4 Heatsink Ass'y – Electrical (See Note 1)			
B1	fan, cooling, 115Vac 50/60Hz	WS2107FL-55	28875	3160-0056
6259B, -61B, -68B, -69B	fxd, cer05µF 400V	33C17A3-CDH	56289	0150-0052
6259B, -61B, -68B, -69B CR101, 102	fxd, elect. 15µF 50V	150D156X0050R2	56289	0180-1834
6259B 6260B	diode, Si. 40A 100V diode, Si. 100A 100V	1N1184AR 1N3289R	05277	1901-0318 1901-0536
6261B, -68B, -69B CR103, 104	diode, Si. 85A 100V	R3710	58849	1901-0729
6259B 6261B, -68B, -69B	diode, Si. 40A 100V diode, Si. 85A 100V	1N1184A \$3710	58849 05277	1901-0317
CR105 CR106 CR107	diode, Si. 40A 100V diode, Si. 40A 100V	1N1184AR 1N1184A	05277	1901-0317
6260B CR108	diode, Si. 40A 100V diode, Si. 40A 100V	1N1184A 1N1184AR	05277 05277	1901-0317 1901-0318
CR110 Q101	thyristor, Si. (SCR) power PNP Si.	2N3898* 2N4902*		1884-0058 1853-0063
6259B, -60B, -61B 6268B, -69B	power NPN Si. power NPN Si.	2N3772 60675	02735	1854-0225 1854-0458
Q103-106 6259B, -60B, -61B 6268B, -69B	power NPN Si. power NPN Si.	2N3771* 60675	02735	1854-0245 1854-0458

植物 化试剂

2

* nearest commercial equivalent

REF. DESIG.	DESCRIPTION	MFG. PART NUMBER	MFG. CODE	HP PART NUMBER
Q107-108	· · ·			191
6260B	power NPN Si.	2N3771*		1854-0245
6269B	power NPN Si.	60675	02/35	1854-0458
Q109-110	1.1		1	1054 0045
6260B	power NPN Si.	2N3771*	1	1854-0245
R106			00000	0011 2000
6259B, -60B, -61B	fxd, ww 0.1 15%	obd	89663	0811-3080
6268B, -69B	fxd, ww 0.2 15%	obd	89003	0811-3081
R123			20400	5090 7144
6259B, -61B, -69B	fxd, ww (Cupron) .01 20ppm		28480	06268-80001
6268B	fxd, ww (Cupron) .0167 20ppm		20400	00200-00001
R123A. 123B	() (0,) 01 20		28480	5080-7144
6260B	fxd, ww (Cupron) .01 20ppm		28480	0811-2545
R150-153	1xd, ww 0.1 5% 8W		20100	
R154, 155	4.d		28480	0811-2545
6259B, -60B, -61B, -69B	1xd, ww 0.1 5% 8W		20100	
R156, 15/	And way 0 1 5% 9W		28480	0811-2545
6259B, -60B, -61B	1x0, ww 0.1 5% 6W		1	
R100-100	frd www.0.1.5%.8W		28480	0811-2545
0200B	switch thermal (opens 230°E)	430.632	80089	0440-0079
15101	switch, thermal topens 250 17	400.002		
	A5 Front Panel Ass'y Electrical			
0110.110	fud cor 01/1E 3kV	41C121A5-CDH	56289	0160-2568
CITU-ITZ	ixa, cerorpr skv	410121110 0011		
6250R 60R 61R 68R	circuit breaker 20A 250Vac 2-pole	AM2-A3-A-20-2	74193	3105-0035
6259B, 400B, 401B, 400B	circuit breaker 25A 250Vac 2-pole	AM2-A3-A-25-3	74193	3105-0034
DS1	LINE ON indicator light, neon		28480	1450-0566
DS2	OVERVOLTAGE indicator light	MCL-A3-1730	07137	1450-0305
MI				
6259B -60B	voltmeter, 0-12Vdc		28480	1120-1170
6261B	voltmeter, 0-24Vdc		28480	1120-1171
6268B -69B	voltmeter, 0-50Vdc		28480	1120-1173
M2				
6250B .61B .60B	ammeter 0-60A		28480	1120-1181

nearest commercial equivalent

6259B, -61B, -69B

R121

R122

R123

6259B, -60B

6268B, -69B

6259B, -60B

6268B, -69B

6260B

6268B

6261B

6261 B

ammeter, 0-60A

ammeter, 0-120A

ammeter, 0.35A

var. ww 2.5k 5%

var. ww 5k 5%

var. ww 10k 5%

var. ww 10 5%

var. ww 50 5%

var. ww 100 5%

var. ww 200 5%

VOLTAGE - COARSE control

VOLTAGE - FINE control

CURRENT - COARSE control

Series 43

2 .

1120-1182

1120-1179

2100-2745

2100-1853

2100-1854

2100-1857

2100-1858

2100-1987

2100-1856

28480

28480

12697

12697

12697

12697

12697

12697

12697

「日本語をいたいない

REF. DESIG. (AND MODELS)	DESCRIPTION	MFG. PART NUMBER	MFG. CODE	PART NUMBER
R124	CURRENT - FINE control	and the second second second	2 606	
	var. ww 10 5%	Series 43	12697	2100-1857
R125	OVERVOLTAGE ADJUST	T		15.1
6259B, -60B	. var. ww 5k 5%	Series 43	12697	2100-1853
6261B, -68B, -69B	var. ww 10k 5%	Series 43	12697	. 2100-1854
	Chassis — Electrical		:	
B2			90 (03 10	$= t^3$
6260B, -61B, -69B	fan, cooling,115Vac 50/60Hz	8500	23936	3160-0209
6269B	fan, cooling, 115Vac 50/60Hz	WS2107FL-55	28875	3160-0056
C19			- 539-6377 -	ś
6259B, -60B	fxd, elect. 68µF 15V	150D686X0015R2	56289	0180-1835
6261 B	fxd, elect. 22µF 35V	150D226X0035R2	56289	0180-0160
6268B, -69B	fxd, elect. 15µF 15∨	150D156X0050R2	56289	0180-1834
6250R -60R	frid elect 100000//E 201/	9656075	03509	0190-2204
6261B -68B	fyd elect 40000//F 50V	12201042242.00P	66290	0190.1031
6269B	frd elect 50000// 50V	36D4512.DOR	56280	0180.2346
C104	1x4, elect. 0000001 00V	3004512-046	50205	0100-2040
6260B	fxd elect 100000uE 20V	8656975	03508	0180-2294
6261B	fxd elect 40000µF 50V	(32D)D42343-DOB	56289	0180-1931
6269B	fxd, elect, 50000µF 50V	36D4512-DOB	56289	0180-2346
C105		0004012 0 00	00200	01002010
6260B	fxd, elect, 100000µF 20V	8656975	03508	0180-2294
6261B	fxd, elect, 40000µF 50V	(32D)D42343-DOB	56289	0180-1931
T1				
6259B	power transformer		28480	06259-80091
6260B	power transformer		28480	06260-80095
6261B	power transformer		28480	06261-80091
6268B	power transformer		28480	06268-80091
6269B	power transformer		28480	06269-80091
	A1 Main PC Board – Mechanical			
TDA	hander all all and a		00400	0000 1515
182	barrier strip, 13-terminal		28480	0360-1518
	barrier strip jumpers (qty. 4)		28480	0360-1143
51	capacitor clamp. C44		28480	1400-0321
-	A2 RFI Filter Ass'y Mechanical			
	heatsink		28480	5020-2282
	heatsink mounting standoff, .75"	4	28480	0380-0902
	rnd. (qty. 4)			one every server to create 36011076ett
	PC board mounting standoff,		28480	0380-0609
14	.625" hex (qty. 4)			
:	washer, fiber, L1 insulator		28480	3050-0697
	Cover		28480	5020-2284
į	cover standoff, 1" hex (qty. 4)		28480	0380-0173

REF. DESIG. (AND MODELS)	DESCRIPTION	MFG. PART NUMBER	MFG. CODE	HP PART NUMBER
 	A3 Interconnection Board Mechanical			
	capacitor clamp, C3		28480	1400-0472
	A4 Heatsink Ass'y Mechanical		14/1 4 /	
6259B, -61B, -68B, -69B	front rectifier heatsink,	16	28480	5020-5769 ⁹
6259B, -61B, -68B, -69B	rear rectifier heatsink,		28480	5020-5769
6260B	front and rear rectifier heatsink, CB101 front CB102 rear (otv 2)		28480	5020-5764
	rear transistor heatsink, Q103-106, TS101		28480	5 020-5763
6259B, -61B, -68B 6260B 6269B	center front heatsink, blank front transistor heatsink, Q107-110 front transistor heatsink, Q107-108		28480 28480 28480	5020-5793 5020-5763 5020-5763
02090	top left heatsink, CR105, CR110, Q101		28480	5020-5765
6259B, -61B, -68B, -69B	bottom left heatsink, CR106, CR108 Q102		28480	5020-5766 .
6260B	bottom left heatsink, CR106-108, Q102		28480	5020-5766
	left end (fan) mounting bracket right end mounting bracket		28480 28480	5000-6256 5000-6255
	insulating spacer strip (qty. 2) plastic support rods (qty. 4)		28480 28480	5020-5787 0380-0901
	flat nylon spacing washers (qty. 8) nylon shoulder washers (qty. 8)		28480 28480	3050-0455 3050-0483
	sleeving for R106	•	28480	0890-1055
	rubber bumper screw, R123 mounting, 10-32, 1/4", Phillips (atv. 2)		28480 28480	2680-0214
	transistor pin insulator (qty. 4 each, Q103-110)		28480	0340-0166
	insulated bushing, CR110		28480	0340-0415
	insulating shoulder washer, CR110 transistor insulator, mica, Q101-102		28480 28480	0340-0174
	transistor insulator, plastic, Q101-102 (qty. 2)		28480	0340-0795
	A5 Front Panel Ass'y Mechanical			
6259B	front panel		28480	06259-60005
6260B	front panel	×	28480	06260-60009
6261B	front panel		28480	06261-60006
6268B	front panel		28480 28480	06268-60009
02038	mont panel		20100	

- Aller

REF. DESIG. (AND MODELS)	DESCRIPTION	MFG. PART NUMBER	MFG. CODE	• HP PART NUMBER
	meter bezel (qty. 2) spring, compression, meter mount		28480 28480	4040-0293 1460-0256
	(qty. 8) knob (qty. 4) bushing, R125 mount retainer, push-on, DS1 and DS2	2 2 2	28480 28480 28480	0370-0084 1410-0052 0510-0509
	(qty. 2) handle (qty. 2) screw, 10-32, 1.75" (for handles, qty. 4)	19	28480 28480	5020-5762 ⁴ 2680-0173
	Chassis — Mechanical			
6259B, -60B, -61B, -68B 6269B 6260B, -61B, -68B 6269B 6259B, -68B, -69B 6260B, -61B 6259B, -60B, -61B, -68B 6260B, -61B 6269B	capacitor tray capacitor tray circuit board tray RFI filter mounting bracket (qty. 2) fan mounting bracket, B2 (qty. 2) fan mounting bracket, B2 (qty. 2) fan mounting bracket, B2 (qty. 2) rubber bumper (qty. 3) capacitor clamp, sheetmetal (qty. 2) capacitor clamp, sheetmetal (qty. 3) capacitor clamp, sheetmetal (qty. 3) capacitor busbar, C101-103 (qty. 2) capacitor busbar, C101-103 (qty. 2) capacitor busbar, C101-104 (qty. 4) cover (qty. 2) rear panel output busbar (qty. 2) busbar insulating spacers, .312" (qty. 4) nylon shoulder washers, busbar mounting (qty. 4) ac input insulating spacers, ³ .625" (qty. 2) rubber bumber (qty. 4) barrier block, 3-terminal, ac input cover, ac input barrier block	603-3	28480 28480	5000-6243 06269-00002 5000-6248 5000-6257 5000-6257 5000-6257 5000-6017 5000-6017 5000-6017 5000-6253 5000-6251 5000-6251 5000-6251 5000-6252 0380-0710 3050-0483 0380-0703 0403-0089 0360-1596 5000-6249
	cover, A1TB2 barrier block binding post, chassis ground	137	28480 83330	00712-20001 1510-0044
	Miscellaneous			
	carton, packing floater pad (qty. 2)		28480 28480	9211-1181 9220-1402

14 - 14 - 14 - 14

Table 6-4. Replacesble Parts

REF. DESIG. (AND MODELS)	DESCRIPTION	MFG. PART NUMBER	MFG. CODE	HP PART NUMBER
A1 R82	OPTION 005 50Hz AC Input fxd, comp 240 5% 1/2W	EB-2415	01121	0686-2415
A5R121 6259B, -60B 6261B 6268B, -69B	OPTION 007 10-Turn Voltage Control var. ww 2k 5% 10-turn var. ww 5k 5% 10-turn var. ww 10k 5% 10-turn knob	Series 8400 Series 8400 Series 8400 Series 8400	84048 84048 84048 28480	2100-2029 2100-1865 2100-1866 0370-0137
A5R123	OPTION 008 10-Turn Current Control var. ww 200 5% 10-turn knob	Series 8400	84048 28480	2100-1863 0370-0137
A5R121 6259B, -60B 6261B 6268B, -69B A5R123	OPTION 009 10-Turn Voltage and Current Controls var. ww 2k 5% 10-turn var. ww 5k 5% 10-turn var. ww 10k 5% 10-turn var. ww 200 5% 10-turn knob (qty. 2)	Series 8400 Series 8400 Series 8400 Series 8400 Series 8400	84048 84048 84048 84048 84048 28480	2100-2029 2100-1865 2100-1866 2100-1863 0370-0137
	OPTION 010 Chassis Slides slides	CTS-120-E6	5A218	1490-0870
A1 R3 A5R121 6259B, -60B 6261B 6268B, -69B	OPTION 013 3-Digit Decadial Voltage Control fxd, comp (selected) 5% 1/2W var. ww 2k 5% 10-turn var. ww 5k 5% 10-turn var. ww 10k 5% 10-turn 3-digit turns-counting dial	EB- Series 8400 Series 8400 Series 8400 411	01121 84048 84048 84048 84048 12697	2100-2029 2100-1865 2100-1866 1140-0020
A1R30 A5R123	OPTION 014 3-Digit Decadial Current Control fxd, comp (selected) 5% 1/2W var. ww 200 5% 10-turn 3-digit turns-counting dial	EB- Series 8400 411	01121 84048 12697	2100-1863 1140-0020
	OPTION 016 115Vac Input (Available in Model 6260B only)			

REF. DESIG. (AND MODELS)	DESCRIPTION	MFG. PART NUMBER	MFG. CODE	PART NUMBER
CB1 6260B T1 6260B	circuit breaker, 30A 250Vac 2-pole power transformer	AM2-A3-A-30-3	74193 28480	3105-0036 06260-80094
A2R3 6260B A2J1, 2	fxd, met. ox. 390 5% 2W	RG42	11502	0698-3633
6260B A2J3	(jumpers for 115Vac operation; see Section II for complete input voltage conversion instructions.)			
A1R1 A1R111 A1R112, 113 A1R114	OPTION 020 Adjustable Voltage Programming (omit) fxd, film 221k 1% 1/8W var. ww 5k 5% fxd, film 249k 1/ 1/8W	CEA T-0 CT-106-4 CEA-993	07716 84048 07716	0757-0473 2100-1760 0757-0270
A1R21 A1R115 A1R116 A1R118 A1R119	OPTION 021 Adjustable Current Programming (omit) fxd, film 23k 1% 1/8W var. ww 5k 5% fxd, film 200k 1% 1/8W var. ww 5k 5%	CEA-993 CT-106-4 CEA-993 CT-106-4	07716 84048 07716 84048	0698-3269 2100-1760 0757-0472 2100-1760
A1R1, 2 A1R111 A1R112, 113 A1R114 A1R115 A1R116, 119 A1R118	OPTION 022 Adjustable Voltage and Current Programming (omit) fxd, film 221k 1% 1/8W var. ww 5k 5% fxd, film 249k 1% 1/8W fxd, film 23k 1% 1/8W var. ww 5k 5% fxd, film 200k 1% 1/8W	CEA T-0 CT-106-4 CEA-993 CEA-993 CT-106-4 CEA-993	07716 84048 07716 07716 84048 07716	0757-0473 2100-1760 0757-0270 0698-3269 2100-1760 0757-0472
CB1 6261B, -68B A2R3 6259B, -61B, -68B A2J1, 2 6259B, -61B, -68B	OPTION 026 115Vac Input (Available in Models 6259B, 6261B, and 6268B only) circuit breaker, 30A 250Vac 2-pole fxd, met. ox. 390 5% 2W (jumpers for 115Vac operation; see Section II for complete input voltage conversion instructions.)	AM2-A3-A-30-3 RG42	74193 11502	3105-0036 0698-3633

1

i

1

1

Ì

ł

and the second

REF. DESIG. (AND MODELS)	DESCRIPTION	MFG. PART NUMBER	MFG. CODE	HP PART NUMBER
A2J3 6259B, -61B, -68B	(omit for 115Vac operation)			* - *
	OPTION 027 208Vac Input (No special parts are used in this option.)			
	OPTION 040 Interfacing for Multiprogrammer Operation (The replaceable parts for Option 040 are the same as for Option 022.)			•
C. 8-8				
				. *
8 1.4				1.00
×				
	i a			
		1. A. T.		

1

. .

SECTION VII CIRCUIT DIAGRAM AND COMPONENT LOCATION DIAGRAMS

1 4

This section contains the schematic diagram and component location diagrams necessary for maintaining this power supply. Differences among the five power supply models covered by this manual are indicated where they exist. The

1 6

See : to have been

> test points indicated by circled numbers on the circuit schematic of Figure 7-8 correspond to those on the component location diagrams and in the troubleshooting procedures in Section V.



Figure 7-1. A2 RFI Assembly Component Locations



Figure 7-2. A3 Interconnection Board Component Locations



Figure 7-4. Chassis Component Locations, Bottom View

-

1.2.8


Figure 7-5. A4 Heatsink Assembly, Top and Front View



And the strength of the strength of the

Figure 7-6. A4 Heatsink Assembly, Bottom and Rear View



WARNING

SOME CIRCUITS ON THIS CIRCUIT BOARD ARE CONNECTED DIRECTLY TO THE INPUT AC POWER LINE. EXERCISE EXTREME CAUTION WHEN WORKING ON ENERGIZED CIRCUITS.

NOTES:

I. THE FIXED AND VARIABLE "ZERO ADJUST" SECTION OF THE BOARD ARE NOT INCLUDED IN THE STANDARC INSTRUMENT. THEY ARE SUPPLIED IN OPTION 020, 021, 022 AND 040 INSTRU-MENTS ONLY.

2. RI OMITTED IN OPTION 020,022, AND 040 INSTRUMENTS.

3. REI OMITTED IN OPTION 021,022, AND 040 INSTRUMENTS.



ŝ



Figure 7-9. A4 Heatsink Assembly Emitter Resistor Board Component Locations

2 .

÷.



Figure 7-8. Mode's 6259B, 6260B, 6261B, 6268B, and 6269B, Schemat



		14	
Ζ.			
		10.	
	-		

	62590	62008	62618	6,2600	62690
AIC4I	D22.F. 200V	022 .F. 200V	022.4F, 200V	.01, F. 200V	.01 . F. 200V
AIRE	39,5%, V2W	39, 5%,1/28	82. 5% .1/2W	160.5%.V2W	NO. 6% . I/EW
AIRS	600.5%.5W	800.5%.0%	800.5%,5W	680.5%.8%	600,0%,6W
AIRS	470.0%.3#	470.5%. 3W	470.8%.3W	IK. 0%.3W	IK, 5%, 3W
AIR24	788.1%	7 6K. P. 1/80	7.0K. 1%, 1/8W	1278,1/4%,1/80	127K,14%,1/0W
AI825	5-99K 1% UPW	5-00K, 1%, 1/0W	BARK, ISL, MEN	BO BK, ML, MOW	80 8K, 1%, MBW
A18-65	IX 5% 1/2W	1K. 5%. V2W	IK, 6%, 1/2W	820, 5%, VEW	820,8%,V2W
AIRSS	80 55 50	50.5%.5W	NOT USED	NOT USED	NOT USED
41857	1.83.24	1.6%.2W	1 0. 5%, 2W	3 9. 5%, 2W	3.9, 9%, 2W
ANDIA	0.55.100	80.0% . IOW	138.8%.IOW	400, 5%, 10%	400,5%,10%
AIDAT	100.05.29	800.0% .FW	200, 5%, 2W	180, 5%, 2W	100,0%,2W
AURTS	PER IS LOW	IPK. 19. 1/80	23K,1%,1/0W	45K,1%,1/80	40K, PS. VOW
A1075	S TTY PL LAND	ATEK PL VEN	4 75K, PL, 1/8W	4 TOK, PA, USW	4 TOK, PL VOW
ANTS	3 4K PL VEW	475K.1% 1/8W	475K, PA. L/8W	475K, PS., LOW	475K,PL,VOW
ANT7	200X.5% .VEW	68.K. 1%, VOW	HOK, 1%, 1/8W	430K, 5%, 1/2W	430K, 8%, 1/2W
ANR TO	80.4K /% . 1/8W	60.4K,1%,1%	HOK,IS,VOW	249K, 1%, 1/8W	249K, 1%, 1/8W
AIRES	30, 9%, VEW	30, 5%, 1/2W	30,5%.V2W	27. 8%, VTW	27.6%.VPW
A1905	330, 8%, 2W	330,8%,8%	\$30,5%.20	270,8%,2W	270,5%, 20
AIRBO	SK, 1%, MOW	3K, 1%	3K, 1%, 1/8W	1 BK, 1%, VOW	1.5K, 1%, 1/8W
AIRIOZ	825, FK, VWW	025, 1%, L/8W	900, I%, L/8W	809,1%,1/8W	\$00,1%, L/DW
ARIOS	1.21K, 1%, 1/00	LOK, 1%, VOW	1.21K, PS, 1/8W	10K,1%,1/8W	1 5K, 1%, L/BW
AVRIO4	4.53K, 1% J/00	4 53K,1%, MW	IOK, ML, WEW	19 K, Ph, VOW	HO IX, PS. LOW
A3C3	8600pF, 25V	HOT USED	8800pF, 25V	8000, F. 45V	8000, F, 45V
AMORICS, ORIO4	1901 - 0317	NOT USED	HOI - 0730	1901-0730	1901-0730
A408107	NOT USED	1901-0317	NOT UBED	NOT USED	NOT USED
44106	01, 15%	01, 15%	01,18%	02.15%	02,15%
A4R123	.Ox, 20 ppm	NOT USED	.01,20 ppm	. 0167 , 20ppm	.OI , 20 ppm
A4R123A	NOT UBED	.01 , 20gpm	NOT USED	MOT USED	NOT USED
ASRI2I	2 54, 5%	2 58.5%	SK. 6%.	10K. 5%	KOK, 5%
A59122	10.5%	10.5%	50.5%	100,5%	100, 8%
AGRI25	3K. 5%	5K. 8%	ЮK, 5%	10K.5%	IOK, 5%
HASSIS					
82	NOT USED	3160-0209	3460-0209	3460-0209	3460-0056
010	60.F. ISY	66. F. 15V	22. F. 35V	15p. F. 15V	15.F. 15V
00.00	100.000 J. 20Y	100,000. F. 20V	40.000 J. BOV	40,000 F,50V	50,000
CI04	NOT USED	100,000, F. 20V	40,000, F,50V	NOT USED	50,000p F. 50V
005	NOT USED	100,000 F, 20V	40,000 F, SOV	NOT UBED	NOT USED

- SCHEMATIC MOTES I ALL RESISTORS ARE IN DHINS, 1/2W 15%, UNLESS OTHERWISE NOTED
- ALL VOW AND 1/4W RE SISTORS ARE ± 1% . UNLESS OTHERWISE NOTED
- ALL CAPACITORS ARE IN MICROFARADS, UNLESS OTHERWISE NOTED
- REAR TERMINALS ARE SHOWN WITH HORMAL STRAPPING FOR USE OF FRONT RIVEL CONTROLS
- DENOTES FRONT PANEL MARKING
- DENOTES VOLTAGE PEEDBACK PATH
- DENOTES CURRENT PEEDBACK PATH
- TRANSFORMERS AND RFI CHOKE SHOWN STRAPPED FOR 230VAC OPERATION SEE SECTION 11 FOR INPUT VOLTAGE CONVERSION INFORMATION

- NOLTAGES WERE MEASURED UNDER THE FOLLOWING CONDITIONS A MEMLETI RACHARD MADEL 427A OR FOLMALENT B 230AC INVESTIGATION FOLMATION C VOLTAGES ANTERPORTED TO 45, UNLESS OTHERWISE NOTED D VOLTAGES ANT TYPICAL LODO, MLESS OTHERWISE NOTED C) VOLTAGES ANT TYPICAL LODO, MLESS OTHERWISE NOTED C) ALL READINGS TAKEN IN CONSTANT VOLTAGE OPPOLATION AT MAXIMUM RATED OUTPUT WITHIN IN OLDAD COMMENTED FULLY CLOCKWISE.

("

- IO ALL COMPONENTS LOCATED ON A MAIN PRINTED CIRCUIT BOARD, UNLESS OTHER-WISE NOTED HISE NOTED A2 IS AFI FRITER ASSEMBLY A3 IS INTERCONNECTION BOARD ASSEMBLY A4 IS HEAT SAME ASSEMBLY A5 IS FRONT PANEL ASSEMBLY

I & DENOTES CHASSIS- MOUNTED COMPONENTS

12 PIN LOCATIONS FOR INTEGRATED CIRCUITS ARE AS FOLLOWS

····) » mananan DOBERE





- IED WITH A STANDARD BUSTRUMENT THE CUSTOMER (AS BISTRUCTED IN PARA RO YOU TAGE AND CURRENT (RESPECTIVE RESISTORS RIIO AND R THESE RESISTORS MAN 5-81 AND 5-91) TO AD IF THE SUPPLY IS NOT I OPTION 040 ECTIVEL YI NO OZI (RESPECTIVELY) OR
- IS RESISTORS RI AND REI ARE OWITTED IN INSTRUMENTS THAT ARE EDURPED WITH OPTIONS DED AND DEI (RESPECTIVELY) OR OPTION DAD FOR & 208 GR
- IS RESISTOR A283 IS NOT USED IN INSTRUMENTS THAT ARE EDU 230VAC INPUT
- IT SEE FIGURE 4-4 FOR PREAEBULATOR CONTROL CIRCUIT WAVEFOR



AC 1230V1.

GND

AC 1250V1 .



A312

ov H

ASJI-2 AP 2

A3.JI- H

9 AJP1-14




