U.S. INDUSTRIAL TOOL INSTALLATION AND SERVICE PARTS LISTING PORTABLE PNEUMATIC RIVET SQUEEZER ALLIGATOR & C-TYPE SERIES US114A, US114TA, US114C, US114TC, US114TC-98

MODEL NO.	DETAILS RE DETAIL A	QUIRED FOR TO DETAIL B	OL BY MODEL # DETAIL C	DETAIL D	DETAIL E	DETAIL F
US114A (INCLUDES ALL JAW LENGTHS)	х			Х	Х	
US114TA (INCLUDES ALL JAW LENGTHS)		Х		Х	Х	
US114C	Х		Х		Х	
US114TC		Х	X		X	
US114TC-98		Х	Х			Х

Always comply with:

- 1) General Industry Safety & Health Regulations, Part 1910, SHA 2206, available from Superintendent of Documents, Government Printing Office, Washington, DC 20402.
- Safety Code for Air Portable Tools ANSIB 186.1 available from American National Standards Institute, Inc., 1430 Broadway, New York, NY 10018.


Care of your new tool:


- 1) Tools shall be used only for purposes intended in their design (refer to U.S. Industrial catalog).
- 2) The efficiency and life of this tool depends on the proper supply of clean, dry, lubricated air at 90 lbs. P.S.I. pressure. The use of lower pressures will result in loss of tool power. Use of an air line filter, regulator and lubricator is recommended. Air supply hose should have a minimum of 1/4" I.D. If extension hose is necessary, use a 3/8" to 1/2" I.D. hose to insure proper S.C.F.M. flow to tool.
- 3) Lubrication of the tool is vital to good operation. If proper air line lubrication is unavailable, squirt on a daily basis several drops of oil into the air inlet before using. U.S. Industrial Air Tool Oil #A1038 is specially formulated with a rust inhibitor for proper lubrication of internal parts. As an alternate a turbine or spindle grade oil with a viscosity of 100-150 SUS is acceptable. Bearing assemblies and main piston bores should be lubricated every 160 hours of operation with Permatex Synthetic Grease with Teflon or equal.
- 4) If unusual sounds or vibration are produced, repair immediately.
- 5) A wide range of C-Yoke and alligator jaws of varying geometry's are available for applications where standard tooling will not provide adequate access. Request supplemental catalog listing of the many stocked designs. Special application design and manufacture is available submit details of your assembly along with fastener sizes, material grades, and approximate quality of fasteners to be installed per hour/day.
- 6) Various non-standard length set holders are available for all series C-type squeezers.
- 7) To achieve optimal force output when setting up tool, be sure that your fastener plus rivet sets don't exceed the total thickness available of tool gap (closed height) when tool is activated. Otherwise tool will not produce the necessary force to compress fastener.
- 8) Preventative maintenance consisting of disassembly of tool, cleaning and inspection of parts for wear should be done on regular intervals by experienced maintenance personnel or can be returned to U.S. Industrial Tool or an authorized U.S. Industrial Tool Distributor for service.


5/04





CALL TOLL FREE 800.521.7394 • Fax 310.464.8880 www.ustool.com














36	ITEM NO.	U.S. PART NO.	DESCRIPTION	ITEM NO.	U.S. PART NO.	DESCRIPTION
2 5046 SWIVEL NIT 64 5011 THRUST WASHER (4) 65 5043 ASKETT OLARY ROLLERS (2) 5044 ASKETT OLARY ROLLERS (2) 5044 ASKETT OLARY ROLLERS (2) 5042 ASKE	1	5047	90 DEGREE	63	5056	GUIDE PLATE (2)
3 5045 GASKET 65 5007 FOLLER BEARINGS (40)			l l			
4 5044 C-RINIG 66 5012 STATIONARY ROLLER 7 5043 AIR INLET SWIVEL HEAD ASSEMBLY (INCLUDES 1-9) 67 5092 STATIONARY ROLLER 7 5042 BACKHEAD BARK 5057 ASSEMBLY (INCL. 62-66 (1 ASSEMBLY ROLLER 2 2 2 2 2 2 2 2 2			l l			
5	_					
6 5047A SWIVEL HEAD ASSEMBLY (INCLUDES 1-9) 68 5057 ASSEMBLY (INCL 06-6-6) (INCLUDES 1-9) 69 5054 ASSEMBLY (INCL 06-6-6) (INCL 06-6-6-6) (INCL 06-6-6-6) (INCL 06-6-6-6-6-6-6-6-6-6-6-6-6-6-6-6-6-6-6-						
(INCLUDES 1-5) 68 5057 ROLLER BRAING 8 50415AF SAFETY TV BUSHING 69 5054 70K 5055 70KE FRAME PLATE (2) 70KE FRAME PLATE (3) 70KE FRAME PLATE PLATE (3) 70KE FRAME PLATE PLAT			l l	67	5092	
7	6	5047A		00	F0F7	` ` ` ` ` ` ` ` ` ` ` ` ` ` ` ` ` ` ` `
8	7	5040	, ,	68	5057	
9 2-10 O-RING 70 5055 YOKE FRAME PLATE 11 5038G T. V. SPIRING 72 5052-2 9/16 SET HOLDER STD. 2-9/16 12 2-8 O-RING T. V. SPIRING 73 5051 SET HOLDER STD. 2-9/16 (C)THER SIZES AWALL (C)TH			l l	00	5054	, , , ,
10	_					
11 5038G						
11	10	5042A				1 ' '
12 2-8 O-RING THORDTLE VALVE-BARE 74 538 C-YOKE (TC-C) 14 5039A	4.4	50000	` , ,	/2	5052-2 9/16	
13			l l	70	5054	, ,
14			l l			
15			l l	/4	538	
ASSEMBLY (INCL. 6, 10, 11, 14) 76				7-	5404	`
16	15	5048SAF				
17	10	5005				
18			l l			
19				78	5101	
200						
21			, ,			·
22			l l			
23					5016	
24			CUP LEATHER PLATE			
25			CUP LEATHER		5013	TRU-ARC RET. RING (2)
C & A TYPE 86 5017 BRG. BOLT WASHER BRG. DOLT WASHER BRG.			PISTON		5014	ROLLER SHAFT
26	25	5027	WEDGE FORK	85	5009	BRG. BOLT
27			(C & A TYPE)		5017	BRG. BOLT WASHER
28	26	5026	WEDGE RIVET		5018	BRG. BOLT WASHER
29			WEDGE SPACER	88	5004	MOVING JAW 1" (STD)
30	28	5072C	WEDGE (C)		5004-2-1/4	MOVING JAW 2-1/4"
South	29	5028	WEDGE (A)		5004-3	MOVING JAW 3"
31	30	5100	WEDGE ASSEMBLY (C)		5004-5.5	MOVING JAW 5-1/2"
S023 S024 OUTER SPRING (2) 92 5020 INNER ROLLER RACE INNER SPRING (2) 93 5003 MOVING JAW END - STATIONARY JAW 1" (STD) - S002-2-1/4 STATIONARY JAW 2-1/4" S002-5-5 STATI JAW 5-1/2" STATIONARY JAW 7-1/2" STATIONARY JAW 8-1/2" STATIONARY JAW 8-1/2" STATIONARY JAW ROLLER GUARD STATIONA			(INCL. 25, 26, 27, 29)	89	5005	BRG. THRUST WASHER
32	31	5098A	WEDGE ASSEMBLY (A)	90	5006	BRG. INNER RACE
33			(INCL. 25, 26, 27, 29)	91	5019	ROLLER RACE
34	32	5023	INNER SPRING (2)	92	5020	INNER ROLLER RACE
35	33	5024	OUTER SPRING (2)	93	5003	MOVING JAW END -
36	34	5083	TANDEM PISTON			BRG. SHAFT
37	35	5080	RETURN RING (2)	94	5002	STATIONARY JAW 1" (STD)
38	36	2-136	O-RING		5002-2-1/4	STATIONARY JAW 2-1/4"
39	37	5081	SEPARATOR		5002-3	STAT. JAW 3"
S079	38	2-112	O-RING		5002-5.5	
40	39	5085A	PISTON ROD (TC)	95	5000	RD. HD. SCREW
41		5079	PISTON ROD (TA)	96	5001	STATIONARY JAW ROLLER
42	40	5077	WEDGE FORK (TC & TA)			GUARD
43	41	5076TC	WEDGE (TC)	97	5008	STATIONARY JAW ROLLER
44		5076TA				
44	43	5077A		98	95086	
Company						
45	44	5098TA		1		
46 5075 CYLINDER (TC) 102 8077 MOUNTING BASE (2) 47 5063 CYLINDER (C) 103 8078 SCREW 48 5060 ROLLER GUARD BLOCK 104 35115-5 SET-HOLDER 49 5062 ROLLER GUARD SCREW 105 5091Y BACKHEAD 50 5064 GUARD BLOCK PIN 106 TP104-13 AIR HOSE 51 5065 LEVER SHAFT 107 8080 SET SCREW (2) 52 5059 LEVER SHAFT WASHER 108 5054W WASHER (4) 53 5058 LEVER SHAFT SCREW 109 US81945A CLAMP 54 5021 THROTTLE VALVE LEVER 110 35179 JAM NUT 55 INNER RACE LEVER 111 TP104-10 1/4 BARB FITTING (2) 56 ROLLER BEARING (32) 112 TP104-11 FERRO (2) 0UTER RACE-LEVER 113 5091 REMOTE FOOT PEDAL 59 5069B SHAFT 116 <t< td=""><td></td><td></td><td></td><td>1</td><td></td><td></td></t<>				1		
47 5063 CYLINDER (C) 103 8078 SCREW 48 5060 ROLLER GUARD BLOCK 104 35115-5 SET-HOLDER 49 5062 ROLLER GUARD SCREW 105 5091Y BACKHEAD 50 5064 GUARD BLOCK PIN 106 TP104-13 AIR HOSE 51 5065 LEVER SHAFT 107 8080 SET SCREW (2) 52 5059 LEVER SHAFT SCREW 109 US81945A CLAMP 53 5058 LEVER SHAFT SCREW 109 US81945A CLAMP 54 5021 THROTTLE VALVE LEVER 110 35179 JAM NUT 55 INNER RACE LEVER 111 TP104-10 1/4 BARB FITTING (2) 56 ROLLER BEARING (32) 112 TP104-11 FERRO (2) 0UTER RACE-LEVER 113 5091 REMOTE FOOT PEDAL 58 95073 LEVER BRG. ASSEMBLY 114 4450 FULL FOOT GUARD (INCL. 55, 56, 57) 115 18037 INL						
48 5060 ROLLER GUARD BLOCK 104 35115-5 SET-HOLDER 49 5062 ROLLER GUARD SCREW 105 5091Y BACKHEAD 50 5064 GUARD BLOCK PIN 106 TP104-13 AIR HOSE 51 5065 LEVER SHAFT 107 8080 SET SCREW (2) 52 5059 LEVER SHAFT WASHER 108 5054W WASHER (4) 53 5058 LEVER SHAFT SCREW 109 US81945A CLAMP 54 5021 THROTTLE VALVE LEVER 110 35179 JAM NUT 55 INNER RACE LEVER 111 TP104-10 1/4 BARB FITTING (2) 56 ROLLER BEARING (32) 112 TP104-11 FERRO (2) 57 OUTER RACE-LEVER 113 5091 REMOTE FOOT PEDAL 58 95073 LEVER BRG. ASSEMBLY 114 4450 FULL FOOT GUARD 10 (INCL. 55, 56, 57) 115 18037 INLET BUSHING (2) 59 5069B SHAFT <			·	1		` '
49 5062 ROLLER GUARD SCREW 105 5091Y BACKHEAD 50 5064 GUARD BLOCK PIN 106 TP104-13 AIR HOSE 51 5065 LEVER SHAFT 107 8080 SET SCREW (2) 52 5059 LEVER SHAFT WASHER 108 5054W WASHER (4) 53 5058 LEVER SHAFT SCREW 109 US81945A CLAMP 54 5021 THROTTLE VALVE LEVER 110 35179 JAM NUT 55 INNER RACE LEVER 111 TP104-10 1/4 BARB FITTING (2) 56 ROLLER BEARING (32) 112 TP104-11 FERRO (2) 0UTER RACE-LEVER 113 5091 REMOTE FOOT PEDAL 58 95073 LEVER BRG. ASSEMBLY 114 4450 FULL FOOT GUARD (INCL. 55, 56, 57) 115 18037 INLET BUSHING (2) 59 5069B SHAFT 116 5037SP LEVER STOP 60 5070 SET HOLDER LEVER 117 95073			` ,	1		
50 5064 GUARD BLOCK PIN 106 TP104-13 AIR HOSE 51 5065 LEVER SHAFT 107 8080 SET SCREW (2) 52 5059 LEVER SHAFT WASHER 108 5054W WASHER (4) 53 5058 LEVER SHAFT SCREW 109 US81945A CLAMP 54 5021 THROTTLE VALVE LEVER 110 35179 JAM NUT 55 INNER RACE LEVER 111 TP104-10 1/4 BARB FITTING (2) 56 ROLLER BEARING (32) 112 TP104-11 FERRO (2) 0UTER RACE-LEVER 113 5091 REMOTE FOOT PEDAL 58 95073 LEVER BRG. ASSEMBLY 114 4450 FULL FOOT GUARD (INCL. 55, 56, 57) 115 18037 INLET BUSHING (2) 59 5069B SHAFT 116 5037SP LEVER STOP 60 5070 SET HOLDER LEVER 117 95073 BEARING (SOLID ASSEME 61 95071 SET HOLDER LEVER 118 95086 </td <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>						
51 5065 LEVER SHAFT 107 8080 SET SCREW (2) 52 5059 LEVER SHAFT WASHER 108 5054W WASHER (4) 53 5058 LEVER SHAFT SCREW 109 US81945A CLAMP 54 5021 THROTTLE VALVE LEVER 110 35179 JAM NUT 55 INNER RACE LEVER 111 TP104-10 1/4 BARB FITTING (2) 56 ROLLER BEARING (32) 112 TP104-11 FERRO (2) 57 OUTER RACE-LEVER 113 5091 REMOTE FOOT PEDAL 58 95073 LEVER BRG. ASSEMBLY 114 4450 FULL FOOT GUARD (INCL. 55, 56, 57) 115 18037 INLET BUSHING (2) 59 5069B SHAFT 116 5037SP LEVER STOP 60 5070 SET HOLDER LEVER 117 95073 BEARING (SOLID ASSEME 61 95071 SET HOLDER LEVER 118 95086 BEARING (SOLID ASSEME 61 95071 SET HOLDER LEVER				1		
52 5059 LEVER SHAFT WASHER 108 5054W WASHER (4) 53 5058 LEVER SHAFT SCREW 109 US81945A CLAMP 54 5021 THROTTLE VALVE LEVER 110 35179 JAM NUT 55 INNER RACE LEVER 111 TP104-10 1/4 BARB FITTING (2) 56 ROLLER BEARING (32) 112 TP104-11 FERRO (2) 57 OUTER RACE-LEVER 113 5091 REMOTE FOOT PEDAL 58 95073 LEVER BRG. ASSEMBLY 114 4450 FULL FOOT GUARD (INCL. 55, 56, 57) 115 18037 INLET BUSHING (2) 59 5069B SHAFT 116 5037SP LEVER STOP 60 5070 SET HOLDER LEVER 117 95073 BEARING (SOLID ASSEME 61 95071 SET HOLDER LEVER 118 95086 BEARING (SOLID ASSEME (INCL. 58, 59, 60) 119 842-1 GREASE FITTING			l l			
53 5058 LEVER SHAFT SCREW 109 US81945A CLAMP 54 5021 THROTTLE VALVE LEVER 110 35179 JAM NUT 55 INNER RACE LEVER 111 TP104-10 1/4 BARB FITTING (2) 56 ROLLER BEARING (32) 112 TP104-11 FERRO (2) 57 OUTER RACE-LEVER 113 5091 REMOTE FOOT PEDAL 58 95073 LEVER BRG. ASSEMBLY 114 4450 FULL FOOT GUARD (INCL. 55, 56, 57) 115 18037 INLET BUSHING (2) 59 5069B SHAFT 116 5037SP LEVER STOP 60 5070 SET HOLDER LEVER 117 95073 BEARING (SOLID ASSEME 61 95071 SET HOLDER LEVER 118 95086 BEARING (SOLID ASSEME (INCL. 58, 59, 60) 119 842-1 GREASE FITTING						` '
54 5021 THROTTLE VALVE LEVER 110 35179 JAM NUT 55 INNER RACE LEVER 111 TP104-10 1/4 BARB FITTING (2) 56 ROLLER BEARING (32) 112 TP104-11 FERRO (2) 57 OUTER RACE-LEVER 113 5091 REMOTE FOOT PEDAL 58 95073 LEVER BRG. ASSEMBLY 114 4450 FULL FOOT GUARD (INCL. 55, 56, 57) 115 18037 INLET BUSHING (2) 59 5069B SHAFT 116 5037SP LEVER STOP 60 5070 SET HOLDER LEVER 117 95073 BEARING (SOLID ASSEMB 61 95071 SET HOLDER LEVER 118 95086 BEARING (SOLID ASSEMB (INCL. 58, 59, 60) 119 842-1 GREASE FITTING			l l	1		` '
111 TP104-10 1/4 BARB FITTING (2) FERRO (2) TP104-11 FERRO (2) FERRO (2) TP104-11 TP104-11 FERRO (2) TP104-11 TP104-10 TP		5058	LEVER SHAFT SCREW	109	US81945A	CLAMP
56 ROLLER BEARING (32) 112 TP104-11 FERRO (2) 57 OUTER RACE-LEVER 113 5091 REMOTE FOOT PEDAL 58 95073 LEVER BRG. ASSEMBLY 114 4450 FULL FOOT GUARD (INCL. 55, 56, 57) 115 18037 INLET BUSHING (2) 59 5069B SHAFT 116 5037SP LEVER STOP 60 5070 SET HOLDER LEVER 117 95073 BEARING (SOLID ASSEMB 61 95071 SET HOLDER LEVER 118 95086 BEARING (SOLID ASSEMB (INCL. 58, 59, 60) 119 842-1 GREASE FITTING		5021	THROTTLE VALVE LEVER	110	35179	JAM NUT
57 95073 OUTER RACE-LEVÈR 113 5091 REMOTÈ FOOT PEDAL 58 95073 LEVER BRG. ASSEMBLY 114 4450 FULL FOOT GUARD (INCL. 55, 56, 57) 115 18037 INLET BUSHING (2) 59 5069B SHAFT 116 5037SP LEVER STOP 60 5070 SET HOLDER LEVER 117 95073 BEARING (SOLID ASSEMB 61 95071 SET HOLDER LEVER 118 95086 BEARING (SOLID ASSEMB (INCL. 58, 59, 60) 119 842-1 GREASE FITTING				111	TP104-10	1/4 BARB FITTING (2)
58 95073 LEVER BRG. ASSEMBLY (INCL. 55, 56, 57) 114 4450 FULL FOOT GUARD INLET BUSHING (2) 59 5069B SHAFT 116 5037SP LEVER STOP 60 5070 SET HOLDER LEVER 117 95073 BEARING (SOLID ASSEMB BEARING (SOLID ASSEMB GREASE FITTING 61 95071 SET HOLDER LEVER (INCL. 58, 59, 60) 119 842-1 GREASE FITTING			ROLLER BEARING (32)	112	TP104-11	FERRO (2)
Second Control of the control of t	57		OUTER RACE-LEVER	113	5091	REMOTE FOOT PEDAL
59 5069B SHAFT 116 5037SP LEVER STOP 60 5070 SET HOLDER LEVER 117 95073 BEARING (SOLID ASSEMB 61 95071 SET HOLDER LEVER 118 95086 BEARING (SOLID ASSEMB (INCL. 58, 59, 60) 119 842-1 GREASE FITTING	58	95073	LEVER BRG. ASSEMBLY	114	4450	FULL FOOT GUARD
60 5070 SET HOLDER LEVER 117 95073 BEARING (SOLID ASSEMB 61 95071 SET HOLDER LEVER 118 95086 BEARING (SOLID ASSEMB (INCL. 58, 59, 60) 119 842-1 GREASE FITTING			(INCL. 55, 56, 57)	115	18037	INLET BUSHING (2)
61 95071 SET HOLDER LEVER 118 95086 BEARING (SOLID ASSEMB (INCL. 58, 59, 60) 119 842-1 GREASE FITTING	59	5069B	SHAFT	116	5037SP	LEVER STOP
(INCL. 58, 59, 60) 119 842-1 GREASE FITTING	60	5070	SET HOLDER LEVER	117	95073	BEARING (SOLID ASSEMBLY)
(INCL. 58, 59, 60) 119 842-1 GREASE FITTING		95071		118	95086	BEARING (SOLID ASSEMBLY)
DOLLED OLLET (2)			(INCL. 58, 59, 60)	119	842-1	GREASE FITTING
62 5008 HOLLEH SHAFT (2) 120 5052 ADJ SPRING	62	5008	ROLLER SHAFT (2)	120	5052 ADJ	SPRING