Day, Date and Time

To set the Day, Date and Time, lift the handset or press ON-OFF, press CLOCK twice, press * until the correct day is displayed then press CLOCK, press the dial keys to set the new date (DD-MM format) press CLOCK and press the dial keys to set the time in 24 hour mode HH-MM. If 12 hour time mode is required press *, otherwise replace the handset or press ON-OFF for 24 hour mode. CLOCK may be used to step from field to field (1).

1

Battery cover

Ringer Volume

Line cord

Handset cord

Ringer pitch

Dialling mode

PABX line switch

Timed loop break

WARNING!
Unplug telephone from line before removing battery cover, to avoid possible high voltage risk.

DESIGNED AND MANUFACTURED IN AUSTRALIA

Abbreviated dialling index (slide out)