



## CASA's In-House Part-Codification for Relays & Contactors

Apply 'part-code' to all images and truncate to 26 characters for CASA's "Intelligent Part #" in Paradox tables (pending possible future increase to 30 characters)

—Region of parametric codification intelligence for CUSTOMER-DEFINED solution finding——>< Style Contact Contact Coil OEM # Image # **Coil Volts** Brand Frame Arrangement Resistance Current (applied ONLY for and/or gallery reference) **P5I P4I** P71 **OEMNo P61 P8I** Brand Open/PCB : xVdc/Vac Sequence **xPCO** хA xRx Name xx etc. Coil Contact Current Volts Style Ohms Xx Brand Image # Prefix Amps ac/dc Frame/Style: code-abbreviation as per established/agreed Example Concatinated description generated abbreviations – may be inherited from other products and from Intelligent P-Code-Descriptions CASA's "Glossary of Terms) SKT 9Vdc **110R** V23154 SIEMENS **2PCO 2**A Makers Type 2 Amps 2 pole C/O 9Volts d.c. 110 Ohms Socket Image # Brand Family/Number 2PCO-2A-9VDC-110R-SKT-V23154-SIEMENS

NOTE - The above parametric concatenated type number is composed from the contents of the 7 fields (P4I~Brand)