Assembly instruction Series H4 ₀₄ No. 3012

Tools and materials required: Stanley blade Scissors Soldering iron 150 Watts Solder Sn/Pb 60/40 activated rosin flux Spanner 11 mm (74 Z-0-0-2)		Straight connectors for flexible cable Cable entry: Screw-type Connector types: (e.g.)					
					11 H4-50-3-1 21 H4-50-3-1	11 H4-50-4-1 21 H4-50-4-1	11 H4-50-5-1 21 H4-50-5-1
					This connector is supplied in 6 parts	Suitable cables e.g.:	RG 58 C/U
		Centre contact:	soldered	soldered		soldered	
Braid:	screwed	screwed	screwed				





]

SUHNER's skilled staff and specialised equipment are available to carry out complete R.F. lead-assembly on your behalf. We mount your connectors on cables at economic prices! Please contact our representative for further details of this service.



HUBER+SUHNER Ltd. CH-9100 HERISAU Switzerland

Deutscher Text: siehe Rückseite