

PEAK PROGRAMME METERS ME12/9-10

Author M.J. Rawley
First issue January 1979

AMENDMENT RECORD

Amendment no.	Remarks	Amended by	Date
1			
2			-
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			

Published by Technical Publications Section, BBC Engineering Training Department, Wood Norton, Evesham, Worcestershire, WR11 4TF

First Published 1979

© British Broadcasting Corporation 1979
All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the permission of the British Broadcasting Corporation.

Printed in Great Britain by The Print Unit, BBC Engineering Training Department, Wood Norton, Evesham, Worcestershire, WR11, 4TF. January 1979

PEAK PROGRAMME METERS - INTRODUCTION


ME12/9-10


1

INTRODUCTION


The ME12/9 and ME12/10 are a monophonic peak programme meter and a stereophonic peak programme meter respectively. They each comprise a meter and an amplifier. Except for the ME12/9G, the amplifier can be mounted on the rear of the meter.

Variations in the ME12/9 and the ME12/10 are variations only in the types of meter used. These types are illustrated below and details are given in the adjacent Table.





Author M.J. Rawley



All meters are 1 mA f.s.d. and have a resistance of 600 ohms. The markings occur at the following percentages of f.s.d.

marking	%
1	10
2	22
3	35
4	51
5	67
6	80
7	93

CONTENTS

		bea.
	Introduction	1
	Meter types	1
ME12/9 (AM20/3)	Functional description	2
	Component layout	2
	Alignment check	2
	Input processing circuit	3
	Peak detection circuit description	4
	Peak detection circuit	5
	Output processing circuit description	n6
	Output processing circuit	7
	ME12/9A-G mounting holes	8
	ME12/9 C and D lampholder details	8
	ME12/9 A-F assembly	9
	ME12/ C and E flush fitting	
	adaptor	10
	ME12/9 D and F flush fitting	
	adaptor	11
ME12/10(AM20/4)	Component layout	12
	Regulation and mode switching	12
	Alignment check	13
	Required panel cut-out	13
	Functional block diagram	14
	Simplified A/B: M/S switching	
	circuit	14
	Input processing circuit	15
	Peak detection circuits	16
	Output processing circuits	17

METER TYPES

P.P.M. code	E.D. meter specification	Ernest Turner Type No.	Approximate Size (mm)	Brief description of distinguishing features
ME12/0A	1470	702	105 01	Laura dia a Disabilitati anno alla santa anno al
ME12/9A	1478	703	105 x 81	Large size — Black plastic case — glass meter panel
ME12/9B	1477	702	73 x 58	Medium size – Black plastic case – glass meter panel
ME12/9C	1499	643	102 x 78	Large size — Transparent all-plastic case
ME12/9D	1498	642	72 x 56	Medium size — Transparent all-plastic case
ME12/9E	1501	903	102 x 78	Large size — Transparent plastic case — glass meter panel
ME12/9F	1500	902	72 x 56	Medium size — Transparent plastic case — glass meter pane
ME12/9G	1497	640	46 x 40	Small size — Transparent all-plastic case
ME12/10A	1502	411 – 848 (ED 1502)	94 x 108	Red and green meter pointers
ME12/10B	1503	411 – 848 (ED 1503)	94 x 108	White and yellow meter pointers

© BBC

FUNCTIONAL DESCRIPTION

INPUT PROCESSING

Accepts an audio signal at the following levels with respect to zero volume programme:-

Programme 8

a) 0 dB b) -20 dB.

c) -43 dB*

and produces an output at -6 dB.

*The performance at this input level is restricted.


PEAK DETECTION

Accepts an audio signal at -6 dB with respect to zero volume programme. It produces a direct voltage output equal to the maximum peak voltage of the input. The charge and discharge time constants are selected during manufacture to give the P.P.M. its correct dynamic performance.

OUTPUT PROCESSING

Amplifies the input voltage into an output current with the pseudo-logarithmic law required by the P.P.M. Preset adjustments are provided to give the correct law.

COMPONENT LAYOUT



ALIGNMENT CHECK

Normally alignment is not required, but the following checks should be carried out if the meter is changed:

- 1. Check that, with no power, the mechanical zero of the meter is correct
- Apply power and terminate the input with 600 ohms. Check that the meter reads zero. If necessary adjust R24
- 3. Apply 1-kHz tone at -4 dB. Check that the meter reads 3. If necessary adjust R4.
- Apply 1-kHz tone at +8 dB. Check that the meter reads 6. If necessary adjust R38.
- 5. Apply 1-kHz tone at -10 dB. Check that the meter reads 11/2. If necessary adjust R39.
- 6. Check that the input levels are within specification for the following meter readings:

1 -12 ± 0.5 dB 2 -8 ± 0.2 dB 3 -4 ± 0.3 dB 4 0 ± 0.2 dB 5 +4 ± 0.3 dB 6 +8 ± 0.2 dB 7 +12 ± 0.5 dB

7. Check that the frequency response is within the following limits:


40 Hz - 20 kHz 0 ± 0.3 dB 10 Hz -2 ± 0.5 dB 5 Hz -5 ± 0.8 dB

- Check that the fallback time of the meter from a reading of 7 to a reading of 1 lies between 2,5 and 3 seconds.
- 9. If a Peak Programme Meter Tester (e.g. TE1/25) is available check the rise time. Set the level of 5-kHz tone to give a meter reading of 6 and measure the drop in indicated level for the following burst durations:


100 ms 0 ± 0.5 dB 10 ms -2.5 ± 0.5 dB 5 ms -4.0 ± 0.75 dB 1.5 ms -9.0 ± 1.0 dB

3


AM20/3 INPUT PROCESSING CIRCUIT



REF	TYPE	BASE
IC1	LIC748CS	1 - 8 - 5
		view on top




©BBC





This is a unity-gain inverting opamp circuit. The gain is given by R10 ÷ R7. The value of R8, equal to R10 in parallel with R7, is chosen to minimise thermal drift. R10
10k
R13
2k
1C2 D1 D2

In this circuit the feedback resistor is split into two by means of diodes. This permits different gains on positive and negative half cycles. The high openloop gain of the op-amp gives a sharp effective knee to the diode charactersitc.



The output of IC3 is the sum of its inputs multiplied by their individual gains, e.g. o/p = -(a + 2b) or $o/p = -\{ \bigcirc +2 \bigcirc -\} = - \bigcirc = \bigcap$






January 1979

AM20/3 PEAK DETECTION CIRCUIT (see page 4)

ME12/9-10

5



REF	TYPE	BASE
TR1	BC108	b e view on base
IC2	LIC748CS	1 = 8
IC4	LIC741CS	4 = 5
		view on top


© BBC

DESCRIPTION OF PPM LAW CIRCUIT

The gain of IC5 is the ratio of the effective feedback resistance (see circuit blocks a to f) to the input resistance (R21).

The value of the feedback resistance, and hence the gain, varies with the value of the output voltage, as shown in the input/output curves given alongside. The effect of the circuit blocks on gain is described in terms of an output voltage becoming progressively more negative as the PPM input signal increases,

- a) Positive output voltages are inhibited by the use of diode D5.
- (b) The circuit of this block modifies the gain over the range 0≥ V₀≥ −1.1 volts. A simplified circuit diagram of blocks (b) and (c) is given here and the following points should be noted about this diagram:
 - For the given range in V_O, the diagram is drawn with vertical position corresponding to the voltage.
 - 2. Transistor TR6 is connected as a diode.
 - 3. Transistor TR2 is used with its collector and its emitter reversed. This reduces the gain but is immaterial as the collector current is less than 4 μ A.
- The open-circuit voltage at the junction of TR6 and R40 in the voltage divider chain, R41, TR6 and R40, is -1.1 volts.



The forward bias on D6 and the base-emitter

junction voltage of TR2 is reduced over this

range of Vo and hence the shunting effect of

R27 is reduced. The gain of IC5 rises over this

(b2) $-0.4 \ge V_0 \ge -1.1 \text{ volts}$


range to 5.4.

Circuit block (b) affects the gain of IC5 over two ranges:

- (b1) $0 \ge V_o \ge -0.4$ volts Diode D6 is forward-biassed pulling V_{TR2b} up to 0.7 volts below V_o . The emitter voltage of TR2 is 0.7 volts more positive, i.e. $V_{TR2e} \approx V_o$, which effectively puts R27 in parallel with R26, giving IC5 a gain of 3.95.
- (c) $-1.1 \ge V_0 \ge -2.45$ volts Resistors R25 and R26 in series give a gain of 5.4.
- (d) $-2.45 \ge V_o \ge -3.45$ volts

 As V_o becomes more negative, TR5 is brought into conduction as V_o falls to more than 0.7 volts below V_{TR5b} . From this point, the slope of the curve changes to:

- (e) $-3.45 \gg V_0 \gg -4.15$ The slope of the curve falls again as TR4 is brought into conduction.
- (f) -4.15 ≥ V_O
 The slope of the curve falls to its least value as TR3 is brought into conduction.



TR2 BOTTOMED


January 1979

CHANGES

AM20/3 OUTPUT PROCESSING CIRCUIT (see page 6)

ME12/9-10

7



COMPONENTS FOR SLUGGED OPERATION 330 μ F ± 10% 6 V Union Carbide Type K330J6KS 150 μ F ± 10% 6 V Union Carbide Type K150J6KS


100 kΩ ± 2% Resistor Type MR25 Single-pole changeover switch.


REF	TYPE	BASE
TR2 TR6	BCY70	c O
TR3 TR4 TR5	BC108	view on base
IC5	LIC741CS	1 8
		view on top


8

MOUNTING HOLES and LAMPHOLDER DETAILS

issue 1 January 1979







DETAIL 5
LAMPHOLDER FOR ME12/9D.
MATERIAL 0-8mm AL.ALLOY. NS4.

FINISH CLEA

SCALE 1:1


Metric dimensions in millimetres.
Normal tolerances:
ho decimal place: ± 1mm
one decimal place: ± 0.3mm
two decimal places: ± 0.1mm
unless otherwise stated.

ASSEMBLY

ME12/9-10


9

BOTTOM NUT ON METER
TERMINALS TO BE ADJUSTED
LF NESSARY TO GIVE CLEARANCE
BETWEEN BACK OF METER AND BOARD.



1 METER CONNECTION


- a. FOR METER ATTACHED TO P.C.B. STRAP PINS 8-9
- b. FOR METER EXTERNAL TO P.C.B.CONNECT METER BETWEEN PIN 9&10.(+ve)
- c. FOR METER ATTACHED TO P.C.B. AND A SLAVE METER CONNECT SLAVE BETWEEN 7&8 (+ve)
- 2. ASSEMBLY TO BE IN ACCORDANCE WITH EA10484 NOTE 1.



10

issue 1 January 1979

©BBC



NOTE

ALL DIMENSIONS ARE FOR REFERENCE PURPOSE ONLY


FINISH - SPRAYED MATT BLACK


CHANGES

FLUSH FITTING ADAPTOR FOR ME12/9D and F


ME12/9-10


11






PANEL APERTURE TO BE (2.891"x 1.441") 73 43mm x 36 6mm





ALTERNATIVE ASSEMBLY SHOWING METER ILLUMINATION

TO PANEL



ADAPTOR IS MANUFACTURED BY ENERST TURNER INSTRUMENTS LTD FOR METER TYPES 642 AND 902

NOTE
ALL DIMENSIONS ARE FOR REFERENCE PURPOSE ONLY


FINISH - SPRAYED MATT BLACK


ME12/9-10

12

AM20/4 COMPONENT LAYOUT and REGULATION and MODE SWITCHING CIRCUIT

issue 1 January 1979





For pin assignments, see pages 12,15,16 and 17.

REF	TYPE	BASE
TR3	BFY51	b c c
		view on base

ALIGNMENT CHECK

Normally alignment is not required, but the following checks should be carried if the meter is changed:

- Check that, with no power applied, the mechanical zeros of the meter are correct and that the meter is in the A/B mode.
- Apply power and terminate each of the inputs with 600 ohms. Check that both pointers read zero.
 If necessary adjust R26 (A SET 0) and R69 (B SET 0).
- 3. Apply 1-kHz tone at -4 dB to both inputs. Check that both pointers read 3. If necessary adjust R6 (A SET 3) and R47 (B SET 3).
- 4. Apply 1-kHz tone at +8 dB to both inputs. Check that both pointers read 6. If necessary adjust R38 (A SET 6) and R81 (B SET 6).
- 5. Apply 1-kHz tone at -10 dB to both inputs. Check that both pointers read 1½. If necessary adjust R41 (A SET 1½) and R84 (B SET 1½).
- 6. Switch the meter to the M/S mode. Feed in-phase 1-kHz tone to both inputs at -3 dB. Check that the A:M pointer reads 4 and that the B:S pointer reads 0. If necessary remove link between pins 10 and 11 to make it easier to adjust R4 (S BAL). Replace link between pins 10 and 11. Switch back to the A/B mode.
- 7. Check that the input levels of 1-kHz tone to give the readings below are within the specified limits:


1	$-12 \pm 0.5 dB$
2	$-8 \pm 0.2 dB$
3	$-4 \pm 0.3 dB$
4	$0 \pm 0.2 dB$
5	$+4 \pm 0.3 dB$
6	$+8 \pm 0.2 dB$
7	$+12 \pm 0.5 dB$

8. Check that the frequency response of both halves of the unit is:

40 Hz to 20 kHz	$0 \pm 0.3 dB$
10 Hz	$-2 \pm 0.5 dB$
5 Hz	$-5 \pm 0.8 dB$

- Check that the fallback time of the pointers from a reading of 7 to a reading of 1 lies between 2.5 and 3 seconds.
- 10. If a Peak Programme Meter Tester (e.g. TE1/25) is available, check the rise time. Set the level of the 5 kHz tone to read 6 on both pointers and measure the drop in indicated level for the following burst durations:

100 ms	$0 \pm 0.5 dB$
10 ms	$-2.5 \pm 0.5 dB$
5 ms	$-4.0 \pm 0.75 dB$
1.5 ms	$-9.0 \pm 1.0 dB$



ME12/9-10


AM20/4 FUNCTIONAL BLOCK DIAGRAM and SIMPLIFIED A/B - M/S SWITCHING CIRCUIT

CHANGES


issue 1 January 1979

© BBC


FUNCTIONAL BLOCK DIAGRAM



SIMPLIFIED CIRCUIT OF A/B: M/S SWITCHING



These two simplified circuits of the Input Processing shows the circuit differences between the A/B and the M/S modes. They also show the levels involved to obtain A, B and M outputs of -6 dB, assuming that the A and B inputs are the same signal. The M output is known as A + B -3 dB. This 3 dB is implied by the $\sqrt{2}$.



In the full circuit, shown on page 15, some of the resistor values are greater than those shown here. This is because some gain is required from the amplifiers to compensate for the loss in Treble Lifting and the loss in excess of 6 dB in the input transformers.

CHANGES


AM20/4 INPUT PROCESSING CIRCUIT

ME12/9-10

15

BASE


view on top



CHANGES

issue 1 January 1979

© BBC





CHANGES

AM20/4 OUTPUT PROCESSING CIRCUITS

ME12/9-10

17





REF	TYPE	BASE
IC5 IC11	LIC741CS	1 8
IC6 IC12	CA3096AE	view on base 1 16 8 9 view on top