



# Relay & Switch Nomenclature


## CASA Relays

### 1PNO




One Pole Normally Open  
(NO)  
Form A  
**SPST (SPNO)**

### 1PNC




One Pole Normally Closed  
(NC)  
Form B  
**SPST (SPNC)**

### 1PCO



One Pole Change-Over  
(CO)  
Form C  
**SPDT**


### xPCO



"x" Pole Change-Over  
(CO)  
Form C  
**xPDT**


"x" = any number  
(of poles)

### 2PNO




Two Pole Normally Open  
(NO)  
Form A  
**DPST**

### 2PNC




Two Pole Normally Closed  
(NC)  
Form B  
**DPST**

### 2PCO



Two Pole Change-Over  
(CO)  
Form C  
**DPDT**

### xPCO



"x" Pole Change-over  
(CO)  
Form C  
**xPDT**