


DC DRIVE MODULE



Key No.	Description	Part Number			Number Recommended
		105-AMP	250-AMP	345-AMP	
1	Potentiometer Board Assembly	12M08-00008-00	12M08-00008-00	12M08-00008-00	1
2	Main Circuit Board Assembly	12M08-00007-00	12M08-00007-00	12M08-00007-00	1
3	Armature Power Supply or	12M08-00003-00	12M08-00004-00	12M08-00016-00	1
—	Silicon Controlled Rectifiers (SCR's)	05P08-00044-00	05P08-00046-00	05P08-00047-00	6
4	Line Fuse	08P01-00144-00	08P01-00145-00	08P01-00152-00	3
5	Field Loss Assembly	12M08-00012-00	12M08-00012-00	12M08-00012-00	1
6	Bridge Rectifier	05P02-00054-00	05P02-00054-00	05P02-00054-00	1
7	Fan	15P01-00007-00	15P01-00007-00	15P01-00007-00	1
8	Control Fuse	08P01-00050-00	08P01-00050-00	08P01-00050-00	2
9	Field Fuse	08P01-00146-00	08P01-00146-00	08P01-00146-00	4
10	Fault Relay	06P1-00016-00	06P1-00016-00	06P1-00016-00	1
—	Retaining Clip for Fault Relay	06P99-00004-00	06P99-00004-00	06P99-00004-00	1
11	Plug-In Relay	06P01-00090-00	06P01-00090-00	06P01-00090-00	1
—	Retaining Clip for Plug-In Relay	06P99-00015-00	06P99-00015-00	06P99-00015-00	1
12	Relay Board Assembly	12M08-00005-00	12M08-00005-00	12M08-00005-00	1
13	Tach Feedback Board	12M08-00017-00	12M08-00017-00	12M08-00017-00	1