

April, 1967

LIST OF SERVICE TYPE & REFERENCE NUMBERS
FOR MARCONI INSTRUMENTS

The following list relates Service type numbers to Marconi Instruments type numbers:-

<u>Type Number</u>	<u>Description</u>	<u>Reference Number</u>	<u>Designation</u>
OA 161	U.H.F. Signal Generator and Modulator	WY.0066	Signal Generator No. 5 Mark II
OA 161A	U.H.F. Signal Generator and Modulator	WY.0216	Signal Generator No. 5 Mark II
OA 161B	U.H.F. Signal Generator and Modulator	WY.0266	Signal Generator No. 5 Mark II
OA 161D	U.H.F. Signal Generator and Modulator	WY.0564	Signal Generator No. 5 Mark II
OA 164	TR.3017 Beacon	10DB/500	Transmitter/Receiver type TR.3107A
OA 164A	TR.3017 Beacon	10DB/1285	Transmitter/Receiver type TR.3107B
OA 167A	Polar Diagram Test Set	10SB/118	Test Set type 81
OA 175	Aerial Impedance Matching Set	10KF/532	Test Set type 128
OA 175A	Aerial Impedance Matching Set	10SB/6008	Test Set type 207
OA 197			Calibrator Output Signal Generator No.1
TME 1	Frequency Measuring Equipment	WY.0098	Wave Meter Standard No. 1
TME 1	Frequency Measuring Equipment	10T/33	Wave Meter type W.1193
TME 1	Frequency Measuring Equipment	10T/689	Wave Meter type W.119A
TME 2	Frequency Measuring Equipment	10D/CA/672	Frequency Measuring Equipment
TME 18	Field Strength Measuring Equipment	10S/558	Test Set type 29
TF 142E	Distortion Factor Meter	10S/74	Test Set type 35
TF 142F	Distortion Factor Meter	10S/17639 6625-99-944- 7661	Indicator Distortion
TF 144F	Standard Signal Generator	WY.0063	Signal Generator No. 1 Mark I
TF 144G	Standard Signal Generator	(WY.0062 WY.0268)	Signal Generator No. 1 Mark II
TF 144G	Standard Signal Generator	Z4/ZD.00391	Signal Generator No.1 Mark III Equip-

<u>Type Number</u>	<u>Description</u>	<u>Reference Number</u>	<u>Designation</u>
TF 144G	Standard Signal Generator	-	Signal Generator Pattern 54704
TF 144G/4	Standard Signal Generator	10S/647	Signal Generator 56
TF 144G/4	" " "	10S/16822	Signal Generator 56A
TF 144G/6	" " "	10S/695	Signal Generator 57
TF 144G/6	" " "	10S/16823	Signal Generator 57A
TF 144H/S	" " "	6625-99-972 -7357	Signal Generator CT.452
TF 144H/2S	Standard Signal Generator	6625-99-913 -1420	Signal Generator CT. 452 Set
TF 144H/4S	Standard Signal Generator	6625-99-580 -6581	Signal Generator CT.452A.
TF 144H/6S	Standard Signal Generator	6625-99-900 -8337	Signal Generator CT.452A Set
TF 144H Accessories:-			
TM 6123	Dummy Aerial	6625-99-913 -9483	Coupler Signal Generator
Type 3429/1	Mains Lead (Ministry)	10HA/8359 5995-99-945 -9896	Connector
TM 6599	Matching Pad 50/75 ohms	5905-99-580 -0511	Matching Pad
TM 5573	20 dB Pad	5905-99-580 -0510	Attenuator Fixed
TM 4726/152	Output Lead 5 ft. (B.N.C. - Belling Lee)	5995-99-580 -0512	Cable Assembly
TM 4969/3	Output Lead 5 ft. (B.N.C. - B.N.C.)	5995-99-580 -0513	Cable Assembly
TF 195L	Beat Frequency Oscillator	10V/11940	Oscillator Unit type 25
TF 195L	" " "	WY.0047	Oscillator Beat Frequency No. 2
TF 195M	" " "	10V/11940	Oscillator Unit type 25
OA 199A/2	R.F. Impedance Bridge Assembly comprising:-	6625-105932	
(TME 20B/1	R.F. Impedance Bridge	(10S/16202	

<u>Type Number</u>	<u>Description</u>	<u>Reference Number</u>	<u>Designation</u>
TF 202E	Impedance Comparison Bridge	10S/108	
TF 229D	Electrolytic Condenser Bridge	WY.0010	Bridge Capacitance (Electrolytic No.1)
TF 301C/1	1,000 Kc/s Inductance Bridge	WY.0013	Bridge Inductance No. 1
TF 301D/1	" " " "	10S/11967	Inductance Bridge type 1
TF 301E	" " " "	10S/16301	Inductance Bridge type 1A
TF 329B-F	Q Meter	WY.0040	Meter Circuit Magnification No. 1 Mark I
TF 329F	Q Meter	10S/11937	Meter Circuit Magnification type 1
TF 329G	Q Meter	10S/16320	Meter Circuit Magnification type 1A
TF 329G	Q Meter	WY.0282	Meter Circuit Magnification Mark II
TF 329G/1	Q Meter	Z4/WD/4024* Z4/WD/3890	Meter Circuit Magnification Mark III
TF 338B	Variable Attenuator	10L/16062	Attenuator Variable
TF 338B	" "	AP.100321	" A.F.
TF 338C	" " A.F.	10L/16559 5905-99-580 -0002	" Variable
TF 340	Output Power Meter	10S/11934	Output Meter type 2
TF 340	" " "	Pattern No. 54708	Output Power Meter
TF 340	" " "	WY.0059	Meters Output Power
TF 373D	Universal Impedance Bridge	WY.2527	Bridge Impedance No. 1 Mark III
TF 373D	" " "	10S/11936	
TF 390F	U.S.W. Signal Generator	WY.0070	Signal Generator No. 2 Mark II
TF 390F/3	U.S.W. Signal Generator	10SB/13	Signal Generator type 9
TF 390F/4	" " "	10SB/17	Signal Generator

<u>Type Number</u>	<u>Description</u>	<u>Reference Number</u>	<u>Designation</u>
TF 390G	U.S.W. Signal Generator	WY.0069	Signal Generator No.2
TF 390G	" " "	WY.0072	Signal Generator No.2 Mark IV
TF 390G	" " "	WY.3180	Signal Generator No.2 Mark V
TF 390G	" " "		Signal Generator Pattern 54705
TF 390G	" " "		Signal Generator Pattern 54706
TF 390G	" " "	10S/65	Signal Generator type 30
TF 390G	" " "	10S/66	Signal Generator type 31
TF 390G/7	" " "	10S/637	Signal Generator type 55
TF 390G/7	" " "	WY.0208	Signal Generator No.2 Mark I
TF 410B	Video Oscillator	10S/72	Test Set type 37
TF 410C	" "	1 0S/72	" " " "
TF 428A	Valve Voltmeter	10S/27	Valve Voltmeter type 1
TF 428A	" "	WY.0097	Voltmeter Valve 150V No. 1
TF 428A/1	" "	WY.0097	Voltmeter Valve 150V No. 1
TF 428B	" "	WY.0213	Voltmeter Valve 150V No. 2
TF 428B	" "	10S/822	Valve Voltmeter type 6
TF 428B/1	" "	10S/11935	Valve Voltmeter type 6
TF 455D/1	Wave Analyser	10S/16201	Analyser Wave Harmonic No. 1
TF 455E	" "	10S/17746 6625-99-944 -7662	Analyser, Spectrum
TF 465	Universal Impedance Bridge	WY.0025	Bridges Impedance No. 2.
TF 468A	Stabilising Transformer Unit	10S/16213	
TF 468A/1	" " "	10S/16214	

<u>Type Number</u>	<u>Description</u>	<u>Reference Number</u>	<u>Designation</u>
TF 517E	U.H.F. Signal Generator	10SB/95	Signal Generator type 32
TF 517E	" " "	-	Signal Generator Pattern W.5001
TF 517E/10	" " "	10SB/150	Signal Generator type 51
TF 517F/1	" " "	10SB/189	Signal Generator type 53
TF 517F/1	" " "	-	Signal Generator Pattern W.5001A
TF 517F/1	" " "	WY.0065	Signal Generator No. 5 Mark I
TF 517F/1	" " "	WY.0137	Signal Generator No. 5 Mark III
TF 558B	Crystal Monitor type 4	10T/46	Monitors Crystal type 4
TF 558B	" " "	10T/573	Monitors Crystal type 4A
TF 562A/1	Oscillator Detector Unit	10S/16203	
TF 602A	Beat Frequency Oscillator	10S/73	Test Set type 38
TF 615A	Test Set type 5		Test Set type 5
TF 615B	Test Set type 5A		Test Set type 5A
TF 615C/1	Test Set type 5A	10S/20	Test Set type 5A
TF 615D	Test Set type 5B	10S/638	" " " 5B
TF 620/1	Audio Frequency Microvolter	10S/11942	Microvolter Audio Frequency type 1
TF 640A	Test Set type 11	10S/12049	Test Set type 11
TF 640B	Test Set type 11A	10S/13002	" " " 11A
TF 640B/1	Test Set 98	10S/13036	Test Set 98
TF 640B/2	Test Set 392	10S/16383	Test Set 392
TF 640B/3	Test Set 98A	10S/16442	Test Set 98A
TF 643	U.H.F. Wavemeter	WY.0104	Wavemeter No. 4 Mark I
TF 643A	" "	WY.0267	Wattmeter No. 4 Mark II
TF 643B	" "	Z4/ZD.00388	Wattmeter No. 4 Mark III

<u>Type Number</u>	<u>Description</u>	<u>Reference Number</u>	<u>Designation</u>
TF 675B	Modulation Generator	WY.0207	Modulator Pulse No.1
TF 675D	" "	WY.2295	Modulator Pulse No.1 Mark II
TF 675F	Pulse Generator	10S/17798	Pulse Generator M.35
TF 675F/1	" "	10S/17702	Signal Generator type 16727
TF 684B	Wavemeter	10T/5	Wavemeter type W.1158
TF 684C	"	10T/100	" " W.1158A
TF 684D	"	10T/13012	" " W.1158B
TF 696	Wavemeter type W.42	10T/82	" " W.42B
TF 697	Absorption Wavemeter	10T/9143	" " W.1095
TF 701	Wavemeter	WY.2129	Wavemeter GL/T No.3
TF 712	"	WY.0099	Calibrator Crystal No. 5
TF 712A	"	WY.0621	Calibrator Crystal No. 5 Mark II
TF 720	"		Wavemeter SL/C No.2
TF 720A	"	WY.1012	Wavemeter No. 1
TF 724	Crystal Calibrator	WY.0303	Calibrator Crystal No. 6
TF 725	Receiver	10PB/35	Receiving Unit type 32
TF 726	Modulator	10DB/50	Modulator Unit type 33
TF 727	Transmitter	10RB/10	Transmitter Unit type 24
TF 728	Power Unit	10KB/364	Power Unit type 120
TF 729	Monitor	10T/83	Monitor type 36
TF 732	Wavemeter	10T/94	Wavemeter type W.1319
TF 735A	Oscillator	10VB/77	Oscillator Unit type 106
TF 736A	Power Unit	10KB/625	Power Unit type 270
TF 737A	Aerial Dipole	10SB/1961	Aerial System type 171
TF 742A	Meter Unit	10SB/151	Meter Unit
TF 756	Adaptors Monitoring	WY.0001	Adaptors Monitoring

<u>Type Number</u>	<u>Description</u>	<u>Reference Number</u>	<u>Designation</u>
TF 762A	U.H.F. Signal Generator	10SB/215	Signal Generator type 54
TF 762C	" " "		Signal Generator type 7904
TF 783	Heterodyne Wavemeter	10T/13029	
TF 783/1	" "	10T/13030	
TF 791B	Carrier Deviation Meter	10S/804	Test Set type 357
TF 791D	" " "	10ZZ/201641 6625-99-952- 2585	Test Set Deviation
TF 796	Modulation Unit	10SB/122	Test Set type 87
TF 801A	Signal Generator	Z4/ZD.00279	Signal Generator No.15
TF 801A/1	" "	10S/16370	" " type 68
TF 801A/1A	" "	6625-99-949 -1648	Signal Generator type 68A
TF 801A/1B	" "	10S/17781	Signal Generator type M.31
TF 801B	" "	10S/16813	Signal Generator type 9137
TF 801B/3	" "	6625-99-943 -1911	Signal Generator CT.394
TF 801D/1S	" "	6625-99-972 -6346	Signal Generator CT.394A
TF 801D/2S	" "	10S/17134 6625-99-901 -9983	Signal Generator CT.394A Set
TF 801D/8S	" "	6625-99-519 -4482	Generator, Signal CT.394B
TF 801D/9S	Signal Generator	6625-99-106 -1189	Signal Generator Set CT.394B
TF 801D Accessories:-			
TM 4919	20-dB Pad	5905-99-972 -8881	Attenuator
TM 4919/1	6-dB Pad	5905-99-951 -4231	Attenuator
TM 5549	Matching Pad 50/75 ohms	5905-99-972 -8900	Attenuator
TM 5548	Matching Pad 50/75 ohms	5905-99-972	Attenuator

<u>Type Number</u>	<u>Description</u>	<u>Reference Number</u>	<u>Designation</u>
TM 4824/2	12 ins. Connector	5995-99-972 -8382	Cable Assembly
TM 5599	12 ins. Connector	5995-99-972 -8383	" "
TM 4824/1	54 ins. Connector	5995-99-972 -8384	" "
TM 5753	Fuse Co-axial	5920-99-932 -4381	Fuse Unit R.F. concentric, enclosed singleway
TF 803	Wavemeter	10T/79	Wavemeter W.1296
TF 805	"	10T/546	" W.1432
TF 828	Oscillator		Oscillator G.208
TF 828/2	"	AP.539208	" G.210
TF 829	Wavemeter G.93		Wavemeter G.93
TF 841	Test Set	10S/16046	Test Set type 250
TF 867	Standard Signal Generator	10S/16392 6625-99-970 -1187	Signal Generator type 70.
TF 867A	Standard Signal Generator	6625-99-947 -5987	Signal Generator
TF 868	Impedance Bridge	10S/16341	Impedance Bridge type 6
TF 868/1	" "	10S/16341	" "
TF 885	Video Oscillator	10S/16344	Signal Generator type 65
TF 885	" "	Z4/ZD.00322	Oscillator Video No.2
TF 885A	" "	10S/16446	Signal Generator type 65A
TF 885A	" "	Z4/ZD/02066	Oscillator Video No. 2 Mark II
TF 885A/1	" "	10S/16499 6625-99-932 -4976	Signal Generator type 65B
TF 885A/1	" (Station Equipment)	Z4/ZD/02762	Oscillator Video No. 3 Equipment
TF 885A/1	" (Station Equipment)	6625-99-901 -8750	Signal Generator Set
TF 888	Portable Receiver Tester	10S/16420	Test Set 393

<u>Type Number</u>	<u>Description</u>	<u>Reference Reference</u>	<u>Designation</u>
TF 890A/4	R.F. Test Set	10S/17509 6625-99-944 -7663	Test Set R.F. type 15147
TF 893A	A.F. Power Meter	10S/16747 6625-99-914 -9811	Wattmeter Absorption Audio Frequency
TF 894	Audio Tester	10S/16345	Test Set 381
TF 894A	" "	10S/17504	Test Oscillator type 15101
TF 899	Valve Millivoltmeter	10S/16727	Valve Voltmeter 8426
TF 899	" "	6625-99-943 -6303	Voltmeter Electronic
TF 899A	" "	6625-99-972 -7776	" "
TF 912A	Transmitter Output Meter	10S/16819 6625-99-944 -7664	Wattmeter Absorption VHF 9259
TF 912A/1	" " "	10S/16963 6625-99-944 -7665	Wattmeter type 3712
TF 928	Deviation Meter	Z4/ZD/01833	Test Set Deviation, F.M. No. 3 Equipment
TF 934	" "	10S/01831 Z4/ZD/00193 6625-99-949- 0515	Test Set Deviation F.M. No. 2 CT.45
TF 934/3	" "	10S/16786 6625-99-943 -7368	Test Set Deviation CT.219
TF 936	Impedance Bridge	Z4/ZD/00254 6625-99-949 -0517	Bridge Impedance No. 5 CT.43
TF 937	Signal Generator	10S/16780	Signal Generator CT.218
TF 937/1	" "	Z4/ZD/02674	Signal Generator No. 12 CT.320 Equipment.
TF 937A	" "	6625-99-102 -8077	Signal Generator Set No. 12/2 CT.320A
TF 938	A.F. Wattmeter	Z4/ZD/02417 6625-99-949 -0510	Wattmeter Absorption A.F. No.1 CT.44

<u>Type Number</u>	<u>Description</u>	<u>Reference Number</u>	<u>Designation</u>
TF 942	High Speed Oscilloscope	Z4/ZD/01094 10S/02367 6625-99-105 -7780	High Speed Oscilloscope CT.90
TF 948	Signal Generator No. 13	WD.3941	Signal Generator No.13
TF 957	H.F. Wattmeter	Z4/ZD/00747 6625-99-105 -7652	Wattmeter Absorption H.F. No.2 CT.211 Equipment.
TF 958	Valve Voltmeter	Z4/ZD/00657 6625-99-949 -0470	Valve Voltmeter No.3 CT.208 Equipment
TF 960	Wide Band Amplifier	Z4/ZD/03015	Amplifier Pulse CT.205
TF 961	Signal Generator		Signal Generator No.14
TF 975	Wave Meter	10T/13126	Wave Meter type S2/1
TF 984/1	Spectrum Analyser	10S/16147 6625-99-943 -4301	Analyser Spectrum Type 1
TF 987/1	Noise Generator	10S/16149	Signal Generator Noise No. 1
OA 989	Test Set 386	10S/16356	Test Set 386
TF 995A/1	FM/AM Signal Generator	10S/16818	Signal Generator type 9203
TF 995A/2	" " "	10S/17625	Signal Generator type 9208A
TF 995A/2M	" " "	10S/17626 6625-99-944 -7666	Signal Generator Set
TF 995A/3S	" " "	Z4/ZD/04302	Signal Generator No. 18 CT.402
TF 995A/3S	" " "	Z4/ZD/05581 6625-99-103 -6633	Signal Generator No. 18 Mark II CT.402 Equipment
TF 995A/5	FM/AM Signal Generator * (Includes 20dB Pad TM 5552)	6625-99-945 -5649	*Signal Generator Set
TF 999/1	Noise Generator (S-Band)	10S/16162	Noise Generator type 2
OA 1000	E.H.T. Stabilised Power Supplied Unit TF 1105	XT.71	Stabilised Power Supply XT.71
TF 1009	Test Set 402	10S/16157	Test Set 402
TF 1015	Test Set 404	10S/16159	Test Set 404

<u>Type Number</u>	<u>Description</u>	<u>Reference Number</u>	<u>Designation</u>
TF 1020A/1	R.F. Power Meter	10S/16820 6625-99-943 -5565	Wattmeter, Absorption type 9287 CT.403
TF 1020A/3	" " "	10S/NIV/1633 6625-99-946 -5432	Wattmeter, Absorption
TF 1020A/4M1	" " "	10ZZ/202759 6625-99-952 -0551	Wattmeter, Absorption
TF 1020A/5M1	" " "	6625-99-952 -0171	Wattmeter, Absorption
TF 1026/1	Portable Frequency Meter	6625-99-933 -1085	Frequency Meter (Absorption)
TF 1026/2M	" " "	6625-99-944 -5554	Frequency Meter (Absorption)
TF 1026/3	" " "	6625-99-913 -1189	Frequency Meter (Absorption)
TF 1026/4M	" " "	10T/695	Frequency Meter type 9938
TF 1026/6	" " "	10T/13125 6625-99-933 -1700	Wavemeter type S1/1
TF 1026/11	" " "	10T/699 6625-99-944 -7667	Frequency Meter type 11528
TF 1030	Test Set	AP.67102	R.F. Test set CT.118
TF 1032	High Voltage Attenuator	ZL/ZD.03340	High Voltage Attenuator CT.117
TF 1035	Spectrum Analyser	AP.60832	Spectrum Analyser CT.152
TF 1037	Frequency Meter	AP.60833	Frequency Meter CT.162
TF 1040	Pulse I.F. Signal Generator	6625-99-943 -2416	Signal Generator Pulse Mod. CT.215
TF 1041A	Vacuum Tube Voltmeter	10S/NIV/569	-
TF 1041B	Vacuum Tube Voltmeter	10S/17050	Multimeter Electronic 13267
TF 1041B	" " "	6625-99-943 -8384	Multimeter Electronic CT.429
TF 1041 Series Accessories:-			
TM 5031A & B	Co-axial 'T' Connector	10AD/3627	Adaptor
TM 5032	Multiplier for TF 1041B(A.C.)	10S/17133	Multiplier Elect. Test A.C.

<u>Type Number</u>	<u>Description</u>	<u>Reference Number</u>	<u>Designation</u>
TF 1041C	Vacuum Tube Voltmeter	6625-99-970 -1124	Voltmeter Electronic
TF 1047	Dummy Load	10S/16410	Dummy Load type 2
TF 1048	Reflection Co-Efficient Meter	AP.62274 6625-99-943 -3266	Indicator, Standing Wave Ratio CT.216
TF 1049	Reflection Co-Efficient Meter,	AP.62275 6625-99-943 -3267	Indicator, Standing Wave Ratio CT.217
TF 1053	Noise Generator	6625-99-943 -3249	Generator Thermal Noise CT.207
TF 1060	U.H.F. Signal Generator	10S/NIV/985 6625-99-970 -2173	-
TF 1060/3S	U.H.F. Signal Generator	6625-99-103 -9281	Signal Generator Set
TF 1064B/5	V.H.F. Signal Generator	10ZZ/202377	-
TF 1065A	Transmitter & Receiver Output Test Set	10ZZ/202272	
TF 1066B/6	F.M. Signal Generator	10ZZ/202999 6625-99-955 -2400	Signal Generator Set
TF 1066B/6S	F.M. Signal Generator with Pre-Amplifier TM 8792	6625-99-106 -0902	Signal Generator Set AF/FM.
TF 1067/1	Heterodyne Frequency Meter	Z4/ZD/04977 6625-99-957 -2362	Frequency Meter Set, Absorption
TF 1073	100 dB Step Attenuator	10S/NIV/57	Attenuator 100 dB
TF 1073	100 dB Step Attenuator	5905-99-972 -8577 AP.104390	Attenuator R.F.
TF 1073A	100 dB Step Attenuator	10L/16832	Attenuator Variable M.4
TF 1073A/2S	" " "	6625-99-972 -9733	Attenuator CT.421
OA 1074 comprising:-		10S/16825	Test Set 9423
TF 1154	Oscillator Unit (A.F. and L.F.)	10V/679	Oscillator Unit T.9426
TF 1155	Signal Generator (Wide Band)	10S/16827	Signal Generator T.9425
TF 1156	Signal Generator (Narrow Band)	10S/16826	Signal Generator T.9424

<u>Type Number</u>	<u>Description</u>	<u>Reference Number</u>	<u>Designation</u>
TF 1279	Calibrator Unit (Range)	10D/20582	Calibrator Unit T.9900
TM 5478	Attenuator T.32	10L/280	Attenuator T.32
TF 1090	Test Set (Interrogator)	6625-99-942 -9868	Test Set type 4339
TF 1090/2	Test Set Radar	6640-99-971 -4513	
OA 1094	Spectrum Analyser	AP.103540 10S/17141	Analysers Spectrum Analysers Spectrum Set 14526
OA 1094 Accessories :-			
TM 5606	L.F. Extension Unit	AP.103544	Frequency Converter
TM 5606	" " "	10S/17168	Converter Frequency Electronic type S1/1
TM 6448/1M1	" " "	10ZZ/202435 6625-99-953 -2063	Converter Frequency Electronic
OA 1094A/S	H.F. Spectrum Analyser	AP.5806737 6625-99-580 -6737	Analysers, Spectrum
TM 6448	L.F. Extension Unit	AP.9475358 6625-99-947 -5358	Converter, Frequency
OA 1094A/1S	H.F. Spectrum Analyser with Trolley etc. comprising:-	6625-99-104 -3144	Analysers Set Spectrum
{ OA 1094A/S H.F. Spectrum Analyser		6625-99-580 -6737	Analysers, Spectrum
{ TM 6448 L.F. Extension Unit		6625-99-947 -5358	L.F. Extension Unit
{ TM 6612 Trolley		6625-99-949 -9552	Trolley Test Equipment
{ TM 6978 Base Plate		6625-99-949 -9553	Mounting Plate Assy.
{ TM 4726/272 Mains Lead		6625-99-104 -7090	Cable Assembly Power Electrical.
{ TM 6723 R.F. Fuse Unit		6625-99-949 -9554	R.F. Fuse Unit
TF 1099/2	20 Mc/s Sweep Generator	10S/NIV/1829 6625-99-971 -4611	Sweep Generator Set
TF 1099/3S	24 Mc/s Sweep Generator	AP.5806736 6625-99-580 -6736	Generator Sweep
TF 1099/3S	24 Mc/s Sweep Generator	6625-99-104	Sweep Generator Set

<u>Type Number</u>	<u>Description</u>	<u>Reference Number</u>	<u>Designation</u>
TF 1100	Sensitive Valve Voltmeter	10S/17508 6625-99-970 -7544	Valve Voltmeter 15145 Valve Millivoltmeter
TF 1101	R.C. Oscillator	10S/17703 6625-99-999 -9604	Signal Generator type 16723
TF 1102	Amplitude Modulator	10D/23402 6625-99-949 -2037	Modulator Amplitude M.10
TF 1104	Test Set	10S/NIV/1095 6625-99-949 -1613	Oscilloscope Alignment
TF 1106	Noise Generator	10S/17169 6625-99-949 -1612	Generator Noise type S4/1
TF 1106/4	" "	10S/NIV/598	
TF 1107	Test Kit 20A	10S/NIV/238	
TF 1143	I.S.B. Two Signal Generator (AP.103480, AP.103481)	AP.1034804/1	I.S.B. Two Tone Test Set and Power Unit.
TF 1147	Testers Performance Type 12004	10S/17379	
comprising:-			
	{ Power Unit type 12003	10K/20866	
	{ Test Set type 6004	10S/17369	
TF 1152	Output Power Meter	6625-99-943 -5567	Wattmeter Absorption CT.418
TF 1152A	" " "	6625-99-101 -9916	" "
TF 1152A/1	" " "	6625-99-943 -5568	Wattmeter Absorption CT.419
TF 1153/1	Oscilloscope	10S/17513	Oscilloscope
TF 1159	L.F. Oscilloscope	24/LDM/31111	Oscilloscope Low Frequency
TF 1160	Signal Generator	10S/17045	"Tacan" Signal Generator type 7760
TF 1167	Telegraph Test Generator (AP.103530 & AP.103531)	AP.1035304/1	Frequency Shift Simulator and Power Unit
TF 1167	Station Equipment Version	6625-99-949 -3165	Test Set Telegraph Set
TF 1167	Telegraph Test Generator	10S/17045	

<u>Type Number</u>	<u>Description</u>	<u>Reference Numbers</u>	<u>Designation</u>
TF 1167	Telegraph Test Generator comprising:- (Telegraph Test Generator (Power Supply Unit	6625-99-933 -3452 6625-99-949 -3166 6130-99-949 -3167	Test Set Telegraph Test Set Telegraph Power Supply
TF 1168	High Discrimination Oscillator	10S/16549	Signal Generator 9428
TF 1168	High Discrimination Oscillator	6625-99-949 -2964	Signal Generator Set
TF 1168/1	High Discrimination Oscillator (centred on 150 Kc/s)	10S/9455648 6625-99-945 -5648	Signal Generator Set
TF 1168/3M1	High Discrimination Oscillator	10ZZ/202135 6625-99-102 -9126	Signal Generator Set
TF 1202A	U.H.F./S.H.F. Power Meter	10S/17130	Wattmeter U.H.F/ S.H.F. type 14441
TF 1202A Accessories:-			
TM 6215	30 dB Attenuator	10S/17164	Attenuator Fixed type S2/2
TM 6231	30 dB Attenuator	10S/17163	Attenuator Fixed type S2/1
TF 1205S	R.F. Power Meter	10S/16846 6625-99-949 -3783	Wattmeter Set Absorption CT.401
TF 1245	Circuit Magnification Meter	10ZZ/202618 6625-99-103 -1083	Panels Test Electrical
TF 1246	40 Kc/s - 50 Mc/s Oscillator	10ZZ/202619 6625-99-103 -5187	Oscillator R.F.
TF 1247	20 - 300 Mc/s Oscillator	6625-99-103 -1073	Oscillator R.F.
TM 4520	Inductors in Case	6625-99-103 -5240	Inductor Set Radio Frequency
OA 1249B	White Noise Test Set	10S/17152 6625-99-933 -1648	Test Set White Noise type S4/1
TF 1226B	Noise Generator	10S/17159 6625-99-933 -1649	Generator Thermal Noise type S2/1
TF 1225A	Receiver	10S/17160 6625-99-933	Receiver Noise type S4/1

<u>Type Number</u>	<u>Description</u>	<u>Reference Number</u>	<u>Designation</u>
TM 5774/1	Band Stop Filter Unit (Fitted with TM 5842, 3, 4 5, 6 & 7)	5915-99-933 -1105	
Filters for OA 1249B:-			
TM 5835/1	552 Kc/s Low Pass Filter	5915-99-933 -1088	Filter, Low Pass
TM 5836/1	1052 Kc/s Low Pass Filter	5915-99-933 -1090	Filter, Low Pass
TM 5832/1	108 Kc/s Low Pass Filter	5915-99-933 -1091	Filter, Low Pass
TM 5833/1	204 Kc/s Low Pass Filter	5915-99-933 -1092	Filter, Low Pass
TM 5840	60 Kc/s High Pass Filter	5915-99-933 -1093	Filter, High Pass
TF 1258/1	V.H.F. Spectrum Analyser	AP.172036	Monitor Unit
TF 1258A/1	" " "	AP.172036A	Monitor Unit Des.45
TM 5735	E.H.T. Transformer Assembly	AP.172047	(Part of TM 5679)
TM 5573/2	Attenuator	AP.189001	
TM 5751	Reactor	AP.184025	
TF 1262	U.H.F. Millivoltmeter	6625-99-933 -1106	Voltmeter
TF 1267	Transmission Test Set	10S/17675 6625-99-944 -7669	Test Set Transmission Line
TF 1269	Tone Source	10S/17165	Generator Signal type S3/1
TF 1270	H.F. Wave Analyser	10S/19 6625-99-944- 7670	Analyser Spectrum
TF 1278/1	T.W.T. Amplifier	10U/17356	Amplifier R.F. S-Band S3/1
TF 1289	V.S.W.R. Indicator	10S/17158	Indicator Standing Wave Ratio type S3/1
TF 1341/1S	Dummy Load R.F.	5985-AP.186178	Dummy Load R.F.
TF 1343A/1S	'X' Band Signal Generator	4935-99-946 - 1354	Generator Signal
TF 1343A/5SML	" " "	6625-99-952 -5091	Generator Noise
TF 1345/2	10 Mc/s Electronic Counter	10AP/777	Counter Frequency Electronic

<u>Type Number</u>	<u>Description</u>	<u>Reference Number</u>	<u>Designation</u>
TF 1348	Test Sets Ignition	Z4/ZD/03007	Test Set Ignition CR No. 2 Equipments
TF 1349	Secondary Surveillance Radar Test Set	10S/CA.486	Test Set 506
TF 1370	Wide Range R.C. Oscillator	6625-99-944 -9754	Signal Generator
TF 1370A	" " " "	6625-99-104 -7574	Signal Generator
TM 6221	Unbal. to Bal. Transformer	10ZZ/202133	Connecting Adaptor
TF 1400S	Double Pulse Generator	6625-99-580 -1364	Generator Pulse CT.434
TF 1400/2S	Double Pulse Generator	6625-99-944 -1474	Generator Pulse CT.434A Set
TF 1400/3S	Double Pulse Generator	6625-99-948 -3511	Generator Pulse CT.434A
TM 6600S	Secondary Pulse Generator (Part of TF 1400S, /3S & /2S)	6625-99-580 -1365	Generator Pulse Sub Assembly
TM 6666	50 ohm. Combining Unit (Supplied with TF 1400/2S)	6625-99-102 -8029	Combining Unit
TF 1417/2	Counter Frequency Meter	6625-99-933 -1822	Counter Electronic Frequency
TF 1434/2	Counter, Electronic Range Extender	6625-99-933 -1823	Counter, Electronic Frequency Range Extender
TF 1434/2 Plug-ins:-			
TM 5951	Frequency Converter 10-100 Mc/s	10D/23537 6625-99-933 -1884	Converter, Frequency Electronic
TM 5952	Frequency Converter 100-220 Mc/s	10ZZ/202116 6625-99-954 -5433	Converter, Frequency Electronic
OA 1430	R.F. Radiation Power Meter comprising:-	6625-99-947 -0570	Meter R.F. Radiation Power CT.477 Set
(TF 1396A	Radiation Hazard Monitor	6625-99-945 -4292	R.F. Radiation Hazard Monitor
(TM 6795	"X" Band Aerial	6625-99-945 -4293	
(TM 6795/1	"S" Band Aerial	6625-99-945 -4294	
(TM 6795/2	"L" Band Aerial	6625-99-945 -4295	

<u>Type Number</u>	<u>Description</u>	<u>Reference Number</u>	<u>Designation</u>
(TM 7103/1	Coupler Aerial (S Band)	6625-99-946 -9511	
(TM 7103	Coupler Aerial (X Band)	6625-99-946 -9512	
(TM 7112	Carrying Case	6625-99-944 -9199	
TF 2000	A.F. Signal Source	5845-99-923 -7246	Oscillator, Audio Frequency
TF 2002	MF/HF A.M. Signal Generator with Standard Accessories	6625-99-104 -6709	Signal Generator Set
TF 2002	MF/HF A.M. Signal Generator less Standard Accessories	6625-99-104 -6708	Generator, Signal
TF 2005R	A.F. Two Tone Signal Source	6625-99-952 -0447	Signal Generator Assembly
OA 2090	White Noise Test Set	10ZZ/202985 6625-99-955 -7835	Noise Generator Set
TF 2162	M.F. Attenuator	5905-99-972 -0856	Attenuator Variable, CT.532
TF 2163S	U.H.F. Attenuator	6625-99-519 -9976	Attenuator CT.553.
TF 2200A	Oscilloscope with Dual Trace Unit TM 6456A	6625-99-955 -0876	Oscilloscope Set
TF 2300	F.M. Modulation Meter	10ZZ/203220	
TF 2330	Wave Analyser	6625-99-972 -4355	Analyser, Spectrum
TF 2331	Distortion Factor Meter	10ZZ/203282	
TF 2332	A.F. Transmission Test Set	6625-99-519 -7952	Measuring Set A.F. Transmission.
TF 2333	M.F. Transmission Test Set	10ZZ/202906 6625-99-933 -3719	Test Set Transmission Line
TF 2400/1	Converter 10-510 Mc/s	6625-99-104 -5121	Converter, Frequency Electronic
(TF 2400	comprising:- Converter 10-110 Mc/s	6625-99-103 -3677	Converter, Frequency Electronic
(TM 7164	500 Mc/s Converter	6625-99-103 -3678	Converter, Frequency
TF 2600	Sensitive Valve Voltmeter (less accessories)	10ZZ/202128 6625-99-103 -3116	Voltmeter Electronic

<u>Type Number</u>	<u>Description</u>	<u>Reference Number</u>	<u>Designation</u>
TF 2600	Accessory Kit comprising:-	6625-99-106 -4406	Accessory Kit Electronic Voltmeter
GE 51002	Shielded Adaptor (2)	5935-99-105 -1562	Plug Assy. Electrical
TM 4726/282	Connector	6625-99-106 -2360	Lead Test
TM 4726/283	Connector	6625-99-106 -2361	Cable Assy. R.F.
TM 8120/1	Probe	6625-99-108 -3765	Probe Test
TF 2600 Optional Accessory:-			
GE 51001	Shielded Adaptor (Twin terminals to type 83)	5935-99-105 -1561	Plug Assy. Electrical.
TF 2600/S	Sensitive Valve Voltmeter less Accessories	6625-99-105 -8030	Voltmeter, Electronic
TF 2600/S	Sensitive Valve Voltmeter with Standard Accessories	6625-99-106 -1341	Voltmeter Set, Electronic.
TF 2700	Universal Bridge	6625-99-104 -3861	Impedance Bridge
TF 2701	In Situ Universal Bridge	6625-99-104 -8297	Bridge Set Universal

INDEX : Type Number

<u>Catalogue, Vocab. or Pattern Number</u>	<u>M.I. Type Number</u>	<u>Catalogue, Vocab. or Pattern Number</u>	<u>M.I. Type Number</u>
AP 53920B	TF 828/2	CT 218	TF 937
AP 54705	TF 390G	CT 219	TF 934/3
AP 54706	TF 390G	CT 320	TF 937/1
AP 54708	TF 340	CT 320A	TF 937A
AP 60832	TF 1035	CT 394	TF 801B/3
AP 60833	TF 1037	CT 394A	TF 801D/1S
AP 62274	TF 1048	CT 401	TF 1205S
AP 67102	TF 1030	CT 402	TF 995A/3S
AP 100321	TF 338B	CT 403	TF 1020A/1
AP 103480	TF 1143	CT 417	TF 1020A
AP 103481	TF 1143	CT 418	TF 1152A
AP 103530	TF 1167	CT 419	TF 1152A/1
AP 103531	TF 1167	CT 421	TF 1073A/2S
AP 103540	OA 1094	CT 429	TF 1041B
AP 103544	TM 5606	CT 434	TF 1400/S
AP 104390	TF 1073	CT 434A	TF 1400/3S
AP 172036	TF 1258/1	CT 452	TF 144H/S
AP 172036A	TF 1258A/1	CT 452A	TF 144H/4S
AP 172047	TM 5735	CT 477	OA 1430
AP 184025	TM 5751	CT 532	TF 2162
AP 189001	TM 5573/2	CT 553	TF 2163/S
AP 1034804/1	TF 1143		
AP 1035304/1	TF 1167	WD/3890	TF 329G/1
AP 5806736	TF 1099/3S	WD/3941	TF 948
AP 5806737	OA 1094A/S	WD/4024	TF 329G/1
AP 9475358	TM 6448		
		WY 0001	TF 756
CT 43	TF 936	WY 0010	TF 229D
CT 44	TF 938	WY 0013	TF 301C/1
CT 45	TF 934	WY 0025	TF 465
CT 90	TF 942	WY 0040	TF 329B-F
CT 117	TF 1032	WY 0047	TF 195L
CT 118	TF 1030	WY 0059	TF 340
CT 152	TF 1035	WY 0062	TF 144G
CT 162	TF 1037	WY 0063	TF 144F
CT 205	TF 960	WY 0065	TF 517F/1
CT 207	TF 1053	WY 0066	OA 161
CT 208	TF 958	WY 0069	TF 390G
CT 211	TF 957	WY 0070	TF 390F

<u>Catalogue, Vocab. or Pattern Number</u>	<u>M.I. Type Number</u>	<u>Catalogue, Vocab. or Pattern Number</u>	<u>M.I. Type Number</u>
WY 0099	TF 712	10AF/773	TM 5033A
WY 0104	TF 643	10AF/777	TF 1345/2
WY 0137	TF 517F/1		
WY 0207	TF 675B	10B/918	TF 660
WY 0208	TF 390G/7		
WY 0213	TF 428B	10D/20582	TF 1279
WY 0216	OA 161A	10D/23402	TF 1102
WY 0266	OA 161B	10D/23537	TM 5951
WY 0267	TF 643A		
WY 0268	TF 144G	10DB/50	TF 726
WY 0282	TF 329G	10DB/500	OA 164
WY 0303	TF 724	10DB/1285	OA 164A
WY 0564	OA 161D		
WY 0621	TF 712A	10D/CA/672	TME 2
WY 1012	TF 720A		
WY 2129	TF 701	10K/20866	TF 1147
WY 2295	TF 675D		
WY 2527	TF 373D	10KB/364	TF 728
WY 3180	TF 390G	10KB/625	TF 736A
Z4/LDM/31111	TF 1159	10KF/532	OA 175
Z4/ZD.00193	TF 934		
Z4/ZD.00254	TF 936	10L/280	TM 5478
Z4/ZD.00279	TF 801A	10L/16062	TF 338B
Z4/ZD.00322	TF 885	10L/16559	TF 338C
Z4/ZD.00388	TF 643B	10L/16832	TF 1073A
Z4/ZD.00391	TF 144G		
Z4/ZD.00657	TF 958	10PB/35	TF 725
Z4/ZD.00747	TF 957		
Z4/ZD.01094	TF 942	10RB/10	TF 727
Z4/ZD.01833	TF 928		
Z4/ZD.02066	TF 885A	10S/NIV/57	TF 1073
Z4/ZD.02417	TF 938	10S/NIV/238	TF 1107
Z4/ZD.02674	TF 937/1	10S/NIV/569	TF 1041A
Z4/ZD.02762	TF 885A/1	10S/NIV/598	TF 1106/4
Z4/ZD.03007	TF 1348	10S/NIV/985	TF 1060
Z4/ZD.03015	TF 960	10S/NIV/1047	TF 1270
Z4/ZD.03340	TF 1032	10S/NIV/1095	TF 1104
Z4/ZD.04302	TF 995A/3S	10S/NIV/1633	TF 1020A/3
Z4/ZD.04977	TF 1067/1	10S/NIV/1829	TF 1099/2
Z4/ZD.05539	TF 1167		

<u>Catalogue, Vocab. or Pattern Number</u>	<u>M.I. Type Number</u>	<u>Catalogue, Vocab. or Pattern Number</u>	<u>M.I. Type Number</u>
10S/65	TF 390G	10S/16370	TF 801A/1
10S/66	TF 390G	10S/16383	TF 640B/2
10S/72	TF 410B & C	10S/16392	TF 867
10S/73	TF 602A	10S/16410	TF 1047
10S/74	TF 142E	10S/16420	TF 888
10S/108	TF 202E	10S/16442	TF 640B/3
10S/558	TME 18	10S/16446	TF 885A
10S/637	TF 390G/7	10S/16499	TF 885A/1
10S/638	TF 615D	10S/16549	TF 1168
10S/647	TF 144G/4	10S/16727	TF 899
10S/695	TF 144G/6	10S/16747	TF 893A
10S/804	TF 791B	10S/16749	TF 1167
10S/822	TF 428B	10S/16780	TF 937
10S/01831	TF 934	10S/16786	TF 934/3
10S/02367	TF 942	10S/16813	TF 801B
10S/11933	TF 144G	10S/16818	TF 995A/1
10S/11934	TF 340	10S/16819	TF 912A
10S/11935	TF 428B/1	10S/16820	TF 1020A/1
10S/11936	TF 373D	10S/16822	TF 144G/4
10S/11937	TF 329F	10S/16823	TF 144G/6
10S/11942	TF 620/1	10S/16825	OA 1074
10S/11967	TF 301D/1	10S/16826	TF 1156
10S/12049	TF 640A	10S/16827	TF 1155
10S/13000	TF 390G	10S/16846	TF 1205S
10S/13002	TF 640B	10S/16963	TF 912A/1
10S/13036	TF 640B/1	10S/17045	TF 1160
10S/16046	TF 841	10S/17050	TF 1041B
10S/16147	TF 984/1	10S/17103	TF 890A/2
10S/16149	TF 987/1	10S/17130	TF 1202A
10S/16157	TF 1009	10S/17133	TM 5032
10S/16159	TF 1015	10S/17134	TF 801D/2S
10S/16162	TF 999/1	10S/17141	OA 1094
10S/16201	TF 455D/1	10S/17152	OA 1249B
10S/16202	TME 20B/1	10S/17158	TF 1289
10S/16203	TF 562A/1	10S/17159	TF 1226B
10S/16213	TF 468A	10S/17160	TF 1225A
10S/16214	TF 468A/1	10S/17161	TM 5774
10S/16301	TF 301E	10S/17163	TM 6231
10S/16320	TF 329G	10S/17164	TM 6215
10S/16341	TF 868/1	10S/17165	TF 1269
10S/16342	TF 868		

<u>Catalogue, Vocab. or Pattern Number</u>	<u>M.I. Type Number</u>	<u>Catalogue, Vocab. or Pattern Number</u>	<u>M.I. Type Number</u>
10S/17379	TF 1147	10T/700	TF 1157
10S/17504	TF 894A	10T/9143	TF 697
10S/17508	TF 1100	10T/13012	TF 684D
10S/17509	TF 890A/4	10T/13029	TF 783
10S/17513	TF 1153/1	10T/13030	TF 783/1
10S/17625	TF 995A/2	10T/13125	TF 1026/6
10S/17626	TF 995A/2M	10T/13126	TF 975
10S/17639	TF 142F		
10S/17675	TF 1267	10U/17356	TF 1278/1
10S/17702	TF 675F/1		
10S/17703	TF 1101	10V/150	TF 758
10S/17712	TM 5582	10V/679	TF 1154
10S/17746	TF 455E	10V/11940	TF 195M
10S/17781	TF 801A/1B		
10S/17798	TF 675F	10VB/77	TF 735A
10S/9522040	TM 6221		
		10ZZ/201641	TF 791D
10S/CA/486	TF 1349	10ZZ/202116	TM 5952
		10ZZ/202128	TF 2600
10SB/13	TF 390F/3	10ZZ/202133	TM 6221
10SB/17	TF 390F/4	10ZZ/202135	TF 1168/3M1
10SB/95	TF 517E	10ZZ/202272	TF 1065A
10SB/118	OA 167A	10ZZ/202377	TF 1064B/5
10SB/122	TF 796	10ZZ/202435	TM 6448/1M1
10SB/150	TF 517E/10	10ZZ/202618	TF 1245
10SB/151	TF 742A	10ZZ/202619	TF 1246
10SB/189	TF 517F/1	10ZZ/202759	TF 1020A/4M1
10SB/215	TF 762A	10ZZ/202906	TF 2333
10SB/1961	TF 737A	10ZZ/202985	OA 2090
10SB/6008	OA 175A	10ZZ/202999	TF 1066B/6
		10ZZ/203220	TF 2300
10T/5	TF 684B	10ZZ/203282	TF 2331
10T/33	TME 1		
10T/46	TF 558B	4935-990946-1354	TF 1343A/1S
10T/79	TF 803	5845-99-923-7246	TF 2000
10T/82	TF 696		
10T/83	TF 729	5905-99-580-0002	TF 338C
10T/94	TF 732	5905-99-580-0510	TM 5573
10T/100	TF 684C	5905-99-580-0511	TM 6599
10T/546	TF 805	5905-99-951-4231	TM 4919/1

<u>Catalogue, Vocab. or Pattern Number</u>	<u>M.I. Type Number</u>	<u>Catalogue, Vocab. or Pattern Number</u>	<u>M.I. Type Number</u>
5905-99-972-8901	TM 5548	6625-99-106-0902	TF 1066B/6S
5915-99-933-1088	TM 5835/1	6625-99-106-1189	TF 301D/9S
5915-99-933-1090	TM 5836/1	6625-99-106-1341	TF 2600/S
5915-99-933-1091	TM 5832/1	6625-99-106-2360	TM 4726/282
5915-99-933-1092	TM 5833/1	6625-99-106-2361	TM 4726/283
5915-99-933-1093	TM 5840	6625-99-106-4406	TF 2600
5915-99-933-1105	TM 5774/1	6625-99-106-5334	TF 2600
5920-99-932-4381	TM 5753	6625-99-108-3765	TM 8120/1
5935-99-105-1561	GE 51001	6625-99-519-4482	TF 801D/8S
5935-99-105-1562	GE 51002	6625-99-519-7952	TF 2332
5985/AP 186178	TF 1341/1S	6625-99-519-9976	TF 2163/S
5995-99-580-0512	TM 4726/152	6625-99-580-1364	TF 1400S
5995-99-580-0513	TM 4969/3	6625-99-580-1365	TM 6600S
5995-99-972-8882	TM 4824/2	6625-99-580-6581	TF 144H/4S
5995-99-972-8883	TM 5599	6625-99-580-6736	TF 1099/3S
5995-99-972-8884	TM 4824/1	6625-99-580-6737	OA 1094A/S
6130-99-949-3167	TF 1167	6625-99-900-8337	TF 144H/6S
6625-105932	OA 199A/2	6625-99-901-8750	TF 885A/1
6625/AP.106210	TME 20B/1	6625-99-901-9983	TF 801D/2S
6625/AP.106211	TF 562B/2	6625-99-913-1189	TF 1026/3
6625-99-101-9916	TF 1152A	6625-99-913-1420	TF 144H/2S
6625-99-102-8029	TM 6666	6625-99-913-9843	TM 6123
6625-99-102-8077	TF 937A	6625-99-914-9811	TF 893A
6625-99-102-9126	TF 1168/3M1	6625-99-932-4976	TF 885A/1
6625-99-103-1073	TF 1247	6625-99-933-1085	TF 1026/1
6625-99-103-1083	TF 1245	6625-99-933-1106	TF 1262
6625-99-103-3116	TF 2600	6625-99-933-1648	OA 1249B
6625-99-103-3677	TF 2400	6625-99-933-1649	TF 1226B
6625-99-103-3678	TM 7164	6625-99-933-1650	TF 1225A
6625-99-103-5187	TF 1246	6625-99-933-1700	TF 1026/6
6625-99-103-5240	TM 4520	6625-99-933-1822	TF 1417/2
6625-99-103-6633	TF 995A/3S	6625-99-933-1823	TF 1434/2
6625-99-103-9281	TF 1060/3S	6625-99-933-1884	TM 5951
6625-99-104-3144	OA 1094A/1S	6625-99-933-3452	TF 1167
6625-99-104-3861	TF 2700	6625-99-933-3719	TF 2333
6625-99-104-5017	TF 1099/3S	6625-99-942-9868	TF 1090
6625-99-104-5121	TF 2400/1	6625-99-943-2416	TF 1040
6625-99-104-6708	TF 2002	6625-99-943-3249	TF 1053
6625-99-104-6709	TF 2002	6625-99-943-3266	TF 1048
6625-99-104-7090	TM 4726/272	6625-99-943-3267	TF 1049
6625-99-104-7574	TF 1370A	6625-99-943-3486	TM 4917