




CS-1012 SCHEMATIC DIAGRAM







NL 1, 2
 D117
 D6, 7, 116, 123
 D4, 5
 D1, 2, 8, 9, 10, 103 ~ 111, 112, 120, 121, 124, 125
 D1, 2, 8, 9, 10, 103 ~ 111, 112, 120, 121, 124, 125
 Q107 ~ 112, 121 ~ 123, 131
 Q101, 102, 115, 130
 Q5
 Q4, 103 ~ 106, 113, 114
 Q3
 Q2, 125
 Q1, 124, 127
 U103
 U102
 U101
 U1
 (X74-1340-03)
 Z-AXIS
 CRT SOCKET (X81-1250-01)
 CRT 1506T M31

VERTICAL AMP & POWER UNIT (X73-1490-03)

CS-1010 SCHEMATIC DIAGRAM

