


ILLUSTRATION BOOKLET


Part of 595-2969-02


PARTS PICTORIAL




















Copyright © 1983
Heath Company
All Rights Reserved


Model HM-2140-A Printed in the United States of America



D4
D5
E1
E2
E3
E4
E5
E6
E7
E8
E9
E10
F1
F2
F3
F4
F5
F6
G1
G2
G3
G4
OR


PARTS PICTORIAL (CONT'D)




























PICTORIAL 1-7




PICTORIAL 1-8




PICTORIAL 2-1




PICTORIAL 2-2



PICTORIAL 3-1




PICTORIAL 3-2




PICTORIAL 4-1


SENSOR REMOTE MOUNTING




PICTORIAL 4-2



PICTORIAL 5-1



PICTORIAL 5-2



S W R CALCULATOR

PICTORIAL 5-4


CIRCUIT BOARD X-RAY VIEWS

NOTE: To find the PART NUMBER of a component for the purpose of ordering a replacement part:

A. Find the circuit component number (R7, C3, etc.) on the "Circuit Board X-Ray View."


B. Locate this same number in the "Circuit Component Number" column of the "Parts List."

C. Adjacent to the circuit component number, you will find the PART NUMBER and DESCRIPTION, which must be supplied when you order a replacement part.



SENSOR CIRCUIT BOARD*
Shown from Component Side

*NOTE: This circuit board is inside the sealed Remote Sensor assembly. To tamper with the assembly or circuit board may void the Warranty.



SWITCH CIRCUIT BOARD

Shown from Component Side