


HP NetServer E60 Technical Reference Card

HP Product No. D7140-80200 Rev. D

A Cabinet/Front LEDs




B Mass Storage Device Locations and Settings

Device	Location in order of recommendation	Device Settings
Standard Hard Disk Drive (Model 9.1 GB)	Shelf 4	SCSI ID 0 [Default]
HP Accessory 4.2 GB HDD or HP Accessory 9.1 GB HDD or HP Accessory 18.2 GB HDD	Shelf 5, 6, 7	For Additional HDD, Set to Unused SCSI ID
HP SureStore T20i	Shelf 3	SCSI ID 4 [Default]
HP SureStore DAT 8i or 24i	Shelf 3	SCSI ID 2 [Default]
Standard SCSI Controller	Embedded	SCSI ID 7
Standard IDE CD-ROM	Shelf 2	Set to Master [Default]

See documentation with each device for further configuration information.


C System Board




HP NetServer E60 Technical Reference Card

HP Product No. D7140-80200 Rev. D

D Mass Storage Cabling/Rear LEDs



E Power Cabling



F Service Information

Electronic Support Services

- Internet Web Pages <http://www.hp.com/netserver>
- Internet FTP <ftp://ftp.netserver.hp.com>
- CompuServe Library GO HPCC
- HP Navigator CD

Support Questions

- HP-Authorized Reseller
- CompuServe Discussion Forum GO HPCC
- US / Canada Phone Support 1-208-331-2767
- Europe Phone Support (+31-20) 581-3330 (Netherlands)


HP has offices in over 100 countries. Check your local telephone directory.

Optional HP 3 Year On-Site Support Pack

- H5525A Next Business Day
- H5517A Same Business Day
- H5512A 7 day/24 hour

G Tips for Removing the System Board

- Unplug Power, Remove Cover
- Retract Feet, Lay Unit on Right Side
- Swing Air Duct Open
- Disconnect All Cables from System Board
- Take out CPUs (If Only One CPU Present, Also Remove Terminator from Second Slot)
- Take out Video Card and All PCI or ISA Cards
- Remove All 11 Screws (See Illustration)
- Grasp and Unsnap the Snaps at Corners Opposite Back Panel
- Swing Edge Opposite Back Panel Outward
- Slide Board Out Carefully



Key to Mounting Screws

- Visible when Cables and Processors have been Removed.
- Not visible when Processor Installed.

Note: For complete instructions, see the Information Assistant on the HP Documentation CD-ROM.

Audience Assumptions

This Technical Reference Card is for trained service personnel. Hewlett-Packard Company assumes you are qualified in the servicing of computer equipment and trained in recognizing hazards in products with hazardous energy levels.

Electrostatic Discharge

To avoid catastrophic or hidden damage to components, wear a wrist strap and use a static-dissipative work surface connected to the chassis when handling components. Use an antistatic service kit, such as 3M 8501/8502/8505 or equivalent.

This information is subject to change without notice and is provided without warranty.

© Copyright 1999. Hewlett-Packard Company

For additional information, see other side.