

Between Series Adaptor

Between Series Adaptors are widely used for high efficiency transitions between various types of RF connectors.


They are used for connecting test equipment to systems employing a different type connector, or they are used as a component in electronic equipment where it is desirable to have one type of connector for external connections and another type for internal connections.



Between Series Adaptor


BNC Plug To RCA Jack Adaptor

- Part Number : **AD1-9001**
- Impedance : 50



BNC Jack To RCA Plug Adaptor


- Part Number : **AD1-9007**
- Impedance : 50



F Plug To RCA Jack Adaptor

■ Part Number : **AD1-9008**


■ Impedance : 50



BNC Jack To F Plug Adaptor

■ Part Number : **AD1-9009**

■ Impedance : 50




Between Series
Adaptor

SMA Jack To TNC Plug Adaptor

■ Part Number : **AD1-9013**


■ Impedance : 50



SMA Plug To BNC Jack Adaptor

■ Part Number : **AD1-9016**


■ Impedance : **50**



SMA Plug To TNC Jack Adaptor

■ Part Number : **AD1-9017**


■ Impedance : **50**



SMA Jack To BNC Plug Adaptor

■ Part Number : **AD1-9030**


■ Impedance : **50**



SMA Jack To N Jack Bulkhead Adaptor

■ Part Number : **AD1-9036**


■ Impedance : 50



N Plug To BNC Jack Adaptor

■ Part Number : **AD1-9045**


■ Impedance : 50



SMB Jack To N Jack Adaptor

■ Part Number : **AD1-9052**


■ Impedance : 50



SMA Plug To BNC Plug Adaptor

■ Part Number : **AD1-9054**


■ Impedance : 50



SMA Jack To BNC Plug Adaptor

■ Part Number : **AD1-9055**


■ Impedance : 50



SMA Jack To BNC Jack Adaptor

■ Part Number : **AD1-9056**


■ Impedance : 50



SMA Jack To N Plug Adaptor

■ Part Number : **AD1-9057**


■ Impedance : 50



SMA Plug To N Plug Adaptor

■ Part Number : **AD1-9059**

■ Impedance : 50




Between Series
Adaptor

N Jack To BNC Plug Adaptor


■ Part Number : **AD1-9060**

■ Impedance : 50




SMA Plug To SMB Jack Adaptor

- Part Number : **AD1-9068**
- Impedance : 50




SMA Jack To SMB Jack Adaptor

- Part Number : **AD1-9069**
- Impedance : 50




SMA Jack To SMB Plug Adaptor

- Part Number : **AD1-9070**
- Impedance : 50




SMA Plug To N Jack Adaptor

- Part Number : **AD1-9075**
- Impedance : **50**



SMA Jack To MMCX Jack Adaptor


- Part Number : **AD1-9078**
- Impedance : **50**



Between Series
Adaptor

SMA Jack To MCX Jack Adaptor

- Part Number : **AD1-9095**
- Impedance : **50**




Between Series Adaptor

F Jack To N Plug Adaptor

■ Part Number : **AD1-9097**


■ Impedance : 50



BNC Jack To SMB Plug Adaptor

■ Part Number : **AD1-9103**

■ Impedance : 50



SMA Plug To SMB Plug Adaptor

■ Part Number : **AD1-9105**

■ Impedance : 50

