


Between Series Adaptor-RP

SMA Plug RP To TNC RP Jack Adaptor

■ Part Number : **AD1-9066-RP**


■ Impedance : 50



SMA Plug RP To N Jack Adaptor

■ Part Number : **AD1-9074-RP**

■ Impedance : 50




Between Series
Adaptor-RP

SMA Jack RP To BNC Jack Adaptor

■ Part Number : **AD1-9077-RP**


■ Impedance : 50



Between Series Adaptor-RP


SMA Jack RP To MCX Plug Adaptor

- Part Number : **AD1-9081-RP**
- Impedance : 50




SMA Jack RP To TNC RP Plug Adaptor

- Part Number : **AD1-9082-RP**
- Impedance : 50



SMA Plug RP To N Plug Adaptor


- Part Number : **AD1-9083-RP**
- Impedance : 50



SMA Jack RP To N Plug Adaptor

■ Part Number : **AD1-9086-RP**


■ Impedance : 50



SMA Jack To TNC Jack RP Adaptor

■ Part Number : **AD1-9089-RP**

■ Impedance : 50




Between Series
Adaptor-RP

SMA Jack RP To TNC Plug Adaptor

■ Part Number : **AD1-9090-RP**


■ Impedance : 50



Between Series Adaptor-RP


SMA Jack RP To N Jack Adaptor

- Part Number : **AD1-9092-RP**
- Impedance : 50




N Jack RP To SMA Jack Adaptor

- Part Number : **AD1-9094-RP**
- Impedance : 50



SMA Jack RP To MMCX Jack RP Adaptor


- Part Number : **AD1-9096-RP**
- Impedance : 50



N Plug To TNC Plug RP Adaptor

■ Part Number : **AD1-9100-RP**


■ Impedance : 50



N Jack To TNC Plug RP Adaptor

■ Part Number : **AD1-9101-RP**

■ Impedance : 50



Between Series
Adaptor-RP

N Plug To TNC Jack RP Adaptor

■ Part Number : **AD1-9102-RP**

■ Impedance : 50

