## **Assembly instruction**

## Series 71Z

В


Cable Feed-Through, crimped

Crimp insert:

AA 08.01.97 No. 3081

Suitable cables e.g.	RG 213/U RG 214/U	RG 59 RG 04233	RG 58 RG 223	
Centre contact:				

D




TYPES	Х	CABLES	CRIMP INSERT
71Z 0-7-7 71Z 0-7-8	10 10	RG 213/U RG 214/U	D D
71Z 0-4-8 71Z 0-4-9	8	RG 59 G 04233d	C
71Z 0-4-9 71Z 0-3-13	8	RG 58	B
71Z 0-3-14	8	RG 223	В


Length of Y+Z as required

C

Ferrule A on cable. Prepare cable according to diagram. Length Y + Z as required. Do not damage inner conductor of cable, braid and dielectric.



Splay out braid, and insert cable in connector body B. Ensure that braid lies above the crimp neck.



Slide ferrule A over braid and crimp as close to connector body B as possible. (Crimp insert: B, C or D).



HUBER + SUHNER Ltd. CH-9100 HERISAU Switzerland