

CROSS-REFERENCE LIST

SUHNER TYPE TO NATO NUMBER

<u>Suhner Code No.</u>	<u>Equivalent NATO STOCK No. 5935-99-</u>
11 BNC-50-3-3	199-0847
11 BNC 50-3-4	199-0845
11 BNC-50-3-10c	945-9134
11 BNC-50-3-12	940-3187
11 BNC-50-3-27	119-6857
11 BNC-50-4-4	199-0846
11 BNC-50-7-2c	115-8987
11 BNC-75-3-3c	950-4271
11 BNC-75-4-1	580-9636
11 BNC-75-4-3c	580-1774
11 BNC-75-4-4	114-2638
12 BNC-50-0-1	622-6388
12 BNC-75-0-1	519-0818
13 BNC-50-0-2	620-0446
13 BNC-75-0-2	620-0448
16 BNC-50-3-1c	104-7930
16 BNC-75-4-1c	913-3610
16 BNC-75-4-2c	522-9985
16 BNC-75-4-3c	195-6033
21 BNC-50-3-5c	952-9775
21 BNC-50-3-16c	119-6855
21 BNC-50-4-1c	117-7057
21 BNC-50-4-3	439-8784
21 BNC-75-3-1	911-3612
21 BNC-75-4-3c	439-8778
21 BNC-75-4-4c	117-7058

DEVERELL ASSOCIATES
WELLINGTON
REG. - 4 FEB 1974

<u>Suhner</u> <u>Code No.</u>	<u>Equivalent</u> <u>NATO STOCK No.</u> <u>5935-99-</u>
22 BNC-50-0-3	999-2429
22 BNC-50-0-9	932-3982
22 BNC-75-0-1	972-6826
22 BNC-75-0-4	519-1594
23 BNC-50-0-2	620-0447
23 BNC-50-0-6	913-2101
23 BNC-50-0-7	911-6872
23 BNC-75-0-1	911-3610
23 BNC-75-0-2	972-8073
24 BNC-50-3-1c	439-8777
24 BNC-50-3-2	114-7423
24 BNC-50-3-13c	119-6856
24 BNC-75-3-2c	523-6048
24 BNC-75-4-1	972-6827
24 BNC-75-4-2c	945-9813
25 BNC-50-2-1c	621-8006
25 BNC-50-3-2c	115-8452
25 BNC-50-3-3	911-6955
25 BNC-50-3-4	920-9079
25 BNC-50-3-6c	952-9759
25 BNC-50-3-10c	521-5465
25 BNC-50-4-4	439-8782
25 BNC-75-4-2c	522-9983
25 BNC-75-4-3	117-7958
25 BNC-75-4-4c	522-9984

<u>Suhner</u> <u>Code No.</u>	<u>Equivalent</u> <u>NATO STOCK No.</u> <u>5935-99-</u>
27 BNC-75-0-1	948-5768
31 BNC-50-0-1	199-0824
31 BNC-75-0-1	952-5118
32 BNC-50-0-1	199-0825
32 BNC-75-0-1	901-9317
34 BNC-50-0-1	521-3752
34 BNC-75-0-1	970-3623
37 BNC-75-0-1	914-3934
43 BNC-75-0-1	999-0974
46 BNC-50-0-1	519-3502
46 BNC-75-0-1	114-9263
53 BNC-75-0-1	914-7549
61 BNC-0-0-1	107-4095
62 BNC-0-0-2	103-7757
65 BNC-50-0-1	5985-99-622-6650
65 BNC-75-0-1	5915-99-522-6730

<u>Suhner</u> <u>Code No.</u>	<u>Equivalent</u> <u>NATO STOCK No.</u> <u>5935-99-</u>
31 BNC-C-75-1	199-0840
32 BNC-C-50-1	972-3763
32 BNC-C-75-1	199-0842
32 BNC-UHF-0-1	199-0837
33 BNC-A-0-1	199-5212
33 BNC-N-75-1	199-0841
33 BNC-UHF-0-1	199-0844
33 C-BNC-50-1	519-3528
33 C-BNC-75-1	199-0843
33 N-BNC-75-1	199-0836
33 TNC-BNC-50-1	622-3523

PATTERN 15

<u>Suhner</u> <u>Code No.</u>	<u>Equivalent</u> <u>NATO STOCK No.</u> <u>5935-99-</u>
11 BNC-50-3-21c	013-1601
11 BNC-50-3-24c	013-1600
11 BNC-50-4-13c	013-1602
11 BNC-50-4-14c	013-1603
11 BNC-50-4-15c	014-2868
21 BNC-50-3-7c	013-1596
21 BNC-50-3-8c	013-1597
21 BNC-50-4-9c	013-1598
21 BNC-50-4-10c	013-1599
21 BNC-50-4-11c	014-2867
23 BNC-50-0-14	013-1604

CROSS-REFERENCE LIST

SUHNER TYPE TO NATO NUMBER

<u>Suhner Code</u> <u>No.</u>	<u>Equivalent</u> <u>NATO STOCK No.</u> <u>5935-99-</u>
11 C-50-4-2c	618-7134
11 C-50-7-6c	523-8853
11 C-50-17-3c	111-5543
11 C-75-4-1c	521-9456
11 C-75-5-1c	521-5632
16 C-50-7-6	117-0053
16 C-50-9-1c	115-9787
16 C-75-3-2c	523-6050
16 C-75-4-2c	618-7132
21 C-50-5-2c	523-6045
21 C-50-7-1	199-0831
21 C-50-7-2c	970-2510
21 C-50-7-3	117-0050
21 C-50-7-4c	523-8854
21 C-75-5-1c	521-5633
21 C-75-7-1	580-1134
23 C-50-0-1	920-9029
24 C-50-7-3	117-0052
25 C-50-7-1	932-5853
25 C-50-7-3	117-0051
25 C-75-4-3	932-5596
25 C-75-7-1	932-5646
25 C-75-7-5	199-0830
31 C-50-0-1	580-1512
31 C-75-0-1	199-0827
37 C-50-0-2	580-6268
43 C-50-0	972-2384

<u>Suhner</u> <u>Code No.</u>	<u>Equivalent</u> <u>NATO STOCK No.</u> <u>5935-99-</u>
31 BNC-C-75-1	199-0840
32 BNC-C-50-1	972-3763
32 BNC-C-75-1	199-0842
33 BNC-UHF-O-1	199-0844
33 C-A-O-1	433-4182
33 C-BNC-50-1	519-3528
33 C-BNC-75-1	199-0843
33 C-TNC-50-1	117-1778
33 UHF-C-O-1	199-0839

CROSS-REFERENCE LIST

SUHNER TYPE TO NATO NUMBER

<u>Suhner</u> <u>Code No.</u>	<u>Equivalent</u> <u>NATO STOCK No.</u> <u>5935-99-</u>
11 H4-50-3-2c	626-2522
11 H4-50-4-1	626-3144
12 H4-50-0-1	618-8726
21 H4-50-3-1	626-2523
22 H4-50-0-1	618-8727
11 SMC-50-2-4c	117-7159
16 SC-50-7-2c/ GUK-UR67	223-0887
16 K-50-2-1c	117-7158
11 M-75-4-1c	111-4144

CROSS-REFERENCE LIST

SUHNER TYPE TO NATO NUMBER

<u>Suhner Code No.</u>	<u>Equivalent NATO STOCK No. 5935-99-</u>
11 N-50-3-1	433-4213
11 N-50-4-1	199-0833
11 N-50-5-3c	624-8597
11 N-50-17-1	111-5963
11 N-75-7-1	624-1449
11 N-75-7-7	580-3675
11 N-75-7-8c	439-8779
16 N-50-3-1c	523-6049
16 N-50-3-3c	618-7133
16 N-50-7-1c	199-0834
16 N-75-2-1c	523-2607
16 N-75-3-1c	523-6047
16 N-75-7-1c	523-6046
21 N-50-7-7	620-0577
23 N-50-0-1	117-0049
23 N-75-0-1	933-0599
25 N-75-4-2c	526-3441
31 N-50-0-1	933-0088
31 N-75-0-1	114-0379
34 N-50-0-1	433-4208
34 N-50-0-1.	624-9051

<u>Suhner</u> <u>Code No.</u>	<u>Equivalent</u> <u>NATO STOCK No.</u> <u>5935-99-</u>
37 N-50-0-1	199-0826
43 N-50-0-1	972-8894
46 N-50-0-1	954-6532
53 N-50-0-1	711-9709
65 N-75-0-1	5985-99-523-8379
33 BNC-N-75-1	199-0841
33 N-BNC-75-1	199-0836
33 N-TNC-50-1	115-8915
33 TNC-N-50-1	119-1517
33 UHF-N-0-1	199-0838

CROSS-REFERENCE LIST

SUHNER TYPE TO NATO NUMBER

<u>Suhner</u> <u>Code No.</u>	<u>Equivalent</u> <u>NATO STOCK No.</u> <u>5935-99-</u>
11 TNC-50-3-1	194-7468
11 TNC-50-3-9	110-6522
11 TNC-50-7-1c	111-8571
11 TNC-50-7-2c	117-1107
11 TNC-75-4-8c	526-0828
16 TNC-75-3-1c	618-7433
22 TNC-50-0-1	114-9033
23 TNC-50-0-2	110-6523
24 TNC-50-3-2	194-7470
31 TNC-50-0-1	223-6219
43 TNC-50-0-1	622-6677
62 TNC-0-0-1	194-7469
32 N-TNC-50-1	222-3283
33 C-TNC-50-1	117-1778
33 N-TNC-50-1	115-8915
33 TNC-A-0-1	433-4190
33 TNC-N-50-1	119-1517
33 TNC-BNC-50-1	622-3523

CROSS-REFERENCE LIST

SUHNER TYPE TO NATO NUMBER

<u>Suhner Code No.</u>	<u>Equivalent NATO STOCK No. 5935-99-</u>
11 UHF-0-4-2c	111-4141
11 UHF-0-7-2c	111-4142
23 UHF-0-0-1	932-5870
23 UHF-0-0-3	199-0835
31 UHF-0-0-1	971-7924
32 UHF-0-0-1	199-0828
43 UHF-0-0-1	971-9680
62 UHF-0-0-1	624-9536
32 BNC-UHF-0-1	199-0837
33 BNC-UHF-0-1	199-0844
33 UHF-C-0-1	199-0839
33 UHF-N-0-1	199-0838
GD 072	580-5122
LD 072	199-0829
RDa 07/04	111-4296

CROSS-REFERENCE LIST

SUHNER TYPE TO NATO NUMBER

TOOLS

<u>Suhner Code No.</u>	<u>Equivalent NATO STOCK No.</u>
75 Z-0-0-1	5120-99-619-3480
75 Z-0-3-1	5120-99-122-7629
75 Z-0-4-1	5120-99-122-7630
76 Z-0-4-1	5940-99-619-3507
76 Z-0-7-1	5940-99-619-3508

SUCOBX

66 CB-35-0-1	5820-99-620-0285
72 Z-0-0-5	3439-99-620-0286
71 Z-0-0-1	5940-99-526-3341

CABLES

96 IEC-50-3-5	6145-99-117-0959
TL.608-1	6145-99-110-5182