

Index of US Military Numbers to Suhner Numbers

US-MIL-Type	series	connector type	O.D. max. inches	Suhner Nr.
UG- 18 B/U	N	plug	.338	11N-50-5-4
UG- 18 E/U	N	plug	.338	11N-50-5-2
UG- 19 B/U	N	panel jack	.338	25N-50-5-3
UG- 19 E/U	N	panel jack	.338	25N-50-5-1
UG- 20 B/U	N	jack	.338	21N-50-5-3
UG- 20 E/U	N	jack	.338	21N-50-5-1
UG- 21 B/U	N	plug	.425	11N-50-7-9
UG- 21 G/U	N	plug	.445	11N-50-7-5
UG- 22 B/U	N	panel jack	.425	25N-50-7-1
UG- 22 F/U	N	panel jack	.445	25N-50-7-7
UG- 23 B/U	N	jack	.425	21N-50-7-1
UG- 23 F/U	N	jack	.445	21N-50-7-7
UG- 27 D/U	N	angle adapter		53N-50-0-1
UG- 28 A/U	N	T-adapter		46N-50-0-1
UG- 29 A/U	N	straight adapter		31N-50-0-1
UG- 29 B/U	N	straight adapter		31N-50-0-2
UG- 30 E/U	N	bulkhead adapter		34N-50-0-1
UG- 57 B/U	N	straight adapter		32N-50-0-1
UG- 58 A/U	N	panel receptacle		23N-50-0-1
UG- 83 B/U	UHF/N	between series		33UHF-N-0-1
UG- 88 B/U	BNC	plug	.209	11BNC-50-3-12
UG- 88 E/U	BNC	plug	.209	11BNC-50-3-3
UG- 89 A/U	BNC	jack	.209	21BNC-50-3-3
UG- 89 C/U	BNC	jack	.209	21BNC-50-3-4
UG- 91 A/U	N	plug	.338	11N-75-5-1
UG- 92 A/U	N	jack	.338	21N-75-5-1
UG- 93 A/U	N	panel jack	.338	25N-75-5-1
UG- 94 A/U	N	plug	.425	11N-75-7-7
UG- 95/U	N	jack	.425	21N-75-7-1
UG- 96 A/U	N	panel jack	.425	25N-75-7-1
UG- 102/U	UHF twin	plug	.414	GD 072
UG- 103/U	UHF twin	panel receptacle		CD 072
UG- 104/U	UHF twin	angle adapter		LD 072
UG- 105/U	UHF twin	straight adapter		VD 072
UG- 106/U	UHF, C, N	hood	.342	Ha 07
UG- 107 B/U	N	T-adapter		43N-50-0-1
UG- 111/U	UHF coax.	plug	.264	11UHF-0-4-6C
UG- 146 A/U	N/UHF	between series adapter		33N-UHF-0-1
UG- 154/U	LC	plug	.886	11LC-50-17-1
UG- 155/U	LC	straight adapter		31LC-50-0-1
UG- 159 A/U	N	bulkhead jack	.338	24N-50-5-4
UG- 159 C/U	N	bulkhead jack	.338	24N-50-5-2
UG- 160 D/U	N	bulkhead jack	.445	24N-50-7-7
UG- 167 F/U	N	plug	.886	11N-50-17-1
UG- 175/U	UHF coax.	reducing adapter	.209	RDa 07/03
UG- 176/U	UHF coax.	reducing adapter	.252	RD 07/04
UG- 177/U	UHF, C, N	hood	.153	H 03
UG- 196/U	UHF	T-adapter		TD 072
UG- 201 A/U	N/BNC	between series adapter		33N-BNC-50-1
UG- 203/U	UHF coax.	plug	.264	11UHF-0-4-7C
UG- 204 D/U	N	plug	.563	11N-50-9-2
UG- 223/U	UHF coax.	bulkhead receptacle		22UHF-0-0-1
UG- 224/U	UHF coax.			similar UG-363/U

Continued on following page

Index of US Military Numbers to Suhner Numbers Continued

US-MIL-Type	Series	Connector Type	O. D. max. inches	Suhner Nr.
UG- 231/U	N			similar UG-58 A/U
UG- 253/U	BNC			similar UG-909 B/U
UG- 255/U	BNC/UHF	between series adapter		33BNC-UHF-0-1
UG- 260 A/U	BNC	plug	.252	11BNC-50-4-8
UG- 260 D/U	BNC	plug	.252	11BNC-50-4-3
UG- 261 A/U	BNC	jack	.252	21BNC-50-4-2
UG- 261 C/U	BNC	jack	.252	21BNC-50-4-3
UG- 262 A/U	BNC	panel jack	.252	25BNC-50-4-2
UG- 262 C/U	BNC	panel jack	.252	25BNC-50-4-4
UG- 273/U	BNC/UHF	between series adapter		33UHF-BNC-0-1
UG- 274 B/U	BNC	T-adapter		43BNC-50-0-1
UG- 281/U	N			similar UG-1095 B/U
UG- 282 B/U	BNC/A	between series adapter		33BNC-A-0-1
UG- 287/U	LC	straight adapter		37LC-50-0-1
UG- 290 A/U	BNC	panel receptacle		23BNC-50-0-6
UG- 291/U	BNC	panel jack	.209	25BNC-50-3-3
UG- 291 C/U	BNC	panel jack	.209	25BNC-50-3-5
UG- 298/U	UHF coax.	T-adapter		43UHF-0-0-1
UG- 299/U	UHF coax.	straight adapter		31UHF-0-0-1
UG- 306 B/U	BNC	angle adapter		53BNC-50-0-1
UG- 318/U	N/UHF	between series adapter		33N-UHF-0-1
UG- 349 B/U	BNC/N	between series adapter		33BNC-N-50-1
UG- 352/U	LC	panel receptacle		23LC-50-0-1
UG- 363/U	UHF coax.	bulkhead adapter		34UHF-0-0-1
UG- 414 A/U	BNC	panel adapter		37BNC-50-0-1
UG- 447/U	BNC	panel receptacle		23BNC-50-0-7
UG- 491 B/U	BNC	straight adapter		32BNC-50-0-1
UG- 492 B/U	BNC	bulkhead adapter		34BNC-50-0-1
UG- 536 B/U	N	plug	.209	11N-50-3-1
UG- 556 B/U	N	bulkhead jack	.209	24N-50-3-1
UG- 564/U	N/C	between series adapter		33N-C-50-1
UG- 565 A/U	C/N	between series adapter		33C-N-50-1
UG- 567 A/U	C	angle adapter		53C-50-0-1
UG- 568/U	C	panel receptacle		23C-50-0-1
UG- 569 A/U	C	bulkhead receptacle		22C-50-0-3
UG- 570 A/U	C	bulkhead jack	.445	24C-50-7-3
UG- 571 A/U	C	panel jack	.445	25C-50-7-3
UG- 572 A/U	C	jack	.445	21C-50-7-3
UG- 573 B/U	C	plug	.445	11C-50-7-5
UG- 593 A/U	N	panel jack	.252	25N-50-4-1
UG- 594 B/U	N	angle plug	.445	16N-50-7-2C
UG- 602 A/U	N	jack	.252	21N-50-4-1
UG- 603 A/U	N	plug	.252	11N-50-4-1
UG- 606/U	BNC/N	between series adapter		31BNC-N-50-1
UG- 625 B/U	BNC	bulkhead receptacle		22BNC-50-0-4
UG- 626 B/U	C	plug	.338	11C-50-5-1
UG- 627 B/U	C	plug	.252	11C-50-4-1
UG- 628 B/U	H1	plug	.425	11H1-50-7-1
UG- 629 A/U	C	panel jack	.338	25C-50-5-1
UG- 630 A/U	C	bulkhead jack	.338	24C-50-5-1C
UG- 631 A/U	C	bulkhead jack	.252	24C-50-4-1C
UG- 632 A/U	H1	bulkhead jack	.425	24H1-50-7-1
UG- 633 A/U	C	jack	.338	21C-50-5-1
UG- 634/U	H1	bulkhead receptacle		22H1-50-0-1

Continued on following page

Index of US Military Numbers to Suhner Numbers Continued

US-MIL-Type	Series	Connector Type	O. D. max. inches	Suhner Nr.
UG- 635/U	BNC/C	between series adapter		33BNC-C-50-1
UG- 636 A/U	C/BNC	between series adapter		33C-BNC-50-1
UG- 637/U	UHF/C	between series adapter		33UHF-C-0-1
UG- 641/U	BNC/A	between series adapter		33BNC-A-0-1
UG- 642 A/U	C	straight adapter		32C-50-0-1
UG- 643/U	C	straight adapter		31C-50-0-1
UG- 646/U	UHF coax.	angle adapter		53UHF-0-0-1
UG- 657/U	BNC	bulkhead receptacle		22BNC-50-0-3
UG- 680 A/U	N	bulkhead receptacle		22N-50-0-2
UG- 701/U	C	bulkhead receptacle		34C-50-0-1
UG- 704 B/U	C	bulkhead jack	.209	24C-50-3-1C
UG- 705 A/U	C	bulkhead receptacle		similar UG-569 A/U
UG- 707 B/U	C	plug	.563	11C-50-9-2C
UG- 708 B/U	C	plug	.886	11C-50-17-2
UG- 709 B/U	C	plug	.209	11C-50-3-4
UG- 710 B/U	C	angle plug	.445	16C-50-7-6
UG- 909 B/U	BNC	bulkhead jack	.208	24BNC-50-3-2
UG- 910 B/U	BNC	bulkhead jack	.252	24BNC-50-4-2
UG- 912 A/U	BNC			similar UG-1094 A/U
UG- 913 A/U	BNC	angle plug	.209	16BNC-50-3-3
UG- 914/U	BNC	straight adapter		31BNC-50-0-1
UG- 931/U	H4	panel receptacle		23H4-50-0-2
UG- 932 A/U	H4	plug	.209	11H4-50-3-1
UG- 935 B/U	N	panel jack	.425	25N-50-7-5 with GK 103
UG- 936 B/U	N	bulkhead jack	.425	24N-50-7-5 with GK 103
UG- 937 A/U	C	bulkhead jack	.425	24C-50-7-4C with GK 103
UG- 938 A/U	C	panel jack	.425	25C-50-7-3 with GK 103
UG- 939 A/U	H1	bulkhead jack	.425	24H1-50-7-1 with GK 103
UG- 940 B/U	N	jack	.425	21N-50-7-7 with GK 103
UG- 941 B/U	N	plug	.425	11N-50-7-5 with GK 103
UG- 942 B/U	H1	plug	.425	11H1-50-7-1 with GK 103
UG- 943 B/U	C	plug	.425	11C-50-7-5 with GK 103
UG- 944 A/U	C	jack	.425	21C-50-7-3 with GK 103
UG- 945 B/U	C	angle plug	.425	16C-50-7-6 with GK 103
UG- 959 A/U	BNC	plug	.445	11BNC-50-7-2C
UG- 961 A/U	H4	panel jack	.252	25H4-50-4-1
UG- 982/U	N	plug	.886	11N-50-17-1 with GK 220
UG-1016 A/U	H4	jack	.252	21H4-50-4-1
UG-1034/U	BNC/N	between series adapter		32BNC-N-50-1
UG-1052/U	N			similar UG-1095 B/U
UG-1094 A/U	BNC	bulkhead receptacle		22BNC-50-0-5
UG-1095 B/U	N	panel jack	.209	25N-50-3-1
UG-1098 A/U	BNC			similar UG-1174/U
UG-1185 A/U	N	plug	.445	11N-50-7-6C
UG-1186 A/U	N	jack	.445	21N-50-7-8C

Continued on following page

Index of US Military Numbers to Suhner Numbers Continued

US-MIL-Type	Series	Connector Type	O. D. max. inches	Suhner Nr.
UG-1187 A/U	N	panel jack	.445	25N-50-7-8C
UG-1195/U	N	plug	.886	11N-50-17-2C with GK 220
CW- 123 A/U	BNC	cap with chain		62BNC-0-0-1
CW- 159/U	BNC	shorting plug		64BNC-50-0-1
CW- 282/U	BNC	cap with chain		61BNC-0-0-1
MX- 913/U	UHF	cap with chain		62UHF-0-0-1
MX-1142/U	C	cap with chain		62C-0-0-1
MX-1143/U	C	cap with chain		61C-0-0-1
MX-1286/U	div.	armor clamp		GK 103
MX-1441/U	div.	armor clamp		GK 220