

US MIL. No.	SUHNER EQUIVALENT	NATO STOCK No.	DESCRIPTION	RANGE
UG-18A/U			Plug, replaced by UG-18E/U	N
UG-18B/U	11N-50-5-4	5935-99-940-3125	Plug, Cable Entry, .340", replaced by UG-18E/U	N
UG-18C/U			Plug, replaced by UG-18E/U	N
UG-18E/U	11N-50-5-2C		Plug, Captive Contact Pin	N
UG-19A/U			Jack, Panel, replaced by UG-19E/U	N
UG-19B/U	25N-50-5-3		Jack, Panel, replaced by UG-19E/U	N
UG-19C/U	25N-50-7-5		Jack, Panel, replaced by UG-19E/U	N
UG-19E/U	25N-50-5-1		Jack, Panel	N
UG-20A/U			Jack, replaced by UG-20E/U	N
UG-20B/U	21N-50-5-3		Jack, replaced by UG-20E/U	N
UG-20C/U			Jack, replaced by UG-20E/U	N
UG-20E/U	21N-50-5-1		Jack	N
UG-21/U		5935-99-933-0242	Plug, replaced by UG-21C/U	N
UG-21A/U			Plug, replaced by UG-21C/U	N
UG-21B/U	11N-50-7-9	5935-99-940-1095	Plug, replaced by UG-21C/U	N
UG-21C/U	11N-50-7-5	5935-99-946-5529	Plug	N
UG-22A/U			Jack, Panel, replaced by UG-22F/U	N
UG-22B/U	25N-50-7-1	5935-99-972-9184	Jack, Panel, replaced by UG-22F/U	N
UG-22D/U			Jack, Panel, replaced by UG-22F/U	N
UG-22F/U	25N-50-7-7		Jack, Panel, with Improved Cable Entry	N
UG-23A/U			Jack, replaced by UG-23F/U	N
UG-23B/U	21N-50-7-1	5935-99-972-9391	Jack, replaced by UG-23F/U	N
UG-23C/U			Jack, replaced by UG-23F/U	N
UG-23D/U	21N-50-7-5		Jack, replaced by UG-23F/U	N
UG-23F/U	21N-50-7-7		Jack	N
UG-27A/U			Adaptor, Angled, Male - Female, replaced by UG-27D/U	N
UG-27B/U		5935-99-943-7287	Adaptor, Angled, Male - Female, replaced by UG-27D/U	N
UG-27C/U		5935-99-932-2405	Adaptor, Angled, Male - Female, replaced by UG-27D/U	N
UG-27D/U	53N-50-0-1		Adaptor, Angled, Male - Female	N
UG-28A/U	46N-50-0-1		Adaptor-T, Female - Female - Female	N
UG-29/U			Adaptor, Straight, Female, replaced by UG-29B/U	N
UG-29A/U	31N-50-0-1	5935-99-933-0088	Adaptor, Straight, Female, replaced by UG-29B/U	N
UG-29B/U	31N-50-0-2		Adaptor, Straight, Female	N
UG-30/U		5935-99-932-1715	Adaptor, Bulkhead, Female, replaced by UG-30E/U	N
UG-30B/U			Adaptor, Bulkhead, Female, replaced by UG-30E/U	N
UG-30E/U	34N-50-0-1		Adaptor, Bulkhead, Female	N

US MIL. No.	SUHNER EQUIVALENT	NATO STOCK No.	DESCRIPTION	RANGE
UG-57/U			Adaptor, Straight, Male, replaced by UG-57B/U	N
UG-57A/U			Adaptor, Straight, Male, replaced by UG-57B/U	N
UG-57B/U	32N-50-0-1		Adaptor, Straight, Male	N
UG-58/U		5935-99-940-1046	Receptacle, Panel, replaced by UG-58A/U	N
UG-58A/U	23N-50-0-1	5935-99-943-7316	Receptacle, Panel	N
UG-83/U			Adaptor, UHF Male - N Female, replaced by UG-83B/U	RTR
UG-83A/U			Adaptor, UHF Male - N Female, replaced by UG-83B/U	RTR
UG-83B/U	33UHF-N-0-1		Adaptor, UHF Male - N Female	RTR
UG-88/U		5935-99-940-1089	Plug, replaced by UG-88E/U	BNC
UG-88B/U	11BNC-50-3-12	5935-99-940-3187	Plug, replaced by UG-88E/U	BNC
UG-88C/U		5935-99-913-2433	Plug, replaced by UG-88E/U	BNC
UG-88C/U		5935-99-940-3188	Plug, replaced by UG-88E/U	BNC
UG-88C/U		5935-99-952-5019	Plug, replaced by UG-88E/U	BNC
UG-88D/U		5935-99-972-0199	Plug, replaced by UG-88E/U	BNC
UG-88E/U	11BNC-50-3-2		Plug, outer contact bronze, Improved Cable Entry	BNC
UG-88E/U	11BNC-50-3-3		Plug, outer contact brass, Improved Cable Entry	BNC
UG-89/U		5935-99-911-8291	Jack, replaced by UG-89C/U	BNC
UG-89A/U	21BNC-50-3-3		Jack, replaced by UG-89C/U	BNC
UG-89B/U		5935-99-999-9243	Jack, replaced by UG-89C/U	BNC
UG-89C/U	21BNC-50-3-4		Jack, with Improved Cable Entry	BNC
UG-91A/U	11N-75-5-1	5935-99-943-7313	Plug	N
UG-92A/U	21N-75-5-1		Jack	N
UG-93A/U	25N-75-7-1		Jack, Panel, 4CH	N
UG-94A/U	11N-75-7-8	5935-99-580-3675	Plug	N
UG-95/U			Jack, replaced by UG-95A/U	N
UG-95A/U	21N-75-7-1	5935-99-580-1675	Jack, Cable Entry, .470"	N
UG-96A/U	25N-75-7-2C		Jack, Panel, Captive Contact Pin	N
UG-102/U	GD-072		Plug, (Twin)	UHF
UG-103A/U	CD-072		Receptacle, Panel, (Twin)	UHF
UG-104/U	LD-072		Adaptor, Angled, Male - Female (Twin)	UHF
UG-105/U	VD-072		Adaptor, Straight, Female (Twin)	UHF
UG-106/U	HA-07	5035-99-972-6944	Hood	UHF-C-N
UG-107A/U		5935-99-972-8894	Adaptor-T, Female - Female - Male, replaced by UG-107B/U	N
UG-107B/U	43N-50-0-1	5935-99-943-7278	Adaptor-T, Male - Female - Male	N
UG-111/U	11UHF-0-4-5C	5935-99-972-6114	Plug, Captive Contact Pin	UHF
CW-123/U		5935-99-911-6871	Cap, for Female Connectors, replaced by CW-123A/U	BNC

US MIL. No.	SUHNER EQUIVALENT	NATO STOCK No.	DESCRIPTION	RANGE
CW-123A/U	62BNC-0-0-1	5935-99-999-7624	Cap, for Female Connectors	BNC
UG-146/U			Adaptor, N Male - UHF Female, replaced by UG-146A/U	RTR
UG-146A/U	33N-UHF-0-1		Adaptor, N Male - UHF Female	RTR
UG-155/U	31LC-50-0-1		Adaptor, Straight, Female	LC
UG-154/U	11LC-50-17-1	5935-99-972-9032	Plug	LC
CW-155A/U	62BNC-0-0-3	5935-99-946-4253	Cap, for Female Contacts	BNC
CW-159/U	64BNC-0-0-1		Plug, Shorting	BNC
UG-159A/U	24N-50-5-4		Jack, Bulkhead, replaced by UG-159C/U	N
UG-159B/U			Jack, Bulkhead, replaced by UG-159C/U	N
UG-159C/U	24N-50-5-2		Jack, Bulkhead	N
UG-160A/U	24N-50-7-1		Jack, Bulkhead, replaced by UG-160D/U	N
UG-160C/U	24N-50-7-8C	5935-99-943-8215	Jack, Bulkhead, replaced by UG-160D/U	N
UG-160D/U	24N-50-7-7		Jack, Bulkhead	N
UG-167/U			Plug, replaced by UG-167F/U	N
UG-167A/U			Plug, replaced by UG-167F/U	N
UG-167F/U	11N-50-17-1		Plug	N
UG-175/U	RD-07/03	5935-99-940-3316	Adaptor, Reducing	UHF
UG-176/U	RD-07/05	5935-99-580-2416	Adaptor, Reducing	UHF
UG-177/U	H-03		Hood	C-UHF-N
UG-196/U	TD-072		Adaptor-T, Female - Female - Male (Twin)	UHF
UG-201/U		5935-99-940-1652	Adaptor, N Male - BNC Female, replaced by UG-201A/U	RTR
UG-201A/U	33N-BNC-50-1	5935-99-943-7276	Adaptor, N Male - BNC Female	RTR
UG-203/U	11UHF-0-4-7C		Plug, Captive Contact Pin	UHF
UG-204A/U	11N-50-9-1		Plug, replaced by UG-204D/U	N
UG-204C/U		5935-99-519-4681	Plug, replaced by UG-204D/U	N
UG-204D/U	11N-50-9-2		Plug	N
UG-223/U	22UHF-0-0-1		Receptacle, Bulkhead	UHF
UG-224/U			Adaptor, Panel, Female	UHF
SO-239	23UHF-0-0-1	5935-99-940-1837	Receptacle, Panel, 4CH	UHF
UG-255/U	33BNC-UHF-0-1	5935-99-943-8203	Adaptor, BNC Male - UHF Female	RTR
PL-258	31UHF-0-0-1	5935-99-971-7924	Adaptor, Straight, Female	UHF
PL-259	11UHF-0-7-4C	5935-99-943-7576	Plug, Captive Contact Pin	UHF
PL-259A	11UHF-0-7-6C	5935-99-940-1839	Plug, Captive Contact Pin	UHF
UG-260/U		5935-99-972-8285	Plug, replaced by UG-260D/U	BNC
UG-260A/U	11BNC-50-4-8	5935-99-914-5078	Plug, replaced by UG-260D/U	BNC
UG-260B/U		5935-99-580-7547	Plug, bronze outer contact, replaced by UG-260D/U	BNC

US MIL. No.	SUHNER EQUIVALENT	NATO STOCK No.	DESCRIPTION	RANGE
UG-260B/U		5935-99-102-3839	Plug, bronze outer contact, replaced by UG-260D/U	BNC
UG-260D/U	11BNC-50-4-2		Plug, bronze outer contact	BNC
UG-260D/U	11BNC-50-4-3		Plug, brass outer contact	BNC
UG-261/U		5935-99-911-3612	Jack, replaced by UG-261C/U	BNC
UG-261A/U	21BNC-50-4-2		Jack, replaced by UG-261C/U	BNC
UG-261B/U			Jack, replaced by UG-261C/U	BNC
UG-261C/U	21BNC-50-4-3		Jack, Improved Cable Entry, .252"	BNC
UG-262/U	25BNC-50-4-3	5935-99-946-9312	Jack, Panel, Cable Entry, .254", replaced by UG-262C/U	BNC
UG-262A/U	25BNC-50-4-2		Jack, Panel, replaced by UG-262C/U	BNC
UG-262C/U	25BNC-50-4-4		Jack, Panel, Improved Cable Entry, .252", 4TH	BNC
SO-264	CD-072		Receptacle; Panel	UHF
UG-273/U	33UHF-BNC-0-1	5935-99-943-7280	Adaptor, UHF Male - BNC Female	RTR
PL-274	34UHF-0-0-1	5935-99-580-2923	Adaptor, Bulkhead, Female	UHF
UG-274/U		5935-99-932-2819	Adaptor-T, Female - Female - Male, replaced by UG-274B/U	BNC
UG-274A/U		5935-99-943-7277	Adaptor-T, Female - Female - Male, replaced by UG-274B/U	BNC
UG-274B/U	43BNC-50-0-1		Adaptor-T, Female - Female - Male	BNC
PL-275	YD-072		Adaptor, Bulkhead, Female (Twin)	UHF
UG-281/U			Jack, Panel, replaced by UG-1095B/U	N
CW-282/U	61BNC-0-0-1		Cap, for Male Connectors	BNC
UG-282/U			Adaptor, BNC to Banana contacts	RTR
UG-287/U	37LC-50-0-1		Adaptor, Panel, Female	LC
UG-290/U		5935-99-940-1040	Receptacle, Panel, replaced by UG-290A/U	BNC
UG-290A/U	23BNC-50-0-6	5935-99-913-2101	Receptacle, Panel, 4TH	BNC
UG-291/U	25BNC-50-3-3	5935-99-911-6955	Jack, Panel, replaced by UG-291C/U	BNC
UG-291A/U		5935-99-943-7279	Jack, Panel, replaced by UG-291C/U	BNC
UG-291B/U		5935-99-932-4048	Jack, Panel, replaced by UG-291C/U	BNC
UG-291C/U	25BNC-50-3-5		Jack, Panel, Improved Cable Entry, 4TH	BNC
PL-293	LD-072		Adaptor, Angled, Male - Female (Twin)	UHF
UG-298/U	43UHF-0-0-1	5935-99-971-9680	Adaptor-T, Female - Female - Male	UHF
UG-299/U	31UHF-0-0-1	5935-99-971-7924	Adaptor, Straight, Female	UHF
UG-306/U		5935-99-940-1047	Adaptor, Angled, Male - Female, replaced by UG-306B/U	BNC
UG-306B/U	53BNC-50-0-1		Adaptor, Angled, Male - Female	BNC
UG-307/U	37UHF-0-0-1	5935-99-580-5047	Adaptor, Panel, Contacts 2 Female, 4CH	UHF
UG-318/U	33N-UHF-0-1		Adaptor, N Male - UHF Female	RTR
UG-349/U			Adaptor, BNC Male - N Female, replaced by UG-349B/U	RTR
UG-349A/U			Adaptor, BNC Male - N Female, replaced by UG-349B/U	RTR

US MIL. No.	SUHNER EQUIVALENT	NATO STOCK No.	DESCRIPTION	RANGE
UG-349B/U	33BNC-N-50-1		Adaptor, BNC Male - N Female	RTR
UG-352/U	23LC-50-0-1		Receptacle, Panel, 4CH	LC
M-358	43UHF-0-0-1	5935-99-971-9680	Adaptor-T, Female - Female - Male	UHF
M-359	53UHF-0-0-1	5935-99-580-3639	Adaptor, Angled, Male - Female	UHF
M-359	53UHF-0-0-1	5935-99-104-7684	Adaptor, Angled, Male - Female	UHF
M-360	Ha 07		Hood	N-UHF-C
UG-363/U	34UHF-0-0-1		Adaptor, Bulkhead, Female	UHF
UG-414/U			Adaptor, Panel, Female, replaced by UG-414A/U	BNC
UG-414A/U	37BNC-50-0-1		Adaptor, Panel, Female, 4TH	BNC
UG-447/U	23BNC-50-0-7	5935-99-911-6872	Receptacle, Panel, 4CH	BNC
UG-491/U			Adaptor, Straight, Male, replaced by UG-491B/U	BNC
UG-491A/U		5935-99-519-3527	Adaptor, Straight, Male, replaced by UG-491B/U	BNC
UG-491B/U	32BNC-50-0-1	5935-99-199-0824	Adaptor, Straight, Male	BNC
UG-492/U			Adaptor, Bulkhead, Female, replaced by UG-492B/U	BNC
UG-492A/U		5935-99-999-7889	Adaptor, Bulkhead, Female, replaced by UG-492B/U	BNC
UG-492B/U	34BNC-50-0-1		Adaptor, Bulkhead, Female, 4TH	BNC
UG-536/U	11N-50-7-9/.195"	5935-99-943-7314	Plug, Cable Entry, .195", replaced by UG-536B/U	N
UG-536A/U		5935-99-943-7281	Plug, replaced by UG-536B/U	N
UG-536B/U	11N-50-3-1	5935-99-923-9431	Plug	N
UG-556/U		5935-99-932-4049	Jack, Bulkhead, replaced by UG-556B/U	N
UG-556B/U	24N-50-3-1		Jack, Bulkhead	N
UG-564/U	33N-C-50-1	5935-99-519-3525	Adaptor, N Male - C Female	RTR
UG-565A/U	33C-N-50-1		Adaptor, C Male - N Female	RTR
UG-566A/U	43C-50-0-1		Adaptor-T, Female - Female - Male	C
UG-567/U			Adaptor, Angled, Male - Female, replaced by UG-567A/U	C
UG-567A/U	53C-50-0-1	5935-99-920-9000	Adaptor, Angled, Male - Female	C
UG-567A/U	53C-50-0-1	5935-99-972-2384	Adaptor, Angled, Male - Female	C
UG-568/U	23C-50-0-1	5935-99-920-9029	Receptacle, Panel, 4TH	C
UG-569/U			Receptacle, Bulkhead, replaced by UG-569A/U	C
UG-569A/U	22C-50-0-3		Receptacle, Bulkhead	C
UG-570/U			Jack, Bulkhead, replaced by UG-570A/U	C
UG-570A/U	24C-50-7-3		Jack, Bulkhead, 4TH	C
UG-571/U			Jack, Panel, replaced by UG-571A/U	C
UG-571A/U	25C-50-7-3		Jack, Panel, 4TH	C
UG-572/U		5935-99-911-6861	Jack, replaced by UG-572A/U	C
UG-572A/U	21C-50-7-3		Jack	C

US MIL. No.	SUHNER EQUIVALENT	NATO STOCK No.	DESCRIPTION	RANGE
UG-573A/U		5935-99-932-5852	Plug, replaced by UG-573B/U	C
UG-573B/U	11C-50-7-5		Plug	C
UG-593/U		5935-99-519-4704	Jack, Panel, replaced by UG-593A/U	N
UG-593A/U	25N-50-4-1		Jack, Panel, 4CH	N
UG-594/U		5935-99-580-9631	Plug, Angled, replaced by UG-594B/U	N
UG-594B/U	16N-50-7-2		Plug, Angled	N
UG-602/U			Jack, replaced by UG-602A/U	N
UG-602A/U	21N-50-4-1		Jack	N
UG-603/U			Plug, replaced by UG-603A/U	N
UG-603A/U	11N-50-4-1	5935-99-519-4703	Plug	N
UG-606/U	31BNC-N-50-1		Adaptor, N Female - BNC Female	RTR
UG-625/U			Receptacle, Bulkhead, replaced by UG-625B/U	BNC
UG-625B/U	22BNC-50-0-4	5935-99-933-2134	Receptacle, Bulkhead, Pressurized	BNC
UG-626A/U			Plug, replaced by UG-626B/U	C
UG-626B/U	11C-50-5-1		Plug	C
UG-627A/U			Plug, replaced by UG-627B/U	C
UG-627B/U	11C-50-4-1	5935-99-972-1088	Plug	C
UG-628A/U			Plug, replaced by UG-628B/U	H1
UG-628B/U	11H1-50-7-1		Plug	H1
UG-629/U			Jack, Panel, replaced by UG-629A/U	C
UG-629A/U	25C-50-5-1		Jack, Panel, 4TH	C
UG-630/U			Jack, Bulkhead, replaced by UG-630A/U	C
UG-630A/U	24C-50-5-1		Jack, Bulkhead, Pressurized	C
UG-631/U			Jack, Bulkhead, replaced by UG-631A/U	C
UG-631A/U	24C-50-4-1C	5935-99-972-1087	Jack, Bulkhead, Pressurized, Captive Contact Pin	C
UG-632/U			Jack, Bulkhead, replaced by UG-632A/U	H1
UG-632A/U	24H1-50-7-1		Jack, Bulkhead	H1
UG-633/U			Jack, replaced by UG-633A/U	C
UG-633A/U	21C-50-5-1		Jack	C
UG-634/U	22H1-50-0-1		Receptacle, Bulkhead	H1
UG-635/U	33BNC-C-50-1	5935-99-945-0704	Adaptor, BNC Male - C Female	RTR
UG-636/U			Adaptor, C Male - BNC Female, replaced by UG-636A/U	RTR
UG-636A/U	33C-BNC-50-1	5935-99-972-2570	Adaptor, C Male - BNC Female	RTR
UG-637/U	33UHF-C-0-1		Adaptor, UHF Male - C Female	RTR
UG-641/U	33BNC-A-0-1	5935-99-416-5820	Adaptor, BNC Male - Banana Contacts, Female	RTR
UG-642/U		5935-99-580-1326	Adaptor, Straight, Male, replaced by UG-642A/U	C

US MIL. No.	SUHNER EQUIVALENT	NATO STOCK No.	DESCRIPTION	RANGE
UG-642A/U	32C-50-0-1		Adaptor, Straight, Male	C
UG-643/U	31C-50-0-1	5935-99-580-1512	Adaptor, Straight, Female	C
UG-646/U	53UHF-0-0-1	5935-99-580-3639	Adaptor, Angled, Male - Female	UHF
UG-657/U	22BNC-50-0-3	5935-99-999-2429	Receptacle, Bulkhead, Pressurized	BNC
UG-680/U		5935-99-913-4838	Receptacle, Bulkhead, replaced by UG-680A/U	N
UG-680A/U	22N-50-0-2		Receptacle, Bulkhead	N
UG-701/U	34C-50-0-1	5935-99-911-8080	Adaptor, Bulkhead, Female	C
UG-704/U		5935-99-913-2436	Jack, Bulkhead, replaced by UG-704B/U	C
UG-704B/U	24C-50-3-1C		Jack, Bulkhead, Pressurized, Captive Contact Pin	C
UG-707A/U	11C-50-9-1	5935-99-519-9044	Plug, replaced by UG-707B/U	C
UG-707B/U	11C-50-9-2		Plug	C
UG-708/U		5935-99-911-6860	Plug, replaced by UG-708B/U	C
UG-708A/U			Plug, replaced by UG-708B/U	C
UG-708B/U	11C-50-17-2		Plug	C
UG-709A/U			Plug, replaced by UG-709B/U	C
UG-709B/U	11C-50-3-4	5935-99-580-2595	Plug	C
UG-710A/U	16C-50-7-4	5935-99-972-6945	Plug, Angled, replaced by UG-710B/U	C
UG-710A/U	16C-50-7-4	5935-99-946-9295	Plug, Angled, replaced by UG-710B/U	C
UG-710B/U	16C-50-7-6		Plug, Angled	C
UG-909/U		5935-99-914-5215	Jack, Bulkhead, replaced by UG-909B/U	BNC
UG-909B/U	24BNC-50-3-2		Jack, Bulkhead	BNC
UG-910/U		5935-99-999-3013	Jack, Bulkhead, replaced by UG-910B/U	BNC
UG-910B/U	24BNC-50-4-2		Jack, Bulkhead, Improved Cable Entry, .252"	BNC
MX-913/U	62UHF-0-0-1		Cap, for Female Connectors	UHF
UG-913/U		5935-99-932-2643	Plug, Angled, replaced by UG-913A/U	BNC
UG-913A/U	16BNC-50-3-3		Plug, Angled, Long Version	BNC
UG-931/U	23H4-50-0-1		Receptacle, Panel, 4TH	H4
UG-932/U			Plug, replaced by UG-932A/U	H4
UG-932A/U	11H4-50-4-1		Plug	H4
UG-935B/U	25N-50-7-5/103		Jack, Panel with Cable Clamp GK-103, 4CH	N
UG-936B/U	24N-50-7-5/103		Jack, Bulkhead, with Cable Clamp GK-103	N
UG-937A/U	24C-50-7-4C/103		Jack, Bulkhead, with Cable Clamp, GK-103, Captive Contact Pin	C
UG-938A/U	25C-50-7-3/103		Jack, Panel, with Cable Clamp GK-103	C
UG-939A/U	24H1-50-7-1/103		Jack, Bulkhead, with Cable Clamp GK-103	H1
UG-940B/U	21N-50-7-7/103		Jack, with Cable Clamp GK-103	N
UG-941B/U	11N-50-7-5/103	5935-99-923-9432	Plug, with Cable Clamp GK-103	N

[illegible]