


FITTING INSTRUCTIONS FOR "EXSTAT" RECEIVER TRANSFORMERS TYPE M.T. FOR MULTI-POINT INSTALLATIONS

For Multi-point installations a receiver transformer type MT must be used at each receiver. The points must be wired in **parallel** with EXSTAT twin screened cable to additional three pin sockets as required. Up to six transformers Type MT may be used with one aerial, depending on the signal strength available. Care must be taken to ensure that all the leads coincide, Black to Black, White to White and Screen to Screen.

The Screened cable must be effectively earthed at the first three pin socket.

Full fitting instructions for 'Extat, Equipment are given in leaflet IL/8/56.

THE CONNECTIONS FOR THE AERIAL TRANSFORMER ARE THE SAME AS FOR SINGLE POINT INSTALLATIONS



IMPORTANT—ALL INSTALLATIONS

The short aerial and earth leads to the receiver from the receiver transformer and must NOT be extended unless EXSTAT twin screened cable is used.

WARNING

Care should be taken with AC/DC receivers when fitting EXSTAT equipment—a qualified engineer should be consulted.

ANTIFERENCE LIMITED, BICESTER ROAD, AYLESBURY, BUCKS.

Telephone:- AYLESBURY 1467/8/9