







CHANNEL	A	B	C	D	E	F	G	H	I
6	2818	2655	1691	597	736	251	899	854	607
7	2727	2571	1640	722	710	249	864	821	584
8	2650	2494	1593	818	686	252	832	791	562
9	2578	2422	1549	897	664	257	803	763	543
10	2459	2303	1476	1010	626	259	753	715	509
11	2400	2244	1440	1060	606	262	728	692	492

TM7S ANTENNA
WITH MTG HARDWARE



CHANNEL	A	B	C	D	E	F	G	H	I
6	2818	2655	1691	597	736	252	899	854	607
7	2727	2571	1640	722	710	250	864	821	584
8	2650	2494	1593	818	686	253	832	791	562
9	2578	2422	1549	897	664	258	803	763	543
10	2459	2303	1476	1010	626	260	753	715	509
11	2400	2244	1440	1060	606	263	728	692	492

TM7SP ANTENNA
WITH MTG HARDWARE