
Warning. Danger of death through electric shock!

- · Must be installed by professional electrician.
 - Disconnect power source.
 - Cover or shied any adjacent live components.
 - · Ensure device cannot be switched on.
 - Check power supply is disconnected.



- Loosen the screws on each side
- Connect the power supply and the load according to the wiring diagram in accordance with the connection cable diagram.
- Fix the bottom to the selected position with the inflated screw (see figure)
- 4. Install the top cover of the sensor, then turn on the power and test it.