




INSTALLATION AND OPERATING INSTRUCTIONS
FOR AA21970, HPS3KW-NNR-032
AA21970, HPS3KW-NNR-032 操作指示

Revised Date : October 13, 2003


CONNECTOR PIN DESIGNATION
(STIFT BELEGUNG AN STECKER)

AC INPUT CONNECTOR



Neutral Earth Line
L₂ GND L₁

OUTPUT CONNECTOR



OUTPUT CONNECTOR PIN-OUT

Signal Pins					
	1	2	3	4	5
D	5VSB	5VSB Return ^X	PSON ^X	SCL	A0
C	5VSB	5VSB Return	PRESENT	SCL/SDA Return	A1
B	5VSB	5VSB Return ^X	PSKILL ^X	SDA	A2
A	48LS	ACOK	PWOK ^X	FAIL	Reserved
Power Blades					
P1, P2			P3, P4		
48VDC Return			48VDC		