

Sony Document Camera Quick Reference Guide

VID P100 & VID P110

**** **Please Note.** The layout of the buttons may be different – functions and names are the same



- ① ② ③ ④ ⑤ ⑥ ⑦ ⑧

1. Press to change the image from Colour to Black & White or visa versa
2. Press to provide a view of the document – object - image you are showing as a negative image (similar to a photo negative)
3. Press to adjust the white balance (do this with no document - object – image on the document camera)
4. Press to switch between Document Camera (VID) and Scan Converter (Video 1 / Video 2) (if scan converter is connected)
5. Auto is recommended. Press Close to darken a bright document – object – image. Press Open to brighten a dull document – object - image
6. Auto is recommended. Press Near or Far to manually adjust the focus
7. Press to zoom in or out
8. Press to switch to toggle between the overhead lights and backlight