


UNDER MICROWAVE INST.



Sanders instruction manual

V.S.W.R. INDICATOR
AND SELECTIVE AMPLIFIER

W. H. Sanders (Electronics) Limited

Gunnels Wood Road · Stevenage · Herts.

A Member of the  Group of Companies

CONTENTS

	<u>Page</u>
General Description	1
Concise Details	1
Operating Instructions	2
Technical Description	3
Maintenance	4
Circuit Diagram.....	facing 4
Component Layout.....	5
Parts List.....	6
Reference Tables	
Conversion of Voltage or Power Ratio to Decibels	9
V. S. W. R. - V. S. W. R. (dB)	10
V. S. W. R. - % Power Transmitted and % Power Reflected	10
Reduction of V. S. W. R. as a Function of Attenuation	11
V. S. W. R. (≤ 1) to Power Reflection Coefficient	12
V. S. W. R. (≤ 1) to Voltage Reflection Coefficient	13

GUARANTEE

W.H.Sanders (Electronics) Ltd., guarantees each instrument manufactured by them to be free from defects in material and workmanship. Our obligation under this guarantee is limited to servicing or adjusting the instrument and to making good any defective parts thereof. Valves, fuses, batteries, semi-conductors and bolometers are specifically excluded from any liability. This guarantee is effective for one year after delivery to the original purchaser, when the instrument is returned to our factory with transportation charges prepaid, and when upon examination by the Company shall be found to be defective. If the fault has been caused by misuse or malhandling repairs will be billed at cost. In this event an estimate will be submitted before the work is started.

REPAIRS

When returning instruments for repair, or for any other reason, please contact the Company for shipping instructions. To expedite repair service, it is important to provide type number, serial number, and a detailed description of the reason for the return of the instrument.

CHANGES

Because we have a programme of continuous product improvement, specifications noted herein are necessarily subject to change without notice. The Company also reserves the right to make changes in design without incurring any obligation to make the same changes in units previously ordered or to continue the production of instruments conforming to former designs.



V.S.W.R. INDICATOR AND SELECTIVE AMPLIFIER

GENERAL DESCRIPTION

The V. S. W. R. Indicator and Selective Amplifier is basically a low noise, high gain amplifier driving a meter output. The instrument is primarily intended for laboratory use, but, its small size and robust construction make it equally suitable for use in the field.

Provision is made for two inputs from crystal detectors, these can be used independently or together for bridge measurements. A separate input is provided with a d.c. bias supply for bolometer operation.

The amplifier can be made selective at 1000 c/s and 3000 c/s or switched to broad band operation (800-3500 c/s) with only a small loss of sensitivity. The accurate attenuators are adjustable from 0 to 40 dB in increments of 1 dB, a continuously variable 0-1 dB attenuator is also provided.

Either a mains a.c. supply or internal batteries can be used to power the instrument which has a very low power consumption.

CONCISE DETAILS

Frequency Range:	800 c/s to 3.5 K c/s.
Selective frequencies:	1 K c/s and 3 K c/s.
Selectivity:	100 c/s bandwidth for 1 K c/s operation, 400 c/s bandwidth for 3 K c/s operation.
Sensitivity (normal):	better than $1\mu\text{V}$ f.s.d. for selective operation, better than $2\mu\text{V}$ f.s.d. for wide band operation.
Sensitivity (expanded scale):	better than $0.4\mu\text{V}$ f.s.d. for selective operation, better than $0.8\mu\text{V}$ f.s.d. on wide band operation.
Input impedance:	approx. 1000 ohms.
Noise level:	less than $0.1\mu\text{V}$ on selective operation, less than $0.3\mu\text{V}$ on wide band operation.
Attenuators:	0 to 30 dB in 10 dB steps ± 0.5 dB. 0 to 10 dB in 1 dB steps ± 0.2 dB. 0 to 1 dB continuously variable.
Meter scales:	1. Response and d.c. 0-100 μA 2. V.S.W.R., ∞ to 1 and 0 to 1 3. V.S.W.R., ∞ to 3 and 0 to 0.33 4. Expanded V.S.W.R., 1.3 to 1 and 0.77 to 1
Meter calibration:	square law.
Bolometer bias:	adjustable from 3 to 10 mA.
Power Supplies:	Mains, 110-120 V or 200-250V, 50-60c/s. Batteries, three Vidor T.6001 or Ever Ready PP1.
Dimensions:	16in. wide x 9in. high x 9in. deep.

OPERATING INSTRUCTIONS

PREPARATION

Mains Voltage

Set the connections on the mains transformer to the appropriate taps, for the local supply.

Fuse

A 250mA fuse is mounted above the mains input socket. If the instrument is to be operated from a 110-120 volt supply, change the fuse for one of 500mA value.

Mains Lead

Fit a three-pin plug to the mains lead, connecting as follows:-

red lead - mains supply - live
black lead - mains supply - neutral
green lead - earth

MEASURING TECHNIQUES

V.S.W.R.

For normal V.S.W.R. measurements the instrument is used in the conventional manner. Either socket A or Socket B may be used for connection to a crystal.

Bridge Applications

If two signals are available from the microwave bench, very small deviations in either of the signals can be accurately measured using bridge techniques. When the two inputs are connected to sockets A and B they complete a bridge network with two primary windings on the input transformer.

Having connected the signals to sockets A and B, proceed as follows:-

- 1) Switching INPUT SELECTOR to A and B in turn, adjust attenuator on microwave bench until the two signals are indicated as being of approximately the same level on the V.S.W.R. Indicator.
- 2) Set INPUT SELECTOR to A+B and note whether reading rises or falls. If reading rises reverse the position of the A+B/A-B switch.
- 3) Switch out attenuation in amplifier to increase the reading to a convenient indication.
- 4) Adjust attenuator on microwave bench to obtain a null on the meter indication.

- 5) Re-adjust one of the microwave attenuators to a position at which the sensitivity of the indication is adequate for the measurement to be performed, at the same time ensure the working region for these measurements is confined to one side of the null. If necessary the meter indication can be calibrated against an attenuator in the arm in which variations are being measured.

A simpler, but slightly less accurate application of the bridge balance facility, particularly useful in measuring insertion losses above 0.1 dB, is as follows:-

- 1) Adjust the two signals, as described above, to obtain a null reading.
- 2) Insert or remove the component, whose insertion loss is to be measured in one arm of the microwave system.
- 3) Adjust the attenuator in that arm of the system to re-establish the null reading. The difference in the two readings of the attenuator is the insertion loss.

Expanded V.S.W.R.

When a V.S.W.R. of less than 1.3:1 is being measured, a more accurate reading can be obtained by using the expanded scale facility as follows:-

- 1) Adjust microwave and/or amplifier attenuators to obtain a reading of approximately a for the standing wave maximum.
- 2) Set NORMAL/EXPAND switch to EXPAND.
- 3) Proceed as in normal V.S.W.R. measurement but read the red EXPANDED V.S.W.R. scale.

NOTE: Ensure that EXPAND/NORMAL switch is returned to NORMAL on completion of the measurement.

Bolometer Operation

On bolometer operation the bolometer bias must be set in the following manner:-

- 1) Set the ADJUST BOL. mA control fully anti-clockwise before connecting the bolometer to the BOLOMETER socket.
- 2) Set INPUT SELECTOR to SET BOL. mA and set ADJUST BOL. mA control to give the required bolometer bias. This is read on the 0-10mA scale of the meter.
- 3) Set the INPUT SELECTOR to BOL. and carry out measurements in the normal way.

TECHNICAL DESCRIPTION

INPUT SIGNAL SELECTION

Signal Input A.

This is the normal input socket for straight-forward V.S.W.R. measurement. Socket A is also used as the input for the direct measurement of crystal current on the 0-100 μ A scale of the meter. Switch wafer SW2a connects the signal directly to the meter when the amplifier is switched off, or to switch wafer SW1b when the amplifier is on. SW1b connects the signal to one primary of input transformer T1 when A or A+B is selected on the INPUT SELECTOR switch SW1.

Signal Input B.

SW1A connects the signal to a separate primary winding of T1, via polarity changeover switch SW7, when B or A+B is selected on the INPUT SELECTOR switch. SW7 is used only when making bridge measurements to ensure that the signals in the two primary windings are of opposite polarities.

Bolometer

When BOL. is selected on SW1, the bolometer socket is connected by d.c. blocking capacitor C3 and SW1b to the input transformer. A d.c. bias supply is also connected to the socket from the bolometer supply circuit (Page).

AMPLIFIER

The signal from the secondary of T1 is taken to a sensitive amplifier, the gain of which is adjusted by means of three attenuators.

The first stage of amplification is provided by the circuit of TR1. This is a conventional low-noise amplifier with feedback from collector to base via R59 to improve linearity. The amplified signal is fed to a 0-30 dB attenuator, formed by resistors R6, R7, R8, R9 and R53. R53 is adjusted on final test to give an accurate 10dB setting, for this reason no value is quoted on the circuit diagram. Switch SW3 permits selection of attenuation in 10dB increments.

If the amplifier was not provided before the attenuator, a lower noise level would be possible, but, with the disadvantage that for small signals the range of attenuation would be limited. On the other hand, high amplification before the attenuator would permit a wide range of attenuation, but at the same time increase the noise level. Thus, the arrangement in this instrument is a compromise to give adequate sensitivity and range of attenuation for normal laboratory use. The high impedance input of emitter-follower, TR2 prevents the amplifier circuits from varying the load on the attenuator.

TR3, TR4 and TR5 are conventional amplifier stages with the collector load of TR5 formed by R26-35 which give 0-10 dB attenuation in 1 dB steps selected by SW4. This is followed by a continuously variable attenuator, RV2, of approximately 1 dB.

After further amplification by TR6 the signal is taken to the 1 Kc/s - 3 Kc/s - WIDE BAND switch which directs the signal through any one of three paths, according to the position selected. These consist of a 1 Kc/s tuned circuit TC1, a 3 Kc/s tuned circuit TC2 and a direct connection to emitter-follower TR7. TC1 and TC2 have a Q of 10, giving the amplifier a narrow bandwidth. The high impedance input of emitter-follower TR7 prevents loss of selectivity due to loading of the tuned circuits by the amplifier.

The final amplifier stage, TR8, drives the output transformer T1, which is in its collector circuit.

OUTPUT CIRCUITS

The output of the amplifier is converted to a d.c. signal by bridge rectifier MR3-6, smoothed by R52, C24 and taken to the meter through switch wafers SW1c and SW2c. The EXPAND/NORMAL switch SW5 in its NORMAL position connects R51, R62 and RV4 to shunt the 100 μ A movement converting it to approximately 250 μ A f.s.d. In the EXPAND position the shunting resistors are disconnected and a backing-off current is provided from the 7.5V supply via R50 and RV3. The meter is now a 100 μ A f.s.d. movement and RV3 is preset to give a backing-off current which expands the 1 to 1.3 portion of the normal scale, to cover the whole of the expand scale.

POWER SUPPLIES

Amplifier Power Supply - Mains

The amplifier operates from any 50-60 c/s supply in the ranges 110-120 volts or 200-250 volts, taps on mains transformer T3 provide adjustment to suit the local supply. A 250mA fuse, F1, is fitted for 200-250 volt operation, for 110-120V operation, a 500mA fuse must be fitted.

The 15V at the secondary of T3 is bridge rectified by MR1, smoothed by C15 and dropped through R37, SW2f and parallel resistors R36, R38 (via SW2e) to feed Zener diode MR2 which holds the voltage within $\pm 5\%$ of 7.5V.

Amplifier Power Supply - Battery

Two six-volt batteries are used to provide the amplifier supply when battery operation is selected. The battery supply is taken through parallel resistors R38 and R36 to the amplifier circuit. MR6 holds the supply at a stable 7.5V.




FIG.1

Battery Check

Fig. 1. shows the arrangement of the battery supply to the amplifier when BATTERY CHECK is selected. The meter is converted to a 10mA movement, by the shunt switched in by SW2d, and connected in series with R36. If the current is below 10mA the meter reading indicates that the batteries are exhausted.

Bolometer Bias Supply

The bolometer bias supply is obtained either from the amplifier supply on mains or a separate 6V battery, according to the position of SW2g. This supply is dropped by R61,




FIG.2

smoothed by C27, C28, and developed across Zener diode MR7 which limits the supply at this point to 4.5 volts, safeguarding the bolometer against accidental over-voltage.

With SW1 switched to "SET BOLOMETER mA" the bolometer is taken through RV1, the bolometer bias setting control, SW1e and SW2b to the meter. The meter shunt is connected in by SW2c, SW1c and SW2d to give 10mA f.s.d. From the meter the supply is taken through SW1d and R10 to the bolometer, socket on the front panel.

When bolometer operation is selected on SW1 the meter is switched back to read the amplifier output and is replaced in the bolometer supply by R58 to maintain constant bias.

MAINTENANCE

General

As the amplifier is transistorised and all components are generously rated the instrument operates for very long periods with very little attention. The batteries should be checked at regular intervals by means of the battery check facility and changed if they are below standard. If the batteries are not used, remove them and tape the connectors to prevent them shorting.

The EXPAND facility should be checked occasionally in the following manner:-



1. Set mechanical zero of meter.
2. Set controls as follows:-
Attenuators to 20dB.
Frequency Selector to WIDE BAND.
Input Selector to A.
Supply Selector to MAINS or BATTERY.
Expand/Normal switch to NORMAL.
3. Apply a suitable signal to give a V.S.W.R. reading of 1 on the normal scale.
4. Set Expand/Normal switch to EXPAND.
5. Check that a V.S.W.R. reading of 1 is obtained on the EXPAND scale, adjust RV3 if necessary.
6. Set Expand/Normal switch to NORMAL.

7. Adjust input to give a V.S.W.R. reading of 1.3 on the normal scale.
8. Set Expand/Normal switch to EXPAND.
9. Check that a reading of $1.3 \pm 1\%$ f.s.d. is obtained on the expand scale, adjust RV4 if necessary.



Progressive adjustment of RV3 and RV4 may be necessary to obtain correct results. If the correct settings cannot be obtained the instrument must be re-calibrated:-

10. Remove link between RV3 and R50.
11. Set controls as follows:-
Attenuators to 20dB.
Frequency Selector to WIDE BAND.
Input Selector to A.
Supply Selector to MAINS or BATTERY.
Expand/Normal switch to EXPAND.
12. Apply a 2 Kc/s signal to input A and adjust level to give a reading of 90 on the response scale.
13. Set Expand/Normal switch to NORMAL.
14. Adjust RV4 to give a reading of 34 on the response scale.
15. Reconnect link between RV3 and R50.

Then, proceed as in Items 1 to 9.



COMPONENT LAYOUT



PARTS LIST

<u>Ref:</u>	<u>Component</u>	<u>Manufacturer</u>	<u>Type No.</u>	<u>Remarks</u>
CAPACITORS				
C1	25mF, 25V, electrolytic	T. C. C.	CE431 CD	
C2	100 mF, 25V, electrolytic	T. C. C.	CE434C	
C3	0.5mF, 150V, paper	Hunts	A. 302. W48	
C4	25mF, 25V, electrolytic	T. C. C.	CE431. CD	
C5	25mF, 25V, electrolytic	T. C. C.	CE431. CD	
C6	0.25mF, $\pm 20\%$, 150V, paper	Hunts	W48, A301	
C7	50mF, $\pm 20\%$, 12V, electrolytic	T. C. C.	CE431. RD	
C8	25mF, 25V, electrolytic	T. C. C.	CE. 431. CD	
C9	25mF, 25V, electrolytic	T. C. C.	CE. 431. CD	
C10	.02mF, 350V, paper	T. C. C.	CP. 33N	
C11	25mF, 25V, electrolytic	T. C. C.	CE. 431. CD	
C12	25mF, 25V, electrolytic	T. C. C.	CE. 431. CD	
C13	100mF, 25V, electrolytic	T. C. C.	CE. 434. C	
C14	10mF, 3V, electrolytic	T. C. C.	CE. 68. A. A.	
C15	500mF, 25V, electrolytic	Dubilier	BR. 5020	
C16	25mF, 25V, electrolytic	T. C. C.	CE. 431. CD	
C17	25mF, 25V, electrolytic	T. C. C.	CE. 431. CD	
C18	100mF, 25V, electrolytic	T. C. C.	CE. 434. C	
C19	25mF, 25V, electrolytic	T. C. C.	CE. 431. CD	
C20				Part of T. C. 1.
C21				Part of T. C. 2.
C22	25mF, 25V, electrolytic	T. C. C.	CE. 431. OD	
C23	100mF, 25V, electrolytic	T. C. C.	CE. 434. C.	
C24	0.5mF, 150V, paper	Hunts	A302. W48	
C25	100mF, 25V, electrolytic	T. C. C.	CE. 434. C	
C26	25mF, 25V, electrolytic	T. C. C.	CE. 431. CD	
C27	1000mF, 12V, electrolytic	T. C. C.	CE. 90B	
C28	50mF, 12V, electrolytic	T. C. C.	CE. 431. BD	
DIODES				
MR1	Rectifier, bridge, 500mA, 12V d.c.	Salford Elect. Inst.	$\frac{1}{2}$ A	
MR2	Diode, Zener	G. E. C.	SX. 75	
MR3, MR4	Diode germanium	G. E. C.	CEX. 23	
MR5, MR6				
MR7	Diode, Zener	G. E. C.	SX. 47	
METER				
M1	Meter 100mA with 10mA shunt	W. H. Sanders	B619/010	
PLUGS AND SOCKETS				
PLA, PLB, PLC	Connector BNC, free play	Greenpar Eng. Ltd.	CE. 35070. C	
SKA, SKB, SKC	Connector BNC, bulkhead socket	Greenpar Eng. Ltd.	CE. 35063	
PLD	Plug	Bulgin	P. 73	
SKD	Socket	Bulgin	P. 73	
	Battery connector, positive	Carr Fastener Ltd.	75/946	3-off
	Battery connector, negative	Carr Fastener Ltd.	75/945	3-off

<u>Ref:</u>	<u>Component</u>	<u>Manufacturer</u>	<u>Type No.</u>	<u>Remarks</u>
RESISTORS				
R1	3.9 Kohms $\pm 5\%$	Erie.	109.	
R2	27 Kohms $\pm 5\%$	Erie.	109.	
R3	220 ohms $\pm 5\%$	Erie.	109.	
R4	470 ohms $\pm 2\%$	Erie.	109.	
R5	5.6 Kohms $\pm 5\%$	Erie.	109.	
R6	10 ohms ± 0.25 ohm	Erie.	109.	
R7	91 ohms $\pm 1\%$	Erie.	109.	
R8	910 ohms $\pm 1\%$	Erie.	109.	
R9	10 K ohms $\pm 5\%$	Erie.	109.	
R10	180 ohms $\pm 5\%$	Erie.	109.	
R11	220 Kohms $\pm 5\%$	Erie.	109.	
R12	680 ohms $\pm 5\%$	Erie.	109.	
R13	8.2 Kohms $\pm 5\%$	Erie.	109.	
R14	5.6 Kohms $\pm 5\%$	Erie.	109.	
R15	Adjusted on test	Erie.	109.	
R16	3.9 Kohms $\pm 5\%$	Erie.	109.	
R17	10 Kohms $\pm 5\%$	Erie.	109.	
R18	22 Kohms $\pm 5\%$	Erie.	109.	
R19	470 ohms $\pm 5\%$	Erie.	109.	
R20	1.2 Kohms $\pm 5\%$	Erie.	109.	
R21	3.9 Kohms $\pm 5\%$	Erie.	109.	
R22	10 Kohms $\pm 5\%$	Erie.	109.	
R23	22 Kohms $\pm 5\%$	Erie.	109.	
R24	1 Kohms $\pm 5\%$	Erie.	109.	
R25	47 ohms $\pm 2\%$	Erie.	109.	
R26	100 ohms $\pm 2\%$	Erie.	109.	
R27	82 ohms $\pm 2\%$	Erie.	109.	
R28	62 ohms $\pm 2\%$	Erie.	109.	
R29	47 ohms $\pm 2\%$	Erie.	109.	
R30	39 ohms $\pm 2\%$	Erie.	109.	
R31	30 ohms $\pm 2\%$	Erie.	109.	
R32	24 ohms $\pm 2\%$	Erie.	109.	
R33	20 ohms $\pm 2\%$	Erie.	109.	
R34	15 ohms $\pm 2\%$	Erie.	109.	
R35	12 ohms ± 0.24 ohms	Erie.	109.	
R36	470 ohms $\pm 2\%$	Erie.	109.	
R37	270 ohms $\pm 2\%$	Erie.	109.	
R38	470 ohms $\pm 2\%$	Erie.	109.	
R39	33 Kohms $\pm 2\%$	Erie.	109.	
R40	150 ohms $\pm 5\%$	Erie.	109.	
R41	10 Kohms $\pm 5\%$	Erie.	109.	
R42	22 Kohms $\pm 5\%$	Erie.	109.	

<u>Ref:</u>	<u>Component</u>	<u>Manufacturer</u>	<u>Type No.</u>	<u>Remarks</u>
R43	680 ohms $\pm 5\%$	Erie.	109.	
R44	2.2 Kohms $\pm 5\%$	Erie.	109.	
R45	4.7 Kohms $\pm 5\%$	Erie.	109.	
R46	22 Kohms $\pm 5\%$	Erie.	109.	
R47	10 Kohms $\pm 5\%$	Erie.	109.	
R48	8.2 Kohms $\pm 5\%$	Erie.	109.	
R49	180 ohms $\pm 5\%$	Erie.	109.	
R50	47 Kohms $\pm 2\%$	Erie.	109.	
R51	1 Kohm $\pm 2\%$	Erie.	109.	
R52	20 Kohms $\pm 5\%$	Erie.	109.	
R53	Adjusted on test.	Erie.	109.	
R54	8.2 Kohms $\pm 5\%$	Erie.	109.	
R55	18 Kohms $\pm 5\%$	Erie.	109.	
R56	430 ohms $\pm 5\%$	Erie.	109.	
R57	47 ohms $\pm 2\%$	Erie.	109.	
R58	22 ohms $\pm 5\%$	Erie.	109.	
R59	47 Kohms $\pm 5\%$	Erie.	109.	
R60	390 ohms $\pm 5\%$	Erie.	109.	
R61	100 ohms $\pm 5\%$	Erie.	109.	
R62	56 ohms $\pm 2\%$	Erie.	109.	
R63	2.2 Kohms $\pm 5\%$	Erie.	109.	

VARIABLE RESISTORS

RV1	2 Kohms $\pm 10\%$, linear, wirewound.	Colvern	CLR. 901C
RV2	10 Kohms $\pm 10\%$, linear, wirewound.	Colvern	CLR. 1106/11
RV3	10 Kohms $\pm 10\%$, linear, wirewound.	Colvern	CLR. 1106/11S
RV4	100 ohm $\pm 10\%$, linear, wirewound.	Colvern	CLR. 1106/11S

SWITCHES

SW1	Wafer switch	W. H. Sanders	B3619/021
SW2	Wafer switch	W. H. Sanders	B3619/022
SW3	Wafer switch	W. H. Sanders	B3619/023
SW4	Wafer switch	W. H. Sanders	B3619/024
SW5	Toggle switch, 1 pole, 2 way	Bulgin	S601/PD
SW6	Wafer switch	W. H. Sanders	B3619/026
SW7	Toggle Switch, 2 pole, c/o	Bulgin	S270/PD

TRANSFORMERS

T1	Input Transformer	The Belclere Co. Ltd.	EX. 2724
T2	Output Transformer	"	KN. 2340
T3	Mains Transformer	Willesden Transformer Co.	23

TUNED CIRCUITS

TC1	Tuned circuit assembly, 1 K c/s	W. H. Sanders	B3619/036
TC2	Tuned circuit assembly, 3 K c/s	W. H. Sanders	B3619/037


<u>Ref:</u>	<u>Component</u>	<u>Manufacturer</u>	<u>Type No.</u>	<u>Remarks</u>
TRANSISTORS				
TR1, TR2	Silicon transistor	Texas Inst.	2S. 302	
TR3, TR4	Silicon transistor	Mullard	BCZ. 11	
TR5, TR6				
TR7, TR8				
FUSE				
F1	Fuse link, 250mA, size 00	Belling-Lee	L. 562	
CONTROL KNOBS				
1	Control Knobs Knob, black	Bulgin	K. 360	Modified to W.H.S. D3619/001/34 6-off
BATTERIES				
B1, B2, B3	Battery, dry, 6V.	Vidor	T. 6001	



REPAIR


In general, replacement components may be ordered from the manufacturer or from W. H. Sanders. However, where a drawing number is quoted the component should be ordered from this company.

Enquiries should be made to:-

Commercial Office,
W. H. Sanders (Electronics) Ltd.
Gunnels Wood Road,
STEVENAGE, Hertfordshire, England.







The Input V.S.W.R. resulting from the insertion of attenuation is found by laying a straight-edge from the original V.S.W.R. to the attenuator value and reading-off on the left hand scale.

s	0	1	2	3	4	5	6	7	8	9	s
00	1.000	9960	9920	9881	9841	9802	9763	9724	9685	9646	00
01	9608	9570	9531	9493	9455	9418	9380	9343	9305	9268	01
02	9218	9194	9158	9121	9085	9048	9012	8976	8940	8905	02
03	8869	8833	8798	8763	8728	8693	8658	8624	8589	8555	03
04	8521	8487	8453	8419	8385	8352	8318	8285	8252	8219	04
05	8186	8153	8121	8088	8056	8023	7991	7959	7927	7896	05
06	7864	7833	7801	7770	7739	7708	7677	7646	7615	7585	06
07	7554	7524	7494	7464	7434	7404	7374	7345	7315	7286	07
08	7257	7227	7198	7169	7141	7112	7083	7055	7026	6998	08
09	6970	6942	6914	6886	6858	6831	6803	6776	6749	6721	09
10	6694	6667	6640	6614	6587	6560	6534	6507	6481	6455	10
11	6429	6403	6377	6351	6326	6300	6275	6249	6224	6199	11
12	6174	6149	6124	6099	6074	6049	6025	6000	5976	5952	12
13	5928	5904	5880	5856	5832	5808	5785	5761	5738	5714	13
14	5691	5668	5645	5622	5599	5576	5553	5531	5508	5486	14
15	5463	5441	5419	5397	5374	5352	5331	5309	5287	5265	15
16	5244	5222	5201	5180	5158	5137	5116	5095	5074	5053	16
17	5033	5012	4991	4971	4950	4930	4910	4889	4869	4849	17
18	4829	4809	4789	4770	4750	4730	4711	4691	4672	4652	18
19	4633	4614	4595	4576	4557	4538	4519	4500	4482	4463	19
20	4444	4426	4408	4389	4371	4353	4335	4317	4299	4281	20
21	4263	4245	4227	4210	4192	4174	4157	4139	4122	4105	21
22	4088	4071	4053	4036	4019	4003	3986	3969	3952	3936	22
23	3919	3902	3886	3870	3853	3837	3821	3805	3789	3773	23
24	3757	3741	3725	3709	3693	3678	3662	3646	3631	3615	24
25	3600	3585	3569	3554	3539	3524	3509	3494	3479	3464	25
26	3449	3435	3420	3405	3391	3376	3361	3347	3333	3318	26
27	3304	3290	3276	3262	3247	3233	3219	3206	3192	3178	27
28	3164	3150	3137	3123	3110	3096	3083	3069	3056	3043	28
29	3029	3016	3003	2990	2977	2964	2951	2938	2925	2912	29
30	2899	2887	2874	2861	2849	2836	2824	2811	2799	2787	30
31	2871	2859	2847	2835	2823	2811	2799	2787	2775	2764	31
32	2854	2842	2830	2818	2806	2794	2782	2770	2758	2746	32
33	2838	2826	2814	2802	2790	2778	2766	2754	2742	2730	33
34	2826	2814	2802	2790	2778	2766	2754	2742	2730	2718	34
35	2818	2806	2794	2782	2770	2758	2746	2734	2722	2710	35
36	2811	2800	2789	2778	2767	2756	2745	2734	2723	2712	36
37	2805	2794	2783	2772	2761	2750	2739	2728	2717	2706	37
38	2800	2790	2780	2770	2760	2750	2740	2730	2720	2710	38
39	2800	2790	2780	2770	2760	2750	2740	2730	2720	2710	39
40	2800	2790	2780	2770	2760	2750	2740	2730	2720	2710	40
41	2800	2790	2780	2770	2760	2750	2740	2730	2720	2710	41
42	2800	2790	2780	2770	2760	2750	2740	2730	2720	2710	42
43	2800	2790	2780	2770	2760	2750	2740	2730	2720	2710	43
44	2800	2790	2780	2770	2760	2750	2740	2730	2720	2710	44
45	2800	2790	2780	2770	2760	2750	2740	2730	2720	2710	45
46	2800	2790	2780	2770	2760	2750	2740	2730	2720	2710	46
47	2800	2790	2780	2770	2760	2750	2740	2730	2720	2710	47
48	2800	2790	2780	2770	2760	2750	2740	2730	2720	2710	48
49	2800	2790	2780	2770	2760	2750	2740	2730	2720	2710	49

s	0	1	2	3	4	5	6	7	8	9	s
00	1.000	9980	9960	9940	9920	9901	9881	9861	9841	9822	00
01	9802	9782	9763	9743	9724	9704	9685	9666	9646	9627	01
02	9618	9599	9579	9559	9531	9512	9493	9474	9455	9436	02
03	9418	9399	9380	9361	9342	9324	9305	9286	9268	9249	03
04	9231	9212	9194	9176	9157	9139	9121	9102	9084	9066	04
05	9048	9030	9011	8993	8975	8957	8939	8922	8904	8886	05
06	8868	8850	8832	8815	8797	8779	8762	8744	8727	8709	06
07	8692	8674	8657	8639	8622	8603	8587	8570	8553	8536	07
08	8519	8501	8484	8467	8450	8433	8416	8399	8382	8366	08
09	8349	8332	8315	8298	8282	8265	8248	8232	8215	8198	09
10	8182	8165	8149	8132	8116	8100	8083	8067	8051	8034	10
11	8018	8002	7986	7970	7953	7937	7921	7905	7889	7873	11
12	7857	7841	7825	7809	7794	7778	7762	7746	7731	7715	12
13	7699	7684	7668	7652	7637	7621	7606	7590	7575	7559	13
14	7544	7529	7513	7498	7483	7467	7452	7437	7422	7406	14
15	7391	7376	7361	7346	7331	7316	7301	7286	7271	7256	15
16	7241	7226	7212	7197	7182	7167	7153	7138	7123	7109	16
17	7094	7079	7065	7050	7036	7021	7007	6992	6978	6964	17
18	6949	6935	6921	6906	6892	6878	6863	6849	6835	6821	18
19	6807	6793	6779	6765	6750	6736	6722	6708	6695	6681	19
20	6667	6653	6639	6625	6610	6596	6584	6570	6556	6543	20
21	6529	6515	6502	6488	6475	6461	6447	6434	6420	6407	21
22	6393	6380	6367	6354	6340	6327	6313	6300	6287	6273	22
23	6260	6247	6234	6221	6208	6194	6181	6168	6155	6142	23
24	6129	6116	6103	6090	6077	6064	6051	6039	6026	6013	24
25	6000	5987	5974	5962	5949	5936	5924	5911	5898	5886	25
26	5873	5860	5848	5835	5823	5810	5798	5785	5773	5760	26
27	5748	5736	5723	5711	5699	5686	5674	5662	5650	5637	27
28	5623	5613	5601	5589	5576	5564	5552	5540	5528	5516	28
29	5504	5492	5480	5468	5456	5444	5432	5420	5408	5397	29
30	5385	5373	5361	5349	5337	5326	5314	5302	5291	5279	30
31	5267	5256	5244	5232	5221	5209	5198	5186	5175	5163	31
32	5152	5140	5129	5117	5106	5094	5083	5072	5060	5049	32
33	5038	5026	5015	5004	4993	4981	4970	4959	4948	4937	33
34	4925	4914	4903	4892	4881	4870	4859	4848	4837	4826	34
35	4815	4804	4793	4782	4771	4760	4749	4738	4728	4717	35
36	4706	4695	4684	4674	4663	4652	4641	4631	4620	4609	36
37	4599	4588	4577	4567	4556	4546	4535	4524	4514	4503	37
38	4493	4482	4472	4461	4451	4440	4430	4420	4409	4399	38
39	4389	4378	4368	4358	4347	4337	4327	4316	4306	4296	39
40	4286	4276	4265	4255	4245	4235	4225	4215	4205	4195	40
41	4184	4174	4164	4154	4144	4134	4124	4114	4104	4094	41
42	4083	4073	4063	4053	4043	4033	4023	4013	4003	3996	42
43	3986	3976	3967	3957	3947	3937	3928	3918	3908	3899	43
44	3889	3879	3870	3860	3850	3841	3831	3822	3812	3803	44
45	3793	3784	3774	3765	3755	3746	3736	3727	3717	3708	45
46	3699	3690	3680	3671	3661	3652	3643	3633	3624	3615	46
47	3605	3596	3587	3578	3569	3559	3550	3541	3532	3523	47
48	3514	3504	3495	3486	3477	3468	3459	3450	3441	3432	48
49	3423	3414	3405	3396	3387	3378	3369	3360	3351	3342	49
50	3325	3316	3307	3298	3289	3280	3271	3263	3254	3245	50
51	3167	3158	3149	3140	3131	3122	3113	3104	3095	3086	51
52	3080	3071	3062	3053	3044	3035	3026	3017	3008	2999	52
53	2996	2987	2978	2969	2960	2951	2942	2933	2924	2915	53
54	2912	2903	2894	2885	2876	2867	2858	2849	2840	2831	54
55	2829	2820	2811	2802	2793	2784	2775	2766	2757	2748	55
56	2747	2738	2729	2720	2711	2702	2693	2684	2675	2666	56
57	2666	2657	2648	2639	2630	2621	2612	2603	2594	2585	57
58	2587	2578	2569	2560	2551	2542	2533	2524	2515	2506	58
59	2508	2499	2490	2481	2472	2463	2454	2445	2436	2427	59
60	2430	2421	2412	2403	2394	2385	2376	2367	2358	2349	60
61	2353	2344	2335	2326	2317	2308	2299	2290	2281	2272	61
62	2278	2269	2260	2251	2242	2233	2224	2215	2206	2197	62
63	2203	2194	2185	2176	2167	2158	2149	2140	2131	2122	63
64	2129	2120	2111	2102	2093	2084	2075	2066	2057	2048	64
65	2056	2047	2038	2029	2020	2011	2002	1993	1984	1975	65
66	1983	1974	1965	1956	1947	1938	1929	1920	1911	1902	66
67	1919	1910	1901	1892	1883	1874	1865	1856	1847	1838	67
68	1848	1839	1830	1821	1812	1803	1794	1785	1776	1767	68
69	1779	1770	1761	1752	1743	1734	1725	1716	1707	1698	69
70	1703	1694	1685	1676	1667	1658	1649	1640	1631	1622	70
71	1635	1626	1617	1608	1599	1590	1581	1572	1563	1554	71
72	1567	1558	1549	1540	1531	1522	1513	1504	1495	1486	72
73	1508	1499	1490	1481	1472	1463	1454	1445	1436	1427	73
74	1442	1433	1424	1415	1406	1397	1388	1379	1370	1361	74
75	1375	1366	1357	1348	1339	1330	1321	1312	1303	1294	75
76	1306	1297	1288	1279	1270	1261	1252	1243	1234	1225	76
77	1249	1240	1231	1222	1213	1204	1195	1186	1177	1168	77
78	1179	1170	1161	1152	1143	1134	1125	1116	1107	1098	78
79	1117	1108	1099	1090	1081	1072	1063	1054	1045	1036	79
80	1056	1047	1038	1029	1020	1011	1002	993	984	975	80
81	995	986	977	968	959	950	941	932	923	914	81
82	905	896	887	878	869	860	851	842	833	824	82
83	817	808	799	790	781	772	763	754	745	736	83
84	728	719	710	701	692	683	674	665	656	647	84
85	638	629	620	611	602	593	584	575	566	557	85
86	548	539	530	521	512	503	494	485	476	467	86
87	458	449	440	431	422	413	404	395	386	377	87
88	368	359	350	341	332	323	314	305	296	287	88
89	278	269	260	251	242	233	224	215	206	197	89
90	188	179	170	161	152	143	134	125	116	107	90
91	98	89	80	71	62	53	44	35	26	17	91
92	7	-2	-11	-20	-29	-38	-47	-56	-65	-74	92
93	-84	-93	-102	-111	-120	-129	-138	-147	-156	-165	93
94	-174	-183	-192	-201	-210	-219	-228	-237	-246	-255	94
95	-264	-273	-282	-291	-300	-309	-318	-327	-336	-345	95
96	-354	-363	-372	-381	-390	-399	-408	-417	-426	-435	96
97	-444	-453	-462	-471	-480	-489	-498	-507	-516	-525	97
98	-534	-543	-552	-561	-570	-579	-588	-597	-606	-615	98
99	-624	-633	-642	-651	-660	-669	-678	-687	-696	-705	99
5											5

$$\frac{1.5}{2.5} = 0.6$$

$$P_v = \frac{S-1}{S+1}$$

$$\frac{1.5}{2.5} = 0.6$$

$$P_b = \left(\frac{S-1}{S+1} \right)^2$$

$$= 0.36$$



W. H. SANDERS (ELECTRONICS) LTD.

STEVENAGE RELAYS LTD.


STEVENAGE TOOLS AND SWITCHES LTD.

ARROW LTD

SANDERS ELECTRONICS G.M.B.H. FRANKFURT-AM-MAIN

PARRISH INSTRUMENTS LTD.

SOMA LTD. (SANDERS OVERSEAS MICROWAVE AGENCY LTD.)



R.F. INDICATOR AND SELECTIVE AMPLIFIER

