

SmartCharger Settings

For SR xxx B and SR xxx B

Ref. no:

Danama - 4 /	Rei. III.	Chacified	Default
Parameter (se	ettings at 20 degreesC)	Specified Settings	Settings
V float			2.3V/cell
V boost			2.45V/cell
Standing load	(A) - maximum allowable		1% of I rated
Current limit (A)		I rated
Over temperat	ure cutout, degrees C (only for Li-ion batteries)		NO
*Current initiat	ted boost point (% of rated current, A)		15%
*Current termi	nated boost point (% of rated current, A)		10%
Microprocesso	or Settings		
Code	Description		
*SBS	Start in Boost State at charger start-up		YES
*СТВ	Current Terminated Boost - allows termination of boost charge via the detection of a predefined value of charge current (default = 15% of max charge current)		YES
*CIB	Current Initiated Boost - allows initiation of boost charge via the detection of a predefined value of charge current (default = 10% of max charge current)		YES
*MRSB	Mains Return Start Boost - after the detection that mains has been restored to the charger a boost charge cycle will be initiated.		YES
PBT (minutes)	Pre-Boost State Time - the time the charger will always stay at the elevated boost voltage whenever an attempt is made to enter a boost charge cycle		1
BT (1-48 hours)	Boost Time - The maximum time the charger can spend in a boost charge cycle. If the charger is still in boost after this time it will enter the forced float state. Reset by turning mains off and on. The forced float state does not allow any further boost cycles unless initiated by user initiated boost button press.		24
PFT (minutes)	Pre Float Time - the time the charger will always stay at the float voltage whenever an attempt is made to enter a float charge cycle		1
RMFT (1-255 minutes)	Recall Mains Fail Time - maximum time of a mains fail where on the reoccurrence of mains the charger will resume charging in the mode as prior to the mains fail		10
MFT (1-24 hours)	Mains Fail Time - the time of a mains fail after which the charger will always restart with a boost cycle when mains reoccurs.		24
PFFT (1-255 minutes)	Pre Forced Float Time - the time the charger will always stay at the float voltage whenever an attempt is made to enter a forced float charge cycle		1
DBMFA (0.06- 8.5 minutes)	Delay before mains fail alarm - the time before alarm activated on a mains failure ('E' versions)		5
	New SFBOOST code to be allocated (IE use only)		

^{*} Auto boost not available for high voltage (64V and above) SR500/SR750 versions, default setting = 'NO'



SmartCharger Settings

For SR xxx B and SR xxx B

* HV (high voltage) versions only B = default version										Manual boost versions (LV)					
CODE	A *	В	D	E	F	G	I	J	K	L	М	N	P*	Q	R
SBS	NO	YES	YES	YES	NO	NO	YES	NO	NO	YES	YES	YES	NO	YES	NO
СТВ	NO	YES	YES	YES	YES	YES	YES	YES	YES	YES	YES	YES	NO	YES	NO
CIB	NO	YES	NO	YES	NO	NO	NO	NO	NO	YES	NO	YES	NO	NO	NO
MRSB	NO	YES	YES	YES	NO	NO	NO	NO	NO	YES	NO	YES	NO	YES	NO
PBT(min)	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
BT (hrs)	24	24	8	12	24	0.02	24	8	4	8	8	7	2	7	1
PFT (min)	1	1	1	1	1	1	1	1	1	10	1	1	1	1	1
RMFT(min)	10	10	10	10	240	240	255	10	1	24	255	10	10	10	70
MFT(hrs)	24	24	24	24	24	24	24	24	255	1	24	24	24	24	24
PFFT(min)	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
DBMFA (mins)	5	5	5	5	1	5	5	1	1	1	1	5	5	5	5

CODE	S	Т	U	V	W	Х	Y	Z	ZA	ZB	ZC	ZD		
SBS	NO	YES	NO	NO	YES	YES	YES	YES	NO	NO	NO	NO		
СТВ	YES	YES	NO	YES	YES	YES	YES	YES	NO	YES	NO	YES		
CIB	NO	NO	NO	NO	YES	YES	YES	NO	NO	NO	NO	NO		
MRSB	NO	YES	NO	NO	YES	YES	YES	YES	NO	YES	NO	NO		
PBT(min)	1	1	1	1	1	1	1	1	1	1	1	1		
BT (hrs)	4	4	5	2	24	2	4	8	2	2	8	3		
PFT (min)	1	1	1	1	1	1	1	1	1	1	1	1		
RMFT(min)	1	10	255	255	10	10	10	10	10	10	70	255		
MFT(hrs)	255	24	24	24	0	24	24	1	2	1	1	24		
PFFT(min)	1	1	1	1	1	1	1	1	1	1	1	1		
DBMFA (mins)	0.1	5	5	5	0	5	5	5	0.1	1	5	5		

Notes:

G = all boost functions disabled, this firmware is used to obtain electronic reverse polarity protection

S = No LED flash codes on mains fail, all other functions unchanged

^{*}HV versions available only in 500W and 750W models