


fi-5120C/fi-5220C Image Scanner





CONTENTS

		egulatory Informationii
		ote, Liabilityiii
	∎ Sa	afety Precautionsv
Chapter1		PREPARING THE SCANNER1
1	1.1	Checking the Contents of the Scanner Package
1	1.2	Names and Functions of Parts1
1	1.3	Operator Panel 2
Chapter2		INSTALLATION OF THE SCANNER
2	2.1	Installing the Scanner 3
2	2.2	Connecting the Scanner to Your PC 4
2	2.3	Installing the Scanner Application5
Appendix	1	TROUBLESHOOTING AP-1
Appendix2	2	DAILY CARE AP-4
Appendix	3	REPLACING CONSUMABLES AP-5

INTRODUCTION

Thank you for purchasing the fi-5120C/fi-5220C Duplex Color Scanner product.

This document describes how to handle fi-5120C/fi-5220C Duplex Color and basic operation methods. Before you start using fi-5120C/fi-5220C Duplex Color be sure to thoroughly read this manual to ensure correct use.

The "Operator's Guide" is stored on the Setup Disk. The guide provides useful and detailed information on Operations when you would like to using advanced features, daily maintenance of the scanner, replacement of consumables.Please also read the Operator's Guide for your reference.

Regulatory Information

FCC Declaration

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- •Reorient or relocate the receiving antenna.
- •Increase the separation between the equipment and receiver.
- •Connect the equipment into an outlet on a circuit different from that to which the receiver is located.
- •Consult your dealer or an experienced radio/TV technician.

FCC warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



The use of a shielded interface cable is required to comply with the Class B limits of Part 15 of FCC rules. The length of the AC cable must be 2 meters (6.6 feet) or less.

.

Canadian DOC Regulations

This digital apparatus does not exceed the Class B limit for radio noise emissions from digital apparatus set out in the Radio interference Regulations of the Canadian Department of Communications.

This Class B digital apparatus complies with Canadian ICES-003.

Le pésent appareil numérique n'ément pas de parasites radioélectriques dépassant les limites applicables aux appareils numériques de la classe B, limites prescridtes dans le Réglement pour le brouillage radioélectrique qui fut dicté par le Ministere des Communications du Canada. Cet appareil numérique de la classe B est conformme à la norme NMB-003 du Canada.

Bescheimigung des Herstellers / Importeurs

Für den fi-5120C/fi-5220C2 wid folgendes bescheinigt:

- •In Übereinsstimmung mit den Bestimmungen der EN45014(CE) funkentstört
- •Maschinenlärminformationsverordnung 3.GPSGV, 06.01.2004: Der höchste Schalldruckpegel beträgt 70 dB (A) oder weniger, gemäß EN ISO 7779.

International ENERGY STAR® Program

As an ENERGY STAR[®] Partner, PFU LIMITED has determined that this product meets the ENERGY STAR[®] guidelines for energy efficiency.



The International ENERGY STAR[®] Office Equipment Program is an international program that promotes energy saving through the penetration of energy efficient computers and other office equipment. The program backs the development and dissemination of products with functions that effectively reduce energy consumption. It is an open system in which business proprietors can participate voluntarily. The targeted products are office equipment such as computers, monitors, printers, facsimiles, copiers, scanners, and multifunction devices.

Their standards and logos (\underline{argue}) are uniform among participating nations.

Note, Liability

BEFORE USING THIS PRODUCT, PLEASE READ THIS MANUAL CAREFULLY. IF THIS PRODUCT IS NOT USED CORRECTLY, UNEXPECTED INJURY CAN OCCUR TO USERS OR BYSTANDERS.

Keep this manual in a safe place so that it can be easily referred to during use of this product.

While all efforts have been made to ensure the accuracy of all information in this manual, PFU assumes no liability to any party for any damage caused by errors or omissions or by statements of any kind in this manual, its updates or supplements, whether such errors are omissions or statements resulting from negligence, accidents, or any other cause. PFU further assumes no liability arising from the application or use of any product or system described herein; nor any liability for incidental or consequential damages arising from the use of this manual. PFU disclaims all warranties regarding the information contained herein, whether expressed, implied, or statutory.

Use in High-safety Applications

This product has been designed and manufactured on the assumption that it will be used in office, personal, domestic, regular industrial, and general-purpose applications. It has not been designed and manufactured for use in applications (simply called "high-safety applications" from here on) that directly involve danger to life and health when a high degree of safety is required, for example, in the control of nuclear reactions at nuclear power facilities, automatic flight control of aircraft, air traffic control, operation control in mass-transport systems, medical equipment for sustaining life, and missile firing control in weapons systems, and when provisionally the safety in question is not ensured. The user should use this product with adopting measures for ensuring safety in such high-safety applications. PFU LIMITED assumes no liability whatsoever for damages arising from use of this product by the user in high-safety applications, and for any claims or compensation for damages by the user or a third party.

About the Use of Mercury



Lamp(s) inside this product contain mercury and must be recycled or disposed of according to local, state, or federal laws.

To avoid unexpected injuries:

•Do not put the substance contained in the lamp in your mouth as it has mercury.

- •Do not breathe the chemical liquid contained in the scanner lamps.
- •Do not incinerate, crush, or shred the lamps or scanner parts.

Trademarks

Microsoft, Windows, and Windows NT are registered trademarks of Microsoft Corporation in the United States and/or other countries. ISIS, QuickScan and their respective logos are trademarks or registered trademarks of Pixel Translations, a division of Captiva Software Corporation in the United States. Adobe, the Adobe logo, and Acrobat are either registered trademarks of Adobe Systems Incorporated in the United States and/or other countries. Other product names are the trademarks or

registered trademarks of the respective companies.

How Trademarks Are Indicated In This Manual

References to operating systems (OS) and applications are indicated as follows:

Windows 95	Microsoft [®] Windows [®] 95 operating system
Windows 98	Microsoft [®] Windows [®] 98 operating system.
Windows Me	Microsoft [®] Windows [®] Millen- nium Edition operating system.
Windows NT 4.0	Microsoft [®] Windows NT [®] 4.0 Server operating system, Microsoft [®] Windows NT [®] 4.0 Workstation operating system.
Windows 2000	Microsoft [®] Windows [®] 2000 Pro- fessional operating system.
Windows XP	Microsoft [®] Windows [®] XP Professional operating system, Microsoft [®] Windows [®] XP Home Edition operating system.

Where there is no distinction between the different versions of the above operating system, the general term "Windows " is used.

Adobe Acrobat Adobe[®] Acrobat[®]

All the descriptions in this manual assume the usage of Adobe Acrobat bundled with this product. However, Adobe Acrobat may be upgraded without notice. If the descriptions differ from the screens actually displayed, refer to the Acrobat's "Help".

Manufacturer

PFU LIMITED


International Sales Dept., Imaging Business Division, Products Group Solid Square East Tower, 580 Horikawa-cho, Saiwai-ku, Kawasaki-shi Kanagawa 212-8563, Japan Phone : (81-44) 540-4538

All Rights Reserved, Copyright© PFU LIMITED 2005.

About Maintenance

The user must not perform repairs on this scanner. Contact the store where you purchased the scanner or an authorized FUJITSU Image Scanner service provider to have repairs done on this product.


Warning Indications Used In This Manual



CAUTION

This indication alerts operators to an operation that, if not strictly observed, may result in safety hazards to personnel or damage to equipment.

Symbols Used In This Manual





A TRIANGLE symbol indicates that special care and attention is required. The drawing inside the triangle shows the specific caution.

.



A CIRCLE with a diagonal line inside shows action which users may not perform. The drawing inside or under the circle shows the specific action that is not allowed.




Outline characters on a colored background show instructions users should follow.

It may also include the drawing that shows the specific instruction.

Warning Label



The glass surface inside the ADF becomes hot during the operation. Be careful not to touch the glass surface inside the ADF.



Screen Examples In This Manual

The screen examples in this manual are subject to change without notice in the interest of product improvement. If the actual displayed screen differs from the screen examples in this manual, operate by following the actual displayed screen while referring to the User's Manual of the scanner application you are using.

The screenshots in this manual were captured from FUJITSU TWAIN32 scanner driver, ScandAll 21 Image Capturing Utility Software, FUJITSU ISIS scanner driver, QuickScanTM

image capturing software and $Adobe^{\mathbb{R}} Acrobat^{\mathbb{R}}$.

Safety Precautions



Do not damage the AC cable.



A damaged AC cable may cause fire or electric shock. Do not place heavy objects on AC cables, or pull, bend, twist, heat, damage or modify AC cables. Do not use damaged AC cables or power

plugs, or install any cables or power plugs to loose wall sockets.

Use only specified AC cables and connector cables.



Use only specified AC cables and connector cables. Failure to use the correct cables might cause electric shock and/or equipment failure.

Please don't use the AC cable provided with this scanner for other devices, since this might cause equipment failure and other troubles or an electric shock.

Use this scanner only at the indicated power voltage. Do not connect to multiple-power strips.



Use this scanner only at the indicated power voltage and current. Improper power voltage and current might cause fire or electric shock. Do not connect to multiplepower strips.

Do not touch the AC cable with wet hands.



Do not touch the power plug with wet hands. Doing so might cause electric shock.

Wipe any dust from the power plug.



Wipe off any dust from metal parts on the power plug or metal fittings with a soft, dry cloth. Accumulated dust might cause fire or electric shock.

Do not install the device in locations that has oil smoke, steam, humidity, and dust.



Do not install the scanner in locations subject to oil smoke, steam, humidity, and dust. Doing so might cause a fire or electric shock.

Turn the scanner OFF if it is damaged.



If the scanner is damaged for any reason, turn the scanner off and unplug the power cable. Contact the store where you purchased the scanner.

Do not put liquids inside the scanner.



Do not insert or drop metal objects in to the scanner. Do not scan wet documents or documents with paper clips or staples. Do not splash or allow the scanner to get wet.



If foreign objects (water, small metal objects, liquids, etc.) get inside the scanner, immediately turn off the scanner and disconnect the power plug from the power outlet. Then, contact the store where you bought the scanner or the Maintenance Service Center. Pay particular attention to this warning in households where there are small children.

Do not touch the inside of the scanner unless necessary.



Do not take apart or modify the scanner. The inside of the scanner contains highvoltage components. Touching these components might cause electric shock or fire.

Do not use the scanner if you smell a strange odor.



If you detect heat coming from the device or detect other problems such as smoke, strange smells or noises, immediately turn off the scanner and then disconnect its power plug. Make sure that any smoke coming from it has stopped, before contacting the store where you bought the scanner or an authorized FUJITSU scanner service provider.

Do not install the scanner on unstable surfaces.



Make sure that the scanner is installed on a flat, level surface and that none of its parts extend beyond the surface top, such as a desk or table. Do not install the scanner on unstable surfaces. Install the scanner on a level surface that is free of vibration to prevent it from falling.

Install the scanner on a strong surface that will support the weight of the scanner and other devices.

Do not block the ventilation ports.



Do not block the ventilation ports. Blocking the ventilation ports generates heat inside of scanner, which may result in fire or scanner failure.

Do not place heavy objects or climb on top of the scanner.



Do not place heavy objects on the scanner or use the scanner's surface top to perform other work. Improper installation might cause injuries and equipment failure.

Firmly insert the power plug.



Firmly insert the power plug as far it can go into the power outlet.

Avoid any contact when scanner is in use.



Avoid touching any scanner mechanism during scanning since this may cause injuries.

Do not use the scanner immediately after moving it from a cold place into a warm room.



Do not use the device immediately after moving it from a cold place into a warm room. Condensation may occur, which might lead to scanning errors. Let the device dry about one or two hours before you use it.

Before moving the scanner, disconnect the power plug from the power outlet.



Do not move the scanner with the power and interface cables connected as this can damage the cables, which can later cause fire, electric shock as well as injury. Before moving the scanner, be sure to disconnect the power plug from the power outlet, and all other data cables. Make sure that the floor is free of any obstructions.

Protect the scanner from static electricity.



Install the scanner away from strong magnetic fields and other sources of electronic noise. Also, protect the scanner against any static electricity, which can cause the scanner to malfunction.

Do not use aerosol sprays near the scanner.



Do not use aerosol sprays to clean the scanner. Aerosol sprays can blow dirt and dust inside the scanner, resulting in scanner failure or malfunction.

Disconnect the power plug from the power outlet when the scanner is not used for a long period of time.



When the scanner is not going to be used for a long period of time, be sure to disconnect the power plug from the power outlet for safety.

Do not install the scanner in the direct sunlight.



Do not install the scanner under direct sunlight or near heating apparatus. Doing so might cause excessive heat to build up inside the scanner, which can cause scanner trouble or even fire. Install the scanner in a well-ventilated location.

Before moving the scanner, make sure the shipping lock is locked.



When moving the scanner, be sure to lock the shipping lock in order to prevent damages to the scanner.

Chapter1 PREPARING THE SCANNER

1.1 Checking the Contents of the Scanner Package


When you open the scanner package, please handle the main unit and its attachments carefully. Make sure it contains all the parts listed in the package contents list that is included in the package box. If any parts are missing or defective, contact the dealer you purchased the scanner or an authorized Fujitsu scanner service provider. Handle the scanner and accessories with care.

1.2 Names and Functions of Parts


This section describes the scanner parts and their functions.













Inside

[fi-5220C]






[fi-5120C]




[fi-5220C]




Removable Parts

Parts that can be removed from the scanner are displayed below.



1.3 Operator Panel

The operator panel is located on the right side of the scanner. This panel comprises of a Function Number display, four buttons and a LED.



Name		Function
Function Number display		Indicates the function Num- ber and error status.
Buttons	Function	Changes the Function activated by the Send to button (*).
	Send to	Launches the linked applica-
	Scan	tion software (*).
	Power button	Turns the scanner ON and OFF.
LED	-	Lights when the scanner is turned ON.

*) About the settings on the launcher, refer to FUJITSU TWAIN32 scanner driver help and the "fi-5120C/fi-5220Cfi-5120C/fi-5220C Operator's Guide" in the Setup CD-ROM.

Indications on the Function Number Display

No.	Descriptions
8	Lights only one time upon turning on the scanner.
Ρ	Indicates that the scanner has been turned ON and is being initialized.
0	Indicates that initialization will soon be completed.
1	Indicates that initialization has been completed successfully. This status is called "Ready Status".
U	Indicates that a temporary error occurred when documents were being scanned. A number appear- ing in alternation following the U (i.e., 1 or 2, etc.) refers to the type of error. To return the scanner to the ready status ("1"), press "Scan" or "Send to" button.
E	Indicates that a device (hardware) alarm has occurred during scanning of documents. "E" and the alarm Number (0 to 9, A,c,d and F) will appear alternately. To return the scanner to the ready status ("1"), press "Scan" or "Send to" button. If this alarm occurs, turn the power off and on again. If the alarm continues after turning the power on again, contact your service engineer.

Chapter2 INSTALLATION OF THE SCANNER

2.1 Installing the Scanner


1. Place the scanner at its installation site.


For details on the scanner's dimensions and required installation space, refer to "fi-5120C/fi-5220C Operator's Guide" "7.2 Installation Specifications" in the Setup CD-ROM. For fi-5120C, go to Step 3.

2. Unlock the Shipping lock.

The carrier unit inside the scanner is fixed in place by the shipping lock to prevent the scanner from becoming damaged during transportation from the factory.

After transporting and placing the scanner, tilt the scanner (approx. 30 degrees) and release the Shipping lock on the bottom of the scanner.







3. Attach the ADF paper chute.

Hold the ADF paper chute and insert its tabs into the corresponding slots in the scanner as shown in the next figure below.


The Side guides of the ADF paper chute have to face up.




4. Connect the AC adapter.



1) Connect the AC cable to the AC adapter.



2) Connect the AC adapter connector to the scanner's DC inlet.



3) Plug the AC cable into the outlet.




The Function Number Display and the LED may flash for an instant when plugging the AC cable into the outlet.

.

2.2 Connecting the Scanner to Your PC


When running Windows 95 or Windows NT 4.0, connect the SCSI interface cable. When running Windows 98, Windows Me, Windows 2000, or Windows XP, connect either the USB interface cable or the SCSI interface cable.



This scanner is provided with two interfaces: Ultra SCSI and USB 2.0 /1.1. Connect only one of the USB or SCSI interface cable. Windows 95 and Windows NT 4.0 do not support USB interface.

Connecting with the USB Interface Cable

Connect the USB interface cable to the USB 1. interface connector.



Connect the other end of the USB interface 2. cable to the PC.



Be sure to use the USB cable which comes as an accessory with this scanner.

Scanning operation with commercially available cables is not guaranteed.

- When connecting to an USB hub, use the first stage USB hub that is closest to the computer. If you use the second or later hub stages, the scanner may not operate correctly.
- If you connect the scanner with USB 2.0, it is required that the USB port and Hub are compliant with USB 2.0. The scanning speed may slow down if it is connected with USB1.1.

.........

Connecting with the SCSI Inter-face Cable

When using the scanner with SCSI interface, a commercially available SCSI interface cable and SCSI card must be purchased in addition.

SCSI interface cable:

Use a connector which complies with Ultra SCSI. A 50 Pin Contact Shielded High-Density SCSI Device Connector is required.

SCSI card:

Find the recommended SCSI card information in the Fujitsu web site (FAQ).


http://imagescanner.fujitsu.com/







- When connecting the SCSI interface cable, turn the scanner off. Be sure to first connect the SCSI interface cable and, then turn on the power of the scanner and the personal computer.
- In a SCSI daisy chain formation, connect the scanner so that it is the terminated device.

Insert the SCSI interface cable into the inter-1. face connector until both sides click.



Connect the other end of the cable to the per-2. sonal computer.





2.3 Installing the Scanner Application

For scanning documents with this scanner, both scanner driver and image capturing application software (called "application" hereafter) must be installed on your PC. The following scanner drivers and applications are provided:

- Scanner Driver: FUJITSU TWAIN 32 Scanner Driver FUJITSU ISIS Scanner Driver
- Scanning application: ScandAll 21 (for FUJITSU TWAIN 32) QuickScan ProTM (for FUJITSU ISIS)

Install the appropiate scanner driver for the application you will use. The following sections descri be installation of each driver and application.

For FUJITSU TWAIN32 Scanner Driver

Preparation

Confirm the following items before installing the application.

- Take out the Setup CD-ROM from its package, but do not insert the Setup CD-ROM into the CD driver yet.
- Connect the scanner correctly to your PC.



For details on how to connect the scanner, refer to "2.2 Connecting the Scanner to Your PC" on page 4.

.

 Uninstall any older versions of FUJITSU TWAIN 32 driver if already installed.

.

Uninstall [Scanner Utility for Microsoft Windows] from [Add/Remove Programs] of the control panel.

-
 - There are two types of FUJITSU TWAIN 32: One of the following driver software will be installed automatically according to your Operating System (OS).

□<u>For Windows 98, Windows Me, Windows</u> 2000, and Windows XP:

FUJITSU TWAIN32 V9

□ For Windows 95, Windows NT 4.0:

FUJITSU TWAIN32 V8

ASPI Manager V4.01 or later is required (generally comes with SCSI board products).

Installing the FUJITSU TWAIN32 Scanner Driver

Windows XP screenshots are used in this section as examples. The windows and operations may slightly vary, if your OS is other than Windows XP.

1. Press the power button to turn on the scanner.

2. Turn on your PC and log on to Windows.

When using Windows NT 4.0, Windows 2000 or Windows XP, log on as a user with "Administrator" privileges (privileges of the administrator of your PC).


 If the scanner is automatically detected, [Found New Hardware Wizard] or [Add/ Remove Hardware Wizard] dialog box will appear. Click [Cancel] to close the Wizard window.

Found New Hardware Wiz	ard
	Welcome to the Found New Hardware Wizard
	This wizard helps you install software for:
	fi-5220Cdj
- the	Uf your hardware came with an installation CD or floppy disk, insert it now.
	What do you want the wizard to do?
	 Install the software automatically (Recommended) Install from a list or specific location (Advanced)
	Click Next to continue.
	< Back Next > Cancel

- 4. Insert the Setup CD-ROM into the CD drive.
 - \Rightarrow <SETUP DISK START UP SCREEN> appears.
- This screen may not appear when the "Autoplay" setting of your PC is off. In this case, run "Install.exe" in this CD-ROM directly from the "Explorer" or "My Computer".

.

5. Click [INSTALL PRODUCTS].




6. Click [TWAIN Driver] on the window below.



7. Error Recovery Guide Installation window appears.

Error Recovery Guide is a software that displays troubleshooting information on screen when any scanner error occurs, and its installation is highly recommended. However, it can be installed later if you do not install it in this step.




 Select a language used for installation on [Choose Setup Language] window and click [OK].

Choose S	ietup Language 🛛 🛛 🔀
2	Select the language for this installation from the choices below.
	English Cancel

- 9. Install the application following the instructions on the window.
- 10. When the [InstallShield Wiizard Complete] window appears, click [Finish].

Scanner Utility for Microsoft Windows Setup		
	InstallShield Wizard Complete The setup installed Scanner Utility for Microsoft Windows in the computer normally.Before using this program, it is necessary to re-start a computer. Yes, I want to restart my computer now. No, I will restart my computer later. Please click [Finish] button and end an setup.	
< Back Finish Cancel		

Your computer will be restarted and the scanner will be detected. Do not remove the Setup CD-ROM from the CD drive until your PC has completely restarted.



Now the installation of the scanner driver is completed.


.




To confirm whether the installation was successful, perform a scanning operation with an application that complies with the TWAIN regulations such as ScandAll 21.

Installing ScandAll 21

"Scandall 21" is an image capturing software that complies with the TWAIN standard.



- 1. Insert the Setup CD-ROM into the CD drive.
 - ⇒ <SETUP DISK START UP SCREEN> appears.
- 2. Click [INSTALL PRODUCTS].



3. Click [ScandAll 21] on the window below.



4. Select a language used for installation on [Choose Setup Language] window and click [OK].



- 5. Install the application following the instructions on the window.
- 6. When the [InstallShield Wizard Complete] window appears, click [Finish]

	InstallShield Wizard Complete
	The InstallShield Wizard has successfully installed ScandAll 21. Click Finish to exit the wizard.
	🔽 I want to run the ScandAll 21 now.
	To Complete Setup, click (Finish) button.
< Back Finish Cancel	

For finishing the installation, it may be necessary to restart your computer. Follow the instructions on the window.

Confirming Installation

1. Set documents on the ADF paper chute.

For details on how to set documents, refer to the "1.2 Loading Documents on the ADF for Scanning" in the fi-5120C/fi-5220C Operator's Guide provided in the CD-ROM.

2. Start ScandAll21


Select [Start] - [Programs] - [Scanner Utility for Microsoft Windows] - [ScandAll 21].


3. Specify the scanner (that you will use)

Select [Select Source...] from the [Scan] menu of ScandAll 21.



4. Select "FUJITSU fi-5120Cdj/fi-5220Cdj" or "FUJITSU TWAIN32" on the dialog box.





- Select [To View...] from the [Scan] menu. 5.
- 6. Set scanning resolution, document size, etc. on the [TWAIN driver] window (for setting details of scanning) and click the [Scan] button.


🏝 TWAIN Driver (32)		X
0 100 200	Image Scanner: fi-5220Cdj Setting Files: 00 : Current Setting	16MB Browse
200	,	1 Type:
100	300 ± dpi Pape □ Predefine □ □	er Size:
200		ndividual Setting
300	Image Mode:	Brightness:
Scanning Area(mm)	Black/White: Static Threshold	Threshold: 128
Left: 0 Top: 0 Width: 216 Length: 279	Halftone:	✓ Contrast.
Scan Preview		Advance
Close Reset	Option	Help About
TWAIN driver. Press [F1] key to show help. Data Size about: 1.0MB		



For details on [TWAIN driver], refer to the "FUJITSU TWAIN32 Scanner Driver User's Guide" provided on the Setup CD-ROM.

7. Documents are scanned, and the generated images are displayed on the [ScandAll 21] window.

.



If the scanning completes without any trouble, the installation performed successfully.

For details on various types of scanning, refer to the "fi-5120C/fi-5220C Operator's Guide" on the Setup CD-ROM.

For FUJITSU ISIS Scanner Driver

Preparation

Confirm the following items before installing the driver application.

- Take out the Setup CD-ROM from its package, but do not insert the Setup CD-ROM into the CD driver yet.
- Connect the scanner correctly to your PC...



For details on how to connect the scanner, refer to "2.2 Connecting the Scanner to Your PC" on page 4.

.

.

.

Installing the FUJITSU ISIS **Scanner Driver**

|--|

Windows XP screenshots are used in this section as examples. The windows and operations may vary slightly, if your OS is other than Windows XP.

- 1. Press the power button to turn on the scanner.
- 2. Turn your PC on and log on to Windows.



-----When using Windows NT 4.0, Windows 2000 or Windows XP, log on as a user with "Administrator" privileges (privileges of the administrator of your PC).

If the scanner is automatically detected, 3. [Found New Hardware Wizard] or [Add/Remove Hardware Wizard] dialog box will appear. Click

[Cancel] to close the Wizard window.


.

Found New Hardware Wizard		
	Welcome to the Found New Hardware Wizard	
	This wizard helps you install software for:	
	fi-5220Cdj	
	If your hardware came with an installation CD or floppy disk, insert it now.	
	What do you want the wizard to do?	
	 Install the software automatically (Recommended) Install from a list or specific location (Advanced) 	
	Click Next to continue.	
	< Back Next > Cancel	

- 4. Insert the "Setup CD-ROM" into the CD drive.
 - \Rightarrow <SETUP DISK START UP SCREEN> appears.
- This screen may not appear when the "Autoplay" setting of your PC is off. In this case, run "Install.exe" in this CD-ROM directly from the "Explorer" or "My Computer".

.

5. Click [INSTALL PRODUCTS].



6. Click [ISIS Driver] on the window below.



7. Error Recovery Guide Installation window appears.


Error Recovery Guide is a software that displays troubleshooting information on screen if any scanner error occurs, and its installation is highly recommended. However, it can be installed later even if you do not install it in this step.

.



When you select [Yes] for installing Error Recovery Guide, the [Choose Setup Language] window appears. Select a language and follow the instructions on the window. The Error Recovery Guide will automatically finish its installation. Please wait until the installation of TWAIN driver automatically starts.


 Select a language used for installation on [Choose Setup Language] window and click [OK].



- 9. Install the application following the instructions on the window.
- 10. When the [InstallShield Wiizard Complete] window appears, click [Finish].

Your computer will be restarted and the scanner will be detected. Do not remove the Setup CD-ROM from the CD drive until your PC has completely restarted


..........



Now the installation of the scanner driver is completed.


Installing QuickScan Pro™

"QuickScan ProTM" is an image capturing software that complies with the ISIS standard.



1. Insert the Setup CD-ROM into a CD drive.


⇒ <SETUP DISK STARTUP SCREEN> appears. 2. Click [INSTALL PRODUCTS].



 Click [QuickScan PRO (Trial)] on the window below.

«SETUP DISK START UP SCREEN»	
	INSTALL PRODUCTS
 TWAIN Driver ISIS Driver 	Please choose an product to install
Image Processing Software	are Option (Trial)
ScandAll 21 QuickScan PRO (Trial))
🔵 Error Recovery Guide	
	SACK

4. Continue to install the application following the instructions on the window.



5. Enter the required information, then click [Next >] button.

🙀 QuickScan	3.0 - InstallShield Wizard	
Customer In Please enter	formation your information.	
User Name:		_
ji <u>O</u> rganizatior	n:	
Serial Numbe	er: An successful and a con-	
Install this a	pplication for:	
	 Anyone who uses this computer (all users) Only for me (furuse) 	
InstallShield ——	< Back	Next > Cancel
	"QuickScan Pro™" inc CD-ROM is a Trial vers	
(r)	after the expiration of it	
	of up to 30 launches, it	
	chase a fully functional	version of Quick-
	Scan Pro™. (When yo	
	evaluation version, do	•
	Serial Number already	alsplayea.)

6. Install the application following the instructions on the window.

...........

Confirming Installation

1. Load the documents on to the scanner.

For details on loading documents, refer to "1.2 Loading Documents on the ADF for Scanning" in the fi-5120C/fi-5220C Operator's Guide on the Setup CD-ROM.

2. Start QuickScan Pro™.

From the [Start] menu select [Programs]-[Quick-Scan]-[QuickScan].

3. Select [Select Scanner...] from [Scan] menu in QuickScan Pro™.


And select fi-5120C/fi-5220C from the list of [Scanner:], and then click the [OK] button.

Scanner Selection	
Scanner:	ОК
Fujitsu fi-4110CU Fujitsu fi-5120C Fujitsu fi-5220C	Cancel
Fujitsu fi-4340C Fujitsu fi-4530C	
Fujitsu fi-4640S Fujitsu fi-4750C Fujitsu fi-4750L	Setup


4. Select [Preview Settings...] from the [Scan] menu. Set the scan resolution, paper size and other scanning requirements, and then click [OK].

nage <u>M</u> ode	Scan <u>T</u> ype		Side
Black & White	 Automatic 	•	Both
esolution	Paper Size: Letter - 8.5 x 11 in	•	C Front C Back
Halftone	Paper Layout		
None	Portrait	🖱 Landscape	More
Pattern	- Feed:		<u>A</u> rea
	Top edge first		Imprint <u>e</u> r
Brightness	େ		JPEG
Manual C Automatic	128		Aboyt
	128 C		
Dar <u>k</u> en <u>N</u> ormal <u>L</u>	ghten C		
	Automatic Size and S	ke <u>w</u> Detection	
C Manual © Automatic	Priority (D):		
T F =	_	0	
	Speed	Accuracy	

5. Select [Preview Scan] from the [Scan] menu. And then the document is scanned.



If the scanning completes without any trouble, the installation performed successfully.



Error Recovery Guide

The Error Recovery Guide is a software that displays troubleshooting information on screen if any scanner error occurs.

If you did not install the Error Recovery Guide when installing the scanner driver, install it following the procedure below.

- Insert the Setup CD-ROM in your CD drive. The <SETUP DISK STARTUP SCREEN> will be displayed.
- 2. Click [Install Products].

SETUP DISK START UP SCREEN>	
FUJITSU Imag	ge Scanner Setup
	README FIRST
	INSTALL PRODUCTS USER'S GUIDE
	BROWSE CD
	EXIT
All Right Reserved, Copyrig	ght(C) FFU LIMITED 1995-2003

3. Click [Error Recovery Guide] on the next screen.

	INSTALL PRODUCTS
 TWAIN Driver ISIS Driver 	Please choose an product to install
S Image Processing Software	e Option (Trial)
ScandAll 21	
🔴 QuickScan PRO (Trial)	
Error Recovery Guide	

4. Select a language to use for the installation in the <Choose Setup Language> window and click [OK].



5. Install the application following the instructions in the window.

6. When the [InstallShield Wizard Complete] screen displays, click [Finish].




Image Processing Software Option (Trial)

For details on the installation of the Image Processing Software Option, refer to the "Image Processing Software Option USER'S GUIDE".

	Adobe [®] Acrobat [®]
	Acrobat from the "Adobe Acrobat CD- ed with this scanner.
	Adobe Acrobat <u>is not supported</u> by Microsoft Windows 95, Microsoft Win- dows 98/98 Second Edition, Microsoft Windows NT4.0, and Microsoft Windows Me.
	Adobe Acrobat is required for displaying the manuals stored in the CD-ROM. * Installation of Adobe Acrobat is not nec- essary if it has already been installed in your PC.
• • • •	•••••
1 Incort the	"Adaha Aarahat CD DOM" into the

- 1. Insert the "Adobe Acrobat CD-ROM" into the CD-ROM drive.
 - \Rightarrow The "Adobe Acrobat Setup" window appears.

.

This window is not displayed automatically when the "Auto play" setting of your computer is deactivated. In this case, please run "Auto play.exe" of this CD-ROM directly using the "Explore" or "My computer".

2. Select the language and Click [OK] button.

<u> </u>
cbe

3. Select "Install Adobe Acrobat".

🗠 Adobe Acrobat 7.0 Standard	
Adobe Acrobat 7.0 Standard	Adda
✓ Install Adobe Acrobat 7.0 Standard	
Rowse CD-ROM	
ୈ Read Me	
🕅 Always show AutoPlay 🗎 Read License Agreement	Quit

4. Click the [Next] button. The set up window appears.



5. Follow the instructions to install the software.



Select "How to install" on the "Adobe Acrobat" window to learn more about Adobe Acrobat installation. Refer to "Adobe Acrobat Help" about how to use Adobe Acrobat.



Notes for using Adobe Acrobat

...........

When scanning a paper document and converting the image to PDF using Adobe Acrobat, unexpected images may be output when:

 Setting "Edge Shadow Removal" in Acrobat, and setting "Digital Endorser" or "Black Background" options in the TWAIN driver at the same time. Letter strings embedded in the image or the background may be missed.
 Solution 1: Set "Edge shadow removal" to "OFF" or set any option other than "Adaptive" for "Color/Grayscale" and/or "Monochrome" under "Compression" by selecting [File]->[Create PDF]-> [From Scanner...]-> [Image Settings...] in Acrobat.

Solution 2: Adjust the scanning density in the TWAIN driver.

- Setting "Adaptive" for "Color/Grayscale" and/or "Monochrome" under "Compression" in Acrobat and scanning in a resolution lower than the resolution recommended for Acrobat.
 Solution: Set OPTION to something other than "Adaptive" under "Compression."
- Scanning a document longer than the double letter (11x17) or A3 size, when setting "Overscan" in the TWAIN driver, the scan may fail.

Solution: When scanning a double letter (11x17) or A3 size of document, do not set "Overscan" in TWAIN driver.

*As for detailed usage and information of Acrobat, refer to "Create a PDF file from a scanned document" in Acrobat Help.



Support and User registration for Adobe products

_ _ _ _ _ _ _ _ _ _ _


Refer to the technical support information stored in the [Customer Support] folder on Adobe Acrobat CD-ROM. (Note that <u>free</u> <u>person-to-person support is not available</u> for this is bundled product.)

Uninstalling Supplied Programs

Follow the procedure below to uninstall supplied programs.

Windows XP screenshots are used in this section as examples. The windows and operations may slightly vary, if your OS is other than Windows XP.

1. Start up your PC.



...............

- 2. Exit all currently running programs.
- 3. Select [Control Panel] [Add or remove Programs] from the [Start] menu.
 - ⇒ This displays the "Add or remove Programs" screen which displays a list of the currently installed applications.
- 4. Select the application to uninstall.
 - When uninstalling FUJITSU TWAIN 32 scanner driver, select "Scanner Utility for Microsoft Win-

dows".

- When uninstalling ScandAll 21, select "ScandAll 21".
- When uninstalling FUJITSU ISIS scanner driver,

select "Fujitsu ISIS Drivers".

- When uninstalling QuickScan Pro[™], select "QuickScan 3.0".
- When uninstalling Error Recovery Guide, select "Error Recovery Guide".
- When uninstalling Software Operation Panel,

select "Software Operation Panel".


.



- When uninstalling Image Processing Software Option, refer to "Image Processing Software Option Operation Guide".
 - When uninstalling Adobe Acrobat, refer to the installation procedure described in the Adobe Acrobat CD-ROM.

_ _ _ _ _ _ _ _ _

- 5. Click the [Change/Remove] or [Remove] button.
- 6. When the confirmation dialogbox appears, Click the [OK] or [Yes] button.
 - \Rightarrow This executes the uninstallation.



......

Appendix1 TROUBLESHOOTING

■ Troubleshooting checklist

Symptom	Check this item	Remedy
Scanner does not turn on.	Have you pressed the power button on?	Push the power button in to turn the scanner.
	Are the AC cable and AC adapter prop- erly connected to the	Correctly connect the AC cable and the AC adapter.
	scanner?	Disconnect the AC cable and the AC adapter from the scanner, then connect them again. If this does not restore the power supply, contact the store where you purchased the scanner or an authorized FUJITSU scanner service provider.
	Are you using the correct AC cable and AC adapter supplied with the scanner from the manufacture?	You must use the AC adapter and cable supplied with your scanner by the manufacture. Please get the correct AC adapter and cable to connect to your scanner.
Scanning does not com- mence.	Are the documents loaded properly on to the ADF paper chute?	Realign and reload the documents on to ADF paper chute.
	Is the ADF closed completely?	Close the ADF completely.
	Is the USB cable or SCSI cable con- nected securely?	Connect the cable. (When a USB hub is used, check the hub's power supply.)
	When using a SCSI interface, Is SCSI ID set correctly?	Use the SCSI ID switch at the rear of the scanner to set the SCSI ID.
	Does the Function Number display indi- cates an alarm or an error?	When the Function Number display indicates an alarm or an error, refer to the "Chapter 5. TROU-BLESHOOTING" in the fi-5120C/fi-5220C Operator's Guide for removing the alarm or the error.
	The alarm status remain displayed even after the scanner has been turned off and on again?	Turn off and on the power button. If this does not eliminate the alarm status, contact the store where you purchased the scanner or an authorized FUJITSU scanner service provider.
Vertical lines appear in the generated image of the scanned document.	Are the glass dirty?	Clean the glass as instructed in the Operator's Guide "3. Daily Care".
The generated image shifts or is distorted.	Are the documents loaded correctly?	Load the documents correctly.
Quality of generated image is unsatisfactory.	Are the glass clean?	Clean dirty locations.
Multi feed frequently occurs.	Do the documents satisfy the "Docu- ment Quality" and the "Multi feed Detection Conditions" in the chapter 6 of the fi-5120C/fi-5220C Operator's Guide?	Use the documents that satisfy the "Document Quality" and the "Multi feed Detection Condi- tions" in the chapter 6 of the fi-5120C/fi-5220C Operator's Guide.
	Are the documents placed properly in the ADF paper chute?	Fan the documents before scanning. Correctly align the document stack and load them on the ADF paper chute. Refer to "2.1 Installing the Scanner" on page 3 for details.
	Is the stack of document thicker than 5 mm?	Reduce the number of sheets of the stack to a thickness of 5 mm or less.
	Is the Pad ASSY dirty?	Clean the Pad ASSY. Refer to Operator's Guide in "3.3. Cleaning the ADF".
	Is the Pad ASSY worn out?	Replace the Pad ASSY. Refer to Operator's Guide in "4.2. Replacing the Pad ASSY".

Symptom	Check this item	Remedy
Paper is not fed (pick error occurs frequently, or docu- ment stops midway).	Do the documents satisfy the "Docu- ment Quality" and the "Multi feed Detection Conditions" in the chapter 6 of the fi-5530C Operator's Guide?	Use the documents that satisfy the "Document Quality" and the "Multi feed Detection Condi- tions" in the chapter 6 of the fi-5530C Operator's Guide.
	Is the Pick roller dirty?	Clean the Pick roller. Refer to Operator's Guide in "3.3. Cleaning the ADF".
	Is the Pick roller worn out?	Change the Pick roller. Refer to Operator's Guide in "4.3. Replacing the Pick Roller".
	Is there any dirt or dust in the document feed path?	Remove any dirt or dust from the document feed path.
The generated images are elongated.	Are the Feed rollers dirty?	Clean the Feed rollers. Refer to Operator's Guide in "3.3. Cleaning the ADF".
	Have you adjusted the scan scale?	For Windows 98, Windows Me, Windows 2000, WindowsXP, select "Scanners and Cameras" in the control panel, then click the [Device Set] tab to adjust scale. For Windows 95, Windows NT 4.0, right click the Scanner Control Center in the task tray, select [Options] and adjust the scan scale.
There is a shadow on the leading edge of the gener-	Are the Feed rollers dirty?	Clean the Feed rollers. Refer to Operator's Guide in "3.3. Cleaning the ADF".
ated image.	Have you adjusted the offset (the scan- ning starting position)?	For Windows 98, Windows Me, Windows 2000, WindowsXP, adjust the [Sub-scan Setting] on [Scanners and Cameras] in the control panel. For Windows 95, Windows NT 4.0, right click the Scanner Control Center, select [Options]-[Sub- scan Setting] and adjust the offset.

I Temporary error

Indication	Meaning
U0	Shipping lock error (fi-5220C)
U1	Paper feed error
U2	Multi feed error
U4	The ADF cover is opened.
U6	Print cartridge not installed (fi-5120C)

To troubleshoot the indicated errors above:

• "U0" error

Confirm that the shipping lock is released.

• "U1" error

Remove all jammed documents. Confirm that the documents meet the paper conditions for scanning. Refer to fi-5120C/fi-5220C Operator's Guide "5. Troubleshooting" on the Setup CD-ROM.

• "U2" error

Remove all jammed documents. Confirm that the documents are within the required paper preconditions for scanning. Refer to fi-5120C/fi-5220C Operator's Guide "6.2 Document Quality" on the Setup CD-ROM.

• "U4" error

Close the ADF cover completely. For the details, refer to "5 TROUBLESHOOTING" in the "fi-5120C/fi-5220C Operator's Guide" on the Setup CD-ROM.

"U6" error

This is a temporary error related with the Imprinter option (sold separately). Refer to fi-512PR Operator's Guide "5 Error Message".

Device alarm (Non-Temporary error)

Indication	Meaning	
E0	Flatbed motor malfunction.	
E1	Trouble in the optical system (Flatbed).	
E2	Trouble in the optical system (front).	
E3	Trouble in the optical system (back).	
E4	The motor's fuse has blown out.	
E6	Trouble in the operator panel.	
E7	Trouble occurred in the internal memory (EEPROM).	
E8	The SCSI interface fuse has blown out.	
E9	An error in the image memory.	
EA	Trouble with the Imprinter.	
Ec	An alarm in the memory.	
Ed	Trouble with the SCSI interface control- ler.	
EF	Trouble with the background switching mechanism.	

When you encounter any alarm on the display, turn the scanner off and on. If the alarm is still displayed on the Function Number display, contact the store where you purchased the scanner or an authorized FUJITSU scanner service provider.

Appendix2 DAILY CARE



The glass surface inside the ADF becomes hot during the operation.



Before you clean inside the scanner, turn off its power and unplug the AC adapter from the outlet. Wait for at least 15 minutes.

Do not turn off the scanner when you clean the Feed rollers.

Cleaning Materials

Cleaning Materials	Parts Number	Remarks
Cleaner F1 (or isopropyl alcohol)	CA99501- 0013	1 bottle Moisten the cloth with this fluid and wipe the scanner clean. (*)
Lint-free dry cloth	Commercially available one	

* For details about cleaning materials, contact the FUJITSU scanner dealer where you purchased the scanner.


Cleaning Method

The ADF must be cleaned with a lint-free cloth moistened with the Cleaner F1.

Parts to Clean and When

Part to clean	Standard Cleaning Cycle
Pad ASSY	Clean these parts after every 1,000 scans.
Pick roller	
Feed rollers	
Plastic rollers	
Glass	





For details on the cleaning the ADF, refer to "3.3 Cleaning the ADF" in fi-5120C/fi-5220C Operator's Guide on the Setup CD-ROM".

Appendix3 REPLACING CONSUMABLES



The glass surface inside the ADF becomes hot during the operation. Before replacing the consumables, turn its power off and unplug the AC adapter from the outlet. Wait at least 15 minutes.




Consumables and Replacement Cycles

Below are specifications of consumable items and their recommended replacement cycles.

Description	Parts Number	Standard Replacement Cycle
Pad ASSY	PA03289- 0111	After 50,000 scans or one year
Pick roller	PA03289- 0001	After 100,000 sheets or one year


To purchase consumables, contact the store where you purchased the scanner or an authorized FUJITSU scanner service provider.

The replacement cycles above are rough guidelines when using A4 or Letter woodfree or wood containing paper 64 g/m2 (17 lb). This cycle varies according to the type of paper and how frequently the scanner is used and cleaned.





The illustration below demonstrates the locations of the replacement parts. Refer to "Chapter 4 Replacing Consumables" fi-5120C/fi-5220C Operator's Guide on the Setup CD-ROM.

Replacing the Pad ASSY



Replacing the Pick Roller





Pick Roller's Shaft

fi-5120C/fi-5220C Image Scanner Getting Started

P3PC-1312-01EN

Date of issuance: October 2005 Issuance responsibility: PFU LIMITED

- Copying of the contents of this manual in whole or in part and copying of the scanner application is forbidden under the copyright law.
- The contents of this manual are subject to change without notice.
- PFU LIMITED. is not liable whatsoever for any damages resulting from use of this scanner and procedures described in this manual, profit due to defects, and any claims by a third party.