Assembly instruction Series QLA

AAI 17.07.99 4515/H.G. No. 27362

Tool and materials required: Stanley blade Scissors Soldering iron 80 to 100 Watts/220 to 240+C Solder Sn/Pb 60/40, 0,8mm Ø activated rosin flux Alcohol, brush Tip trimmer No. W 164		Straight connectors for Sucoform cable Cable entry : soldered
		Connector types : (e.g.)
		24 QLA-01-2-5
This connectors is supplied in 2 parts	Suitable cables :	Sucoform 86 FEP
	Centre contact :	plugged-in
	Braid :	soldered
		Slide shrinking tube A onto cable. Prepare cable according to diagram. Form tip of inner conductor to a 90° cone using tip trimmer W 164.
		Push cable into connector body B until to the positive stop. Solder connector body B to jacket at point Promptly swab soldered area with alcohol to cool joint and remove any residual flux.
		Slide shrinking tube C over body B and shrink close to connector body B.

⊕

HUBER + SUHNER AG CH-9100 HERISAU

Deutscher Text: siehe Rückseite