

code, after 5 seconds. Showing to hold will show PASS; Revise be over at this time. (You should calibrate the scale when the temperature change or other reasons).

8. Counting operation

At weighing mode 0.00, get 25, 50, 75 or 100 pcs as sample, put the sample on the weighing pan and display the value, then press "PCS" 3 seconds it will display P25PCS (P50, P75, P100), press "UNIT" to choose the sample quantity value, press "COUNT" button for confirming, it will display the quantity of the weighing article, press "COUNT" again to return counting mode, it shows PCS, now can add the quantity of the weighing articles to count

Unit Conversion

1. Please use the scale in stable & windless place
2. Never put on the tray the weight over the rated one, otherwise the sensor part will be damaged. When applying the article, please conduct it gently.
3. Do not making the phone call in a range of 50 cm when using the product, or it will affect the result.
4. Read the weighing value when the units symbol stop flashing.
5. Please change the battery when the battery symbol flashing, the scale will power off.
6. Please use the product in 0-30 °C, big temperature difference may cause error. If temperature difference is noticeable, please do the calibration, Please guarantee the product work on over 30 minutes when doing the calibration.
7. It will display "EEEE" when overload.

Tare care of the Scale and Do not disassemble.

This product has been patented, and copying is not permitted.

Accessories list: 1. spoon 2. USB power supply line 3. weighing plate 5. tweezers 6. weights

Digital Scale User Manual

Thank you for choosing our digital scale, which scale is designed base on the environmental philosophy, please read the user manual carefully before use it.

Parameter

Auto Power Off: 3 Minutes (60 Minutes)

Operation Temperature: 0-35 °C

LCD Display: 6 digits LCD Display

Back light: Blue (Optional)

Power Supply: 2XAAA Batteries or USB

Dimension: 115X67X35MM

Net Weight: 95G

Salver size: 52X52 MM

Tare Function

Counting Function

Low Power Indicator

Unit: g/oz/t/gn/ozt/dwt/ct ("J" unit can choose or remove the unit.)

Operation Instruction

Put the Scale on the stable & windless place with 2XAAA batteries or USB connection.

1. Press "⏻", it displays 0.000 after 3 seconds.

2. Put the article on the tray, it reading the result of the article when the unit stop flashing.

3. Press UNIT to change the weighing unit.

4. Press TARE gently can be tared

5. Press PCS for counting function.

6. Press "⏻" to power on or power off.

7. Calibration function

Press "⏻", press down UNIT key and don't put after swth on, showing to hold will appear CAL; Click the UNIT key once again, Showing to hold will show a weights (50G); Put up to should the

