CW CRYSTAL FILTER YG-455C

INSTALLATION PROCEDURE

Specifications

Center frequency:	45
Passband width:	50
Attenuation bandwidth:	82
Guaranteed attenuation:	Be

55.7kHz DOHz at —6dB 20Hz at —60dB etter than 80dB

• TS-830S

When installing the YG-455C crystal filter in the TS-830S, proceed as follows:

- 1. Using a number 2 Phillips screwdriver, remove the top cover (eight screws). Unplug the speaker and set the cover aside.
- 2. Remove the bottom cover (eight screws).
- 3. Remove the eight screws holding the IF unit X48-1290-00 and swing the printed-circuit board over.
- 4. Using a 45-W (or less) soldering pencil, clear the six holes for the filter, if they are filled with solder.
- 5. Install the filter into its position on the IF unit. Tighten the two nuts, and solder the four input and output pins to the circuit boards.

Solder sparingly, and heat the connections only long enough to insure a good solder joint. Don't overheat the filter or circuit board.

ØKENWOOD

- 6. Carefully inspect your soldering. Be certain that all pins are actually soldered, and that you have not soldered across any spots on the board or between any of the pins on the filter. Clip the pins flush to the board.
- 7. Replace the IF unit. Make certain no wires will be pinched underneath the board. Replace the eight screws.
- 8. Move the connector as illustrated from CW1 to CW2 \sim CW4.
- 9. Reinstall the bottom cover. Reconnect the speaker lead, and reinstall the top cover.
- 10. Apply power and verify your work. Filter installation is now complete.

455 kHz	8.83 MHz	Terminal
YG-455C	When a CW filter is not installed.	CW3
YG-455C	When YK-88C or YK-88CN is installed.	C₩₄



• R-2000

When installing the YG-455C crystal filter in the R-2000, proceed as follows:

- 1. Using a No. 2 Phillips screwdriver, remove the bottom cover (eight screws).
- 2. Remove the ten screws holding the IF unit X55-1430-00 and carefully unplug the five connectors at the side and rear, as shown in Fig. 2. Swing the printed-circuit board forward.
- 3. Using a 45-W (or less) soldering pencil, clear the six holes for the filter, if they are filled with solder.
- 4. Install the filter into its position on the IF unit. Tighten the two nuts, and solder the four input and output pins to the circuit boards.

Solder sparingly, and heat the connections only. long enough to insure a good solder joint. Don't overheat the filter or circuit board.

- 5. Carefully inspect your soldering. Be certain that all pins are actually soldered, and that you have not soldered across any spots on the board or between any of the pins on the filter. Clip the pins flush to the board.
- 6. Replace the IF unit. Make certain no wires will be pinched underneath the board. Replace the ten screws and 5 connectors.
- 7. Reinstall the bottom cover.
- 8. Apply power and verify your work. Fliter installation is now complete.



Fig, 1 Removal of Bottom



Fig. 2 Bottom View

A product of TRIO-KENWOOD CORPORATION

17-5, 2-chome, shibuya, shibuya-ku Tokyo 150, Japan

TRIO-KENWOOD COMMUNICATIONS 1111 West Walnut Street. Compton California 90220, U.S.A. TRIO-KENWOOD COMMUNICATIONS, GmbH D-6374 Steinbach TS. Industriestrasse 8A. West Germany TRIO-KENWOOD ELECTRONICS, N.V. Leuvensesteenweg 504, B-1930 Zaventem, Belgium TRIO-KENWOOD (AUSTRALIA) PTY. LTD. 4E Woodcock Place, Lane Cove N.S.W. 2066. Australia

© 25301 PRINTED IN JAPAN B50-2578-10 (K.O)