**Date**: 7/06/2020

**Page**: 1 of 4

Note: The body and coupling styles represented in this nomenclature have been adapted from Huber & Suhner so as to give a uniform prefix applicable to all brands of connectors which CASA stocks. The CASA nomenclature simplifies and at the same time enhances the intelligence in the nomenclature to better achieve parametric part-codification for CASA's stock numbers while still identfying the brand and design variances that CASA can offer as a wider cloice of product from our multi-sourcing and OEM manufacture to in-house and customer specifications etc.

FileName: Connector-Prefixes.vsd



http://www.casa.co.nz

Further Reference (Wiki)

## Connector PREFIX Nomenclature

Note: These abbreviations are adopted as CASA's part-number prefixes as part of our "Intelligent Typer Number" system

























**Page**: 2 of 4

## Connector PREFIX Nomenclature

Note: These abbreviations are adopted as CASA's part-number prefixes as part of our "Intelligent Typer Number" system

FileName: Connector-Prefixes.vsd



http://www.casa.co.nz

Further Reference (Wiki)



32 = Plug-Plug, adaptor



42 = Jack-Plug-Jack, asymmetric T-adaptor




33 = Plug-Jack, adaptor



43 = Jack-Plug-Jack, T-adaptor




34 = Jack-Jack, bulkhead-fixing



**44** = Plug-Jack-Plug, T-adaptor



36 = Plug-Jack, bulkhead-fixing




45 = Jack-Plug-Jack, asymmetric T-adaptor



37 = Jack-Jack, panel-fixing



**46** = Jack-Jack, T-adaptor



**41** = Plug-Plug-Plug, T-adaptor



51 = Jack-Jack, Angle-adaptor

**Page**: 3 of 4

## Connector PREFIX Nomenclature

Note: These abbreviations are adopted as CASA's part-number prefixes as part of our "Intelligent Typer Number" system

FileName: Connector-Prefixes.vsd



http://www.casa.co.nz
Further Reference (Wiki)



**52** = Plug-Plug, Angle-adaptor



82 = PCB Jack



**53** = Plug-Jack, Angle-adaptor



**83** = PCB Cable-Receptical



**61** = Cap for Plugs



**84** = PCB Angle-Plug



**62** = Cap for Jacks



**85** = PCB Angle-Jack



65 = Termination-Plug



**86** = PCB Angle Cable-Receptical



81 = PCB Plug

**Page**: 3 of 4

**Date**: 7/06/2020

**Page**: 4 of 4

## Connector PREFIX Nomenclature

Note: These abbreviations are adopted as CASA's part-number prefixes as part of our "Intelligent Typer Number" system

FileName: Connector-Prefixes.vsd



http://www.casa.co.nz

Further Reference (Wiki)

**Page**: 4 of 4