




Quick start guide

First time using


Please open the paper compartment cover and put the printing paper on top of the printer. After closing the paper compartment cover, the printing paper will expose a short section of the printer, as shown in the figure:



⚠ Only one side of the printing paper can be printed. Please place the printing paper in the correct direction.

Product introduction

- ① Opening button
- ② Power button
Long press for 3 seconds to turn on/off
- ③ Type-C



Power indicator status

Steady green light: power on/standby/charge completed

Red light is always on: charging/out of paper/overheating/opening the cover

Flashing red: low battery will cause weak handwriting, please charge in time.

⚠ Please avoid direct contact with the print head to avoid damage, especially after printing, do not directly touch the print head immediately to prevent overheating.

App download and settings

Mobile Download

Search "**Marklife**" in the App Store





Settings

After entering the app, click to search for bluetooth devices, click to connect now.

(Note: Please do not search and connect a Bluetooth printer in the Bluetooth settings of your mobile phone)

Bluetooth connection




The label printer cannot be connected to the Bluetooth of the mobile phone.

Note: The mobile phone needs to turn on the Bluetooth function in order to search for the Bluetooth number of the label printer normally in the APP (the Bluetooth permission of the mobile phone is equal to the bridge that the mobile phone and the printer can connect to).



Please agree to the location permission so that when the the mobile phone searches for the label printer, it can normally find the Bluetooth number of the printer and aconnectit. This is the requirement of the Android system. Aslong as the Bluetooth electronic product is connected, the lcaton permission must be required, other wisethe mobile phone will notbe able to find this Bluetooth electronics.


Note: Keep GPS turned on when connecting your Android phoneto the label printer.



This is the bluetooth
number name of
the label printer

APP Connect Bluetooth
Successfully



Create label



You can scan the QRcode of the label paper for editing and printing , or you canselect the corresponding label paper for editing and printingby the "Create label" editor.

Follow these steps to print out the labels you want:Go to Click Connect Device>Scan to get the template>Use> .

NOTE:Label calibration need to done each time the bin is opened beforeprinting , otherwise the label content will be printed off-set.Make sure the Device selection is match your label maker model.




1) The label machine is installed with a gap sticker-----40mm*12mm, select the gap label.

2)The default size is shown here: 40mm *12mm,if you use other sizes of stickers, please select the correct size.

Replacement of consumables

- ① Opening the cover: in the direction of the arrow as shown, press the cover opening button to open the cover
- ② Consumables: in the direction shown in the figure, put the heat sensitive surface of the paper on the same side as the heat sensitive head



Safety and precautions

- ① There is a built-in lithium battery, please do not use it in the environment with temperature higher than 40 ℃; keep away from fire and other heat sources, and do not place it in the hot sun, such as closed car;
- ② Children should be charged and used under the supervision of adults. After full charge, please make sure to pull out the charging line in time to prevent overheating, short circuit or fire;
- ③ Do not put the product in fire or water to avoid battery short circuit or fire or burn;
- ④ The operating temperature range is 0 ℃ to 40 ℃, please do not exceed the recommended temperature range.

Safety and precautions

- ① There is a built-in lithium battery, please do not use it in the environment with temperature higher than 40 °C; keep away from fire and other heat sources, and do not place it in the hot sun, such as closed car;
- ② Children should be charged and used under the supervision of adults. After full charge, please make sure to pull out the charging line in time to prevent overheating, short circuit or fire;
- ③ Do not put the product in fire or water to avoid battery short circuit or fire or burn;
- ④ The operating temperature range is 0 °C to 40 °C, please do not exceed the recommended temperature range;
- ⑤ If you suspect that there is a problem with the battery, please contact the after-sales service center for assistance.