



hp scanjet 7400c series scanner
setup and support guide

Copyright information

© Copyright Hewlett-Packard Company
2000

All rights reserved. Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under copyright laws.

Trademark credits

Microsoft, Windows, Windows NT, and Hotmail are U.S. registered trademarks of Microsoft Corporation. Pentium is a U.S. registered product of Intel Corporation.

All other products mentioned herein may be trademarks of their respective companies.

Warranty

The information contained in this document is subject to change without notice.

Hewlett-Packard makes no warranty of any kind with respect to this information. HEWLETT-PACKARD SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Hewlett-Packard shall not be liable for any direct, indirect, incidental, consequential, or other damage alleged in connection with the furnishing or use of this information.

NOTICE TO U.S. GOVERNMENT
USERS: RESTRICTED RIGHTS
COMMERCIAL COMPUTER SOFTWARE:
"Use, duplication, or disclosure by the
Government is subject to restrictions as set
forth in subparagraph (c) (1) (ii) of the Rights
in Technical Data Clause at DFARS 52.227-
7013."

Material scanned by this product may be protected by governmental laws and other regulations, such as copyright laws. The customer is solely responsible for complying with all such laws and regulations.

1 Installing and troubleshooting

This section provides information for installing the scanner and resolving issues that might occur during installation. For usage problems after installation, see the [user's manual](#).


Installing the scanner and accessories

Before you begin

- Ensure you have a USB connection or SCSI card properly installed in your computer. If you choose to use SCSI, you will need a SCSI cable.
- If you are connecting the scanner to a Macintosh and this scanner supports the Mac OS, locate the Macintosh CD package.

4 Installing and troubleshooting

1. Check the box contents



- HP ScanJet 7400C series scanner
- HP PrecisionScan Pro CD-ROM
- Automatic Document Feeder (ADF) (some models only)
- USB cable
- Power cable
- Transparency/slide Adapter (XPA)


System requirements

See the box in which the scanner shipped.

2. Connect the ADF

If your scanner came with an ADF or you purchased one separately, attach the ADF to the scanner. Use the ADF to scan multiple pages.


- a Remove the protective film from the bottom of the ADF.
- b Attach the ADF to the scanner.
- c Connect the ADF cable to its port on the scanner.



See "Using accessories" in the HP PrecisionScan Pro Help for usage instructions.

3. Unlock the scanner

Use your finger to flip the lock down to the unlocked position. If the lock is not completely in the unlocked position, you will hear a grinding noise when you try to scan.



6 Installing and troubleshooting


4. Install software

- a Quit all open programs.
- b Insert the CD-ROM. The installation program should start automatically. If the installation program does not start: On the **Start** menu, click **Run** and type: `x:\setup.exe`, where x is the letter of the CD-ROM drive.
- c Follow the directions on screen.

The installation program suggests which connection, USB or SCSI, you should use.

5. Connect interface cable

- a Turn off the computer.
- b Choose ONE:
 - Connect the USB cable between the USB ports on the scanner and the computer.
 - Connect the SCSI cable between the SCSI ports on the scanner and the computer. **Note:** You MUST install the scanning software before connecting a SCSI cable.



6. Connect the power cable


- a Connect the power cable between the scanner and a surge protector or grounded wall outlet that is easily accessible. This turns on the scanner. (There is no power switch.)
- b Turn on the computer.

If you see a dialog box informing you that new hardware has been found, follow the directions on screen.

7. Change the front panel overlay (if necessary)

The scanner has a front panel overlay installed. If necessary, change the overlay to match your language.

- a From the bottom, front center of the overlay, gently lift the overlay off of the scanner.




- b Align the pegs on the back of the new overlay with the holes on the scanner and snap the overlay into place.

Start scanning

Use one of these methods:

- **Scanner buttons.** Scan directly to a destination by pressing one of these buttons:




- **HP PrecisionScan Pro software.** Use the software to view or change the scanned image before you send it.

8 Installing and troubleshooting

Connect the XPA (optional)

Use the XPA to scan negatives, slides, and other transparent items.

- a** Connect the XPA cable to its port on the scanner.



- b** Restart the scanning software.

See “Using accessories” in the HP PrecisionScan Pro Help for usage instructions.

Find help and support

See these sources:

- View the three-minute product tour when you start the software.
- For installation help, support, and specifications: See more information later in this guide.
- For tips and information on scanning and optional accessories: Visit the HP ScanJet website at www.scanjet.hp.com.
- For customer support on the Web, visit www.hp.com/go/support.

Performing basic troubleshooting

If the scanner or software is not working, perform these steps first.

- Check that the power cable is securely connected between the scanner and a live electrical outlet or surge protector that is turned on.
- Make sure you have properly and securely connected the scanner to the computer using either the Universal Serial Bus (USB) or the SCSI Input/Output (I/O) interface. See "[Checking connections](#)" on page 10.
- If the scanner is making a loud grinding noise, make sure the scanner is unlocked. Move the lock down to the unlocked position.
- Disconnect the power cable from the scanner and turn off the computer. After 30 seconds, reconnect the power cable and then turn on the computer, in that order.
- If you receive installation file errors or the scanning software will not run, make sure all programs are closed, and then uninstall and reinstall the scanning software.
- Make sure your computer meets the minimum system requirements. See the box in which the scanner shipped. If you do not have enough hard disk space, remove unnecessary files or install the software on a different disk drive.
- If using a SCSI cable, make sure you installed the scanning software BEFORE you connected the scanner. If not, uninstall the software and disconnect the SCSI cable. Then, reinstall the software before reconnecting the SCSI cable.
- If you received a message like "Destination Directory Is Invalid" or "Program Folder Is Invalid" during installation, type a valid destination folder, find a valid folder by clicking **Browse**, or restore the defaults. The destination folder name cannot contain the following characters: /, \, :, *, <, >, ", or |.

Checking connections

The scanner can be connected to the computer using a USB or a SCSI connection. When you run the scanning installation program, the program checks to see if the computer supports USB. If supported, USB is recommended because its installation is simpler.

If the installation program displays a message saying it cannot find USB but you think you have it, see "[Checking the USB connection](#)" below. If you are having trouble with SCSI, see "[Checking the SCSI connection](#)" on page 11.


Checking the USB connection

This scanner can be connected to the computer using USB if these requirements can be met:

- The computer has a USB connector on the back (see below).
- The computer is running Microsoft Windows 98, 2000, or Me.
- In the computer BIOS, USB is enabled. In some older computers, it is disabled. See the documentation that came with the computer. If you change the BIOS, restart the computer and reinstall the software.


If the system still does not detect USB, use the SCSI connection. See "[Checking the SCSI connection](#)" on page 11.

Note: A USB connection is not supported in Windows 95 and Windows NT 4.0. You must have a SCSI connection to use the HP ScanJet with these operating systems.



USB port on the scanner

USB port on the computer




Checking the SCSI connection

You can connect this scanner to a computer using a SCSI card and cable that meet the requirements shown below. These requirements are the same as those on any SCSI flyer that might be included in the scanner box.

For all SCSI cards and cables:

- The SCSI card must be compliant with the operating system that your computer is running.
- The SCSI card must be installed with appropriate software drivers. See the documentation for the card.
- The SCSI card must have a connector visible on the back of the computer that allows you to connect a SCSI cable.
- The SCSI cable must have a connector on one end that matches the SCSI connector on the computer (see example below).
- The other end of the SCSI cable must have a connector that matches the high-density, mini 50-pin connector on the scanner (see example below).



Possible shapes of the SCSI connector on the computer



SCSI connector on the scanner

Connecting the scanner

You must have a SCSI card installed before you install the scanning software. Then, install the scanning software BEFORE physically connecting the scanner to the SCSI card.

If you have other SCSI devices to connect to the SCSI card, connect the scanner to the last device in the chain. For more information, see the documentation that came with the SCSI card.

Testing the SCSI installation

Test the SCSI installation to see if it is working.

To test the SCSI installation

- 1 Turn off the computer and disconnect the power cable from the scanner.
- 2 After 30 seconds, reconnect the power cable to the scanner.
- 3 Turn on all other external SCSI devices and then turn on the computer.
- 4 On the **Start** menu, point to **Settings**, and click **Control Panel**.

For Windows 98, 2000, and Me:

- 1 On the **Start** menu, point to **Settings**, and click **Control Panel**.
- 2 Double-click **Scanners and Cameras**.
- 3 Select your scanner model, such as the HP ScanJet 7400C, from the list and click **Properties**.
- 4 Click **Test Scanner or Camera**.
- 5 When the test finishes, you receive a message indicating if the test passed or failed. If test failed, see "[SCSI troubleshooting](#)" on page 13.

For Windows NT 4.0:

Windows NT 4.0 does not provide an automatic method for testing the SCSI installation. If you experience problems with the SCSI installation, see "[SCSI troubleshooting](#)" on page 13.

SCSI troubleshooting

If the scanner test fails, follow these steps.

- Repeat basic troubleshooting. See "[Performing basic troubleshooting](#)" on [page 9](#).
- Make sure the SCSI chain is less than 20 feet (6 meters) long, including any cabling to SCSI devices inside the computer.
- If other SCSI devices are connected to the computer, make sure the scanner is the last physical device in the SCSI chain.
- Disconnect all other SCSI devices and connect the scanner directly to the computer to see if the problem is with the scanner or with another SCSI device or cable.
- Make sure that any SCSI devices connected between the computer and the scanner have their termination turned off.
- Check for an address conflict. See "[Changing the SCSI address](#)" below.

Changing the SCSI address

The address for the HP scanner is preset to 2. If you have other SCSI devices attached to this SCSI card, you may need to change the scanner address to prevent address conflicts. If this is the case, use the following procedure only AFTER installing the scanning software.

To change the SCSI address

- 1 Find an available address using the documentation that came with the computer. Do not choose the addresses for the SCSI card, typically 7, and the hard disk drives, typically 0 or 1.
- 2 Press **FAX** and **FILE** on the scanner at the same time. “SCSI Address: 2” should appear on the front panel display.
- 3 Use the **NUMBER OF COPIES** button on the scanner to select a number for the SCSI address. The number changes on the front panel display as you press the button.
- 4 To exit the SCSI address settings, press any button on the scanner except the **NUMBER OF COPIES** button.

Uninstalling the software

The Uninstall option of the setup program allows you to remove the scanning software from your computer.

To uninstall software

Note: To uninstall the software from Windows NT 4.0 or 2000, you must log on with administrator privileges.

- 1 Click **Start**, point to **Settings**, and click **Control Panel**.
- 2 Double-click the Add/Remove Programs icon.
- 3 Select the HP PrecisionScan Pro software and click **Add/Remove**.
- 4 Follow the instructions on screen.

2 Support, warranty, and specifications

This section provides information for finding support for your scanner, the warranty, and specifications.

Finding HP help on the Web

HP provides several resources on the Web to provide help with your scanner whenever you want.

Visiting HP websites

HP product support

Visit www.hp.com/go/support to find information for your scanner model. Once you enter the section that covers your scanner model, you will be able to choose information about setting up and using your scanner, downloading drivers, solving a problem, ordering, and information about the warranty.

HP ScanJet website

Visit www.scanjet.hp.com for:

- tips for using your scanner more effectively and creatively.
- HP ScanJet driver updates and software.

HP assistance

If you cannot find an answer to your question using the sites listed above, visit www.hp.com/cposupport/mail_support.html. From there, you can discover how to contact HP via e-mail, phone, and other methods.

Visiting related websites

Links to third-party websites are provided solely as a convenience to you. HP has not reviewed all of these third-party sites and does not control and is not responsible for any of these sites or their content. Thus, HP does not endorse or make any representations about them, or any information, software or other products or materials found there, or any results that may be obtained from using them. If you decide to access any of the third-party sites, you do this entirely at your own risk.

ConnectCom Solutions website

If you need to install a SCSI card on your computer to connect the computer to the scanner, HP recommends buying and installing a ConnectCom Solutions SCSI card. Visit the ConnectCom Solutions website for information about the recommended SCSI card, or to check for and download updated drivers for the card.

www.connectcom.net/products/hpscannersol.html

Contacting HP Customer Support

In addition to the Web, you can contact HP by telephone or mail for support and service for your scanner. Prices, availability, and hours of support are subject to change without notice.

How HP can help

HP's support hotline can help resolve problems with:

- setup
- installation
- configuration
- operation

For questions relating to operating systems or network configurations, contact your point of purchase or internal support department. For help with non-HP hardware or software, please contact the manufacturer of the other product.

Before you call

Please have the following information ready before you call.

- serial number (found on the back or bottom of your scanner)
- product name
- date of purchase

Obtaining support within the United States

Free telephone support for one year

Within one year of your purchase, telephone support is provided to you free of charge. If this is a long distance call for you, long distance charges will apply.

Call (208) 323-2551.

Our support staff is available from 6 am to 6 pm Mountain Time, Monday through Friday, or 9 am to 4 pm Saturday.

After the first year

Call (900) 555-1500.

Charges are \$2.50 per minute with a \$25.00 maximum, charged to your phone bill. Charges begin only when you connect with a support technician.

If you think your HP product may need service, call the Customer Support Center, which can help determine if service is required and direct you to a service site. Otherwise, contact the store where you purchased the product. Or, visit www.hp.com/cpso-support/guide/psd/repairhelp.html for the nearest sales and service office.

Obtaining support worldwide

If you need help with your HP product, please call the phone number listed below for the Customer Support Center in your country. Telephone support is free for 90 days in Asia and the South Pacific and 30 days in Europe, the Middle East, and Africa.

If you think your HP product may need service, call the Customer Support Center, which can help determine if service is required and direct you to a service site. Otherwise, contact the store where you purchased the product. Or, visit www.hp.com/cpso-support/guide/psd/repairhelp.html for the nearest sales and service office.

If the number below has changed, visit www.hp.com/cposupport/mail_support.html to check for a new one.

Argentina

(5411) 4778 8380
0810 555 5520 (clientes del interior)

Australia

+63 (3) 8877 8000

Austria

+0810 00 6080

Belgium

Dutch: +32 (0)2 626 8806
French: +32 (0)2 626 8807

Brazil

(11) 3747 7799 (Grande São Paulo)
0800 157 751 (Demais regioes)

Canada

905 206 4663 (for support during the warranty period)
877 621 4722 (for support after the warranty period)

Chile

800 22 5547 (Post-sales Business Computing)
800 360 999 (Post-sales Home Computing)

China

+86 (10) 6564 5959

Colombia

+9 800 919 477

Czech Republic

+42 (0)2 6130 7310

Denmark

+45 39 29 4099

Finland

+358 (0)203 47 288

France

+33 (0)1 43 62 34 34

Germany

+49 (0)180 52 58 143 (24 pf/min)

Greece

+30 (0)1 619 64 11

Guatemala

1 800 999 5305

Hong Kong

+852 800 967729

Hungary

+36 (0)1 382 1111

India

+91 11 682 6035

Indonesia

+62 (21) 350 3408

Ireland

+353 (0)1 662 5525

Israel

+972 (0)9 952 48 48

Italy

+39 02 264 10350

Japan

+81 3 3335 8333

Korea, Republic of

+82 (2) 3270 0700 (Seoul)
080 999 0700 (outside Seoul)

Malaysia

+60 (3) 295 2566 (Kuala Lumpur)
1 300 88 00 28 (Penang)

Mexico

52 58 9922 (Mexico City)
01-800-472-6684 (outside
Mexico City)

Middle East/Africa

+44 (0) 207 512 52 02

Netherlands

+31 (0)20 606 8751

New Zealand

+64 (9) 356 6640

Norway

+47 22 11 6299

Peru

0 800 10111

Philippines

+63 (2) 867-3551

Poland

+48 22 519 06 00

Portugal

+351 21 3176333

Puerto Rico

1 877 232 0589

Russian Federation

+7 095 797 3520 (Moscow)
+7 812 346 7997 (St. Petersburg)

Singapore

+65 272 5300

South Africa

086 000 1030 (RSA)
+27-11 258 9301 (outside RSA)

Spain

+34 902 321 123

Sweden

+46 (0)8 619 2170

Switzerland

+41 (0)848 80 11 11

Taiwan

+886 (2) 2717 0055

Thailand

+66 (2) 661 4000 (Bankok)
+66 (53) 357990 (Chiang-Mai)

Turkey

+90 212 221 69 69

Ukraine

+7 (380-44) 490-3520

United Arab Emirates

971 4 883 8454

Warranty Statement

HEWLETT-PACKARD LIMITED WARRANTY STATEMENT

HP PRODUCT	DURATION OF LIMITED WARRANTY:
HP ScanJet 7400C, 7450C, 7490C Scanners and/or HP ScanJet Automatic Document Feeder and/or HP ScanJet Transparency Adapter	1 year

- 1 HP warrants to you, the end-user customer, that HP hardware, accessories and supplies will be free from defects in materials and workmanship after the date of purchase, for the period specified above. If HP receives notice of such defects during the warranty period, HP will, at its option, either repair or replace products which prove to be defective. Replacement products may be either new or equivalent in performance to new.
- 2 HP warrants to you that HP software will not fail to execute its programming instructions after the date of purchase, for the period specified above, due to defects in material and workmanship when properly installed and used. If HP receives notice of such defects during the warranty period, HP will replace software which does not execute its programming instructions due to such defects.
- 3 HP does not warrant that the operation of HP products will be uninterrupted or error free. If HP is unable, within a reasonable time, to repair or replace any product to a condition as warranted, you will be entitled to a refund of the purchase price upon prompt return of the product.
- 4 HP products may contain remanufactured parts equivalent to new in performance or may have been subject to incidental use.
- 5 Warranty does not apply to defects resulting from (a) improper or inadequate maintenance or calibration, (b) software, interfacing, parts or supplies not supplied by HP, (c) unauthorized modification or misuse, (d) operation outside of the published environmental specifications for the product, or (e) improper site preparation or maintenance.
- 6 TO THE EXTENT ALLOWED BY LOCAL LAW, THE ABOVE WARRANTIES ARE EXCLUSIVE AND NO OTHER WARRANTY OR CONDITION, WHETHER WRITTEN OR ORAL, IS EXPRESSED OR IMPLIED AND HP SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY, SATISFACTORY QUALITY, AND FITNESS FOR A PARTICULAR PURPOSE. Some countries, states or provinces do not allow limitations on the duration of an implied warranty, so the above limitation or exclusion might not apply to you. This warranty gives you specific legal rights and you might also have other rights that vary from country to country, state to state, or province to province.

- 7 HP's limited warranty is valid in any country or locality where HP has a support presence for this product and where HP has marketed this product. The level of warranty service you receive may vary according to local standards. HP will not alter form, fit or function of the product to make it operate in a country for which it was never intended to function for legal or regulatory reasons.
- 8 TO THE EXTENT ALLOWED BY LOCAL LAW, THE REMEDIES IN THIS WARRANTY STATEMENT ARE YOUR SOLE AND EXCLUSIVE REMEDIES. EXCEPT AS INDICATED ABOVE, IN NO EVENT WILL HP OR ITS SUPPLIERS BE LIABLE FOR LOSS OF DATA OR FOR DIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL (INCLUDING LOST PROFIT OR DATA), OR OTHER DAMAGE, WHETHER BASED IN CONTRACT, TORT, OR OTHERWISE. Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.
- 9 THE WARRANTY TERMS CONTAINED IN THIS STATEMENT, EXCEPT TO THE EXTENT LAWFULLY PERMITTED, DO NOT EXCLUDE, RESTRICT OR MODIFY AND ARE IN ADDITION TO THE MANDATORY STATUTORY RIGHTS APPLICABLE TO THE SALE OF THIS PRODUCT TO YOU.

Hardware repair services

If you think your scanner, ADF, or XPA needs repair, first call the Customer Support Center, which can help determine if service is required and direct you to a service site. Please see "[Contacting HP Customer Support](#)" on page 19. Otherwise, contact the store where you purchased the product. Or, visit www.hp.com/cpso-support/guide/psd/repairhelp.html for nearest sales and service office.

Service is free of charge during the warranty period. Beyond the warranty period, service will be charged.

Recycling materials

HP offers a variety of product end-of-life return programs in a number of geographic areas. To determine if one is available in your area, please contact your nearest HP sales office.

Products returned to HP are reused, recycled, or disposed of in a responsible manner. Each month, HP reuses or recycles more than 3.5 million lb (1.6 million kg) of material at our product recovery centers in Grenoble, France; Boeblingen, Germany; and Roseville, California, USA. This represents 99 percent by weight of all the material we receive from customers and HP operations.

Specifications

Environmental specifications

Scanner

Temperature

Operating: 10° to 35° C (50° to 95° F)

Storage: -40° to 60° C (-40° to 140° F)

Humidity

Operating: 15% to 80% noncondensing
10° to 35° C (50° to 95° F)

Storage: up to 90%
(0° to 70° C or 32° to 158° F)

ADF

Temperature

Operating: 10° to 35° C (50° to 95° F)

Storage: -40° to 60° C (-40° to 140° F)

Humidity

Operating: 10% to 80% noncondensing
(10° to 35° C or 50° to 95° F)

Storage: 10% to 90%
(0° to 40° C or 32° to 104° F)

XPA

Temperature

Operating: 10° to 35° C (50° to 95° F)

Storage: -40° to 60° C (-40° to 140° F)

Humidity

Operating: 15% to 80% noncondensing
(10° to 35° C or 50° to 95° F)

Storage: 10% to 90%
(0° to 70° C or 32° to 158° F)

Product specifications

Scanner

Scanner Feature	Specification
Scanner type	Flatbed
Maximum item size	216 mm by 356 mm (8.5 in by 14 in), or letter width by legal length
Scanning element	Charged-coupled device
Interface	USB or SCSI
Optical resolution	2400 dpi
Selectable resolution	12 dpi to 999,999 dpi at 100% scaling
Image processing (options)	Dithering, thresholding, scaling, interpolation, gamma adjustment, matrix adjustment
AC line voltage	100-240 VAC, 50-60 Hz
Power consumption	22 W maximum, 10 W idle mode, ENERGY STAR compliant.  As an ENERGY STAR Partner, Hewlett-Packard Company has determined that this product meets the ENERGY STAR guidelines for energy efficiency.
Weight	5.6 kg (12.4 lb)

ADF

ADF Feature	Specification
Size	535 by 290 by 90 mm (21.06 by 11.42 by 3.54 inches)
Weight	2.20 kg (4.85 lb)
Paper tray capacity	50 sheets of 75 g/m ² (20 lb bond)
Maximum paper size	216 by 356 mm (8.5 by 14 inches)
Minimum paper size	210 by 149 mm (8.27 by 5.85 inches)
Maximum paper weight	105 g/m ² (28 lb bond)
Minimum paper weight	60 g/m ² (16 lb bond)
Power requirements	420 mA (24 V dc) average
Speed	C7716B: 15 ppm for 216 by 279 mm (8.5 by 11 inches) sheets

XPA

XPA Feature	Specification
Size	330 by 235 by 88 mm by 88.9 mm (13.0 by 9.25 by 3.54 in by 3.50 in)
Weight	0.95 kg (2.1 lb)
Power requirements	120 Vac (60.0 Hz)

Regulatory information

German Noise Declaration

The German noise declaration is required in Germany. It gives noise output figures.

Scanner

Geräuschemission

LpS < 70 dB

am Arbeitsplatz

normaler Betrieb

nach DIN 45635 T. 19

Die Daten sind die Ergebnisse von Typenprüfungen

ADF

Geräuschemission

LpS < 70 dB

am Arbeitsplatz

normaler Betrieb

nach DIN 45635 T. 19

Die Daten sind die Ergebnisse von Typenprüfungen

FCC Declaration of Conformity (scanner)

Supplier's Name:	Hewlett-Packard Company
Supplier's Address:	Colorado Digital Imaging 700 71st Avenue Greeley, CO 80634 USA
Contact Person:	CDI Regulatory Manager
Telephone:	970-350-4000
Product Name:	HP ScanJet 7400C, HP ScanJet 7450C, HP ScanJet 7490C
Model Number:	C7710A (Base Scanner), C7717A or C7718A (Worldwide), C7713A or C7715A (US Commercial), C7712A or C7714A (US Retail)
Product Options:	C7671B (transparency adapter); C7716B (automatic document feeder; may contain different suffix)

The supplier listed above declares that this product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician.

Changes or modification of this equipment not expressly approved by Hewlett-Packard could void the user's authority to operate this equipment. Only use the cables, connectors, power cords and accessories supplied with this equipment or expressly approved by Hewlett-Packard.

Test report on file:C7710-1

Date: February 2001

EU Declaration of Conformity (scanner)

According to ISO/IEC Guide 22 and EN 45014:

Supplier's Name Hewlett-Packard Company
 Supplier's Address Colorado Digital Imaging
 700 71st Avenue
 Greeley, Colorado 80634
 USA

declares that the product:

Product Name HP ScanJet 7400C, HP ScanJet 7450C, HP ScanJet 7490C
 Model Number(s) C7710A (Base Scanner), C7717A or C7718A or C7719A
 (Worldwide), C7713A or C7715A or C7714A (US Commercial),
 C7712A or C7714A (US Retail)
 Product Options C7671B (transparency adapter); C7716B (automatic document
 feeder; may contain different suffix)

conforms to the following Product Specifications:

Safety EN 60950:1992+A1:1992+A2:1993+A3:1995+A4:1996 +A11:1997
 EN 60825-1: 1994 Class 1

EMC CISPR 22: 1993+A1+A2, Class B/ EN55022:1994+A1+A2, Class B
 IEC 1000-3-2: 1995/EN61000-3-2: 1995 Class A
 IEC 1000-3-3: 1994/EN61000-3-3: 1995
 EN 50082-1: 1997/EN 55024: 1998
 EN/IEC 61000-4-2, 4kV CD, 8 kV AD
 EN/IEC 61000-4-3, 3 V/m
 EN/IEC 61000-4-4, 1kV Power Lines
 EN/IEC 61000-4-5, High Energy Transients
 EN/IEC 61000-4-6
 EN/IEC 61000-4-8
 EN/IEC 61000-4-11

Supplementary Information:

The product herewith complies with the requirements of the Low Voltage Directive 73/23/EEC and the EMC Directive 89/336/EEC and carries the CE-marking accordingly. LEDs in this product are Class 1 in accordance to EN60825-1.

Greeley, Colorado, USA, February 2001

